

User's Manual Model: EPH5212 HDcctv 12X IP66 Speed Dome





Contents

Warnings and Cautions	3
FCC Compliance statement	4
CE Compliance statement	4
1. Overview	5
1.1 Description	5
1.2 Features	5
1.3 System Configuration	6
1.4 Termination Settings	6
2. Installation and Connection	7
2.1 Package Contents	7
2.2 Base Installation	8
2.3 Connection Interface and Wiring cables	9
2.4 Setting RS-485 Parameters	9
3. Program and Operation	14
3.1 Getting Started	16
3.2 Main Menu	17
3.3 System Setup Menu	17
3.4 Display Setup Menu	20
3.5 Camera Setup Menu	23
3.6 Dome Motion Menu	26
3.7 Preset Menu	29
3.8 Pattern Menu	30
3.9 Tour Menu	31
3.10 Auto Scan Menu	32
3.11 Alarm Menu	33
4. Troubleshooting	34
5 Specifications	36
5.1 General Specifications	36
5.2 Dimensions	37
A.1 Appendix. Pelco Protocol Function List	38

Warnings and Cautions

If you fail to read this information and handle the product incorrectly, death or serious injury may occur. This device MUST be securely anchored to a solid surface in a manner that will resist wind, snow and ice loading, and any other hazard which might compromise the security of the mounting.

*Precautions & Safety------

Should any liquid or foreign material enter the dome, unplug the dome and have it checked by qualified personnel before operating it any further.

Installation-----

Do not install the dome in an environment which exceeds the specifications of the unit. Avoid excessive dust and mechanical vibration.

The dome was designed to be weather resistant (IP66). The unit should not be immersed in water or any other liquid.

Cleaning-----

Clean the dome with a damp soft cloth. Use a mild household detergent. Never use strong solvents such as thinner or benzene as they might damage the finish of the unit.

Retain the original carton and packing materials for safe transport of this unit in the future.

Important Safeguards

Read this manual carefully.

Keep these instructions.

Heed all warnings.

Follow all instructions.

Clean only with dry or damp soft cloth.

Install in accordance with the manufacturer's instructions.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.

Protect the power cord and other cables from abrasion or being pinched particularly at the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Lightning protection is recommended.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as if the power-supply or other cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, does not operate normally, or has been dropped.

CAUTION – These installation instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any service other than that contained in the operating instructions unless you are qualified to do so.

Use a certified/listed power supply transformer only.

Never move Pan/Tilt with your hands. It may cause serious damage to the camera.

The unit should be installed by trained personnel.

Always stop using when the product if it should emit smoke or abnormal heat.

Never install the product in area exposed to oil or gas; this PTZ is NOT rated as 'explosion proof'.

Never install the product on a surface that cannot hold its weight.

Never touch the power cord with wet hands.

Clean only with dry or damp soft cloth.

Never install the dome in an environment which exceeds the specifications of the unit..

Never drop the dome or subject it to excessive vibration.

Avoid touching or scratching the clear dome.



This symbol is intended to alert the user to the presence of un-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance

FCC Compliance statement-----

This Equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his expense.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CE Compliance statement-----

Warning: This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

THIS CLASS A DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMERIQUE DE LA CLASSE A EST CONFORME A LA NORME NMB-003 DU CANADA.

1. Overview

1.1 Description

The EPH5212 is an HDcctv IP66 speed dome camera equipped with autofocus 12X optical zoom plus 10X useable digital zoom with true Day/Night capability, DNR to improve image clarity, BLC/HSBLC and EWDR to handle the most challenging of bright or unbalanced lighting conditions, and DSS to improve low light performance. Based on a 1/2.8" Sony Exmor R progressive scan 2.1 megapixel CMOS sensor for your choice of HD 1080p or 720p resolution 100% digital images, it delivers vastly superior video quality compared to traditional CCTV images. This superior resolution not only captures more critical evidentiary information, but the inherent ability for megapixel video also extends the area of coverage, expedites completion of investigations, resolves complaints and reduces both capital and operational costs.

With conventional PTZ optical zoom only the area in the reduced field of view can be displayed and recorded, often requiring multiple cameras to achieve coverage of large areas. The ability to employ digital zoom at the DVR to magnify both live and playback images allows more effective coverage of larger areas by recording the full optical field of view while concentrating on areas of interest using the DVR's digital zoom. For example, using a mere 4X digital zoom at the DVR in place of optical zoom at the PTZ allows the recording of an area 16 times that being analyzed on screen by systems comprised of EverFocus DVRs and HDcctv cameras.

A full function PTZ speed dome, the EPH5212 features everything you expect from a high quality PTZ: 360° 'endless pan' rotation, 180° tilt with digital auto-flip, 210 preset positions, 8 auto scan zones, 6 patterns, 8 tours (consisting of presets, patterns and scans), 4 NO/NC alarm input triggers, a 'form C' alarm output, speed proportional to zoom ratio, motion detection, privacy masking (up to 8 areas) flexible programming of functions and alarm actions, multi-language support, built-in heater for operation down to -40° and much more, in a compact package only 6.6" in diameter and weighing only 7.7 pounds (PTZ module plus wall arm).

No major upgrade to the IT network is required to deploy this powerful technology; HDcctv cameras communicate at digital speeds up to 1.5Gb/s over existing or new coaxial cable (RG59 or other types for longer distances), using industry standard BNC connectors. The EPH5212 responds to conventional RS-485 control signals formatted in EVF-1, Pelco P or Pelco D protocol. For convenience, a full time analog video output is also provided. The EPH5212 delivers flexible, robust coverage in a wide range of demanding surveillance environments while delivering stunning HD image quality.

1.2 Features

- HDcctv Megapixel real time 1920x1080 or 1280x720 HD video over coax for superlative image detail
- o Supports video outputs of 1080i60/50; 1080p30/25; 720p60/50/30/25 (field select)
- HDcctv Alliance Base Line Compliance in 1080 mode*
- True day/night operation with automatic ICR module
- Zoom ratios 12x optical plus 10x digital (120x total) with auto focus
- o BLC & Electronic WDR functions handle bright and unbalanced lighting conditions
- o Includes DNR to improve picture clarity while enabling DVRs to improve disk storage utilization
- Easy to use OSD setup menu plus OSD data display
- RS-485 support for EVF-1, Pelco-P and Pelco-D protocols
- o SD/analog TV Out for setup, aim and focus using a standard hand held test monitor
- Pan capable of 360° 'endless rotation'
- Tilt range of 180° with digital auto-flip
- Choice of 210 Preset Positions
- Programmable for up to 8 Auto Scans, 6 Patterns, 8 Tours (consist of Presets, Patterns and Scans), 8 Privacy Masks, alarm actions, home function, etc.
- 4 Alarm Inputs (NC/NO) and 1 Alarm Output (form "C")
- Programmable PTZ Speed is Proportional to Zoom Ratio
- Multi-language OSD Support
- Power Source 24VAC
- IP66 Weather Resistant with built in heater to operate to -40 degrees
- o Includes wall mounting arm

*The HDcctv Alliance states

Look for the unique HDcctv logo to be sure:

- O 100m transmission over even low-grade RG59
- O Plug-and-play interoperability with other compliant products
- O Forward compatibility with future versions of the standard
- O See <u>www.hidefcctv.org</u> for details

1.3 System Configuration



Portable test monitor

1.4 Termination Settings [SW303: Refer to 2.4 Dome Camera Settings]

To prevent malfunctions and/or interference with communication signals between the camera and controller, the domes (shaded with gray color) at the end of line must have their terminations set to ON. All other domes in the "chain" should have their terminations set to OFF.



2. Installation and Connection

2.1 Package Contents



2.2 Base Installation

- Make holes for mounting and cable hole on the wall where the dome camera is to be installed. Attach the arm firmly with the supplied mounting screws (4) or other means which will secure the unit properly to resist wind and snow/ice loading.



- After mounting the arm, clip the safety cable to the arm, pass the video and other wires through the arm; there is an access port in the arm if connections will

be made at that point. Insert the dome housing into the arm, rotate ¹/₄ turn CW to lock, then secure with the set screw.
Remove any packing foam inside the PTZ module, verify switch settings, then lock the housing cover with torx screws (3).



2.3 Connection Interface and Wiring cables

*Caution

Do not connect the power cable until all other connections have been completed.

Be sure to remove the shipping foam ring and sheet before connecting the power to the dome camera.

2.3.1 Connecting the RS-485 lines

The dome camera can be controlled remotely by an external device or control system such as a controller using RS-485 half duplexer (RS-485 Connection). For connecting multiple 'home run' PTZ cameras, use the EDA997A Data Distributor.

2.3.2 Connecting Video Jack

Connect the 'silver' video Jack (BNC connector) to the video input of the HDcctv DVR or other HDcctv device.

(Optional) Connect the 'yellow' video to an analog monitor or other analog video equipment.

2.3.3 Connecting Alarms

- Alarm In: You can use external devices to trigger the dome camera to react to events. Mechanical or electrical switches can be wired to the Alarm Input and Ground pins
- Alarm Out: The dome camera can activate external devices such as buzzer. Connect the device to NO (or NC) and COM pins.

2.3.4 Connecting the power

Connect the power jack of AC24V adaptor to the dome camera.



2.4 Setting RS-485 Parameters

The device can communicate with external controllers and DVRs by setting the Rotary switches and Dip switches. Refer to the tables below for setting the dome camera ID and protocol. Total length of the cable for communication should not exceed 1km.

2.4.1 Setting the address (ID) of dome camera

To prevent incorrect operation or malfunction, each dome camera must have a unique address (ID). The default setting is 0. This corresponds to EVF-1 & Pelco-P ID 00 and Pelco-D ID 01.

Dome Camera ID Setting (Rotary Switch, SW301, SW302)

X10	X1
SW301	SW302

2.4.2 Setting the analog video format and RS-485 protocol

Analog Composite Video (Dip Switch, SW303)

No1	Baud Rate(bps)
Off	NTSC
ON	PAL

Dome Camera Protocol Setting (Dip Switch, SW303)

No2	Protocol
Off	Pelco D/P
ON	Others(Pelco P/ EVF-1)

Dome Camera Baud Rate Setting (Dip Switch, SW303)

No3	No4	Baud Rate(bps)
Off	Off	2400
Off	On	4800
On	Off	9600
On	On	38400

Example: Address 01, EVF-1 Protocol, 9600 baud Termination ON



Dome Camera Termination Setting Off/ON (NO5, Dip Switch, SW303)



3. Programming PTZ and Camera Functions and Options

[OSD Menu Structure]

Main Menu/Title



- Operation Menu





-Next Page Continue-





This manual is designed to be a reference for the programming and operation of the system. You can see information about features of the dome and commands as well as an operation method.

The symbols below mean some action of the joystick controller.

- \blacktriangle/Ψ : move joystick up and down
- ◄/▶ : move joystick left and right direction
- : select or change settings

 \mathbb{A} [Tele/Wide]: move joystick clockwise or counter-clockwise for zooming

[KEY]: press the defined key.

3.1 Getting Started

You should install and connect the dome to an interface device before using this operating guide. Refer to {2. Installation and connection of this manual}.

Once installed, apply power to the dome and the start-up screen is displayed on the monitor.

EPH-5212 V2.02 RS485/-2400 NTSC ID001
CAM TEST PASS

Before installing and operating the dome camera, please read this user's manual carefully. This dome camera can be operated using two methods:

- Use hot keys [Refer to Appendix].
- Use OSD Menu on the monitor [Read this operation manual].

*Notice: You shall check the saving state of each step at sub menu or edit menu, after editing functions or changing settings. You may save setting one function twice. For example, after {the position or title of Preset} is saved at 'Sub Menu', {the status of Preset Setup} has to be saved at 'Preset Setup Menu' again.

*Notice: To stop an action, press [ESC] button or [96+Preset]. In that case, the dome goes to manual mode or is to be paused temporarily (about 10sec in Alarm mode)

3.1.1 Accessing to MAIN MENU [95] + [Preset]/ [Menu]*

When you use Pelco-D and Pelco-P protocol with your controller, you can access to the main menu on your monitor by pressing the key [95] + [Preset] or pressing and holding the [Menu] key for 2 seconds.

3.1.2 Editing a TITLE

ABCDEFGHUKL MNOPQRSTUVMXY Z0123456789/+ -=:?!#.,*~()

Title:

SELECT: (MOVE) SET/CLEAR: (TELE/MDE) SAVE: (NEAR) EXIT: (FAR) The title edit menu can be used in the setup for Preset/Pattern/Tour/Scan commonly.

- Move the joystick right in Main Menu. The screen appears on the monitor:
- Move the joystick right, left, up or down to select a character.
- Press [Tele] button to input a character and [Wide] button to cancel the character.
- When the label is completed, use [Near] or move the joystick to save the selected title.
- If you want to cancel the selected title, return to the previous menu using [Far] button.

3.2 Main Menu

Main Menu SYSTEM SETUP DISPLAY SETUP CAMERA SETUP DOME MOTION PRE SET SETUP PATTERN SETUP TOUR SETUP SCAN SETUP ALARM SETUP EXIT

- \blacktriangle/∇ : move joystick up and down for selecting an item.
- \triangleleft > : move joystick left and right for moving an item.
- ► / [Open]/ [Near]: move joystick right to select or save settings or go to edit pages.
- / [Close]/ [Far]: move joystick to cancel or to exit current menu. (Back to previous menu without saving)

3.3 System Setup Menu

SYSTEM SETUP INFO. REBOOT INITIALIZE PASSWORD EXIT

- \blacktriangle/∇ : move joystick up and down for selecting an item.
- \triangleleft **)** : move joystick left and right for moving an item.
- / [Open]/ [Near]: move joystick right to select, save settings or go to the edit page.
- / [Close]/ [Far]: move joystick to cancel or to exit current menu (Back).

3.3.1 System Information

EPH-5212 V2.02 RS485/-2400 ID001 NTSC
- EXIT: FAR

The system Information displays model name/Running Version/Protocol/Communication Type/Camera ID No./System. It is read only for reference. Use the following steps to display the System Information screen: Camera ID changes with respect to ID switching setting.

- Enter into {Main MENU}
- Select {System} using the joystick [>].
- Move the joystick right [**>**] for selecting {Info} in the sub menu of {System}.
- Press [Far] button or use joystick [>] to return to previous menu (Back).

3.3.2 Reboot

REBOOT
CONTINUE? YES: NEAR NO : FAR

Reboot the system if there are some anomalous problems to control or operate the domes. Rebooting the system will recycle power of dome and camera without changing settings of dome.

- Enter into {Main Menu} Select {System) using joystick and move to {Reboot} in the sub menu of {System}
- To {Reboot} the system, Press [Near] key.
- To cancel Reboot, Press [Far] key.

3.3.3 Initialize

INITIAL	IZE	
ALL CAM PRESE TOUR PATTE SCAN ETC	ET : RN:	NO CLR NO CLR NO CLR NO CLR NO CLR NO CLR NO CLR
SAVE: BACK:	OPI CLC	EN DSE

Use this function to initialize all or specific parameters of dome to factory default parameters.

- Enter into {Main Menu}
- Select {System} using joystick [>] and move to {Initialize} in the sub menu of {System}
- Select items to be initialized.
- Press [Near] button or use joystick [>] to select {Clear}
- Press [Far] button or use joystick [>] to return to previous menu (Back).

[ALL]: Clear All saved items (CAM/PRESET/TOUR/PATTERN/SCAN)

[CAM]: Clear Camera related settings.

[PRESET]: Clear saved presets. (To clear each preset, refer to PRESET Menu)

[TOUR]: Clear saved Tours.

[PATTERN]: Clear saved Patterns.

[SCAN]: Clear saved Scan items.

[ETC]: Clear other setting value except items of Camera & PTZs (CAM status and saved data of PRESET, TOUR, PATTERN and SCAN)

3.3.4 Entering a Password

PASSWORD
CURRENT : ENABLE: DISABLE NEW : CONFIRM :
0123456789 - Set/Clear:Telemide) - EXIT : (FAR)

To prevent unauthorized changes to the dome settings, the dome have the feature of password protection. An unauthorized operator cannot access to any of the dome settings menus. The password must be entered before programming. The valid password with four characters must be entered to continue programming.

- Enter into {Main Menu} (refer to Accessing Main Menu)
- Select {System} and move to {Password} in the sub menu of {System} using joystick [>].
- Select numbers using joystick left/right and press [Tele] key.
- To lock the password, set Enable: Enable

Note*:

0000 is the default password.

3.4 Display Setup Menu

DISPLAY SETUP

LANGUAGE: ENGLISH OSD SETUP IMAGE SETUP PRIVACY ZONE MD EXIT

- \blacktriangle/∇ : move joystick up and down for selecting an item.
- \triangleleft > : move joystick left and right for moving an item.
- / [Open]/ [Near]: move joystick right to select or save settings or go to edit pages.
- ► / [Close]/ [Far]: move joystick to cancel or to exit current menu (Back).

3.4.1 Language

- Select {Display Setup} and move to {Language} using joystick [▶].

- If you want to use another language, select one

from English/Chinese/Russian/Spanish/German/Italian/French/Netherlandish.

3.4.2 OSD Setup

OSD Setup
LABEL POSITION OFF
DTIME : ON
ID : ON
MODE : ON
ANGLE : 3SEC
SAVE: OPEN
BACK: CLOSE
- TO SETUP: (TELE)
, r
ERROR MSG
-EXIT FAR
-ID -

ZOOM - ANGLE-

You can see only video or some character with video. Each element is able to handle. OSD setup allows you to program how labels are displayed on the monitor. Labels are such as Title, Dwell Time, Zoom ratio, Camera ID, Operation Mode and PTZ Angle Label position can be set where you want to place on the monitor.

- Enter into {Main Menu}
- Select {Display} and move to {Setup} using joystick [>]
- Use the joystick to move the label up, down, left, and/or right.
- Press [Tele] button to edit the position of labels.
- Move the joystick right [>] to change the status of labels
- Other labels can be set with same method.
- Press [Far] button to return the previous menu (OSD setup).
- Press [Open] button or use joystick to save the status.
- Press [Close] button or use joystick to return to previous menu (Back).

3.4.3 Privacy zones

PRIVACY ZONE SETUP
ZONE NO.00: NOT USE(EDIT: DISPLAY: WDTH: HEIGHT: CLEAR
SAVE : OPEN BACK : CLOSE - CHANGE: (_EFT/LIGHT)

PRIVACY ZONE SETUP

PRESS MOVE KEY SAVE: NEAR EXIT: FAR

A privacy mask zone allows an administrator to program one four-sided, user defined zone which cannot be viewed by operators. The mask can be changed with pan angle and tilt angle using joystick and be adjusted in size according to zoom ratio [Tele/Wide]. Maximum 8 zones can be created. Note that the tracking speed of displayed masks is proportional to the number of masks on the screen. It is recommended that you set the size to at least twice the size of the object (height and width) so that the mask does not reveal the private zone during some motion.

- Enter into {Main Menu}
- Select Display and Privacy Zone using joystick [▶].
- Move the joystick left or right to select zone ID[00~8].
- To program a Privacy Zone, select Edit Mask, move to a Target (Pan/Tilt) and adjust a Mask size (Zoom).
- Press [Near] button or use joystick to save it.
- After editing a mask, you can re-size width & height using joystick [>]. (e.g. ~5X)
- Set display On to display saved mask.
- It is possible to clear saved zone No.xx individually.
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.4.4 Image Setup



This menu is for changing displayed image settings.

- Enter into {Main Menu}
- Select {Display} and move to {Image Setup} using joystick [▶].
- Using joystick [>], Normal image, Horizontal image, Vertical image or H/V image can be selected.
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.4.5 MD (Motion Detection)

MOTION DETECTION
MD : OFF(ON) ALARM : OSD/OSD +ALARM_OUT ATIME:
SAVE: OPEN BACK: CLOSE

The dome camera can monitor the movement of image, and it sends an alarm message with OSD and Alarm Out action. The level for sensitivity can be changeable.

NOTE* To stop alarm temporarily (about 10sec), press [ESC] button or [96+preset].

- Set MD for Off/MD using the joystick.
- Set Alarm mode for OSD/Alarm Out/Both using the joystick.
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.5 Camera Setup Menu

CAMERA SETUP

FOCUS/ZOOM WBALANCE EXPOSURE DAY/NIGHT ADVANCED EXIT

- \blacktriangle/∇ : move joystick up and down for selecting an item.
- \triangleleft **)** : move joystick left and right for moving an item.
- / [Open]/ [Near]: move joystick right to select or save settings or go to edit pages.
- ► / [Close]/ [Far]: move joystick to cancel or to exit current menu (Back).

3.5.1 Focus/Zoom



Auto Focus allows the lens to remain in focus during zoom-in, zoom-out and motion functions automatically. Zoom speed allows the user to define how fast the dome will go from full wide zoom to the 12X optical zoom. There are four modes (Slow, Normal, and Fast). And the default setting is 'Fast'.

D.Zoom allows the user to use Digital Zoom. Default setting is Optical Zoom without Digital Zoom

- Enter into {Main Menu}
- Select {Camera Setup} and move to {Focus/Zoom} using joystick [>].
- Set Focus mode for Auto, Manual, or Semi-Auto.
- Set Zoom Speed for Fast, Normal or Slow.
- Select On/Off to set a status of D.Zoom.
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.5.2 WB Setup (White Balance Setup)

WBSETUP

MODE : AWB R GAIN : B GAIN : SAVE : OPEN BACK : CLOSE

This feature automatically processes the viewed image to retain color balance over a color temperature range. The default setting for auto white balance is Auto mode.

In Manual mode, you can change the R or B gain value to adjust the color on a monitor.

*Auto Trace White balance (ATW): It aligns the white balance automatically. (2,300 to 11,000 K) *Indoor: 3200 K Base Mode

- * Outdoor: 5400 K Base Mode
- * Push WB mode: The white balance is aligned during key input. (White balance push auto key)
- * Manual WB mode: Red and Blue gain values can be set by user, 0 ~ 255
- * Auto White Balance mode (AWB): Wide range auto white balance mode. In this mode, the white balance is performed at a faster operating speed than ATW.
- Enter into {Main Manu}
- Select {Camera Setup} and move to {WB Setup} using joystick [>].
- Set WB mode for AWT, Indoor, Outdoor, Onepush, AWB or Manual.
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.5.3 AE Setup (Auto Exposure Setup)



Shutter speed is the duration of the electronic shutter. Set the shutter speed to operate automatically (Auto) or manually (Numeric Value).

The AGC (Automatic Gain Control) adjusts the brightness of the pictures. The brightness increases as the number gets higher.

DSS enhances digital noise reduction properly. There are three settings: Low/Middle/High. When gain level is higher, DSS will reduce the noise to make clearer image.

When Input luminance level is too dark, Slow Shutter function (DSS) is set automatically higher.

Brightness increases as the number gets higher. The backlight compensation function provides compensation by

increasing the brightness of the overall screen so that subjects being shot with a loss of dark detail due to backlight will have just the right brightness level.

- Enter into {Main Manu}
- Select {Camera Setup} and move to {AE Setup} using joystick [▶].
- Set AE mode for Full Auto, Manual, Shutter PRI.
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

AE Mode	Full Auto	Manual	SHUT PRI
Shutter (Auto, X2~X64,1/30~1/10000)	х	O (Auto)	O (Auto)
AGC Gain(OFF, Low/Mid/High)	Х	O (High)	Х
DSS(OFF, X2~X64)	O (Off)	Х	Х
Bright(0~100)	O (50)	O(050)	O (50)

3.5.4 Day & Night Setup



The Day & Night function improves the camera's sensitivity at night or when the brightness level of the ambient environment. According to the luminance level, Day & Night filter is automatically switched.

- Enter into {Main Manu}
- Select {Camera Setup} and move to {Day/Night Setup} using joystick [>].
- Set Day/Night for Auto, Day or Night.
- Set D&N Detector for Sensor or Video.
- Set switching time that you want. Default value is 5 second.
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.5.5 Advanced Setup

ADVANCED SETUP

SHARPNESS : 50 DIS : OFF BLC LEVEL: OFF WDR LEVEL: OFF HSBLC LEVEL: OFF DNR LEVEL: OFF SAVE: OPEN

BACK: CLOSE

Sharpness enhances picture detail by increasing the aperture gain of the camera and sharpening the edges in the picture.

Digital Image Stabilizer (DIS) function internally detects shaking of the image due to camera shaking and performs digital compensation processing inside the DSP to suppress this shaking and stabilize the image output. Compensation uses the electronic zoom function, so the digital zoom function cannot be set by the user while using the DIS function.

- Enter into {Main Manu}
- Select {Camera Setup} and move to {Advanced Setup} using joystick [>].
- Set sharpness level and brightness and DIS on/off
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

When both high-brightness subjects and low-brightness subjects have been shot at the same time, overexposure in the high-brightness subjects or loss of dark detail in the low-brightness subjects may occur. The WDR (Wide Dynamic Range) function creates images free from over-exposure or loss of dark detail by combining two images after tripping the shutter for a long exposure time and for a short exposure time in one field.(One mode can be selected from BLC/WDR/HSBLC/DNR)

- Enter into {Main Manu}
- Select {Camera Setup} and move to {Advanced} using joystick [>].
- Set WDR for On/Off and a level in 'On' mode.
- Set other mode for On/Off and a level in 'On' mode in the same way.
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.6 Dome Motion Menu

DOME MOTION SETUP

GENERAL SETUP MOTION SETUP HOME ACTION CALIBRATION EXIT

 \blacktriangle/∇ : move joystick up and down for selecting an item.

- \triangleleft > : move joystick left and right for moving an item.
- / [Open]/ [Near]: move joystick right to select or save settings or go to edit pages.
- ► / [Close]/ [Far]: move joystick to cancel or to exit current menu (Back).

3.6.1 General Setup

GENERAL SETUP POWER-UP ACT. ON TURBO SPEED : ON PRESET SPEED : FAST SAVE: OPEN

BACK: CLOSE

This menu control general function of dome.

Power-up Action is a function (preset, tour, pattern and scan) to be performed when the power is re-cycled or after alarm action. The following settings are available. Set the dome 'On' (default) to resume its prior activity.

- Use the joystick [▶] to select On/Off

Turbo Speed defines the pan and tilt speed only for manual operation of Pan/Tilt.

- Use the joystick [▶] to select On/Off

Preset Speed is possible to set preset speed with 3 options. : Fast, Normal, and Slow.

- Use the joystick [▶] to select {Preset Speed}
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.6.2 Motion Setup

MOTION SETUP

Prop. Pan/Til: On Auto flip : On Over tlt : Off

SAVE: OPEN BACK: CLOSE

Proportional Pan/Tilt is possible to set manual speed with Zoom.

- Use the joystick [▶] to select On/Off

Auto-Flip is a function automatically reversing the image when zoom module camera passes

through the top of tilt direction (90 degree)

When tilt angle arrives at the top of tilt orbit (90degree), zoom camera module keep moving to opposite direction of tilt to keep tracking targets. As soon as zoom camera module passes through the top of tilt direction (90degree), image should be reversed automatically.

- Use the joystick [▶] to select On/Off

Over-Tilt is for restricting vertical view angle related to the operation range of IR sensor and some blocking view angle mechanically. When the dome is covered with window bubble, it is recommended Over-Tilt to Off.

To prevent horizontal view cut with tilt angle, it is to restrict vertical view angle.

- Use the joystick [▶] to select On/Off

- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.6.3 Home Action Setup

Home action setup Action : Home NUMBER : TIME : 010 MIN Mode : OFF SAVE : OPEN BACK : CLOSE

Home Action can be set so that the dome automatically goes to a preset, a tour or auto scan after the joystick control has been idle for some amount of time.

The dwell time can be set from 1 minute to 60 minutes.

- Using the joystick [>], {Home Action} can be selected to Home (default), Preset, Scan and Tour.
- {Number} is the number of {Action}. For example, {Action: Preset/Number: 001} mean Preset [1]
- Set {Time} xx min using the joystick [>].

- Using the joystick [▶] to select Auto (On)/Manual (Off).
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu {Dome Motion Setup} (Back).

NOTE* In order to call an action (Preset, Pattern, Tour or Scan), you must save Preset, Pattern, Tour, or Scan first.

3.6.4 Calibration Setup

CALIBRATION SETUP AUTO CAL : AUTO ERROR MSG DISP : ON CALIBRATION SAVE: OPEN BACK: CLOSE

CONTINUE? YES: NEAR NO: FAR

- Set calibration mode for Manual/Auto using the joystick [▶].
- In manual mode, select {Calibration} to execute {Calibration} using the joystick, and press [Near] button or use joystick to continue.
- Set {Error Message Display} for On/Off using the joystick [>].
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

Note: {Calibration} is a function for correcting an error on the angle of Pan/Tilt automatically.

{Calibration} can be set for Manual/Auto. In Manual mode, if there is an error on the angle of the dome, execute

{Calibration}. Press [Near] button to continue calibration or press [Far] button to cancel calibration.

In Auto mode, when there is an error on the angle of the dome, the dome is corrected automatically. The motor of the Pan/Tilt will adjust its angle automatically.

{Error Message Display} is a function for displaying an error message to let a user know {Sensing error} on the monitor.

3.7 Preset Menu

PRESET SETUP NO.001:NOT USED EDIT: TITLE: DTIME: CLEAR SAVE: OPEN BACK: CLOSE

 \blacktriangle/∇ : move joystick up and down for selecting an item.

- \triangleleft **)** : move joystick left and right for moving an item.
- / [Open]/ [Near]: move joystick right to select or save settings or go to edit pages.
- ► / [Close]/ [Far]: move joystick to cancel or to exit current menu (Back).

The dome has maximum 210 preset positions. Each of the user-defined presets includes Pan/Tilt/Zoom. Use the following steps to program {Preset}.

PRESET SETUP

PRESSMOVE KEY SAVE: NEAR EXIT: FAR

- Enter into {Main Manu}

- Select {Preset} and Move left or right to select Preset Number.
- Move the joystick right [>] to edit a {Preset}
- Using the joystick, move to a desired target (Pan/Tilt/Zoom)
- Press [Near] button or use joystick to save settings.
- Press [Far] button or use joystick to return to previous menu {Preset Edit} (Back).
- To edit and clear the {Preset Title}, refer to Editing a Title section (3.2.1).
- It is possible to clear saved Preset No.xxx in the {Preset Setup Menu} individually.
- Set {Dwell Time} using the joystick [▶]
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.8 Pattern Menu

PATTERN SETUP NO.001:NCT USED EDIT: TITLE: TIME : CLEAR SAVE: OPEN BACK: CLOSE

- \blacktriangle/∇ : move joystick up and down for selecting an item.
- \triangleleft **)** : move joystick left and right for moving an item.
- / [Open]/ [Near]: move joystick right to select or save settings or go to edit pages.
- ► / [Close]/ [Far]: move joystick to cancel or to exit current menu (Back).

A {Pattern} is to display (or recall) a memorized, repeated and serial trace of pan, tilt, zoom. The dome has maximum 8 {Patterns}. Each of the user-defined scans includes Pan/Tilt/Zoom.

Use the following steps to program {Pattern}.

PTIME 022 START POSITION SETUP PATTERN SET JP PRESSMOVE KEY START: (NEAR)

START: (NEAR) SAVE: (NEAR) EXIT: (FAR)

- Enter into {Main Manu}
- Select {Auto Scan} and move left or right to select {Pattern} Number.
- Move the joystick right [▶] to edit {Pattern}
- Using the joystick, move to a desired target and press [Near] button to start programming {Pattern}
- Press [Near] button or use joystick to save settings.
- Press [Far] button or use joystick to return to previous menu {Pattern Setup} (Back).
- To edit and clear {Pattern Title}, refer to Editing a Title section (3.2.1).
- It is possible to clear saved Pattern No.xxx in the {Pattern setup} Menu individually.
- Press [Open] button or use joystick to save settings.
- Press [Close] or use joystick to return to previous menu (Back).

3.9 Tour Menu

TOUR SETUP

NO.001 : NOT USED

BACK: CLOSE -CHANGE ID:(TELEAVIDE) -CHANGE ACTION: (NEAR)

- \blacktriangle/∇ : move joystick up and down for selecting an item.
- \triangleleft **)** : move joystick left and right for moving an item.
- / [Open]/ [Near]: move joystick right to select or save settings or go to edit pages.
- / [Close]/ [Far]: move joystick to cancel or to exit current menu (Back).

The dome can have 8 {Group Tours}. And each of the tour has 28 items.

Each item has pre-defined preset, pattern, and scan.

NOTE* In order to call an action (Preset, Pattern or Scan), you must save Preset, Pattern, or Scan first.

- Enter into {Main Manu}
- Select {Tour} and Move left or right to select {Tour} Number.
- Using the joystick $[\blacktriangle/\checkmark/\checkmark/\blacktriangleright]$, move to each item.
- Select an action/number (PRESET, TOUR, PATTERN and/or SCAN), with [Tele] button or clear item with [Wide] button and change mode using [Near] button.
- It is possible to clear saved Tour No.xxx in the {Tour Setup Menu} individually.
- Press [Open] button or use joystick to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.10 Auto Scan Menu

SCAN SETUP
NO.001: NOT USED EDIT: SPEED : DTIME: DIRECTION: MODE: CLEAR
SAVE: OPEN BACK: CLOSE

 \blacktriangle/∇ : move joystick up and down for selecting an item.

 \blacktriangleleft > : move joystick left and right for moving an item.

- ► / [Open]/ [Near]: move joystick right to select or save settings or go to edit pages.
- ► / [Close]/ [Far]: move joystick to cancel or to exit current menu (Back).

An {Auto scan} is a PTZ function that can be moved from one position to another position.

The dome has maximum 8 {Auto Scan} and {Scan Speed} can be changed from 1 to 35 degree/sec. Use the following steps to program a {Auto Scan}.

START POSITION SETUP	STOP POSITION SETUP
PRESSMOVE KEY	PRESSNOVE KEV
Save: (Near)	Save: (NEAR)
Exit: (Far)	Back: (FAR)

- Enter into {Main Manu}
- Select {Auto Scan} and move left or right to select {Auto Scan} Number.
- Move the joystick right [>] to edit {Auto Scan}: {Edit Start Point}/ {Edit Stop Point}
- Using the joystick, move to a desired target (Pan/Tilt/Zoom) at screen of {Edit Start Point}/ {Edit Stop Point}
- Press [Near] button or use joystick to save settings.
- Press [Far] button or use joystick to return to previous menu {Scan Setup} (Back).
- To edit and clear the {Scan Title}, refer to Editing a Title section (3.2.1).
- It is possible to clear saved Scan No.xxx in the {Scan setup} Menu individually.
- Set {Dwell Time} using the joystick [>].
- Press [Open] button or use joystick [>] to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

3.11 Alarm Menu

ALARM SETUP
NO.001 : NOT USED
IN :
OUT :
PRIORITY.
ACTION :
NUMBER:
DTIME:
SAVE: OPEN
BACK: CLOSE
-SET/CLEAR: (TELEAMIDE)

- \blacktriangle/∇ : move joystick up and down for selecting an item.
- \triangleleft > : move joystick left and right for moving an item.

- / [Open]/ [Near]: move joystick right to select or save settings or go to edit pages.
- ► / [Close]/ [Far]: move joystick to cancel or to exit current menu (Back).
- Enter into {Main Menu}
- Using the joystick [\blacktriangleright], select Alarm Input type (NO/NC).
- Using the joystick [>], select Alarm Output (On/Off)
- Alarm priority can be set using the joystick [>],
- Change an action/number {Off, Preset, Pattern, Scan, or Tour}.
- Set Alarm action time (Dwell Time): 3~60sec/On, default setting is 'ON'.
 - -> Time Out (3~60sec): This is activated during a period of a selected dwell time when an alarm is triggered.
 - -> Momentary (On): When an alarm is triggered, the dome camera will maintain alarm activation continuously, until it is stopped manually (96+preset or/and changing in alarm menu).
- It is possible to clear saved {Alarm No.xxx}, pressing [Wide] button at a position of {No.xxx} individually.
- Press [Open] button or use joystick [>] to save settings.
- Press [Close] button or use joystick to return to previous menu (Back).

NOTE* In order to call an action (Preset, Pattern, Tour or Scan), you must save Preset, Pattern, Tour, or Scan

first. To pause alarming (about 10sec) temporarily, press [ESC] button or [96+preset]

4. Troubleshooting Guide

If problems occur, check the installation of the dome with the instructions in this manual. And refer to this manual for further information.

Problem	Solution			
	 Verify that power is connected to all components in the system. 			
No video on the screen	 Verify that the power switches are ON. 			
	- Verify the status of cables or connection of cables			
	 Check the power supply voltage (normal 24VAC 			
	- Check the setting of camera.			
Poor video quality.	- If the lens or the dome is dirty, clean up the dome window			
	with a clean cloth.			
	- Re-cycle the power supply re-connecting the power code. Or			
	reset the dome camera using the Dome configuration			
Dome camera is not working	menus. [Main>System>Reboot]			
properly (including wrong position of dome camera)	- Check that the connection of power cable and assembling			
	status of dome camera.			
	- Initialize the dome camera. [Main>System>Initialize]			
	- Check that RS-485 communication cable is not connected			
The communication between	correctly. [Refer to 2.3 Connection Interface and Wire cables]			
controller and cameras is not	- Check ID/Protocol/Baud rate/Termination Setting.			
working properly. (Via 485 cable lines)	[2.4 Setting Dome Camera]			
	- See the configure of [1.3 Termination Settings]			
	- Check the voltage level of the dome camera and the			
The surface of the dome case is	assembling status of dome camera.			
hot.	- Check that the dome camera is connected to the proper			
	power.			
	- Does the camera face directly into the sun or fluorescent			
The image on the screen is flickers	lamp? If so, reposition the dome. Check for flicker-less			
	setting of the dome.			

5. Specifications

5.1 General Specifications

Pickup Device	1/2.8" Sony Exmor R 2.1 megapixel Color Progressive CMOS sensor			
Pixels	1920x1080 with 2.5µx 2.5µ pixel size			
Image Area Dimensions	4.8mm x 2.7mm (16:9 aspect ratio; 5.52mm diagonal)			
Sensitivity	0.2lux/F=1.6 DSS off color; 0.1lux ICR removed; .001lux DSS @ 64X			
	[EverFocus recommends not exceeding 4x~8x DSS without careful consideration]			
Digital Slow Shutter	Programmable Off or 2X~64X; max 8X recommended			
S/N Ratio	Max. 50dB			
Video Format Main Output	HDcctv			
Resolution Main Output	Field select HD1080 or HD720			
Video Mode Main Output	Field select 1080i60/50; 1080p30/25; 720p60/50/30/25			
Main Output Connector	BNC-F			
Video Format Test Output	NTSC/PAL selectable			
Analog Video Output Connector	BNC-F			
Electronic Shutter	Auto/Manual selectable			
Lens Focal Length &	12X zoom: 5.0mm wide ~ 60mm tele (F2.0~3.0)			
Angle of View	Optical view angle ~52.4°(wide) to ~4.64° (tele)			
Digital Zoom	Up to 10X; optional activation after full 12X optical zoom			
Auto Focus	Choose Off/manual, full auto or 'one touch' (holds focus after initial setting after movement)			
Pan and Tilt	Pan: Speed up to 360°/sec; continuous 360° rotation			
Range and Speed	Tilt: speed up to 260°/sec; 180° range (+/- 90°); digital auto flip for continuous tracking			
	Maximum 0.75 seconds present recall time; manual speed proportional to zoom ratio			
True Day/Night Control	Yes (Auto IR cut filter removal); Manual select always color or always B/W.			
Electronic Wide Dynamic Range	On/Off selectable			
Back Light Compensation	On/Off selectable			
Auto Gain Control	Yes (Level 0~186)			
Auto White Balance	ATW/Push/Manual/Specific Color or Color Temperature			
DNR	Off/Low/Mid/High selectable			
OSD Menu	Yes (controlled via RS-485; optional password protection)			
OSD Data Display	Select interval and position for optional display of zoom level, camera ID, mode and/or angle			
Image Flip	Digital auto flip at when camera tilts thought bottom position selectable on/off			
Presets	Up to 210 positions may be stored; programmable preset speed			
Auto Scan Zones	Up to 8 auto scan zones			
Patterns	Up to 6 patterns may be memorized and stored			
Tours	Up to 8 tours (consisting of presets, patterns and scans)			
Privacy Zones	Up to 8 'smart' zones that automatically adjust relative position as the camera moves			

Alarm Inputs	4 NO/NC programmable trigger inputs; programmable relative priority of alarms			
Alarm Output	Form "C" relay rated at 12VDC/1A			
Alarm Actions	Go to preset, pattern, scan or tour; optional programmable duration of 3~60 seconds			
Other Actions	On inactivity of 1~60 minutes, go to preset position, pattern, scan or tour			
RS-485 Protocols Supported	EVF-1, Pelco-P, Pelco D			
RS-485 Baud Rate	2400~38,400			
RS-485 Addressing	Address range 00~99			
Device Currhy	24VAC (+/- 10% nominal)			
Power Supply	2.5A capacity recommended (heater on); 1A recommended (heater off)			
Power Consumption	~850mA heater off; ~1.8A heater on			
Power Input Surge Protection	Built in			
	Body diameter 6.55"; height with wall arm 10"			
Dimensions	Clear bubble diameter 4.7"			
	Projection from rear with wall arm 13.4" (10.2" to center line of dome)			
Weight	PTZ unit: 4.9 lbs; included EPH-WMB wall mount arm: 2.8 lbs.			
	Total in wall mount configuration: 7.7 lbs.			
Operating Temperature	-40°C~50°C ; -40°F~122°F (heater on below ~30°F)			
Environmental	IP66 weather resistant			
Mounting Provision	Wall mount arm included			
Certifications	FCC, CE, HDcctv Alliance Base-Line Compliance			

5.2 Dimensions



APPENDIX. RS-485 Function List



Function	Key	Preset No.	Operation	e.g. 1	e.g. 2
MOVE to Preset	Preset	1~59, 101~250	Preset+No.+Go	Preset+1+Go	
SET Preset	Preset	1~59, 101~250	Preset+No+Set	Preset+14+Set	
Run FLIP	Preset	33	Preset+No.+Go	Preset+33+Go	
Run PAN ZERO	Preset	34	Preset+No.+Go	Preset+34+Go	
Scan Setup	Preset	60	Preset+No.+Go	Preset+60+Go	
SCAN	Preset/Scan	61~68	Preset+No.+Go	Preset+61+Go	1+Scan
Tour Setup	Preset	70	Preset+No.+Go	Preset+70+Go	
TOUR	Preset/Tour	71~78	Preset+No.+Go	Preset+71+Go	1+Tour
Pattern Setup	Preset	80	Preset+No.+Go	Preset+80+Go	
PATTERN	Preset/Pattern	81~88	Preset+No.+Go	Preset+81+Go	1+Pattern
ENT Key	Preset	90	Preset+No.+Go	Preset+90+Go	
Run HOME	Preset	91	Preset+No.+Go	Preset+91+Go	
CLR Key	Preset	92	Preset+No.+Go	Preset+92+Go	
ENT2 Key	Preset	94	Preset+No.+Go	Preset+94+Go	
MENU Key	Preset/**Menu	95	Preset+No.+Go	Preset+95+Set	**Menu
ESC Key	Preset/ESC	96	Preset+No.+Go	Preset+96+Go	
D. Zoom (Toggle)	Preset	97	Preset+No.+Go	Preset+97+Go	

**To go to OSD Main Menu, Press and hold [MENU] key for 2 seconds.