Single phase input 200V class Three phase input 200V class Three phase input 400V class HF-320 Series Instructions

Sumitomo Heavy Industries, Itd.



SAFETY

For the Best Results with HF-320 Series inverter, read this manual and all of the warning sign attached to the inverter carefully before installing and operating it, and follow the instructions exactly. Keep this manual handy for your quick reference.

Definitions and Symbols

A safety instruction (message) is given with a hazard alert symbol and a signal word; **WARNING** or **CAUTION**. Each signal word has the following meaning throughout this manual.



This symbol means hazardous high voltage. It used to call your attention to items or operations that could be dangerous to your and other persons operating this equipment.

Read these message and follow these instructions carefully.



This is the "Safety Alert Symbol.." This symbol is used to call your attention to items or operations that could be dangerous to your or other persons operating this equipment. Read these messages and follow these instructions carefully.



G WARNING

Indicates a potentially hazardous situation which, if not avoided, can result in serious injury or death.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, can result in minor to moderate injury, or serious damage of product. The matters described under \triangle **CAUTION** may, if not avoided, lead to serious results depending on the situation. Important matters are described in **CAUTION** (as well as **WARNING**), so be sure to observe them.

NOTE NOTE: Notes indicate an area or subject of special merit, emphasizing either the product's capabilities or common errors in operation or maintenance.

HAZARDOUS HIGH VOLTAGE

Motor control equipment and electronic controllers are connected to hazardous line voltages. When servicing drives and electronic controllers, there might be exposed components with cases or protrusions at or above line potential. Extreme care should be taken to protect against shock.

Stand on an insulating pad and make it a habit to use only one hand when checking components. Always work with another person in case an emergency occurs. Disconnect power before checking controllers or performing maintenance. Be sure equipment is properly grounded. Wear safety glasses whenever working on an electronic controllers or rotating electrical equipment.

PRECAUTIONS

WARNING : This equipment should be installed, adjusted and serviced by qualified electrical maintenance personal familiar with the construction and operation of the equipment and the hazards involved. Failure to observe this precaution could result in bodily injury.

WARNING : The user is responsible for ensuring that all driven machinery, drive train mechanism not supplied by Sumitomo Heavy Industries,Ltd., and process line material are capable of safe operation at an applied frequency of 150% of the maximum selected frequency range to the AC motor. Failure to do so can result in destruction of equipment and injury to personnel should a single point failure occur.

WARNING : For protection, install a leak breaker type with a high frequency circuit capable of large currents to avoid an unnecessary operation. The ground fault protection circuit is not designed to protect personal injury.

▲ WARNING : HAZARD OF ELECTRICAL SHOCK. DISCONNECT INCOMING POWER BEFORE WORKING ON THIS CONTROL.

WARNING : SEPARATE MOTOR OVERCURRENT, OVERLOAD AND OVER-HEATING PROTECTION IS REQUIRED TO BE PROVIDED IN ACCORDANCE WITH THE SAFETY CODES REQUIRED BY JURISDICTIONAL AUTHORITIES.

CAUTION: These instructions should be read and clearly understood before working on HF-320 series equipment.

CAUTION: Proper grounds, disconnecting devices and other safety devices and their location are the responsibility of the user and are not provided by Sumitomo Heavy Industries,Ltd.

CAUTION: Be sure to connect a motor thermal switch or overload device to the HF-320 series controller to assure that the inverter will shut down in the event of an overload or an overheated motor.

A CAUTION: DANGEROUS VOLTAGE EXISTS UNTIL POWER LIGHT IS OFF.

CAUTION: Rotating shafts and above ground electrical potentials can be hazardous. Therefore, it is strongly recommended that all electrical work conform to the National Electrical Codes and local regulations. Installation, alignment and maintenance should be performed only by qualified personnel.

Factory recommended test procedures, included in the instruction manual, should be followed. Always disconnect electrical power before working on the unit.

This equipment has high leakage current and must be permanently(fixed) hard wired to earth via two independent cable.

MOTORS


- a) Any motor used must be of suitable rating.
- b) Motors may have hazardous moving parts, in this event suitable protection must be provided.

Alarm connection may contain hazardous live voltage even when inverter is disconnected. In case of removing front cover for maintenance or inspection, confirm that incoming power for alarm connection is surely disconnected.

Hazardous (main) terminals for any interconnection (motor, contact breaker, filter etc) must be inaccesible in end installation.

This equipment should be installed in IP54 or equivalent(see EN60529). The end application must be in accordance with BS EN60204-1(with reference to manual page4-1 and 4-2, the digagram measurements to be suitably amended).

Connection to field wiring terminals must be reliably fixed having two independent means of support.Using terminal with cable support (figure below),or cable gland,cable clamp etc.



A double pole disconnection device must be fitted to the incoming mains supply close to the inverter. Additionally, a protection device meeting IEC947-1/IEC947-3 must be fitted at this point(protection device data shown in page 5-8)

The Above instructions, together with any other requirements highlighted in this manual, must be complied with for continued LVD compliance.

LVD: Low Voltage Directive

Precautions for EMC (Electro Magnetic Compatibility)

It is required to satisfy the EMC directive (89/336/EEC) when using HF-320 inverter in EU country. To satisfy EMC directive and to comply with standard, the followings should be kept.

WARNING:

This cquipment should be installed, adjusted and serviced by qualified personal familiar with construction and operation of the equipment and the hazards involved. Failure to observe this precaution could result in bodily injury.

1. Power supply to HF-320 inverter

- 1) Voltage fluctuation $\pm 10\%$ or less.
- 2) Voltage unbalance $\pm 3\%$ or less.
- 3) Frequency variation $\pm 4\%$ or less.
- 4) Voltage distortion THD = 10% or less.

2. Installation

1) Use filter designed for HF-320 inverter.

3. Wiring

- 1) Sielded wire(screened cable) is required for motor wiring, and length is less than 50m.
- 2) Carrier frequency must be setting less than 5kHz to satisfy EMC requirement.
- 3) Separate the main circuit wiring from signal/process circuit wiring.

4. Environment condition

When using a filter, keep the following condition.

- 1) Ambient temperature : -10 to 40° C
- 2) Humidity : 20 to 90 % RH (no dew condensation)
- 3) Vibrations : 5.9 m/s²(0.6 G) 10-55Hz
- 4) Location : 1000 meter or less altirude, indoor (no corrosive gas or dust)

TABLE OF CONTENTS

1.	SAFETY PRECAUTIONS	1-1
2.	INSPECTION UPON UNPACKING	2-1
3.	APPEARANCE AND NAMES OF PARTS	3-1
4.	INSTALLATION	4-1
5.	WIRING	5-1
6.	OPERATION	6-1
7.	FUNCTION OF CONTROL CIRCUIT TERMINAL	7-1
8.	OPERATION OF THE DIGITAL OPERATOR	8-1
9.	PROTECTIVE FUNCTIONS	9-1
10.	TROUBLESHOOTING	10-1
11.	MAINTENANCE AND INSPECTION	11-1
12.	STANDARD SPECIFICATIONS	12-1
APP	ENDIX 1 CAPACITOR LIFE CURVE	A-1


1. SAFETY PRECAUTIONS

1. Installation

Be sure to install the unit on flame resistant material such as metal. Otherwise, there is a danger of fire.		p. 4-1
Be sure not to place anything inflammable in the vicinity. Otherwise, there is a danger of fire.	•••••	p. 4-1
Be sure not to let the foreign matter enter such as cut wire refuse, spatter from welding, iron refuse, wire, dust, etc. Otherwise, there is a danger of fire.		p. 4-1
Be sure to install it in a place which can bear the weight according to the specifications in the text (4. Installation). Otherwise, it may fall and there is a danger of injury.		p. 4-1
Be sure to install the unit on a perpendicular wall which is not subject to vibration. Otherwise, it may fall and there is a danger of injury.		p. 4-1
Be sure not to install and operate an inverter which is damaged or parts of which are missing. Otherwise, there is a danger of injury.		p. 4-1
Be sure to install it in a room which is not exposed to direct sunlight and is well ventilated. Avoid environments which tend to be high in temperature, high in humidity or to have dew condensation, as well as places with dust, corrosive gas, explosive gas, inflammable gas, grinding-fluid mist, salt damage, etc. Otherwise, there is a danger of fire.		p. 4-1
Be sure that the wall surface is a nonflammable material, such as steel plate.	•••••	p. 4-2

2. Wiring

⚠️ "Use 60/75°C Cu wire only" or equivalent.	p. 5-1
. "Open Type Equipment".	p. 5-1
\triangle "AClass 2 circuit wired wiht Class 1 wire" or equivalent.	p. 5-1
\triangle "Suitable for use on a circuit capable of delivering not more	p. 5-1
than 5,000 rms symmetrical amperes, 240V maximum".	
For HF3202- * * * -W models.	
\triangle "Suitable for use on a circuit capable of delivering not more than	p. 5-1
5,000 rms symmetrical amperes, 480V maximum"	
For HF3204- * * * -W models.	
\triangle Be sure to ground the unit.	p. 5-1
Ohterwise, there is a danger of clectric shock and/or fire.	
\triangle Wiring work shall be carried out by electrical experts.	p. 5-1
Otherwise, there is a danger of electric shock and/or fire.	
\triangle Implement wiring after checking that the power supply is off.	p. 5-1
It might incur electric shock and/or fire.	
\triangle After installing the main body, carry out wiring.	p. 5-1
Otherwise, there is a danger of electric shock and/or injury.	



3. Control and operation

Be sure to turn on the input power supply after closing the front case. While being energized, be sure not to open the front case. Otherwise, there is a danger of electric shock.	p. 6-1
Be sure not to operate the switches with wet hands. Otherwise, there is a danger of electric shock.	p. 6-1
 While the inverter is energized, be sure not to touch the inverter terminals even during stoppage. Otherwise, there is a danger of electric shock. 	p. 6-1
▲ If the retry mode is selected, it may suddenly restart during the trip stop. Be sure not to approach the machine. (Be sure to design the machine so that personnel safety will be secured even if it restarts.) Otherwise, there is a danger of injury.	p. 8-11
 Even if the power supply is cut for a short period of time, it may restart operation after the power supply is recovered if the operation command is given. If it may incur danger to personnel, be sure to make a circuit so that it will not restart after power recovery. Otherwise, there is a danger of injury. 	p. 6-1
The Stop Key is effective only when the function is set. Be sure to prepare the Key separately from the emergency stop. Otherwise, there is a danger of injury.	p. 6-1
After the operation command is given, if the alarm reset is conducted, it will restart suddenly. Be sure to set the alarm reset after checking the operation command is off. Otherwise, there is a danger of injury.	р. 6-1 р. 7-12
Be sure not to touch the inside of the energized inverter or to put a bar into it. Otherwise, there is a danger of electric shock and/or fire.	p. 6-1
When the power is turned on when the running command is on, the motor starts rotation and it is dangerous. Before turning the power on, confirm that the running command is not on.	р. 7-4
 When the Stop key function is ineffective, pressing the Stop key does not cancel the stop and trip. Be sure to provide an emergency stop switch separately. When the operation command destination is a digital operator, this selection is ineffective. 	p. 8-12


Be sure not to touch them.	 p. 6-2
 Otherwise, there is a danger of getting burned. Low to high speed operation of the inverter can be easily set. Be sure to operate it after checking the tolerance of the motor and machine. Otherwise, there is a danger of injury. 	 p. 6-2
value(50Hz/60Hz), be sure to check the speeds of the motor and the machine with each manufacturer, and after getting their consent, operate them.	 p. 6-2
 Otherwise, there is a danger of machine breakage. A Check the following before and during the test run. Otherwise, there is a danger of machine breakage. Was the short-cut bar between P1 and P(+) removed? Was the direction of the motor correct? Was the inverter tripped during acceleration or deceleration? 	 p. 6-4
Were the rpm and frequency meter correct?Were there any abnormal motor vibrations or noise?	


4. Maintenance, inspection and part replacement


After a lapse of more than 5 minutes after turning off the input power supply, perform the maintenance and inspection. Otherwise, there is a danger of electric shock.	p. 11-1
Make sure that only qualified persons will perform maintenance, inspection and part replacement. (Before starting the work, remove metallic objects from your person (wristwatch, bracelet, etc.) (Be sure to use tools protected with insulation.) Otherwise, there is a danger of electric shock and/or injury.	p. 11-1

When removing connectors, never pull the wires. (Wires for cooling p. 11-1 fan and logic P.C.board) Otherwise, there is a danger of fire due to wire breakage and/or injury.			

5. Others








In all the illustrations in this manual, covers and safety devices are occasionally removed to describe the details. When the product is operated, make sure that the covers and safety devices are placed as they were specified originally and operate it according to the instruction manual.

2. INSPECTION UPON UNPACKING


Before installation and wiring, be sure to check the following:

- Make sure that there was no damage during transportation the unit.
- After unpacking the unit, make sure that the package contains one inverter and one operation manual
- Make sure that the product is the one you ordered by checking the specifications label on the side of the unit.



Contents of Specifications Label

If you discover any problems, contact your sales agent immediately.




3. APPEARANCE AND NAMES OF PARTS


3.1 Mechanical guidance and parts name

Switch cover ,Front case and Rear cover of the inverter Screw Front case Case Cooling fin Cooling fin

Key cover can be opened by hand without any tool.

And the signal wires can be connected to the control circuit terminals Also the function keys are available.






4. INSTALLATION

Be sure to install the unit on flame resistant material such as metal. Otherwise, there is a danger of fire.			
Be sure not to place anything inflammable in the vicinity. Otherwise, there is a danger of fire.			
Be sure not to let the foreign matter enter such as cut wire refuse, spatter from welding, iron refuse, wire, dust, etc. Otherwise, there is a danger of fire.			
Be sure to install it in a place which can bear the weight according to the specifications in the text (4. Installation). Otherwise, it may fall and there is a danger of injury.			
Be sure to install the unit on a perpendicular wall which is not subject to vibration. Otherwise, it may fall and there is a danger of injury.			
Be sure to install the unit with opening the front case and tighten the mounting screw bolt. Otherwise, it may fall and there is a danger of injury.			
 Be sure not to install and operate an inverter which is damaged or parts of which are missing. Otherwise, there is a danger of injury. 			
 Be sure to install it in a room which is not exposed to direct sunlight and is well ventilated. Avoid environments which tend to be high in temperature, high in humidity or to have dew condensation, as well as places with dust, corrosive gas, explosive gas, inflammable gas, grinding-fluid mist, salt damage, etc. Otherwise, there is a danger of fire. 			


Inverter should be mounted vertically on no-flamable wall to prevent from over heating and fire. Make sure following clearance arround the inverter to keep cooling air flow.

Foreign object should not be dropped into the equipment especially conductive chips, which may cause not only mulfunction and damage but also electrical and fire hazard.



Cover all ventilation holes on the inverter during installation to prevent from any foreign objects dropped into the equipment.

Be sure to remove those covers before start operation .




Be sure to check the ambient temperature -10 to 40 $\,$. In case of 50 $\,$, set the carrier frequency 2.1kHz and derate output current80% or less.

Higher ambient temperature cause shorter equipment life.

If there are some hot equipment near the inverter, keep it away from inverter as far as possible. When the inverter is installed in a cubicle and/or a box, temperature around inverter should be kept as above rating. Consider ventilation and clearance around the inverter.

For safety reason, front cover should be closed and don't open it during operation. For safety requirement, the end application must be in accordance with BS EN60204-1.


5. WIRING



 Make sure that the input voltage is: Single/Three phase 200 to 240V 50/60Hz (Up to 2.2kW) Three phase 200 to 240V 50/60Hz (Abore 2.2kW) Three phase 380 to 460V 50/60 Hz 			
 Be sure not to connect AC power supply to the output terminals (U, V, W). Otherwise, there is a danger of injury and/or fire. INPUT OUTPUT 			
Note: (L1) (N) (T1) (T2) (T3) L1 L2 L3 U V W Note: L1,N : Single phase 200 to 240V 50/60Hz L1,L2,L3: Three phase 200 to 240V 50/60Hz Three phase 380 to 460V 50/60Hz Power supply			
 Fasten the screws with the specified fastening torque. Check so that there is no loosening of screws. Otherwise, there is a danger of fire. 			
<u>Nemarks for using earth leakage circuit breakers in the mains supply:</u> Frequency inverters with CE-filters(RFI-filter) and screened motor cables have a higher leakage current against earth. Especially in the moment of switching on this can cause unintentional triggerings of earth leakage circuit breakers. Because of the rectifier on the input side of the inverter there is the possibility to stall the switch-off function through amounts of DC-current. The following should be observed:			
Only short time-invariant and pulse current-sensitive earth leakage circuit breakers with higher trigger current should be used. Other components should be secured with separate earth leakage circuit breakers. Earth leakage circuit breakers in front of an inverter are not an absolute protection			
against direct touching. A Be sure to set the fuse(s) (the same phase as the main power supply) in the operation circuit. Otherwise, there is a danger of fire.			
As for motor leads, earth leakage breakers and electromagnetic contactors, be sure to use the equivalent ones with the specified capacity (rated). Otherwise, there is a danger of fire.			
 Double pole disconnection device must be fitted to the incoming mains supply close to the inverter. And protection device meeting IEC947-1/IEC947-3 must be fitted at this point. 			
Connection to wiring terminal must be reliabily fixed with two means of support.			

5.1 Wiring the power supply and motor


Main circuit terminals and alarm terminals will be exposed after front case open Refer page 3-1 APPEARANCE AND NAME OF PARTS.




- Don't connect power source to any terminals except L1, L2, L3/N
- Don't connect any wires to no-assigned terminals on upper side. Those terminals are used for internal circuit.
- Refer to page 5-10 Terminal dimensions.
- When pallarel motor operation is required, put thermal relays for each motor.
- Make sure power source type and terminals as below

AC power type	Applicable terminals
Single Phase, 50/60Hz	Terminal L1, L3/N
Three Phase , 50/60Hz	Terminal L1, L2, L3/N


• Don't remove short bar between (P1) and P(+) terminals.



Control circuit terminals




Control circuit terminal diagram (For example)




NOTE: See page 5-11 for changing function.

NOTE 1: When changing the power supply of the motor between the inverter and commercial power, be sure to install mechanically interlocked switches Mg1 and Mg2.




- **NOTE 2:** Install an earth leakage breaker at the input of the inverter. (Select an earth leakage breaker whose sensitive current level is raised in high frequency range.) When the cable between the inverter and motor is more than 10 m long, the thermal relay may malfunction due to high-frequency waves. To prevent this, install an AC reactor on the output side of the inverter or use a current sensor rather than a thermal relay.
- **NOTE 3:** Be sure that the specified grounding is carried out. Be sure to separate the unit's grounding pole from those of other heavy electric machinery, and avoid using common grounding poles.

If multiple inverters are used, make sure that the grounding connections do not create a loop.




NOTE 4: When a frequency arrival signal is used, be sure to install a surge absorbing diode in parallel with the relay. Otherwise, the surge voltage created when the relay goes ON or OFF may damage the output circuit.

NOTE 5: Use a twisted and shielded wire for the signal line, and cut the shielded covering as shown in the diagram below. Make sure that the length of the signal line is 20 meters or less. If the line must be longer than 20 meters, please use a remote control device or a insulated signal converter.




- **NOTE 6:** When the frequency setting signal is turned on and off with a contact, use a relay which will not cause contact malfunctions, even with the extremely weak currents and voltages, such as crossbar twin contacts, etc.
- **NOTE 7:** Use relays which do not have contact defects at 24 V DC, 3 mA for the other terminals.
- **NOTE 8:** Separate the main circuit wiring from the relay control circuit wiring. If they must cross, be sure that they cross at a right angle.



- **NOTE9:** Do not short circuit the terminals P24 and COM, +V, IRF, FRQ by mistake. Inverter may be damaged.
- **NOTE10:** Do not short-circuit the terminals +V and COM. The control power supply may cause a failure.

Connection to the Programmable Controller

(1) When the internal interface power source is used



NOTE 1: Do not short circuit the terminals P24 and COM by mistake. The control power supply may cause a failure.

5.2 Wiring Equipment, Options

CAUTION: Provide the wiring equipment in accordance with the safety codes required by jurisdictional authorities.

Motor Wiring Applicable equipment Inverter output Power model Fuse (class J) Signal (kW) lines lines rated 600V 10A 0.2 HF3202-A20-W (*) 0.14 AWG16/1.3mm² to 0.75 10A 0.4 HF3202-A40-W mm^2 Shielded wire 15A 0.75 HF3202-A75-W AWG14/2.1mm² 20A (single ph.) 1.5 HF3202-1A5-W AWG12/3.3mm² 15A (three ph.) 30A (single ph.) 2.2 HF3202-2A2-W AWG10/5.3mm² 20A (three ph.) 3.7 HF3202-3A7-W AWG12/3.3mm² 30A HF3204-A40-W 3A 0.4 HF3204-A75-W 6A 0.75 AWG16/1.3mm² HF3204-1A5-W 1.5 10A 2.2 10A HF3204-2A2-W 15A 4.0 HF3204-4A0-W AWG14/2.1mm²

If specified in the standard or laws and regulations, follow their instructions.

NOTE 1: Field wiring connection must be made by a UL Listed and CSA Certified closed-loop terminal connector sized for the wire gauge involeved.

Connector must be fixed using the crimp tool specified by the connector manufacturer.

- **NOTE 2:** Be sure to consider the capacity of the circuit breaker to be used.
- **NOTE 3:** Be sure to use bigger wires for power lines if the distance


exceeds 20 m.

NOTE 4: Install an earth leakage breaker meeting requirements of IEC947-1/IEC947-3 at the input.

(*) Use 0.75 mm² wire for the alarm signal wire.

Wire stripping length : 5 to 6 mm.

Max wire sleeve diameter except for the alarm signal wire 2 mm².



NOTE 1: EMI filter is required for EMC directive(Europe), but others are not for this purpose.


Reactor and others of the above table except EMI filter are for noise reduction.

5.3 Terminal


(1) Terminal dimensions

Main circuit terminal

Main Circuit Terminal(HF3202-A75 ~ 3A7-W HF3204-A40 ~ 4A0-W)




Ground Terminal



Control circuit terminal


(2) Main circuit terminal function




Alarm Circuit Terminal

AL0	AL1	AL2

Main Circuit Terminal(HF3202-A20 ~ A40-W)





Main circuit terminal

Note:Value inside () : HF3202-A20 ~ A40-W

	Screw diameter	Width (mm)
Main circuit	M4(M3.5)	9 (7.1)
Control circuit	M2	
Alarm circuit	M3	
Grounding	M4	

Terminal symbol	Terminal description	Function	
L1,L2,L3 (L1),(N)	Main power	Connect the power supply L1,L2,L3Three phase L1,NSingle phase	(L1) (N) (T1)(T2)(T3)
U,V,W T1,T2,T3	Inverter output	Connect the motor	$\begin{array}{c c c c c c c c c c c c c c c c c c c $
P1,P(+)	External DC Reactor	Usually the short-cut bar is attached between terminals P1 and P(+).When the DC Reactor is to be connected, be sure to remove the short-cut bar.	γ
P(+),PR	External Regenerative Resistor	Connect a regenerative resistor (opshion) (when braking torque is required)	Make sure that the short-cut bar attached
	Ground	Ground (connect grounding to avoid electric shock)	between P1 and P(+) is not removed except when the DC reactor is to be mounted .

Tightening torque

Screw	Tightening torque	
M2	0.2 N•m (max. 0.25 N•m)	
M3	0.5 N•m (max. 0.6 N•m)	
M3.5	0.8 N•m (max. 0.9 N•m)	
M4	1.2 N•m (max. 1.3 N•m)	

(3)Control circuit

	Terminal symbol	Terminal description and function	Initial setting	Remarks
	RST	Intelligent input terminals	Reset input (Note 2)	Dry contact
	AD2	Forward running Reverse running External trip command command	2 stage acc/dec	- Close: ON (run) Open: OFF (stop)
	USP	Multistage speed Jogging USP function	USP	Min. ON time:
	AUT	(First stage) (Note 1) Multistage speed Analog input Reset	Analog input	12 ms or more
Input	RR	(Second stage) command (Note 2)	Reverse running command	
signal	FR	Multistage speed 2 stage acc./dec. Terminal (Third stage) time software lock	Forward running command	-
		Multistage speed Free run stop B mode (Forth stage) Freq. Up/Down PTC (Note 3)		
		External DC damping		
	P24	Common for input signals		24 VDC max.30mA
Monitor signal	FRQ	Analog frequency monitor/Digital frequency monitor/Analog output current monitor	Analog frequency monitor	
	СОМ	Common for monitor		
Frequency command	+V	Power supply for frequency command		10 VDC max.10mA
input	VRF	Voltage frequency command		0-10 VDC (nominal) (Input impedance 10 kΩ)
	IRF	Current frequency command		DC 4-20 mA (nominal) Input impedance 250 Ω
	СОМ	Common for frequency command		
Output signal	UPF	Intelligent output terminal Arrival signal at constant speed, Arrival signal at set speed,	Arrival signal at constant speed	27 VDC 50 mA max
	DRV (Note 2)	RUN signal,Current detection signal Deviation signal at PID control, Alarm signal	Run signal	_
	ОМ	Common for output signals		
Fault alarm output (Note 4)	AL0 AL1 AL2		ntact rating VAC 2.5 A (Resistor lo 0.2 A (cos =0.4 VDC 3.0 A (Resistor lo	.) 10 mA (bad) 5 VDC
		Abnormal, Power off : AL0-AL1 open (Initial setting)	$0.7 \text{ A} (\cos = 0.4)$.) (100 mA)

NOTE 1: USP: Prevention function of restart upon power on.

NOTE 2: The reset terminal and terminal DRV can not be changed from "a contact" (NO) to "b contact" (NC).

NOTE 3: See page 7-14.

NOTE 4: This terminal serves both as fault alarm output and intelligent output.

6. OPERATION

6.1 Before Starting Operation

Prior to the test run, check the following.

	Be sure to turn on the input power supply after closing the front case. While being energized, be sure not to open the front case. Otherwise, there is a danger of electric shock.
	Be sure not to operate the switches with wet hands. Otherwise, there is a danger of electric shock.
	While the inverter is energized, be sure not to touch the inverter terminals even during stoppage. Otherwise, there is a danger of electric shock.
	If the retry mode is selected, it may suddenly restart during the trip stop. Be sure not to approach the machine. (Be sure to design the machine so that personnel safety will be secured even if it restarts.) Otherwise, there is a danger of injury.
	Even if the power supply is cut for a short period of time, it may restart operation after the power supply is recovered if the operation command is given. If it may incur danger to personnel, be sure to make a circuit so that it will not restart after power recovery.
\triangle	Otherwise, there is a danger of injury. The Stop Key is effective only when the function is set. Be sure to prepare the Key
Â	separately from the emergency stop. Otherwise, there is a danger of injury.
∠!∖	After the operation command is given, if the alarm reset is conducted, it will restart suddenly. Be sure to set the alarm reset after checking the operation command is off. Otherwise, there is a danger of injury.
	Be sure not to touch the inside of the energized inverter or to put a bar into it. Otherwise, there is a danger of electric shock and/or fire.

	Cooling fin will have high temperature. Be sure not to touch them. Otherwise, there is a danger of getting burned.					
af	Low to high speed operation of the inverter can be easily set. Be sure to operate it after checking the tolerance of the motor and machine. Otherwise, there is a danger of injury.					
be an	⚠️ If a motor is operated at a frequency higher than standard setting value(50Hz/60Hz), be sure to check the speeds of the motor and the machine with each manufacturer, and after getting their consent, operate them. Otherwise, there is a danger of machine breakage.					
Note:						
(1)	Make sure that the power lines (input power supply $L1(L1)$, L2 and L3(N), and output terminals, U(T1), V(T2) and W(T3) are connected correctly.					
(2)	Make sure that there are no mistakes in the signal line connections.					
(3)	Make sure that the ground terminal $(\textcircled{=})$ is grounded.					

(4) Make sure that terminals other than those specified are not grounded.

- (5) Make sure that the inverter is installed vertically on a wall, and a nonflammable material such as a steel plate is used as a mounting surface.
- (6) Make sure that there are no short-circuits caused by stray pieces of wire, solderless terminals or other objects left from wiring work. Also, make sure that no tools have been left behind.
- (7) Make sure that the output wires are not short-circuited or grounded.
- (8) Make sure that there are no loose screws or terminals.
- (9) Make sure that the maximum frequency setting matches the machine specifications.
- (10) With the front case opened, do not operate the inverter. Make sure that the front case is completely closed and locked with the screw before operating the inverter.


Never test withstand voltage tests. Because this inverter has the surge absorber between the main circuit terminal and the ground.

6.2 Test Run

An example of a general connection diagram is shown below.

Operating with digital operator:

To set frequency, run and stop is used by digital operator. Frequency setting: Potentiometer on the digital operator Run and stop: key pad on the digital operator



Procedure(Operating with digital operator)

- (1) Turn on supply power to the inverter. Make sure that the **POWER** LED on the digital operator goes ON.
- (2) Set \overrightarrow{A} 02 to $\overrightarrow{02}$.
- (3) Set A 01 to 00.
- (4) Check to turn on the lamp above the potentiometer and turn the potentiometer.
- (5) Start running after pressing (once and turn on the RUN lamp.
- (6) Check output frequency by monitor mode d 01.
- (7) Press $(\text{STOP}_{\text{RESET}})$ and decelerate to a stop.

Check the following after the test run is complete. Otherwise, there is a danger of machine breakage.

- Was the direction of the motor correct?
- Was the inverter tripped during acceleration or deceleration?
- Were the frequency meter correct?
- Were there any abnormal motor vibrations or noise?

When overcurrent tripping or overvoltage tripping occurs during the test run, increase the acceleration time or deceleration time.

Factory settings

Maximum frequency: 60 Hz Forward operation

7. FUNCTION OF CONTROL CIRCUIT TERMINAL

7.1 List of Control Circuit Terminals

	rminal nbol	Function		Contents
Intelligent input terminals FR, RR, AUT, USP, AD2, RST	00	Forward run/stop		SWF Contact (close): SWR SWF Output frequency Forward run (open): Stop RR FR F24
	01	Reverse run/stop		SWR Contact (close): SWP ON + OFF + OFF Reverse run (open): Stop Both contacts SWF and SWR are close-stop.
	02	Multistage speed	1	Frequency (Hz) 0th Speed Third 1 Terminal F R : 00 Terminal R R : 01 Terminal R R : 01
	03		2	speed Second First speed speed speed +v VRF IRF COM
	04	Multis	3	Switch Time AUT ON ON USP ON ON FR ON
	05		4	FR ON RR
	06	Jogging		Jogging run
	07	External DC braking		When the terminal [DB] is turned on the DC braking operation can be performed.
	19	PTC thermistor Thermal protection		When thermistor is connected with this terminal, the thermal protection can be used. The common is terminal COM. NOTE: Refer to p.7-14 about details.
	16	Analog current input sellection		Analog input voltage-current swiching(When this terminal is ON, current input signal to IRF-COM is active.)
	09	2 stage acceleration and deceleration		When the assigned terminal is turned on, the acceleration and deceleration can be executed by the 2nd stage acceleration and deceleration time.
ntellige	11	Free run stop		When the assigned terminal is turned on, the inverter stops output and the motor enters the free run state.
Ι	12	External trip		When the assigned terminal is turned on, the inverter enters the trip state, stops output, and displays E12.
	13	Power reclos- ing restart prevention		When the assigned terminal is turned on, the restart when the power is turned on with the running command kept on can be prevented.
	18	Reset		When the assigned terminal is turned on, the trip state can be canceled. During turning on,the output is stopped. NOTE: The function cannot be used in the N.C. contact state.
	08	B made		When the terminal[BMD] is turned on, the set frequency, torque boost, acceleration and deceleration time, second acceleration and deceleration time, and control system can be changed in a hatch.
-	27	Remote control function acceleration		When the contackt is turned on the, operation decelerated. (Available only when the frequency command is sent to the operator.)
	28	Remote function decelera	ı	When the contackt is turned on the, operation decelerated. (Available only when the frequency command is sent to the operator.)
	15	Software lock		When the assigned terminal is turned on, the data of each function is locked.
I	224	24VDC common for input		Common terminal for the intelligent input terminals

Terminal symbol		Function	Contents			
9	+V	Power supply terminal to command a frequency	¥ The external voltage signal is 0 to 9.6 V (10 V nominal).			
Frequency command	VRF	Frequency command terminal (voltage command)	$\begin{array}{c} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\$	$\begin{array}{c c} VRF & IRF & COM \\ \hline \\ \oplus & \bigcirc \\ 4 \text{ to } 19.6 \text{ mA DC} \\ \hline \\ \end{array}$		
	IRF	Frequency command terminal (current command)	$\begin{array}{c} (1k\ \Omega\ to\ 2\ k\Omega) & 0\ to\ 9.6\ VDC\ (nominal\ 10\ V)\\ Input\ impedance\ 10\ k\Omega \end{array}$ NOTE: If there is no setting for analog current input at the input integration sum of both analog input signals is outputted. When selecting the selection of the select			
	СОМ	Frequency command common	input current or voltage, make sure that the analog current ir the input intelligent terminal.	put is allocated to		
Monitor terminal	FRQ	Frequency monitor	¥ Analog frequency monitor/Digital frequency monitor/Analog output current monitor			
minal UPF, DRV (Note)	01 02	Frequency arrival signal 01 : FA1 02 : FA2	 When 01/02 is set for a terminal, at the time of constant speed arrival, two types of methods for outputting a frequency more than an optionally set frequency can be executed. Frequency Freq	Output terminal specification Open collector output 27 V DC max 50 mA max		
tput te	00 DRV	RUN signal	¥ When 00 is set for a terminal, the inverter outputs when the motor is driven.			
Intelligent output ter	03	Overload signal	¥ This signal is outputted when the motor current is more than the set value.			
Intell	04	Deviation signal at PID control	¥ This signal is outputted when the difference between reference and feed-back is greater than the set value at PID control.			
	05	Alarm signal	¥ When an alarm occurs, this signal is outputted.			
	ОМ	Output Signal Common terminal	 ¥ Common terminal for intelligent output terminal (Output terminals are open collector output and isolated from L common) 			
	ALO AL1	Alarm terminal Contact rating 250 V AC 2.5 A (resistance load) 0.2 A (cos		en AL0 and AL2 are		
	AL2		$\begin{bmatrix} 30 \text{ V DC} & 3.0 \text{ A (resistance load)} & 0.7 \text{ A (cos} = 0.4) \\ \begin{bmatrix} \text{Minimum} \\ 100 \text{ V AC} & 10 \text{ mA} & 5 \text{ V DC } 100 \text{ mA} \end{bmatrix}$			

NOTE: "N.O. contact" is set by initialization for terminal UPF, DRV. About terminal UPF, when "N.C. contact" is to be used, switch the contact setting by [[]].

C 23, b 81 Terminal name: Monitor terminal [FRQ] Function No. b 86 (Analog, digital) to be set Function contents Setting contents Monitor output frequency signal or the 1. Select Frequency Monitor(Analog/Digital) current of the inverter is output from the or Current Monitor by C 23. control circuit terminal. Monitor output current signal is output as an 2. When the analog meter is used, adjust the analog signal only. meter so that the needle of the meter indicates the maximum value at the time of (1) Analog Frequency Monitor Signal maximum frequency by b 81 (analog The meter outputs duty cycle in propormeter adjustment). tion to the output frequency with full scale at the maximum frequency. 3. In the case of digital frequency monitor, AD2 USP AUT 10V **NOTE:** The converted value of digital COM FRQ ОМ frequency monitor is limited to about : Changeable 3.6 kHz. (\oplus) 0 to 10V T = 4 ms (constant) Accuracy of output current monitor 1mA **NOTE:** This is a dedicated indicator, so that it cannot be used as a line speed The output display accuracy is about $\pm 10\%$ signal. Inverter output current : Im Monitor display current : Imc Indication accuracy after adjust-Reted current of the inverter : Ir ment: About $\pm 5\%$ (The accuracy of some meters may exceed this $\frac{\text{Imc - Im}}{\text{Ir}} \times 100 \le \pm 10\%$ value.) (2) Digital Frequency Monitor Signal The indication value may exceed this Pulse train of a frequency which is accuracy by the load current condition. converted the output frequency is output. Use the moving tron type ammeter for the (The convert value is setting by $|\mathbf{b}| | | \mathbf{86} |$.) precise current measurement. The duty is about 50%. \$10V AD2 USP AUT P24 Circuit for FM signal monitor for process COM FRQ control (just only monitor) Output frequency 821 FRQ (3) Analog Current Monitor Signal ΊμF 33k The duty cycle in proportion to the output CON current with full scale at 200% of the rated current of the inverter. Specification of analog meter follows the analog frequency monitor specifications.

7.2 Function Contents of Monitor Terminal

7.3 Function Contents of Intelligent Input Terminals

Terminal name: Forward running/stop	Function No.C 01 to C 06to be setA 02
Function content	
• When the running command is inputted via the assigned terminal, the terminal executes the forward running command or stop command.	When the power is turned on when the running command is on, the motor starts rotation and it is dangerous. Before turning the power on, confirm that the running command is not on.
Terminal setting method Digital operator Set the set value 00 in one of the input terminals C 01 to C 06.	 Precautions When the running command is inputted via the forward running terminal and reverse running terminal at the same time, the running command enters a state which is the same as stop. Note that when the forward running terminal is set to "N.C. contact", the running automatically starts. Set the value 01 to the A 02, then this terminal is available.
Terminal name: Reverse running/stop	Function No. C01 to C06 to be set A02
Terminal name: Reverse running/stop Function content	
	to be set <u>A 02</u>
 Function content When the running command is inputted via the assigned terminal, the terminal executes the reverse running command or 	to be set A 102 WARNING When the power is turned on when the running command is on, the motor starts rotation and it is dangerous. Before turning the power on, confirm that the

Terminal name: Multistage speed

Function content

- When [Multispeed 1, 2, 3 and 4] are selected as intelligent input terminals, Multispeed 1 to Multispeed 15 can be set. When the frequency command from the normal operator (or terminal) is combined with them, up to 16 stages of running are available.
- When the control terminal is set at each speed by the switch, the numerical value displayed at <u>d 01</u> indicates the output frequency at the time of each multispeed. Set the speed as shown below.
- (1) Turn the running command off.
- (2) Turn each switch on and set it toMultispeed n. Display the data section ofF 01
- (3) Set an optional output frequency by pressing the () and () keys.
- (4) Press the (stop) key once so as to store the set frequency. If this occurs, F 01 indicates the output frequency of Multispeed n.
- (5) Press the *wind* key once. (Confirm that the indication is the same as the set frequency.)
- (6) When the operations in (1) to (4) are repeated, the frequency of Multispeed n can be set. It can be set also by one of $\boxed{A \ 20}$ to $\boxed{A \ 35}$.


Terminal setting method

-Digital operator –

Set the set values $\boxed{02}$ to $\boxed{05}$ in the input terminals \boxed{C} $\boxed{01}$ to \boxed{C} $\boxed{06}$.

Function No. C 01 to C 06 F 01 to be set A 20 to A 35

Example of the input terminal connection



Setting of multispeed


Multispeed	Control circuit terminal			
	SW4 SW3		SW2	SW1
Multispeed 0	OFF	OFF	OFF	OFF
Multispeed 1	OFF	OFF	OFF	ON
Multispeed 2	OFF	OFF	ON	OFF
Multispeed 3	OFF	OFF	ON	ON
Multispeed 4	OFF	ON	OFF	OFF
Multispeed 5	OFF	ON	OFF	ON
Multispeed 6	OFF	ON	ON	OFF
Multispeed 7	OFF	ON	ON	ON
Multispeed 8	ON	OFF	OFF	OFF
Multispeed 9	ON	OFF	OFF	ON
Multispeed 10	ON	OFF	ON	OFF
Multispeed 11	ON	OFF	ON	ON
Multispeed 12	ON	ON	OFF	OFF
Multispeed 13	ON	ON	OFF	ON
Multispeed 14	ON	ON	ON	OFF
Multispeed 15	ON	ON	ON	ON

Precautions

• After any data is changed, be sure to press the $(\text{STOP}_{\text{RESET}})$ key every time and then set the

next one. Note that when the $(STOP)_{RESET}$ key is not pressed, no data will be set.

 When a frequency more than 60Hz is to be set, it is necessary to switch the maximum frequency <u>A 04</u>.



Terminal name: Analog input command	Function No. C 01 to C 06 to be set A 01
 Function content When the assigned terminal is turned on, it is possible to set the output frequency by current input signal (DC4~20mA) at IRF-COM. 	Terminal setting method Digital operator Set the set value 16 in one of the input terminals C 01 to C 06. Precautions
Function switching methodWhile the switch between the assigned terminals and P24 is on, it is possible to set the output frequency by the current input signal 	 If there is no setting for analog input switching at the input intelligent terminal, the sum of both analog input value is outputted. When selecting one of analog input value (current or voltage), make sure that the analog input switching is allocated to the input intelligent terminal. Be sure to set the value 101 to A 01.


Terminal name: Second stage acceleration and deceleration

Function content

• When the assigned terminal is turned on, the equipment can be accelerated or decelerated (acceleration time 2, deceleration time 2) by the 2 stage acceleration and deceleration time.

Function switching method

- While the switch between the assigned terminal and P24 is on, the equipment operates by the 2 stage acceleration and deceleration time (acceleration time 2, deceleration time 2).
- When the terminal is turned off, the equipment is returned to the original acceleration and deceleration time (acceleration time 1, deceleration time 1).



Function No. C 01 to C 06, to be set A 92, A 93, A 94

2 stage acceleration and deceleration time setting method


Use A 92 (acceleration time 2) and A 93 (deceleration time 2) to set the 2 stage acceleration and deceleration time (acceleration time 2, deceleration time 2).

Between assigned terminals and P24	Acceleration and deceleration time for operation
OFF state	Acceleration time 1, Deceleration time 1
ON state	Acceleration time 2, Deceleration time 2

Precautions

Running	 	
2-stage acc./d	ec.	
Output frequency —		


Setting A 94 to 00 enable to switch by this terminal.




Terminal name: External trip	Function No. C 01 to C 06 to be set
Function content	Function switching method
• When the assigned terminal is turned on, the inverter enters the trip state by an indication of E 12 and stops output.	When the switch between the set terminal and P24 is turned on, the equipment enters the trip state. Even when the switch is turned off, the trip
Terminal setting method Digital operator	state will not be canceled. Reset the equip- ment or turn the power off and on again to cancel the trip state.
Set the set value 12 in one of the input terminals C 01 to C 06.	$\begin{array}{c cccc} COM RST & AD2 USP & AUT & RR & FR & P24 \\ \hline CO1 = 00 & & & & \\ CO3 = 12 & & & & & \\ \end{array}$
Running command [FR,RR]	
External trip assigned terminal	/ Free run
Motor revolution speed	
Reset assigned	
Alarm output terminal	


Terminal name: Prevention function of re upon power on [USP fur	
 Function content If the running command is set when power is turned on, the inverter starts running immediately after it is activated. The USP function prevents it so that the inverter will not execute sudden running. To reset an alarm and restart running, turn the running command off or perform a reset operation by the ^r Reset _J terminal or the (STOP) key. Refer to the time chart indicated below. 	Function switching methodWhile the switch between the set terminal and P24 is on, the equipment executes the USP operation. If the power is turned on when the running command is inputted, the equipment
Terminal setting method Digital operator Set the value 13 in one of the input terminals C 01 to C 06.	 Note that when a USP error occurs and it is canceled by resetting in the state that the running command from the terminal is inputted, the inverter restarts running immediately. Even when the trip state is canceled by turning the ^r Reset j terminal on and off after an under voltage protection (E 9) occurs, this function will be performed. When the running command is inputted immediately after the power is turned on, a USP error will be caused. When this function is used, input the running command after three (3) seconds since the power is turned on.
Inverter power supply Running command [USP] terminal [USP] terminal Alarm output Inverter output frequency Alarm display E 13 Canceling Canceling	g of Running start g of alarm

Terminal name: Reset	Function No. [C 01]to [C 06] to be set
Function content	
• The trip content can be canceled.	After the operation command is given, if the alarm reset is conducted, it will restart suddenly. Be sure to set the alarm reset after checking that the operation command is off. Otherwise, there is a danger of injury.
Terminal setting method Digital operator Set the set value 18 in one of the input terminals C 01 to C 06. Function switching method • When the switch between the assigned terminals and [COM] is turned on and off, the equipment executes the reset operation. COM RST AD2 USP AUT RR FR P24 C06=18	 Precautions When the RESET assigned terminal is turned off from on, it becomes valid. The (STOP) key of the digital operator is valid only when an alarm occurs. Only "N.O. contact" can be set to the RESET assigned terminal. The terminal cannot be used in the "N.C. contact" state. Even when the power is turned off or on, the function of the terminal is the same as that of the reset terminal. [RS] terminal Alarm output The (STOP) key on the inverter is available for a few second after reset signal coming with the remote operator connected. When the RESET assigned terminal is the same as that on while the motor is running ,the






Terminal name: Terminal software lock	Function No.C 01 to C 06to be setb 31
Function content	Function switching method
• When the assigned terminal is turned on, the data of all the functions except the output frequency is locked. When the data is locked, no data can be changed.	When the switch between the assigned terminal and P24 is turned on, the equipment enters the software lock state.
Terminal setting method	$\begin{array}{c} C01 = 00 \\ C03 = 15 \end{array} \qquad \bigcirc \qquad$
Digital operator	When terminal software lock is allocated to the terminal AUT
Set the set value 15 in one of the input terminals C 01 to C 06.	Precautions
	 When the assigned terminal is turned on, only the output frequency can be changed. Software lock can be made possible also for the output frequency by b 31. Software lock by the operator is also possible without the assigned terminal being used. (b 31)





Terminal name: B mode function	Function No. C 01 to C 06 (NOTE) to be set
Function content	Terminal setting method
 When the assigned terminal is turned on, it is possible to set two types of motor constants and execute running by one inverter. If select the second setting function, confirm the equipment is completely stopped. 	Digital operator Set the set value $\boxed{08}$ in one of the input terminals \boxed{C} 01 to \boxed{C} 06.
Function which can be set by the B mode function (NOTE) Refer to 7. 6 Explanation of B mode function.	
Function switching method	
While the switch between the assigned terminals and P24 is on, the equipment is operated by the setting of the B mode function. When the terminal is turned off, the setting is returned to the original setting (first function). If the terminal is turned off during the equipment is running, the equipment keeps the operation by the setting of the B mode function until it is stopped.	


(NOTE) Refer 7.6 Explanation of B mode function.





7.4 Function Contents of Intelligent Output Terminals (Initial setting is "N.O. contact" state)











Function Contents of Alarm Terminals 7.5

Terminal name: A [/	larm terminal AL1, AL2-AL0]		ction No. e set	C 33	3
Function content		Precautions			
 [AL0], [AL1], and [tact. If this occurs, t the alarm content. Terminal setting metho Digital operator "N.O. contact" or be selected by C The initialization 	nal from the terminals AL2] via the c con- the operator displays d	 <u>Holding of an alarm signal</u> When an alarm signal is outputted, the alarm content will be stored even if the input power is turned off. Therefore, by turning the power on again, the content can be confirmed. However, when the input power is turned off, the alarm output will be reset (canceled) when the power is turned on again. Therefore, to hold the alarm output, hold the alarm once by the external sequence. When the alarm contact output is set to N.C., a time delay occurs until the contact is closed when the power is turned on. Therefore, when the alarm contact output is to be used, set a delay of about 2 seconds when the power is turned on. 			
Contact specification					
A.C. 2503	Maximum			nimum	<u> </u>
	V, 2.5A (load R) 0.2A (om m, 3.0A (load R) 0.7A (V, 10 mA	
The alarm output termi	nals are connected as sh vn in Fig. (b) by setting	own in Fig. (a)	at the time	e of initial	J
(a)N.C. contact (at the ti	,	(b) N.O. contact During normal running When an alarm occurs			
During normal running	When an alarm occurs or power is turned off	or when power is		when an	alarm occurs
AL0 AL1 AL2	AL0 AL1 AL2	AL0 AL1 AL2		AL0	AL1 AL2
Contact Power Running state N.C. ON Normal (Initialized value) ON Trip	AL0-AL1 AL0-AL2 Closed Open Open Closed Open Closed	Contact Pow N.O. ON OF	Normal Trip	AL0-AL1 Open Closed Open	AL0-AL2 Closed Open Closed

Closed

Open

OFF

Closed

Open

OFF

7.6 Explanation of B mode function

Outline of the function

When it is necessary to set two types of motor constants and execute running by one inverter, this function is used to switch the type of motor constant.

It is possible to select the motor constant while the inverter is stop condition, by the intelligent input terminal [ON / OFF] which is allocated to B mode function.

If B mode function is allocated to the intelligent input terminal, the indication for B mode function is added to the display menu on the panel.

The indication of the menu No. for B mode is as follows.

[1st setting menu No.] + 200

ex) A20 - - A220

Function name	Parameter display
Multispeed frequency setting	A20/A220
Acceleration 1	F02/F202
Deceleration 1	F03/F203
Acceleration 2	A92/A292
Deceleration 2	A93/A293
Selection of method to use second acceleration decelaration	A94/A294
Changed frequency from acc1 to acc2 setting	A95/A295
Changed frequency from acc1 to acc2 setting	A96/A296
Level of electronic thermal setting	b12/b212
Selection of electronic thermal characteristic	b13/b213
Selection of method of torque boost	A41/A241
Value of manual torque boost setting	A42/A242
Manual torque boost frequency adjustment	A43/A243
V/F characteristic setting	A44/A244
Base frequency setting	A03/A203
Maximum frequency setting	A04/A204
Selection of the motor constant	H02/H202
Motor capacity setting	H03/H203
Motor poles setting	H04/H204
Motor constant R1 setting (Standard, Auto tuning)	H20/H30/H220/H230
Motor constant R2 setting (Standard, Auto tuning)	H21/H31/H221/H231
Motor constant L setting (Standard, Auto tuning)	H22/H32/H222/H232
Motor constant Io setting (Standard, Auto tuning)	H23/H33/H223/H233
Motor constant J setting (Standard, Auto tuning)	H24/H34/H224/H234
Motor constant Kp setting (Standard, Auto tuning)	H05/H205
Motor stabilization constant	H06/H206

7.7 Explanation of SLV (Sencer Less Vector) control

Function content

The SLV control realize the high starting torque and the high accuracy operation. The motor data for the SLV control can be set either the data of the standard motor or the data by autotuning.(see 7-25)

Under the B mode operation, it can be set either the above mentined too.

(NOTE) Under the SLV control, the inverter cannot put out the full performance to the motor which capacity is too smaller than that of the inverter.

Function setting method

SET 02 (SLV) to the A44 (A244). Set the data to the H02 (H202) according as the motor data. (Standard/Autotuning) Set the motor capacity to the H03(H203) Set the motor poles to the H04(H204)

Motor constant Kp setting : H05 Adjustment the response of the feedback control in the speed control system.

Motor stabilization constant : H06 Adjustment when the resonance phenomena of the motor is appeared.

7.8 Autotuning

Function content

This is a function for automatically setting the motor circuit constant necessary for the sensorless vector.

A Sumitomo general purpose motor is given a constant which is default value.

Therefore, in every case, the characteristics will be obtained without trouble.

When the characteristics cannot be obtained, measure the motor circuit constant by the autotuning function.

Function setting method

Set F02 (Acceleration 1) and F03 (Deceleration 1) Set the acceleration time and the deceleration time. It is better for the quick response to set the short time. Pay attention to the OC trip or OV trip.

Set H03 Set the motor capacity.

Set H04 (Motor poles setting) Set the count of the motor poles.

Set A01 Set 02 (Panel) to A01

Set A03 Set the base frequency. (Normally 60Hz)


Set A20 Set the output frequency, except 0Hz. When 0Hz is set, the autotuning function is not performed.

Set A82 Set the voltage which is given the motor.

Set A51 Set the 00 (not available), the DC braking function is available.

Set H01 Select the autotuning mode. Normally the set data is 01. If the motor cannot rotate, the set data is 02.

(NOTE) When autotuning start, the motor is accelerated up to 80% of base frequency.



After the measurement ends the motor is stopped

Indication at process end

Display in the normal state



Display in the failure state


Setting method

(1)Digital panel


No.	Function name	Range	Description
H01	Autotuning Mode setting	0, 1, 2	0: not available1: autotuning2: measure the resistance and the inductance
H02	Motor setting	0, 1	0: Standard motor data 1: Autotuning data
H03	Motor capacity setting	0.2/0.4/0.75/ 1.5/2.2/3.7	The unit is kW
H04	Motor poles setting	2/4/6/8	The unit is pole
H20/H30	Motor constant R1 setting	0.000- 65.535	The unit is ohm 0.000-0.999 1.00-9.99 10.0-65.5
H21/H31	Motor constant R2 setting	0.000- 65.535	The unit is ohm 0.000-0.999 1.00-9.99
H22/H32	Motor constant L setting	0.00- 655.35	The unit is mH 0.000-0.999 1.00-9.99 10.0-65.5
H23/H33	Motor constant Io setting	0.00- 655.35	The unit is Arms 0.000-0.999 1.00-9.99 10.0-65.5
H24/H34	Motor constant J setting	1.0 to 100.0	Set the ratio per the inertia of the separated motor, which has the same capacity as the inverter
H05	Motor constant Kp setting	0-99	Code
H06	Motor stabilization constant	0-255	Code, 0:OFF

The data (H30 to H34) are set by autotuning function.

8. OPERATION OF THE DIGITAL OPERATOR



8.2 **Operation Procedure (Example for the digital operator.)**




8.3 Key Description

FUNC.

[Function key] . . . This key allows the change from parameter area to data area and extended function entrance alternately.


When each time the key is pressed, the display changes as follows.



NOTE: After the data is changed, be sure to press the STR key.



[Up key, Down key] . . . These keys change the values of data, and parameters.






[RUN key] . . . This key starts the run. The set value of $\boxed{F \ \Box Y}$ determines forward run or reverse run.



[STOP/RESET key] . . . This key stops the run.

When a trip occurs, this key becomes the reset key.

Data setting for extended function



Explanation of display at power on

When the inverter is turned on, the display which is displayed when the power is turned off before it is turned on appears. (Except the extended function mode.)

Initialization List of Digital Operator 8.4

(1)Monitor mode, function modeThe initial value and settable range of each mode are displayed.(1, 1) Monitor mode.

(1-1) Mo	nitor mode					
Display order	Function name	Туре	Parameter display	Settable during running	Range of set value	Initializ- ation
1	Output frequency monitor	Monitor- ing	d01	-	Display from 0.5Hz to 360.0Hz. Light on Hz LED.	-
2	Output current monitor	Monitor- ing	d02	-	Display from 0.01 to 999.9A Light on A LED.	-
3	Running direction monitor	Monitor- ing	d03	-	FForwardStop rReverse	-
4	Feedback data of PID control monitor	Monitor- ing	d04	-	Display the converted feed back value scaled by A75.	-
5	Condition of input intelligent terminal monitor	Monitor- ing	d05	-	Display the condition of input intelligent terminal.	-
6	Condition of output intelligent terminal monitor	Monitor- ing	d06	-	Display the condition of output intelligent terminal and alarm. terminal No. AL DRV UPF	-
7	Output frequency converted value monitor	Monitor- ing	d07	-	Display the output frequency converted value scaled by b86. Display =(output frequency) *(b86 value) (1)0.01 ~ 99.99 <u>1 1.1 1</u> (11.11) (2)100.0 ~ 999.9 <u>1 1 1 1.1</u> (111.1) (3)1000 ~ 999.9 <u>1 1 1 1 1</u> (1111) (4)10000 ~ 99990 <u>1 1 1 1 1</u> (11110)	-

(NOTE) This indicator use the filter.(Time constant is 100ms)

Display order	Function name	Туре	Parameter display	Settable during running	Range of set value and contents	Initializ- ation
8	Trip monitor	Monitor- ing	d08	-	Display latest trip contents -Display order and operation Alarm cause press FUNC key Output frequency at trip press FUNC key Motor current at trip press FUNC key DC voltage at trip press FUNC key "d08" display -There is no latest trip	
9	Trip history monitor	Monitor- ing	d09	-	Display last 2times trip except latest trip. Displays only alarm cause "d09" display press FUNC key Cause of the last trip press FUNC key Cause of the last trip but one press FUNC key "d09" display If there is no trip,display	

(1-2)Basic function mode

This mode can be set the basic function

Display order	Function name	Туре	Parameter display	Settable during running	Range of set value and contents	Initializ- ation
1	Output frequency setting	Set value	F01		 0.5-360.0Hz / Resolution ± 0.1Hz (1)Digital Operator on the front case In this function, the output frequency can be set in the inverter by using the key pad. But it is necessary to set the frequency distination to the digital operator (A01 =02). (2)Multispeed The output frequency in the multispeed mode can be set as specified following; Connect the multispeed terminal for setting the frequency, that is to say, to set the frequency of each multispeed must be made the relation between multipeed 1 to 15 on the terminal. (3) Terminal, Potentiometer In setting the frequency from the terminal(VRF-COM, IRF-COM) or the potentiometer on the front case, data of this function is just monitored the frequency from each device. 	0.0Hz
2	Acceleration 1	Set value	F02	possible	0.1 second to 3000 seconds [Resolution of setting] 0.1 - 999.90.1 second 1000 - 30001 second	10 seconds
3	Deceleration 1	Set value	F03	possible	0.1 second to 3000 seconds [Resolution of setting] 0.1 - 999.90.1 second 1000 - 30001 second	10 seconds
4	Running direction setting	Set value	F04	Not possible	Set the motor direction Set the motor direction when running by pressing (RUN) key. 00forward run 01reverse run	00
5	Extended function of A group setting	Set value	A	possible	Extended function of A group can be entered from A function. A group regards control setting or function setting.	
6	Extended function of b group setting	Set value	b	_	Extended function of B group can be entered from b function. B group regards protection setting or others.	
7	Extended function of C group setting	Set value	C	possible	Extended function of C group can be entered from C function.C group regards intelligent terminal setting.	
8	Extended function of H group setting	Set value	H	Not possible	Extended function of H group can be entered from H function. H group regards intelligent terminal setting.	

(2)Extended function mode A group

Display order	Function name	Туре	Parameter display	Settable during running	Range of set value	Initializ- ation
Basic par	ameter setting		1	1	1	I
1	Frequency distination setting	Set value	A01	Not possible	Method to command output frequency is selected by this function. 00 Potentiometer on the front case 01 Control terminal on the logic board 02 Digital operator	01
2	Running command distination setting	Set value	A02	Not possible	Method to command running is selected by this function. 01 Control terminal on the logic board 02 Digital operator	01
3	Base frequency setting	Set value	A03	Not possible	50 to maximum frequency / Setting resolution 1Hz V 100% 0 Base Maximum f frequency frequency	60Hz
4	Maximum frequency setting	Set value	A04	Not possible	base frequency to 360Hz / Setting resolution 1Hz (NOTE 1)	60Hz
Analogue 5	e input setting External	Set	A11	хт :	0 to 260Hz (Sotting modelsting 0 1Hz	011
5	frequency setting start	value	AII	Not possible	0 to 360Hz /Setting resolution 0.1Hz This function set the start frequency when the inverter receives 0V or 4mA analog input Frequency A12 A11 0 A13 A14 10V 4 20mA Analog input	OHz
6	External frequency setting End	Set value	A12	Not possible	0 to 360Hz /Setting resolution 0.1Hz This function set the end frequency when the inverter receives 10V or 20mA analog input.	0Hz
7	External frequency setting start rate	Set value	A13	1	0 to 100% /Setting resolution 1% This function set the rate of starting point of analog input for full scale(10V or 20mA). In other words, the bias of analog input can be set.	0%
8	External frequency setting end rate	Set value	A14	Not possible	0 to 100% /Setting resolution 1% This function set the rate of endding point of analog input for full scale(10V or 20mA). In other words, the bias of analog input can be set.	100%
9	External frequency start pattern setting	Set value	A15	Not possible	This function should set the starting pattern if the start frequecy and starting rate of analog input are set some value as following; Freq- A12 A15=00 A15=01 A15=01 A15=01 Analog input 0 Start frequency 01 OHz start	01
10	Time constant of the filter of analog	Set value	A16	Not	1 to 8 This value is average time of calculating filter.For example,8 is	8
	input setting			Possible	8 Stimes average for analog input.	
Multispee 11	ed frequency setting		A 20 A 25	no:11	0.5 to 360.0 Hz/satting resolution 0.1 Hz	All
11	Multispeed frequency setting	Set value	A20-A35	possible	0.5 to 360.0Hz/ setting resolution 0.1Hz These parameter are set frequency of multistage speed. Standard(0th) speed can be set A20 parameter, and they can be set from first multispeed (A21) to fifteenth multispeed(A35).	All parameters are 0Hz


Display order	Function name	Туре	Parameter display	Settable during running	Range of set value	Initializ- ation
12	Jogging frequency setting	Set value	A38	0	0.5 to 9.99Hz / setting resolution 0.01Hz The jogging frequency is inching operation by external signal from terminal.	1.0Hz
13	Stop mode of jogging	Set value	A39	Not possible	00 Freerun stop after stop signal 01 Deceleration stop after stop signal 02 Dc braking after stop signal	00
V/F chara		<i>a</i> .			Colocted which is manual torque baset or automatic torque	
14	Selection of method of torque boost	Set value	A41	Not possible	Selected which is manual torque boost or automatic torque boost. 00 Manual torque boost 01 Automatic torque boost	00
15	Value of manual torque boost setting	Set value	A42	possible	Set voltage of manual torque boost Motor torque can be adjusted to increase the output voltage when the starting torque is not sufficient in V/F control. Pay attention not to cause the motor to burnout and an inverter trip. V 100% A A A A A A A A	11
					$6.0 \text{Hz} 30.0 \text{Hz} \text{f base} =$ $\boxed{10.0\%} 60.0 \text{Hz}$	
16	Manual torque boost frequency adjustment	Set value	A43	possible	Set the point A in the above torque boost graph within the range of 0% to 50% of the base frequency.	10.0%
17	V/F characteristic setting	Set value	A44	Not possible	Set V/F characteristic 00 Constant torque characteristic 01 Reduced torque characteristic 02 Sensorless vector	02
18	V-Gain setting	Set value	A45	possible	Set the voltage gain of V V/F characteristic 100% 50% 0 frequency	100
DC brakin	ng setting				1	
19	Selection of DC braking operation	Set value	A51	Not possible	Selected which DC braking is avilable or not. 00 not available 01 available	00
20	DC braking frequency setting	Set value	A52	Not possible	0.5 to 10.0 Hz / setting resolution 0.1Hz The frequency at which the DC braking is set.	0.5
21	DC braking waiting time setting	Set value	A53	Not possible	0.1 to 5.0 seconds / setting resolution 0.1 second This time is interval from end of running to start of DC braking.At this interval the motor is free running.	0.0
22	DC braking force setting	Set value	A54	Not possible	Ű	0
23	DC braking time setting	Set value	A55	Not possible	0.1 to 60 seconds / setting revolution 0.1 second Set time during DC braking operates.	0.0
24	in relation to freque Frequency upper limiter setting	Set value	A61	Not possible	0.5 to 360.0 Hz / setting resolution 0.1Hz Set the limits of frequency setting within the maximum frequency. If 0.0Hz is set, lower limiter is not available. output frequency A61 upper limiter A62 lower limiter frequency frequency command	0.0Hz
25	Frequency lower limiter setting	Set value	A62	Not possible	0.5 to 360.0 Hz / setting resolution 0.1Hz Set the limits of frequency setting within upper limiter frequency. If 0.0Hz is set, lower limiter is not available.	0.0Hz
26	Jump frequency setting	Set value	A63,A65, A67	Not possible	0.0 to 360.0 Hz /setting resolution 0.1Hz.0.0 Hz is not available To avoid a resonance with load, the frequencies at up to 3 points can be jumped. The frequency equivalent to the jump frequeny setting cannot be set.	0.0Hz
27	Jump frequency width setting	Set value	A64,A66, A68	Not possible	0.0 to 10.0 Hz /setting resolution 0.1Hz The frequency width where frequencies are jumped is set.	0.5Hz

Display order	Function name	Туре	Parameter display	Settable during running	Range of set value and contents	Initializ- ation
PID contr	ol				· · · · · · · · · · · · · · · · · · ·	ı
28	Selection of PID control	Set value	A71	Not possible	This parameter selects which PID control operates or not. 00 PID control is not available 01 PID control is available	00
29	P(proportion) gain setting	Set value	A72	possible	0.2 to 5.0 times /setting resolution 0.1 time This function is used to set proportional gain of PID control operation.	1.0
30	I(Integral) gain setting	Set value	A73	possible	0.0 to 150.0 seconds /setting resolution 0.1 second This function is used to set integral gain of PID control operation	1.0
31	D(Differential) gain setting	Set value	A74	possible	0.0 to 100.0 seconds /setting resolution 0.1 second This function is used to set differential gain of PID control operation.	0.0
32	Scale conversion of PID control setting	Set value	A75	Not possible	0.01 to 99.99 / setting resolution 0.01 This function is used to convert target value which feedback is fit.	1.0
33	feedback destination setting	Set value	A76	Not possible	Set the destination which feedback come from. 00 IRF terminal(current input) 01 VRF terminal(voltage input)	00
					(NOTE 2 : PID feedback diagram)	
AVR func	tion					
34	Selection of AVR function	Set value	A81	Not possible	Select the operation of AVR function 00 AVR function is available at all range of operation 01 AVR function is not available at all range of operation 02 AVR function is not available at deceleration AVR function is that the output voltage from the inverter keeps constant even if input power varies.	02
35	Selection of voltage of AVR function for the motor	Set value	A82	Not possible	200/220/230/240/ for 200V class inverter	230/ 460
Second ac	cceleration(acc) and		ration(dec)			
36	Second acceleration time setting	Set value	A92		0.1 to 999.9seconds / setting resolution 0.1 second 1000 to 3000 seconds /setting resolution 1 second Acceleration 2 is worked by 2CH terminal input or setting changed frequency.	15.0
37	Second deceleration time setting	Set value	A83	possible	0.1 to 999.9seconds / setting resolution 0.1 second 1000 to 3000 seconds /setting resolution 1 second Deceleration 2 is worked by 2CH terminal input or setting changed frequency.	15.0
38	Selection of method to use second acceleration / deceleration (acc2/dec2)	Set value	A84	Not possible	00 Acc2/Dec2 command input from terminal 01 changed frequency from acc/dec1 to acc/dec 2 frequency A95	00
39	Changed frequency from acc1 to acc2 setting	Set value	A95	Not possible	0.0 to 360.0Hz / setting frequency 0.1Hz When output frequency reaches this frequency ,acceleration time changes from acc1 to acc2. (NOTE 3)	0.0
40	Changed frequency from dec1 to dec2 setting	Set value	A96	Not possible	0.0 to 360.0Hz / setting frequency 0.1Hz	0.0

Display order	Function name	Туре	Parameter display	Settable during running	Range of set value and contents	Initializ- ation
41	Pattern of acceleration setting	Set value	A97	Not possible	Set the pattern of acceleration 1 and accelration2 00 linear 01 S-curve setting frequency linear Acceleration time	00
42	Pattern of deceleration setting	Set value	A98		Set the pattern of acceleration 1 and decelration2 00 linear 01 S-curve	00

NOTE 1 : To keep the motor stability, the output frequency exceeds the maximum frequency set by [A 04].(Max.1.5Hz) Adjust the output frequency setting.

NOTE 2 : PID feedback diagram



NOTE 3 : When the acceleration or the deceleration time is set small value (less than 1.0 s), the actual changed frequency delays to the set value.

Diaplay	nded function mo		Parameter	Settable		Initializ-
Display order	Function name	Туре	display	during running	Range of set value and contents	ation
Restart m	ode					
1	Selection of restart mode (NOTE 1)	Set value	b01	Not possible	 Select the inverter retry method. 00 Alarm output after tripped 01 OHz start at the time of restart 02 Frequency matching start at the time of restart 03 Frequency matching at the time of restart and then deceleration stop and display Trip information. Trips of restart are overcurrent trip,overvoltage trip and undervoltage trip. The number of restart is 3 times at overcurrent 	00
2	Allowable	Set	b02	Not	trip and overvoltage trip, and 16 times at undervoltage trip. 0.3 to 25 seconds / setting resolution 0.1 second	1.0
	undervoltage power failure time setting	value			When an undervoltage power failure occurs, the allowable time until the power failure is recover is set. If the time of the undervoltage power failure is over this parameter, the inverter trips even if the restart mode is selected.	
3	Retry waiting time setting	Set value	b03	Not possible	0.3 to 100 seconds /setting resolution 0.1 second The restart waiting time after an undervoltage power failure is recovered is set. power motor speed b02 b03	1.0
Electronic		-				
5	Level of electronic thermal setting	Set value	b12	Not possible	Set a level of electronic thermal which is range between 50% to 120% for the rated current of the inverter. It can be set by ampere. Range of setting 0.5 * (Rated current of the inverter) to 1.2 * (Rated current of the inverter) setting resolution 0.01A	Rated current for each inverter (NOTE 2)
6	Selection of electronic thermal characteristic	Set value	b13	Not possible	Select the characteristic of electronic thermal whether CRT(constant torque characteristic) or SUB(reduced torque characteristic) The thermal characteristic accords with the load to be used because the motor protects. 00 - General purpose motor 01 - Constant torque motor Output current $00 = \frac{100}{80}$ $0 = \frac{100}{5}$ $0 = \frac{100}{20}$ $0 = \frac{100}{5}$ $0 = \frac{100}{20}$ $0 = \frac{100}{5}$ $0 = \frac{100}{20}$ $0 = \frac{100}{5}$ $0 = \frac{100}{20}$ $0 = \frac{100}{5}$ $0 = \frac$	01
	restriction					
7	Selection of overload restriction operation mode	Set value	b21	•	This function is used to select the mode to operate overload restriction. 00 Not available 01 Available at acceleration and constant speed 02 Available at constant speed At deceleration, overload restriction function is not available always.	01
8	Level of overload restriction setting	Set value	b22	Not possible	Set a level of overload restriction which is range between 50% to 150% for the rated current of the inverter. It can be set by ampere. Range of setting 0.5 * (Rated current of the inverter) to 1.5 * (Rated current of the inverter) setting valueCurrent (A) setting resolution 1% of the rated current	Rated current * 1.25 for each inverter
9	Rate of deceleration at overload restriction	Set value	b23	Not possible	Set the deceleration rate at operation of overload restriction function 0.1 to 30.0 / setting resolution 0.1. Motor current Output frequency b23	1.0

NOTE 1 : In case the restart mode [b 01] is set [00], if inverter is reset by long power failure with the run command setting, inverter restarts immediately after power coming. See the other warning at p.1-3.

Display	Eupotion non-	The	Parameter	Settable during	Range of set value	Initializ-
order	Function name	Туре	display	running	and contents	ation
Other pro	otection			8		
10	Selection of software lock mode	Set value	b31	Not possible	 Software lock is the function that cannot be changed any parameter except this function. This function is set by the set-maker in order to avoid that end-user change the parameter and missoperation of the system. 00 It is impossible to change all parameter except this function when SFT from terminal is on. 01 It is impossible to change all parameter except this function and frequency setting function when Software lock assigned terminal is on. 02 It is impossible to change all parameter except this function and frequency setting function when Software lock assigned terminal is on. 02 It is impossible to change all parameter except this function as soon as 02 is set. 03 It is impossible to change all parameter except this function and frequency setting function as soon as 03 is set. 	01
11	Reactive Current setting (NOTE 3)	Set value	b32	Not possible	Setting resolution : 1% Amps of inverter rated current. Set the no load current of motor at the down sized motor, multiple motor or 230V / 460V motor driving.	Rated Current *0.58 for each inverter
Others						
13	Analog meter adjustment	Set value	b81	possible	This function is used to adjust the analog meter connected to the frequency monitor(FRQ). 0 to 255 / setting resolution 1	80
14	Start frequency adjustment	Set value	b82	Not possible	0.5 to 9.9 Hz / setting resolution 0.1Hz Set the frequency for starting output of the inverter.	0.5
15	Carrier frequency setting (NOTE 1)	Set value	b83	Not possible	0.5 to 16.0 kHz / setting resolution 0.1kHz Set the carrier frequency for PWM waveform output of the inverter. When the carrier frequency over 12kHz is set, the rated current of the inverter has to be reduced.	5.0
16	Selection data initialization or clear of trip history (NOTE 2)	Set value	b84	Not possible	 the inverter has to be reduced. select whether it is data initialization or trip history clear. 00 Trip history clear 01 Data initialization The method of this function is that ; 1)set the this function 00 or 01, 2) FUNC, (a) (b) (c) on the operator are pressed at same time, 3)and then continue this condition and press (STOP) key. 4)Wait 2 seconds holding the key (FUNC), (a) (c), the display will blink d 00. Then release the all keys. 	
17	Selection of initialized data	Set value	b85	Not possible	5) Then the initialize operation starts. Select the initialized data 04 00 Japan version 01 Europe version 02 US version 03 Exclusive version (Do not set)	02
18	Frequency converted value setting	Set value	b86	possible		1.0
19	Selection of STOP key meaning	Set value	b87	Not possible	Decide the STOP key meaning when running destination is terminal 00 STOP key is available at terminal condition 01 STOP key is not available at terminal condition	00
20	Selection of operation at FRS signal canceled	Set value	b88	Not possible	Select the operation after freerun function is canceled. 00 Restart from 0Hz 01Restart from the frequency which is picked up at the real speed of the motor.	00

NOTE 1 : While the DC braking is performed, the carrier frequency is held to 1kHz automaticaly. When SLV is selected, set the carrier frequency more than 2.1kHz at b83.
 NOTE 2 : This function is not performed when the remote operator is connected. Take off the remote operator and operate from the key pad on the inverter.

Display order	Function name	Туре	Parameter display	Settable during running	Range of set value and contents	Initializ- ation
21	Selection of the contents for digital operator	Set value	b89	possible	Set the monitoring data for using the digital operator 01 Output frequency monitoring (d 01) 02 Output current monitoring (d 02) 03 Running direction monitoring (d 03) 04 Feedback data of PID control monitoring (d 04) 05 Condition of input intelligent terminal monitoring (d 05) 06Condition of output inteligent terminal monitoring (d 06) 07 Scale conversion data of output frequency monitoring (d 07)	01
22	Dynamic braking usage ratio	Set value	b90	Not possible	This command sets the rate of use (in percentage) of the regenerative braking resistor for 100 seconds. When the resistor is used more than this rate, the Braking Resistor Overlond Trip (E06) occurs 1. When 0% is set, BRD is not performed. 2. When the value T exceeds a preset value, the BRD function is terminated. 3. When mounting an external BRD unit, set the usage ratio to 0.0 and remove the external resistors. 4. The length of the cable between the external resistor and the inverter, should not exceed 5m. 5. The cable between the external resistor and the inverter, should not be bundled. Function contents BRD ON $T= \frac{(t1 + t2 + t3)}{100 \text{ seconds}} \times 100$	00
					Machine type HF3202-A75-W ' -3A7-W HF3202-A20-W -A40-W HF3204-2A2-W -4A0-W HF3204-A40-W ' -1A5-W Minimum resistance 35 ohm 100 ohm 180 ohm	
23	Stopping mode selection	Set value	b91	Not possible	Select the operation in stopping 01 DEC (Decelerate and stop) 02 FRS (Free run and stop)	00
24	Cooking FAN Control seletion	Set value	b92	Not possible	The cooling FAN is turn on or off, according as inverter operation. 00 FAN os always ON 01 ON (Inverter operate) OFF (Inverter stop) (NOTE) When the inverter is stopped, after one minute later, the cooling FAN is stop. When the inverter power is turn on, the cooling FAN operates one minute for confirmation.	00

(4)Extended function of C group

These function have relation with terminal.

ninal(function) Function of terminal FR setting	Set value				
	value	C01	Not possible	Set the function of input terminal FR (codes)	00
			F	00 Forward command 01 Reverse command 02 Multispeed1 03 Multispeed2 04 Multispeed3 05 Multispeed4 06Jogging command 07External DC damping 08 B mode function 09 2-stage acceleration and deceleration 11 Free run command 12 External trip 13 USP function 15 Software lock 16 Analog input voltage/current switching 18 Reset 27 FRQ UP 28 FRQ DOWN	
terminal RR setting	value		1	(codes) same C01	01
terminal AUT setting	value		possible	(codes) same C01	16
Function of terminal USP setting	Set value	C04		Set the function of input terminal USP (codes) same C01	
Function of terminal AD2 setting	Set value	C05	Not possible	Set the function of input terminal AD2 (codes) same C01 and there is additional code. 19 PTC(motor thermistor input)	
Function of terminal RST setting	Set value	C06	Not possible	Set the function of input terminal RST (codes) same C01 and there is additional code.	
	<i>a</i>				0.0
Condition of terminal FR setting	Set value	CII	Not possible	Set the condition of input terminal FR which is normally open or normally close. 00 normally open [NO] 01 normally close [NC]	00
Condition of terminal RR setting	Set value	C12	Not possible	Set the condition of input terminal RR which is normally open or normally close.	00
Condition of terminal AUT setting	Set value	C13	Not possible	Set the condition of input terminal AUT which is normally open or normally close.	00
Condition of terminal USP	Set value	C14	Not possible	Set the condition of input terminal USP which is normally open or normally close.	01
Condition of terminal AD2 setting	Set value	C15	Not possible	Set the condition of input terminal AD2 which is normally open or normally close.	00
Condition of terminal RST setting	Set value	C16	Not possible	Set the condition of input terminal RST which is normally open or normally close. When assigned RESET, normally open only. See page 7-1,7-12.	00
rminal(function)			1		
Function of terminal UPF setting	Set value	C21	Not possible	 00 RUN(signal during running) 01 FA1(frequency arrival signal:at the time of constant speed arrival) 02FA2(frequency arrival signal:at the time of set frequency or more) 03 OL(overload signal) 	01
	setting Function of terminal AUT setting Function of terminal USP setting Function of terminal AD2 setting Function of terminal RST setting Condition of terminal FR setting Condition of terminal RR setting Condition of terminal AUT setting Condition of terminal AUT setting Condition of terminal AUT setting Condition of terminal AUT setting Condition of terminal ST setting Condition of terminal ST setting	terminal RR setting Function of terminal AUT setting Function of terminal USP setting Function of terminal AD2 setting Function of terminal RST setting Condition of terminal RR setting Condition of terminal RR setting Condition of terminal AUT setting Condition of terminal SSE value setting Condition of terminal CSE value setting Condition of terminal CSE setting Condition of terminal CSE setting CSE Setting	terminal RR setting Function of terminal AUT setting Function of terminal USP setting Function of terminal AD2 setting Function of terminal RST setting Condition of terminal RR setting Condition of terminal RR setting Condition of terminal AUT setting Condition of terminal CP setting Condition of terminal RST setting Condition of terminal RST setting Condition of terminal CP setting Condition of terminal RST setting Condition of terminal CP setting Condition of terminal CP setting Condition of terminal RST setting Condition of terminal CP setting Condition of terminal RST setting Condition of terminal CP setting Condition of terminal RST setting Condition of terminal CP setting Condition of t	terminal RR setting Function of terminal AUT setting Function of terminal USP setting Function of terminal AD2 setting Function of terminal AD2 setting Function of terminal RST setting Condition of terminal RR setting Condition of terminal AUT setting Condition of terminal CUP setting Condition of terminal RST setting Condition of terminal RST setting Condition of terminal CUP setting Condition of terminal RST setting Condition of terminal CUP Set value Condition of terminal CUP setting Condition of terminal CUP Set value CON Set C16 Not possible Set c17 Not possible Set c18 Not possible Set Set Set C16 Not possible Set Set Set Set Set Set Set Set Set Se	Observed SettingSet ValueCO2 Condition of SetNot PossibleSet the condition of input terminal RT is settingFunction of reminal RT valueSet CO2 valueNot possibleSet the function of input terminal RR possibleFunction of reminal AUT valueSet CO2 valueNot possibleSet the function of input terminal RR possibleFunction of reminal AUT valueSet CO2 valueNot possibleSet the function of input terminal AUT possibleFunction of reminal AUT valueSet valueCO2 possibleNot possibleFunction of reminal AUT valueSet valueSet the function of input terminal AUT possibleFunction of reminal AUT valueSet valueSet the function of input terminal AUT possibleFunction of reminal RST valueSet valueCO4 possibleFunction of reminal RST valueSet valueSet the function of input terminal AD2 possibleFunction of reminal RST valueSet valueSet the function of input terminal RST possibleCondition of reminal RST valueSet valueCO1 set the function of input terminal RST possibleCondition of reminal AUT valueSet valueCO1 set the function of input terminal RST possibleCondition of reminal AUT valueSet valueCO1 set the condition of input terminal RST possibleCondition of reminal AUT valueSetCO2 set the condition of input terminal AUT which is normall

Display order	Function name	Туре	Parameter display	Settable during running	Range of set value and contents	Initializ- ation
Output te	erminal(condition))			· · · · · · · · · · · · · · · · · · ·	·
14	Function of terminal DRV setting	Set value	C22	Not possible	Set the function of terminal DRV (code) same C21	00
15	Function of FRQ terminal setting	Set value	C23	Not possible	Set the function of frequency monitorFRQ (code) 00 Momitor of analog output freuqency 01 Momitor of analog output current 02 Momitor digital output freuqency	00
16	Function of AL terminal setting	Set value	C24	Not possible	Set the function of output terminal alarm relay (code) same as C21	05
<u>^</u>	rminal(condition)					
17	Condition of terminal UPF setting	Set value	C32	Not possible	Set the condition of intelligent output terminal UPF which is normally open or normally close. 00 normally open 01 normally close	00
18	Condition of terminal AL setting	Set value	C33	Not possible	Set the condition of alarm relay which is normally open or normally close. (See 7-21) 00 normally open 01 normally close	01
Function	relation with outp	out term	inal			
19	Level of overload signal setting	Set value	C41	Not possible	Set the level of overload signal which is range between 0% and 200% for rated current of the inverter. Range of setting 0.0* (Rated current of the inverter) to 2.0* (Rated current of the inverter) setting resolution 0.01A motor current overload signal	Rated current of each inverter
20	Arrival frequency setting for acceleration	Set value	C42	Not possible	Set the frequency that the arrival signal should be outputted at acceleration. 0.0 to 360Hz output frequency arrival signal	0.0
21	Arrival frequency setting for deceleration	Set value	C43	Not possible	Set the frequency that the arrival signal should be outputted at acceleration. 0.0 to 360Hz	0.0
22	Level of deviation signal setting	Set value	C44	Not possible	This function sets deviation level between target and feedback at PID control. 0.0 to 100.0% / setting resolution 0.1% 100% means fullscale PID control Deviation signal	3.0
23	Analog meter adjustment VRF	Set value	C81	Not possible	Adjustment the relationship between the external the frequency command and the inverter output frequency. (Voltage command [VRF-COM])	
24	Analog meter adjustment IRF	Set value	C82	Not possible	Adjustment the relationship between the external the frequency command and the inverter output frequency. (Current command [IRF-COM])	

Display order	Function name	Туре	Parameter display	Settable during running	Range of set value and contents	Initializ- ation
25	Debug mode selection	Set value	C91	possible	Factory use only, DO NOT CHANGE	00
26	Core monitor address		C92		Factory use only, DO NOT CHANGE	0000
27	Core monitor date		C93		Factory use only, DO NOT CHANGE	-
28	Core set address		C94		Factory use only, DO NOT CHANGE	d001
29	Core se date		C95		Factory use only, DO NOT CHANGE	_

Extended function mode H group

Display order	Function Name	Туре	Parameter display	Settable durring	Range of see value and contents	Initialization
Funct	tion relation with	Sensorle	ss vector co	ontrol		1
1	Autotuning Mode settineg	Set Value	H01	Not possible	00: not available 01: autotuning 02: measure the resistance and the inductance	00
2	Motor constant select	Set Value	H02	Not possible	0: Standard motor data 1: Autotuning data	0
3	Motor capacity setting	Set Value	H03	Not possible	0.1/0.2/0.4/0.75/1.5/2.2/3.7 (kW)	1
4	Motor poles	Set Value	H04	Not possible	2/4/6/8	4
5	Motor constant kp setting	Set Value	H05	Not possible	Adjustment Speed Resporce 0 to 99 setting resolution 1. "1"means 10msec.	20
6	Motor stabilization constant	Set Value	H06	Not possible	0 to 255% setting resolution 1%	100
Moto	or constant data					
7	R1 setting	Set Value	H20	Not possible	0.000 to 0.999, 1.00 to 9.99, 10.0 to 65.5 The unit is	2
8	R2 setting	Set Value	H21	Not possible	0.000 to 0.999, 1.00 to 9.99, 10.0 to 65.5 The unit is	2
9	L setting	Set Value	H22	Not possible	0.000 to 0.999, 1.00 to 9.99, 10.0 to 65.5 The unit is mH	2
10	Io setting	Set Value	H23	Not possible	0.000 to 0.999, 1.00 to 9.99, 10.0 to 65.5 The unit is A	2
11	J setting	Set Value	H24	Not possible	The ratio of motor inatia per the motor of same capacity of inverter	2
Auto	tuning Motor co	nstant dat	a			1
12	R1 setting	Set Value	H30	Not possible	0.000 to 0.999, 1.00 to 9.99, 10.0 to 65.5 The unit is	3
13	R2 setting	Set Value	H31	Not possible	0.000 to 0.999, 1.00 to 9.99, 10.0 to 65.5 The unit is	3
14	L setting	Set Value	H32	Not possible	0.000 to 0.999, 1.00 to 9.99, 10.0 to 65.5 The unit is mH	3
15	Io setting	Set Value	H33	Not possible	0.000 to 0.999, 1.00 to 9.99, 10.0 to 65.5 The unit is A	3
16	J setting	Set Value	H34	Not possible	The ratio of motor inatia per the motor of same capacity of inverter	3

1 Same capacity as inverter

2 Standard motor data

3 Standard motor data

(NOTE) When SLV is selected at A44, set the carrier frequency to 2.1kHz or higher at b83. When the inverter drives the small inertia load, the motor occurs hunting running.

Take the following counter measure.

1)Adjust the stabilization constant(H06).

2)Decrease the carrier frequency (b83).3)Set the selection of AVR function (A81) to "01 (not available at all range of operation)".

9. PROTECTIVE FUNCTIONS

The HF-320 series inverters trip by protective functions against overcurrent, overvoltage, and undervoltage which protect the inverter. If the protective functions are engaged, the output is shut down, motor runs free and holds that condition until it is reset.

Description	Contents	Display				
Power module protection	When output of an inverter is short circuited or the motor is locked, a large current flows through the inverter and causes a fault.	E01				
(NOTE 1)	When the current flowing through the power module or a temperature abnormality of the main devices comes to certain level, the output is cut off.Dec.Acc.					
	Stop	E 0 4				
Overload protection (NOTE 1)	When a motor overload is detected by the electronic thermal function, the output of the inverter is cut off.	E05				
Braking resistor overload	When regenerative braking resistor exceeds the usage time ratio an overvoltage caused by the stop of the BRD function is detected, and output of the inverter is cut off.	E06				
Overvoltage protection	When the converter voltage exceeds a certain level due to regenerative energy from the motor, this protection function engages, and the output of inverter is cut off.	E D 7				
EEPROM error (NOTE 2)	When the memory built in has problems due to noise or excessive temperature rise, this protective function engages, and the output of inverter is cut off.					
Undervoltage protection	A decrease of the input voltage of an inverter results in improper function of the control circuit. It also generates motor heat and causes low torque. Output is cut off when the input voltage goes down to less than 150 V to 160 V (200 V class), 300 V to 320 V (400 V class).					
CT error	When a large noise source is near the inverter or an abnormality occurs on built-in CT, the output of the inverter is cut off.					
CPU error	Malfunction or abnormality on built-in CPU and the output of the inverter is cut off.					
External trip	An abnormality signal from external equipment cuts off the output of the inverter.					
USP error	It indicates an error when power is turned on while the inverter is being run. (When USP function is selected)	E 13				
Ground fault protection	The inverter is protected by detection of ground faults between the inverter output and the motor upon power on. There may be the power module failure. This protection is provided for the inverter, not for humans.					
Input overvoltage	When the input voltage is highlier than the specified value, it is detected 100 seconds after power is turned on and the output is cut off.					
Thermal protection	When the temperature of the inverter module is higher, the themal sensor in the inverter module detects the higher temperature of power chip and the inverter is cut off.					
PTC error	When the resistance value of the external thermistor is too large, the equipment detects the abnormal condition of the themistor and then cut off the output. (When PTC function is selected)					

NOTE 1: If an EEPROM error occurs, be sure to confirm the setting value again.

If the power is turned off while the RST terminal is held [ON],the EEPROM error occurs at the power is turned on in the next time. (In case, RST terminal is assigned to Reset function.)

Other

Contents	Display
Under stand-by condition at power on. At reset signal coming.	- <u>5555</u> ↓ []]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]
It is displayed when the under voltage or the power is shut off.	
It displays the rest time of retry waiting time after the power recovery of undervoltage when selecting the retry mode.	0000
During the initialization of the parameters	<u>Susa</u>
During the initialization of the trip history data	<u>,</u> 2
No data(Trip history, PID feedback data).	

10. TROUBLESHOOTING

Sy	mptom	Probable cause	Countermeasure
The motor will not run.	The inverter outputs U, V and W are not supply-	 Is the parameter setting of the frequency command destination [A01] correct? Is the parameter setting of the running command destination [A02] correct ? 	Make sure of the parameter setting [A01].Make sure of the parameter setting [A02].
	ing voltage.	• Is power being supplied to terminals L1, L2 and L3(N)? If it is, the POWER lamp should be on.	 Check terminals L1, L2 and L3(N), U, V, and W. Turn on the power supply.
		• Is the display E []?	• Press FUNC and check the content. Then press the reset key.
		 Is the allocation of intelligent input terminal correct ? Is the operation instruction RUN ON? Is terminal FR (or RR) connected to terminal P24? . 	 Make sure of the allocation of the terminal [C 01] ~ [C 05]. Set to ON. Connect terminal P24 to terminal FR (or RR). (When the terminal mode is selected.)
		 Has the frequency setter been turned on by pushing (A) (V) key to select [F 01] and then (A) (V) key. Are the control circuit terminals +V, VRF and COM connected to the potentiometer? . 	 Push down keys and set. When terminal mode is selected, connect the potentiometer to +V, VRF, and COM, and then set.
		• Has reset / free run stop terminals been left ON?	• Release reset.
	Inverter outputs U, V, and W are supplying voltage.	• Has the motor the load too heavy?	 Reduce the load. Test the motor independently.
The direction of the motor is reversed		 Are the connections of output terminals U, V, and W correct? Is the phase sequence of the motor forward or reverse in respect to U, V, and W? 	• Make the connections according to the phase sequence of the motor. (In general, forward should be in the sequence: U, V, and W.)
		 Are the control terminal connection correct? . Is the parameter [F 04] set correctly ? 	• Terminal FR for forward, and RR for reverse. (When the terminal mode is selected.)

Syn	nptom	Probable cause	Countermeasure	
The rpm of the motor will not		• After checking the wiring of the frequency setter, the rpm still does not increase when the setter is turned.	• Replace the frequency setter.	
increase.		• Is the load too heavy?	 Reduce the load. When the load is too heavy, the overload restriction will be activated, so that the rotational speed will be lower than the setting. 	
Rotation is unstable.		 Is the fluctuation in load too great? Is the power supply voltage fluctuating? Is some peculiar frequency causing the problem? 	 Increase the capacity. (Both of the motor and inverter.) Decrease the fluctuation. Change the output frequency slightly. Change the carrier frequency(b83 p.8-12) 	
The rpm of the motor does not match the inverter.		• Is the maximum frequency setting correct ?	• Check the V/F pattern against the motor specifications.	
The data is incorrect.	The data has not changed.	• Was the power turned off without pushing the STR key after the data was changed with (A) (V) keys.	• Input the data and push the STR key once.	
		• The data is memorized upon power off. Is the time from power OFF to ON less than six seconds?	• Take six seconds or more when turning power OFF and ON after changing the data.	

Syn	nptom	Probable cause	Countermeasure
The data is not changed.	Frequency setting can not be changed. Run and stop can not be done.	• The change of the terminal mode and digital operator mode were correct?	• Confirm the change in[A 01], [A 02] setting mode. (See page 8-7.)
	The data can not be changed.	 Is software lock ON? Is software lock ON with software lock selection [b 31] 	 Open software lock terminal and P24. Change the data of [b 31]. Turn the switch OFF.

Precautions for data setting

When changing any set data by one of the following methods, keep the equipment unoperated for 6 seconds or more after the selected method is executed. When any key is pressed, or the reset operation is performed, or the power is turned off within 6 seconds, correct data may not be set.

1) Changing the data and pressing the (STR) key to store the data

11. MAINTENANCE AND INSPECTION

11.1 Maintenance and Inspection Precautions

After a lapse of more than 5 minutes after turning off the input power supply, perform the maintenance and inspection.

Otherwise, there is a danger of electric shock.

Make sure that only qualified persons will perform maintenance, inspection and part replacement. (Before starting the work, remove metallic objects from your person (wristwatch, bracelet, etc.) (Be sure to use tools protected with insulation.)

(Be sure to use tools protected with insulation.)

Otherwise, there is a danger of electric shock and/or injury.

When removing connectors, never pull the wires. (Wires for cooling fan and logic P.C. board)

Otherwise, there is a danger of fire due to wire breakage and/or injury.


• General precautions

Always keep the unit clean so that dust or other foreign matter does not enter the inverter. Take special care in regard to breaking lines and connection mistakes. Firmly connect terminals and connectors. Keep electronic equipment away from moisture and oil. Dust, steel filings and other foreign matter can damage insulation, causing unexpected accidents, so take special care.

11.2 Inspection Items

- (1) Daily inspection
- (2) Periodic inspection (Approximately once a year)
- (3) Insulation resistance test

Conduct the insulation resistance test by short circuiting the terminals as shown below.



Use 500V DC megohm meter, and make sure that 5M ohm or greater is indicated.

Never test withstand voltage test. Because this inverter has the surge absorber between the main circuit terminal and the ground.

We recommend that the following parts be stocked to reduce down time.

Part description	Symbol	Qua	ntity	Remarks	
r art description	Symbol	Used	Spare	Kelliarks	
Cooling fan	FAN	1	1	HF3202-2A2-W -3A7-W HF3204-1A5-W ² -4A0-W	
Case		1	1	Front case Key cover Case Rear cover	

Recommended Spare Parts

Inspection	Inspection item	Inspection content	Inspec	ction cycle	Inspection method	Criteria	Standard replacement	Instruments
location		inspection content	Daily	Periodic	Inspection method	ontoinu	period	mstruments
Overall	Ambient environment	Check ambient temperature, humidity, dust, corrosive gases, oil mist, etc.	V			Ambient temperature between -10 to +40;C; no icing. Ambient humidity 20 to 90%; no dew condensation.		Thermometer
	Devices overall	Check for abnormal vibrations and noise.	~		Visual and aural inspection.			Hygrometer
	Power supply voltage	Check the input line voltage.			Measure the voltage between inverter terminals L1, L2 and L3(N).	No abnormalities. (200V class) 200 to 240V 50/60Hz (400V class) 380 to 460V 50/60Hz		Tester
Main circuit	Overall	 Check installation for looseness. Check for evidence of overheating in the various components. Clean. 			(1) Tighten.(2) Visual inspection.	Tightening torque (except for terminal block) • M3: 0.5 - 0.6 N•m • M4: 0.98 - 1.3 N•m .		

Daily Inspection and Periodic Inspection (1/3)

Inspection	Inspection item	Inspection content	Inspec	ction cycle	Inspection method	Criteria	Standard replacement	Instruments
location	inspection nem	inspection content	Daily	Periodic	inspection method	Chiefin	period	motrumento
Main circuit	Terminal block	No damage.		~	Visual inspection	No abnormalities.		
	Smoothing capacitor	(1) Check for leaking(2) Check for swelling			Visual inspection of (1) and (2).	No abnormalities in (1) and (2).		
	Relays	(1) Check for stuttering noise when operating			(1) Aural inspec- tion.	(1) No abnormalities.		
	Resistors	(1) Check for large cracks or changes in color		~	(1) Visual inspection	(1) No abnormalities.		Tester
	Cooling fan	(1) Check for abnormal vibrations and noise	V		(1) Rotate manually with power off.(2) Increase tightening	(1) Smooth rotation	2 - 3 years	
		(2) Check for dust	V			(2) No abnormality		

Inspection	Inspecti	on item	Inspection content	Inspec	ction cycle	Inspection method	Criteria	Standard replacement	Instruments
location	linspece		inspection content	Daily	Periodic	inspection method		period	
Control circuit	· · · · · · · · · · · · · · · · · · ·		(1) Check the balance of the output voltage of individual phases when operating the inverter independently.		V	(1) Measure the voltage between the phases of inverter output terminals U, V, and W.	(1) Within 2% voltage difference between phases.		
			(2) Conduct a sequence protection operation test, and make sure that there are no errors in the protec- tion and display circuits.			(2) Simulate operation of the inverter protect- ion circuit.	(2) Operate without any abnormalities.		
	Compo- nent check, including printed-		(1) No abnormal odor or changes in color.(2) No significant corrosion.			Visual inspection	No abnormalities		
	circuit boards	Capacitor	No fluid leakage or deformation.	V		Visual inspection			
Display		Digital operation (1) No illegible displa		V		Visual inspection	Normal operation		
	panel		(2) No lack of character	~			Display can be read out.		
			(3) No blown out LEDs	V					

Daily Inspection and Periodic Inspection (3/3)

NOTE: 1. The life of capacitor will be affected by the amibient temperature. See Appendix 4 Capacitor Life Curve.

2. The inverter must be cleaned periodically. If dust accumulates on the fan and heat sink, it can cause overheating of the inverter.

11.3 Measurement Method for I/O Voltage, Current, and Power

General measuring instruments for I/O voltage, current, and power are indicated below. The voltage to be measured is the fundamental wave effective voltage and the power to be measured is the total effective value.




Table 3 Parts to be measured

Measurement item	Parts to be measured	Ме	asuring instrument	Remarks	Reference value			
Supply voltage E ₁	Between L1 and L2, L2 and L3, L3 and L1 (ER) (ES) (ET)	\checkmark	Moving-iron type voltmeter or rectifier type voltmeter	Fundamental wave effective value	Commercial supply voltage (200 V class) 200-240 V, 50/60 Hz (400 V class) 380-460 V 50/60 Hz			
Supply current I ₁	L1, L2, L3 (IR)(IS)(IT)	\checkmark	Moving-iron type ammeter	Total effective value				
Supply power W ₁	Between L1 and L2, L2 and L3 (W11)(W12)		Electrodynamic type wattmeter	Total effective value				
Supply power factor Pf ₁	supply current I_1 and suppl	Calculate the supply power factor from the measured supply voltage, E ₁ , supply current I ₁ and supply power W ₁ . $Pf_1 = \frac{W_1}{\sqrt{3} \bullet E_1 \bullet I_1} \times 100(\%)$						
Output voltage E ₀	Between U and V, V and W, W and U (EU)(EV)(EW)	→	Rectifier type voltmeter	Total effective value				
Output current I ₀	U, V, W (IU)(IV)(IW)	×	Moving-iron type ammeter	Total effective value				
Output power W ₀	Between U and V, V and W(W01)(W02)		Electronic type wattmeter	Total effective value				
Output power factor Pf ₀	Calculate the output power and output power W. $Pf_0 = \frac{W_0}{\sqrt{3} \bullet E_0 \bullet I_0} \times 100(\%$		om the output voltage E, o	output current I,				

- **NOTE 1:** Use a meter indicating a fundamental wave effective value for voltage, and meters indicating total effective values for current and power.
- **NOTE 2:** The inverter output waveform is a distorted wave, and low frequencys may cause errors. However, the measuring instruments and methods indicated above provide comparatively accurate values.
- **NOTE 3:** A tester (general purpose) may not be suited often to measurement of a distorted wave.

12. STANDARD SPECIFICATIONS

	Model name [200V Class]	HF3202 -A20-W	HF3202 -A40-W	HF3202 -A75-W	HF3202 -1A5-W	HF3202 -2A2-W	HF3202 -3A7-W		
Protectiv	ve structure (NOTE 1)		1	Ι	IP20	1	I		
Maximu	m motor size (4P, kW)(NOTE 2	2) 0.2	0.4	0.75	1.5	2.2	3.7		
Maxim capacit		0.6	1.0	1.5	3.1	4.3	6.9		
(kVA)	240 V	0.6	1.0	1.6	3.3	4.5	7.2		
Input su	pply phase		W ; Single-pl W ; Three-ph		phase				
Rated in	put AC voltage (V)	200V -109	%~240V +5%	, 50/60 Hz	± 5%				
Rated or	ntput voltage (V) (NOTE 3)		e 200 to 240 ds to input vo						
	put current (A) phase / Three phase)	3.5 / 2.0	5.8/3.4	9.0 / 5.2	17.5 / 10.0	24.0 / 14.0	- / 22.0		
Rated or	utput current (A) (NOTE 4)	1.6	2.6	4.0	8.0	11.0	17.5		
Output f	requency range (NOTE 5)	0.5 to 360	Hz						
Frequen	cy accuracy(at 25 $\pm 10^{\circ}$ C)		Digital command: $\pm 0.01\%$ of Max. frequency Analog command: $\pm 0.2\%$ of Max. frequency						
Frequen	cy setting resolution	Digital setting : 0.1 Hz , Analog setting : Max. frequency devided by 1000							
Voltage/	frequency characteristics	Constant or starting tor	Constant or Reduced torque with any variable voltage/frequency and High starting torque with SLV control.(NOTE 8)						
Overload	d current capacity	150%, 60 s	econds						
Accelera	ation/deceleration time		0.1 to 3000 seconds, in selectable linear or non-linear mode, second acceleration/deceleration usable.						
Starting (When S	torque LV has been set)	200% or m	ore				180% or more		
Braking torque	Dynamic braking (NOTE 6) Feedback to capacitor		Approx. 100%	ó		Appro	ox. 20%		
	Dynamic braking using external regenerative resistor		Approx. 150% Appro						
	DC injection braking		Braking is ON at the min. frequency or less. Braking can be selected by the operator. (Min. frequency, braking time and braking force can be set.)						

	Model designation [200V Class]		HF3202 -A20-W	HF3202 -A40-W	HF3202 -A75-W	HF3202 -1A5-W	HF3202 -2A2-W	HF3202 -3A7-W			
Input signals	Frequency	Digital operator	Settings with the potentiometer or $$ $$ in the key pad.								
6		External signals	0 - 10 VDC (Input impedance 10 kΩ) 4 - 20 mA(Input impedance 250Ω) 1kΩ to 2 kΩ (1 W) Variable resistor								
	Forward/ reverse	Digital operator	RUN/STO the factory)	OP switch (T	The forward r	un when ship	pped from				
	run, stop	External signals	s Intelligent input terminal (FR / RR)								
	Intelligent	input terminal	Forward run/stop, Reverse run / stop Multi-stage speed, Jogging command Analog current input selection, Change of 2nd accel/decel time Free run, External trip, USP function Reset, Software lock, Frequency UP, Frequency DOWN, B mode Thermal protection								
Output signals		output terminal	FA1/FA2 : Frequency arrival signal RUN: RUN signalOL: Overload previous notice signalOD : Deviation signal at PID control AL : Alarm signal								
	Frequency	monitoring	Analog met frequency s	ter (0 - 10 VI signal ,analog	DC 1 mA full frequency si	-scale) Selec gnal or analo	ction of the d	igital rent monitor.			
Fault al	arm contact		ON when the inverter trips.(1c contact) / This terminal serves both as fault alarm output and inteligient output.								
Other functions			automatic voltage regulation, retry, analog gain/vias adjustment, frequency jump, upper/lower limiter, output frequency display, trip history monitoring, carrier frequency setting(0.5~16kHz), PID control, automatioc torque boost, etc.								
Protect	Protection functions			overcurrent, overvoltage, undervoltage, electronic thermal, temperature abnormality, ground fault upon starting, overload limit CT error internal communication error, BRD error							

	Model name [200V Class]		HF3202 -A40-W	HF3202 -A75-W	HF3202 -1A5-W	HF3202 -2A2-W	HF3202 -3A7-W				
General specifi-	Ambient temperature (NOTE 7)	-10 to 50°C									
cations	Storage temperature/ Humidity	-25 to 70°C (during short-term transportation period) / 20 to 90% RH (no dew condensation)									
	Vibration	5.9 m/S ² (0.6G) 10 - 55 Hz									
	Installation location	1,000 meter or less altitude, indoors									
Options		reactor for improving power factor, noise filter for inverters									
Estimated	Estimated mass (kg)		0.85	1.3	2.2	2.8					


- **NOTE 1:** Protective structure is based upon EN60529.
- **NOTE 2:** The applicable motor is a Sumitomo standard four-pole motor and a AF motor. When using another motor, make sure that the rated motor current does not exceed the rated inverter current.
- **NOTE 3:** The output voltage will decrease if input voltage decreases.
- **NOTE 4:** So be sure to set the value [b 12] (Level of the electric thermal) and [b 22] (Level of overload restriction setting) for each motors.
- **NOTE 5:** Confirm with the motor manufacturer the motors maximum rpm when using a motor running at frequency higher than 50/60 Hz.
- **NOTE 6:** Torque will be reduced when the base frequency exceeds 50 Hz.
- **NOTE 7:** In range of 40 to 50 , reduce carrier frequency 2.1kHz and derate output current 80% , and remove the top cover.
- **NOTE 8:** When SLV is selected, set the carrier frequency more than 2.1kHz at b83.

	Model name [400V Class]	HF3204 -A40-W	HF3204 -A75-W	HF3204 -1A5-W	HF3204 -2A2-W	HF3204 -4A0-W		
Protectiv	ve structure (NOTE 1)	IP20						
Maximu	m motor size (4P, kW)(NOTE 2)	0.4	0.75	1.5	2.2	4.0		
Maxim capacit (kVA)		1.1	1.9	3.0	4.3	6.8		
Input su	oply phase	Three-phase (For Low Volt	age directive, s	upply 4 wire ear	thed neutral)			
Rated in	put AC voltage (V)	380V -10%~4	460V +10% , 50	0/60 Hz ±5%				
Rated or	tput voltage (V) (NOTE 3)	Three-phase 3 (Corresponds	80 to 460V to input voltage	.)				
Rated in	put current (A)	2.0	3.3	5.0	7.0	11.0		
Rated or	tput current (A)(NOTE 4)	1.5	2.5	3.8	5.5	8.6		
Output f	requency range (NOTE 5)	0.5 to 360 Hz						
Frequen	cy accuracy(at 25 $\pm 10^{\circ}$ C)			f Max. frequenc Max. frequenc				
Frequen	cy setting resolution	Digital setting : 0.1 Hz , Analog setting : Max. frequency devided by 1000						
Voltage/	frequency characteristics	Constant or Reduced torque with any variable voltage/frequency and High starting torque with SLV control.(NOTE 8)						
Overload	l current capacity	150%, 60 seconds						
Accelera	tion/deceleration time	0.1 to 3000 seconds, in selectable linear or non-linear mode, second acceleration/deceleration usable.						
Starting (When S	torque LV has been set)	200% or more				180% or more		
Braking Dynamic braking (NOTE 6) torque Feedback to capacitor		Approx.	100%	Approx. 70%	Approx	x.20%		
	Dynamic braking using external regenerative resistor		Approx.150%	, D	Approx			
	DC injection braking	Braking is ON at the min. frequency or less. Braking can be selected by the operator. (Min. frequency, braking time and braking force can be set.)						


	Model nai [400V Cl		HF3204 -A40-W							
Input signals	Frequency	Digital operator	Settings with the potentiometer or $\textcircled{\bullet}$ \textcircled{V} in the key pad.							
	$ \begin{array}{ c c c c c } \hline External signals & 0 - 10 \ VDC \ (Input impedance \ 10 \ k\Omega) \\ & 4 - 20 \ mA(Input impedance \ 250\Omega \) \\ & 1k\Omega \ to \ 2 \ k\Omega \ (1 \ W) \ Variable \ resistor \end{array} $									
Forward/ reverse Digital operator RUN/STOP switch (The forward run (FW) when shipped from the factory)						from				
	run, stop	External signals	Is Intelligent input terminal (FR / RR)							
	Intelligent i	input terminal	Forward run/stop, Reverse run / stop, Multi-stage speed, Jogging command, Analog current input selection, Change of 2nd accel/decel time Free run, External trip, USP function Reset, Software lock, Frequency UP, DOWN, B mode, Thermal protection							
Output signals	Intelligent of	output terminal	FA1/FA2 : Frequency arrival signal RUN: RUN signal OL: Overload previous notice siganl OD : Deviation signal at PID control AL : Alarm signal							
	Frequency	monitoring	Analog meter frequency sign	(0 - 10 VDC 1 analog frequ	mA full-scale) and full-scale and full-scale and full-scale and full states and full scale and full scale and f	Selection of the analog output cu	digital irrent monitor.			
Fault ala	rm contact		ON when the	inverter trips.(1	c contact)					
Other functions			automatic voltage regulation, retry, analog gain/vias adjustment, frequency jump, upper/lower limiter, output frequency display, trip history monitoring, carrier frequency setting(0.5~16kHz), PID control, automatioc torque boost, autotunning, B mode, Frequency UP, DOWN, etc.							
Protectio	on functions		overcurrent, overvoltage, undervoltage, electronic thermal, temperature abnormality, ground fault upon starting, overload limit							

	Model name [400V Class]	HF3204 -A40-W	HF3204 -A75-W	HF3204 -1A5-W	HF3204 -2A2-W	HF3204 -4A0-W				
General specifi-	Ambient temperature (NOTE 7)	-10 to 50°C								
cations	Storage temperature/ Humidity	-10 to 60°C (during short-term transportation period) / 20 to 90% RH (no dew condensation)								
	Vibration	5.9 m/S ² (0.6G) 10 - 55 Hz								
	Installation location	1,000 meter or less altitude, indoors								
Options		reactor for improving power factor, noise filter for inverters								
Estimated mass (kg)		1.3	1.7		2.8					

- **NOTE 1:** Protective structure is based upon EN60529.
- **NOTE 2:** The applicable motor is a Sumitomo standard four-pole motor and a AF motor. When using another motor, make sure that the rated motor current does not exceed the rated inverter current.
- **NOTE 3:** The output voltage will decrease if input voltage decreases.
- **NOTE 4:** So be sure to set the value [b 12] (Level of the electric thermal) and [b 22] (Level of overload restriction setting) for the motor.
- **NOTE 5:** Confirm with the motor manufacturer the motors maximum rpm when using a motor running at frequency higher than 50/60 Hz.
- NOTE 6: Torque will be reduced when the base frequency exceeds 50 Hz.
- **NOTE 7:** In range of 40 to 50 , reduce carrier frequency 2kHz and derate output current 80% , and remove the top cover.
- **NOTE 8:** When SLV is selected, set the carrier frequency more than 2.1kHz at b83.




Terminal Connection Diagram




NOTE 1: Common terminal	for each terminal is different.
-------------------------	---------------------------------


Terminal name	FR,RR,AUT,USP,AD2,RST	FRQ	+ V,VRF, IRF	UPF,DRV
Common	P24		СОМ	ОМ


- **NOTE 2:** The regenerative resistor has a temperature sensor. When it works, turn off power supply to the inverter or set the deceleration time longer.
- NOTE 3: When the power supply is 400V, put in the trans.
- **NOTE 4:** Put the fuse in the circuit. Otherwise, there is a danger of fire.





- **NOTE 5:** When the operation command is input first and the main circuit power is turned ON, a direct start results and a trip occurs.
- **NOTE 6:** Do not input the operation command simultaneously when the main circuit is turned on.
- **NOTE 7:** Do not turn OFF the main circuit power during running.











* When the inverter is stored in the cabinet, the ambient temperature is the temperature in the cabinet.