

Your two year guarantee

It is important to retain the retailers receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.

Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 24 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You will be asked to return the product (in secure, adequate packaging) to the address below along with a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions) the faulty appliance will then be repaired or replaced and dispatched usually within 7 working days of receipt.

If for any reason this item is replaced during the 2 year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

Morphy Richards products are intended for household use only.

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of its models at any time.

To qualify for the 2 year guarantee the appliance must have been used according to the manufacturers instructions. For example kettles should have been regularly descaled.

EXCLUSIONS

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturers recommendations or where the fault has been caused by power surges or damage caused in transit.
- 2 The appliance has been used on a voltage supply other than that stamped on the products.
- 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
- 4 Where the appliance has been used for hire purposes or non domestic use.
- 5 Morphy Richards are not liable to carry out any type of servicing work, under the guarantee.
- 6 Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.

This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer.

- This guarantee is valid in the UK and Ireland only.

morphy richards®

The After Sales Division
Registered address
Morphy Richards Ltd, Mexborough
South Yorkshire, England, S64 8AJ

Helpline (office hours)
UK (local rate) 0870 060 2610
Republic of Ireland 1800 409119


CM47001M Rev 1

morphyrichards®

Cafe Rico 10 cup filter coffee maker



Please read and keep these instructions



getting the best from your new coffee maker

- **Safety first**

Caution must be used when handling hot water, coffee or steam.

- **Run water through your machine before first use**

It is important to run water through your coffee maker in order to rinse the machine. You can also run water through to warm your coffee machine.

- **Descale as appropriate for the hardness of the water in your area**

It is important to descale as the performance of your coffee maker may be impaired by limescale and other impurities in the water supply.

2year
guarantee



www.morphyrichards.co.uk

Important safety instructions

The use of any electrical appliance requires the following common sense safety rules.

Primarily there is danger of injury or death and secondly the danger of damage to the appliance. These are indicated in the text by the following two conventions:

WARNING: Danger to the person!

IMPORTANT: Damage to the appliance! In addition we offer the following safety advice.

Location

- Remove all the packaging and retain for future reference.
- Ensure the coffee maker is used on a firm, flat surface.
- Do not use the coffee maker outdoors or in a bathroom.
- Do not place the coffee maker on a highly polished wooden surface as damage may occur to the surface.
- Do not place the coffee maker on or near hot surfaces such as a hot plate or radiant rings or near a naked flame.
- **WARNING:** Do not place the coffee maker onto a metal tray or metal surface whilst in use.

Children

- Children do not understand the dangers associated with operating electrical appliances. Never allow children to use this appliance.

Other safety considerations

- Disconnect the coffee maker from the mains supply when filling, cleaning or not in use.
- Keep the outside of the coffee maker area clean and dry at all times.
- Do not touch hot surfaces. Always use handles or knobs.
- Do not immerse the coffee maker itself in water and always ensure the electrical connections are kept dry.

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Ring the helpline number for advice on examination and repair.
- The use of attachments or tools not recommended or sold by Morphy Richards may cause fire, electric shock or injury.
- Do not use abrasive cleaners on the outside of the coffee maker, they may scratch the surface. Clean only with a soft damp cloth.
- Do not use the coffee maker for anything other than its intended purpose.

Product safety

- Never use warm or hot water to fill the water reservoir.
- Do not overfill the water reservoir.

Treating scalds

- Run cold water over the affected area immediately. Do not stop to remove clothing, get medical help quickly.

Personal safety

- Ensure the lid of the glass jug is securely in place before pouring.
- Take care to pour hot coffee slowly and carefully without tipping the glass jug too fast.
- Do not place the glass jug on the hot plate unless the lid is in position.
- Do not fill above the capacity of the water level gauge marked on the jug.
- Do not use the glass jug in a microwave.
- Do not adjust strength control whilst the unit is brewing.
- Do not touch metal parts until the unit has cooled.

Electrical requirements

Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be A.C. (Alternating current).


For appliances with fitted plug.

If the socket outlets in your home are not suitable for the plug supplied with this appliance the plug should be removed and the appropriate one fitted.

IMPORTANT : THE PLUG REMOVED FROM THE MAINS LEAD, IF SEVERED, MUST BE DESTROYED AS A PLUG WITH A BARED FLEXIBLE CORD IS HAZARDOUS IF ENGAGED INTO A LIVE SOCKET OUTLET.

Should the fuse in the 13 amp plug require changing a 13 amp BS1362 fuse must be fitted.

WARNING: THIS APPLIANCE MUST BE EARTHED.




The first time you use your coffee maker


Before using your coffee maker the first time, operate the coffee maker with water only.

General use

- 1 Lift up the hinged reservoir lid.
- 2 Fill the water reservoir with the required amount of water using the water level indicator as a guide. Both the jug and the water level indicator are marked in cups. Do not exceed the maximum level on the water gauge.



- 3 Spoon the required amount of ground filter coffee into the mesh filter spreading it evenly. We suggest one level measuring spoon for every cup. Ensure the filter is sitting properly in the filter holder.
- 4 Close the reservoir lid.
- 5 Select the strength of coffee required using the strength selector on the reservoir lid.




- 6 Slide the jug into the coffee maker ensuring it sits correctly on the hot plate. The jug lid must be in place during the brewing process, otherwise the non-drip valve will not open, causing the filter to flood.
 - 7 Plug the filter coffee maker in at the wall socket and switch the coffee maker ON. The orange light will glow to show coffee maker is working.
 - 8 Hot water will start to flow through the coffee grounds and into the glass jug as coffee.
 - 9 When the coffee has been made, the green ready light will glow. Serve as required. The anti-drip valve will prevent any remaining coffee dripping onto the hot plate. Ensure that the jug is replaced on the hot plate after serving. While the coffee maker is switched ON the hot plate will keep the coffee warm.
 - 10 Switch off the coffee maker when the jug is empty or the coffee is no longer required.
- WARNING: The coffee maker and hot plate are hot and remain hot for some time after switching off.**
- 11 Allow the unit to cool.
 - 12 Remove the permanent mesh filter and empty the used coffee grounds. Wash the filter immediately and dry thoroughly.
- NOTE: THE MESH WILL BECOME DISCOLOURED AFTER A WHILE DUE TO THE STAINING EFFECT OF COFFEE.

Refilling

- 1 Switch off the coffee maker and allow 3 minutes to cool before refilling with cold water.

Locating the filter

- 1 To remove the filter, slide the locking tab on the removable filter holder to the unlock position and lift both the holder and mesh filter out to clean. (see cleaning)
- 2 To refit, place the removable filter holder into the top of your coffee maker, making sure the tab lines up with the rib then slide the locking tab to the lock position. Then place the permanent mesh filter inside the filter holder by lining up the locating tab with the groove in the filter holder as shown.



Descaling

- If you live in a hard water area, we recommend that your coffee maker is descaled at regular intervals, e.g. every 2-3 months. In areas of moderately hard water you should descale every 6 months.
- If the water filters through more slowly than usual, it is a sign that descaling is necessary.
- We recommend you use proprietary liquid descaler which is especially made for coffee makers and plastic kettles. Follow the instructions on the bottle or sachet, and then operate the coffee maker with just water 3 times before making coffee.
- Do not use kettle descaler unless the packet specifically states it is suitable for coffee makers.

Note: The permanent mesh filter should not be used during descaling.

Cleaning care

Unplug the coffee maker and allow to cool.

Do not immerse the coffee maker in liquid.

Rinse the water reservoir occasionally with cold water. Do not use a cloth as any residue or lint may be left behind to clog the coffee maker.

Remove the permanent filter, discard used coffee and wash. Extended soaking helps to remove coffee stains from the mesh.

Wash the glass jug, jug lid, and filter holder in warm soapy water. Rinse and dry all parts thoroughly. Refit filter and filter holder.

Wipe all external surfaces including the warming plate with a damp cloth and dry thoroughly.

Care must be taken to ensure that non-drip valve situated on the bottom of the filter holder is not damaged during cleaning.

Never use harsh or abrasive cleaners.

ALL WASHABLE PARTS ARE
DISHWASHER SAFE.

Helpline

If you have any difficulty with your appliance, do not hesitate to call us.

We are more likely able to help than the store from where you bought it.

Please have the following information ready to enable our staff to deal with your query quickly.

- Name of the product
- Model number and serial number as shown on the underside of the appliance.

