GA-8EGXR Series Workstation / Server Motherboard

USER'S MANUAL

Pentium® 4 Processor Motherboard Rev. 1002 12ME-8EGXR-1002

Table of Content

Item Checklist		4
WARNING!		4
Chapter 1 Introdu	uction	5
•	mary	
	otherboard Layout	
	are Installation Process	
•	he Central Processing Unit (CPU)	
	1-1: CPU Installation	
	1-2: CPU Heat Sink Installation	
Step 2: Install r	nemory modules	11
Step 3: Install	expansion cards	12
Step 4: Conne	ct ribbon cables, cabinet wires, and power supply.	13
Step	4-1: I/O Back Panel Introduction	13
Step	4-2: Connectors Introduction	15
Step	4-3: Jumper Setting Introduction	21
Chapter 3 BIOS	Setup	25
Main (BIOS Ve	rsion)	27
Advanced		30
Adv a	nced Configuration	31
Chips	et Configuration	33
Powe	er Management Configuration	34
Plug	and Play Configuration	36
Perip	heral Configuration	38
Hardy	vare Monitor Configuration	41
Security		44
Boot		46
Exit		48

	Table of Content
Chapter 4 Technical Reference	50
Block Diagram	50
Chapter 5 Appendix	51

Item Checklist

- ☑ The GA-8EGXR(C) motherboard ☑ Driver CD for motherboard driver & utility
- ☑ I/O Shielding x 1 ☑ GA-8EGXR user's manual
- ☑ SCSI Cable x 1 (For GA-8EGXR with color box Only)
- ☑ IDE cable x 2/ Floppy cable x 1

GA-8EGXR Series Model List

- ✓ GA-8EGXR (Supports 533MHz / with SCSI function)
- ✓ GA-8EGXR-C (Suppots 533MHz / without SCSI function)



Computer motherboards and expansion cards contain very delicate Integrated Circuit (IC) chips. To protect them against damage from static electricity, you should follow some precautions whenever you work on your computer.

- 1. Unplug your computer when working on the inside.
- Use a grounded wrist strap before handling computer components. If you do not have one, touch both of your hands to a safely grounded object or to a metal object, such as the power supply case.
- Hold components by the edges and try not touch the IC chips, leads or connectors, or other components.
- 4. Place components on a grounded antistatic pad or on the bag that came with the components whenever the components are separated from the system.
- Ensure that the ATX power supply is switched off before you plug in or remove the ATX power connector on the motherboard.

Installing the motherboard to the chassis...

If themotherboard has mounting holes, but they don't line up with the holes on the base and there are no slots to attach the spacers, do not become alarmed you can still attach the spacers to the mounting holes. Just cut the bottom portion of the spacers (the spacer may be a little hard to cut off, so be careful of your hands). In this way you can still attach the motherboard to the base without worrying about short circuits. Sometimes you may need to use the plastic springs to isolate the screw from the motherboard PCB surface, because the circuit wire may be near by the hole. Be careful, don't let the screw contact any printed circuit write or parts on the PCB that are near the fixing hole, otherwise it may damage the board or cause board malfunctioning.

Chapter 1 Introduction Features Summary

Form Factor	30.48cm x 24.38cm ATX size form factor, 6 layers PCB.
CPU	Socket 478 for Intel® Micro FC-PGA2 Intel® Pentium® 4 processor
	 Intel Pentium® 4 400/533MHz FSB
	2nd cache depend on CPU
Chipset	Serverworks CMIC-SL Northbridge
	Serverworks CSB6 Southbridge
Memory	4 184-pin DDR DIMM sockets
	 Supports Up to 4 Register DIMM DDR200/266
	 Supports up to 4 GB (Max)
	 Supports only 2.5V DDR DIMM
I/O Control	• NS PC87417
Slots	Support PCI 64/33 MHz x 4 Slot
	PCI 32/33 MHz x 2 Slot
On-Board IDE	2 IDE bus master (ATA100) IDE ports for up to 4 ATAP1 devices
On-Board Peripherals	 1 Floppy port supports 360K, 720K,1.2M, 1.44M
	and 2.88M bytes.
	 1 Parallel port supports Normal/EPP/ECP mode
	 2 COM ports (COM1 & COM2; one at front and one at rear)
	 4 USB ports (Two ar front and two at rear)
Hardware Monitor	CPU/System Fan Revolution detect
	CPU/System Fan Fail Warning
	CPU/System Overheat Warning
	System Voltage Detect
	Caseopen intrusion

to be continued......

On-Board LAN	•	Build in Intel® 82540EM 10/100/1000 Gigabit Ethernet Chipset
		(Server Adaptec)
	•	Build-in Intel 82550PM 10/100 Fast Ethernet
On-Board VGA	•	Build in ATI Rage XL VGA PCI Chipset with 8M SDRAM on board
On-Board SCSI	•	Adaptec 7899W SCSI Chipset; Dual Channel Ultra 160
(For GA-8EGXR Only)		
PS/2 Connector	•	PS/2 Keyboard interface and PS/2 Mouse interace
BIOS	•	Licensed AMI BIOS, 4M bit Flash ROM
Additional Features	•	Wake on LAN (On board LAN 1 & LAN 2)
	•	Wake on Moderm
	•	Support Intel ZCR and Adaptec ZCR card
		(Note: Insert to the green PCI slot; For GA-8EGXR Only)

Please set the CPU host frequency in accordance with your processor's specifications. We don't recommend you to set the system bus frequency over the CPU's specification because these specific bus frequencies are not the standard specifications for CPU, chipset and most of the peripherals. Whether your system can run under these specific bus frequencies properly will depend on your hardware configurations, including CPU, Chipsets,SDRAM,Cards... .etc.

SYS_FAN4
CASEOPEN1


*SCSI 1 *SCSI 2 TERM_EN2

CLK_JP1

TO REPORT A WIND COMMENT OF THE PROPERTY OF THE PROPERT

GA-8EGXR Series Motherboard


GA-8EGXR Motherboard Layout



Chapter 2 Hardware Installation Process

To set up your computer, you must complete the following setups:

- Step 1- Install the CPU
- Step 2- Install memory modules
- Step 3- Install expansion cards
- Step 4- Connect ribbon cables, cabinet wires, and power supply
- Step 5- Setup BIOS software




Step 1: Install the Central Processing Unit (CPU)

Step 1-1: CPU Installation



CPU Top View



CPU Bottom View



- 1. Pull up the CPU socket lever and up to 90-degree angle.
- 3. Press down the CPU socket lever and finish CPU installation.




 Locate Pin 1 in the socket and look for a (golden) cut edge on the CPU upper corner. Then insert the CPU into the socket.

- Please make sure the CPU type is supported by the motherboard.
- If you do not match the CPU socket Pin 1 and CPU cut edge well, it will cause improper installation. Please change the insert orientation.

Step 1-2: CPU Heat Sink Installation



 Hook one end of the cooler bracket to the CPU socket first.



Hook the other end of the cooler bracket to the CPU socket.

- You should apply the thermal paste to provide better heat conduction between your CPU and heatsink.
- Make sure the CPU fan power cable is plugged in to the CPU fan connector, this completes the installation.
- Please refer to CPU heat sink user's manual for more detail installation procedure.

Step 2: Install memory modules

The motherboard has 4 dual inline memory module (DIMM) sockets. The BIOS will automatically detects memory type and size. To install the memory module, just push it vertically into the DIMM Slot. The DIMM module can only fit in one direction due to the notch. Memory size can vary between sockets.



Registered DDR



- 1. The DIMM slot has a notch, so the DIMM memory module can only fit in one direction.
- 2. Insert the DIMM memory module vertically into the DIMM slot. Then push it down.
- Close the plastic clip at both edges of theDIMM slots to lock the DIMM module.
 Reverse the installation steps when you wish to remove the DIMM module.
- Please note that the DIMM module can only fit in one direction due to the one notches. Wrong orientation will cause improper installation. Please change the insert orientation.


Step 3: Install expansion cards

- 1. Read the related expansion card's instruction document before install the expansion card into the computer.
- 2. Remove your computer's chassis cover, screws and slot bracket from the computer.
- 3. Press the expansion card firmly into expansion slot in motherboard.
- 4. Be sure the metal contacts on the card are indeed seated in the slot.
- 5. Replace the screw to secure the slot bracket of the expansion card.
- 6. Replace your computer's chassis cover.
- 7. Power on the computer, if necessary, setup BIOS utility of expansion card from BIOS.
- 8. Install related driver from the operating system.



Step 4: Connect ribbon cables, cabinet wires, and power supply

Step 4-1: I/O Back Panel Introduction



PS/2 Keyboard and PS/2 Mouse Connector




PS/2 Mouse Connector (6 pin Female)



PS/2 Keyboard Connector (6 pin Female)


➤ This connector supports standard PS/2 keyboard and PS/2 mouse.

USB Connector



➤ Before you connect your device(s) into USB connector(s), please make sure your device(s) such as USB keyboard, mouse, scanner, zip, speaker..etc. Have a standard USB interface. Also make sure your OS (Windows 2000, Win dows ME, Win NT with SP 6) supports USB controller. If your OS does not support USB controller, please contact the OS vendor for pos sible patch or driver upgrade. For more information please contact your OS or device(s) vendors.

3 Parallel Port / Serial Port / VGA Port (LPT/COMA/VGA)



➤ This connector supports 1 standard COM port ,1 Parallel port and 1 VGA port. Device like printer can be connected to Parallel port; mouse and modem etc can be connected to Serial ports.

⑤/**③** LAN1 / LAN2 Port






➤ LAN 2: Giagbit Ethernet 10/100/100

➤ LAN 1: 10/100 Ethernet

LAN1 / LAN2 LED Indicator Description

LAN Port	Status	Description
LAN 1	Yellow LED Blink	LAN1 active
	Yellow LED On	LAN1 connected
	Green LED On	LAN1 at Speed 100MB
	Green LED Off	LAN1 at speed 10MB
LAN 2	Yellow LED Blink	LAN2 active
	Yellow LED On	LAN2 connected
	Green LED On	LAN2 at speed 100/1000MB
	Green LED Off	LAN2 at speed 10MB


Step 4-2: Connectors Introduction



A) ATX1	K) System FAN 3
B) ATX2	L) System FAN 4
C) IDE1	M) SCSI 1
D) IDE2	N) SCSI 2
E) FDD1	O) CPU FAN1
F) F_PANEL1	P) WOL1
G) USB2	Q) WOM1
H) COM2	R) CASEOPEN
I) System FAN 1	S)BT
J) System FAN 2	


▶ Note: the * indicates the feature is available for GA-8EGXR only

A) ATX1 (2x10 Pin ATX Power)



➤ AC power cord should only be connected to your power supply unit after ATX power cable and other related devices are firmly connected to the mainboard.

B) ATX2 (+12V Power Connector)



➤ This connector (ATX +12V) is used only for CPU Core Voltage.


Q) CPU FAN 1 Connector




➤ Please note, a proper installation of the CPU cooler is essential to prevent the CPU from running under abnormal condition or damaged by overheating. The CPU fan connector supports Max. current up to 600mA.

I / J / K / L) System FAN 1/2/3/4 Connectors







H) COM 2 Connector



P) Wake On LAN Connector



M / N) *SCSI1/SCSI2 Connector




Q) Wake On Ring Connector




▶ Note: the * indicates the feature is available for GA-8EGXR only

C / D) IDE 1/ IDE 2 [IDE1 / IDE2 / Connectors(Primary/Secondary)]




E) FDD1 (Floppy Connector)



Floppy


R) CASE OPEN



> Please note that uder normal circumstance, the CASEOPEN connector is set at closed status. When it is at open status (for example, the chassis cover is opened) system will alarm warning beeping.

We recommend user to use the **Normal-Close** switch.

G) USB2



➤ Be careful with the polarity of the front panel USB connector. Check the pin assignment while you connect the front panel USB cable. Please contact your nearest dealer for optional front panel USB cable.

S) BT1 (Battery)


Li-Battery 3V



CAUTION

- Danger of explosion if battery is incorrectly replaced.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the manufacturer's instructions.


F) F_PANEL1 (2x15 Pins connector)



1) HD+ (HDD LED)	2) HD- (HDD LED)
3) PD- (Power LED)	4) SK- (Speaker)
5) PD- (Power LED)	6) NC (Not Connect)
7) PD+ (Power LED)	8) NC (Not Connect)
9) PW+ (Power Switch)	10) SK+ (Speaker)
11) PW- (Power Switch)	12) RS+ (Reset Button)
13) KEY (Not Connect)	14) RS- (Reset Button)
15) GD+ (System Sleep LED)	16) GD- (System Sleep LED)
17) GN+ (System Sleep Switch)	18) GN- (System Sleep Switch)
19)BS+ (Not Connect)	20) BS- (Not Connect)
21) AE+ (Not Connect)	22) AE- (Not Connect)
23) HE+ (Not Connect)	24) HE- (Not Connect)
25)FE+ (Not Connect)	26) FE- (Not Connect)
27)PE+ (Not Connect)	28) PE- (Not Connect)
29) IR+ (Not Connect)	30) IR- (Not Connect)

[➤] Please connect the power LED, PC speaker, reset switch and power switch etc of your chassis front panel to the F_PANEL1 connector according to the pin assignment above.


Step 4-3: Jumper Setting Introduction



1)	CLK_JP1	6) TERM_EN2
2)	CMOS_CLR1	7) LAN1_EN1
3)	WRITE_P1	8) VGA_EN1
4)	SCSI_EN1	9) LAN2_EN1
5)	TERM_EN1	

Please note that the highlight white mark on the motherboard is presented as Pin 1

1) CLK_JP1




2-3 dose: CPU Speed at 533MHz (Default)

1 000

None: CPU Speed at 400MHz

♦ Please note that the highlight white mark is presented as Pin 1.

2) CMOS_CLR1 (Clear CMOS Function)




1-2 close: Clear CMOS

2-3 close: Normal (Default)

➤ Please note, You may clear the CMOS data to its default values by this jumper


3) WRITE_P1 (Write Protect Function)



1 OOO 1-2 dose: BIOS Write Protect Enables

1 2-3 close: Writer Protect Disabled (Default)


4) SCSI_EN1 (SCSI Function)



1 O O 1-2 close: SCSI Enabled (Default)

1 O O 2-3 close: SCSI Disabled

5) TERM_EN1 (SCSI1 On-Board Terminator Function)




1 OOO 1-2 close: SCSI Terminator Enabled (Default)

1000

2-3 close: SCSI Terminator

Disabled


6) TERM_EN2 (SCSI2 On-Board Terminator Function)



1 1-2 close: SCSI Terminator Enabled

1 2-3 close: SCSI Terminator Disabled


7) LAN1_EN1 (LAN1 Function)



1 1-2 close: LAN1 Enabled (Default)

1 2-3 close: LAN1 Disabled


8) VGA_EN1 (VGA Function)



1 OOO 1-2 close: VGA Enabled (Default)

1 2-3 close: VGA Disabled

9) LAN2_EN1 (LAN2 Function)



1 1-2 close: LAN2 Enabled (Default)

1 2-3 close: LAN2 Disabled

Chapter 3 BIOS Setup

BIOS Setup is an overview of the BIOS Setup Program. The program that allows users to modify the basic system configuration. This type of information is stored in battery-backed CMOS RAM so that it retains the Setup information when the power is turned off.

ENTERING SETUP

Power ON the computer and press immediately will allow you to enter Setup.

CONTROL KEYS

COMING	AL KEIS				
< ↑ >	Move to previous item				
<√>	Move to next item				
< ← >	Move to the item in the left hand				
< >> >	Move to the item in the right hand				
<esc></esc>	Main Menu - Quit and not save changes into CMOS Status Page Setup Menu and				
	Option Page Setup Menu - Exit current page and return to Main Menu				
<+/PgUp>	Increase the numeric value or make changes				
<-/PgDn>	Decrease the numeric value or make changes				
<f1></f1>	General help, only for Status Page Setup Menu and Option Page Setup Menu				
<f2></f2>	Reserved				
<f3></f3>	Reserved				
<f4></f4>	Reserved				
<f5></f5>	Restore the previous CMOS value from CMOS, only for Option Page Setup Menu				
<f6></f6>	Reserved				
<f7></f7>	Load the Optimized Defaults				
<f8></f8>	Reserved				
<f9></f9>	Reserved				
<f10></f10>	Save all the CMOS changes, only for Main Menu				

GETTING HELP

Main Menu

The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Status Page Setup Menu / Option Page Setup Menu

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc>.

Mair

This setup page includes all the items in standard compatible BIOS.

Advanced

This setup page includes all the items of AMT special enhanced features. (ex: Auto detect fan and temperature status, automatically configure hard disk parameters.)

Security

Change, set, or disable password. It allows you to limit access the system and setup.

Boo

This setup page include all the items of first boot function features.

• Exit

There are five options in this selection: Exit Saving Changes, Exit Discarding Changes, Load Optimal Defaults, Load Failsafe Defaults, and Discard Changes.

Main (BIOS Version)

Once you enter AMI BIOS CMOS Setup Utility, the Main Menu (Figure 1) will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

		AMI EAS	AMI EASY Setup Utility			
Main	Advanced	Security	Boot	Exit		
System	Date:	Aug 14 2	2002		[Setup Help]	
System	Time:	00:13:12	2			
Floppy	Drive A:	1.44MB	31/2			
Floppy	Drive B:	Not Insta	illed			
▶ Prima	ary IDE Master	ST38002	21A			
▶ Prim	ary IDE Slave					
▶ Sec	ondary IDE Master					
▶ Sec	ondary IDE Slave					
▶ Sys	tem Information					
F1: Help	↑↓: Sele			J	F5: Setup Defaults	
Esc: Exit	←→: Se	elect Menu	Enter: Se	lect ▶ Sub-	-Menu F10: Save&Exit	

Figure 1: Main

♡ System Date

Set the System Date. Note that the "Day" automatically changed after you set the date. (Weekend: DD: MM: YY) (YY: 1099~2099)

♡ System Time

The time is calculated based on the 24-hour military time clock. Set the System Time (HH:MM:SS)

☐ Floppy Drive A/B

This category identifies the type of floppy disk drive A or drive B that have been installed in the computer.

None No floppy drive installed
▶1.2MB, 3.5 in. 3.5 inch AT-type high-density drive; 1.2M byte capacity
▶720K, 3.5 in. 3.5 inch double-sided drive; 720K byte capacity
▶1.44M, 3.5 in. 3.5 inch double-sided drive; 1.44M byte capacity
▶2.88M, 3.5 in. 3.5 inch double-sided drive; 2.88M byte capacity

○ IDE Primary Master, Slave / Secondary Master, Slave

The category identifies the types of hard disk from driveC to F that has been installed in the computer. There are two types: auto type, and manual type. Manual type is user-definable; Auto type which will automatically detect HDD type.

Note that the specifications of your drive must match with the drive table. The hard disk will not work properly if you enter improper information for this category.

If you select User Type, related information will be asked to enter to the following items. Enter the information directly from the keyboard and press <Enter>. Such information should be provided in the documentation form your hard disk vendor or the system manufacturer.

▶ TYPE

1-50: Predefined types.

Users: Set parameters by User.

Auto: Set parameters automatically. (Default Vaules)

CD-ROM: Use for ATAPI CD-ROM drives or double click [Auto] to set all HDD parameters

automatically.

➤ Cy linders
 ➤ Write Precompensation
 ➤ Sectors
 ➤ Maximum Capacity
 Number of cy linders
 Write precompensation
 Number of sectors
 Maximum Capacity

▶LBA Mode This field shows if the device type in the specific IDE channel

support LBA Mode

▶ Block Mode This field only shows the information of Block Mode.

▶ Fast Programmed I/O Mode This field only shows the information of Fast Programmed

I/O Mode

▶32 Bit Transfer Mode Enables 32 bit access to maximize the hard disk data

transfer rate

Option: On (Default Value); Off

If a hard disk has not been installed select NONE and press <Enter>.

♡ System Information

This category displays the system information on CPU Type, Speed, Cache and Memory.

Advanced




Figure 2: Advanced

About This Section: Advanced

This section "Advanced" is divided into six sub-menus.

- Advanced Configuration
- Chipset Configuration
- **◆** Power Management Configuration
- ◆ Plug & Play Configuration
- **◆** Peripheral Configuration
- Hardware Monitor Configuration

With this section, allowing user to configure your system for basic operation. A user can change the system's default boot-up sequence, keyboard operation, shadowing and security, etc.

Advanced Configuration

	AMI EASY Setup Utility							
Main	Adv anced	Security	Boot	Exit				
	Adv anced Configu	ıration			[Setup Help]			
Show	Full Screen Logo		Enabled					
S.M.A	.R.T for Hard Disk		Disabled					
MPS V	ersion for O.S		1.4					
	Num-Lock per Threading		On Enabled					
CPU F	Ratio		Auto					
*CPU	Ferquency Ratio		Locked					
F1: Help Esc: Exi		ect Item lect Menu	+ -: Change Enter: Selec		F5: Setup Defaults Menu F10: Save&Exit			

Figure 2-1: Adv anced Configuration

→ Advanced Configuration

This category allow user to configure advanced functions.

▶ Show Full Screen Logo (If vaild)

▶ Enabled Enable Show Full Screen Logo function. (Default Value)

→ Disabled Disable this function.

▶ S.M.A.R.T for Hard Disk

This filed shows if the device in the specific IDE channel supports S.M.A.R.T.

S.M.A.R.T stands for Self-Monitoring Analysis and Reporting Technology.

▶ Enabled Set this option "Enable" to permit BIOS to use S.M.A.R.T.

▶ Disabled Disable S.M.A.R.T function. (Default Value)

▶ MPS Version for O.S

This option allows a user to select MP (Multi Processors) system supported version.

Note: Some old MPS OS support 1.1 version only.

▶ 1.4 Support MPS Version 1.4. (Default Value)

▶ 1.1 Support MPS Version 1.1.

▶ BootUp Num-Lock

▶ ON Set this option "On" to turn the Num Lock On at a system boot. (Default Value)

→ OFF Disable this function.

▶ Intel Hyer Threading

▶ Enabled Enable Inel Hyper Threading. (Default Value)

▶ Disabled Disable Inel Hyper Threading.

▶ CPU Ratio

→ Auto Set the CPU Ratio at Auto Mode (Default Value)

► Manual Set the CPU Ratio at Manual Mode

Note that it will not have any effect on the CPU Frequency whether uesr set the CPU Ratio at Auto or Manual mode.

Chipset Configuration

	AMI EASY Setup Utility						
Main	Adv anced	Security	Boot	Ex	it		
	Chipset Configuration	on			[Setup Help]		
Memroy	Scrubbing		Enabled				
F1: Help	↑↓: Selec	t Item	+ -: Change \	/alue	es F5: Setup Defaults		
Esc: Exit	c: Exit ←→: Select Menu Enter: Select ▶ Sub-Menu F10: Save&Exit						

Figure 2-2: Chipset Configuration

⇔ Chipset Configuration

▶ Memory Scrubbing

▶ Enabled Enable this option to write back the ECC corrected memory data to the

DRAM. (Default Value)

▶ Disabled Disable this function.

Power Management Configuration

AMI EASY Setup Utility					
Main	Adv anced	Security	Boot	Exit	
Power Management Configuration					[Setup Help]
Soft-off by Power Button			Instant-off		
Sleep Button			Enabled		
Wake Up On Ring			Enabled		
System After AC Back			Off		
F1: Help	↑ ↓: Se	lect Item	+ -: Change	e Values	F5: Setup Defaults
Esc: Exi	Esc: Exit ←→: Select Menu Enter: Select ▶ Sub-Menu F10: Save&Exit				

Figure 2-3: Power Management Configuration

Power Management Configuration

The Power Management Configuration allows you to reduce system power consumption through different saving power methods for various devices.

▶ Soft-Off by Power Button

- ▶Instant-off Turn off system as soon as power button is pressed.
- Delay 4 Sec Turn off system when power button is pressed and hold for more than 4 seconds.

▶ Sleep Button

Leaves on the default for best compatibility

- ▶ Enabled Enable Sleep Button. (Default Value)
- → Disabled Disable this function.

▶ Wake Up Ring

System is waken up when Moderm-Ring is on.

► Enabled Enable Wake Up Ring. (Default Value)

Disabled Disable this function.

▶ System After AC Back

System power state when AC cord is re-plugged.

▶ Pre-State Set system power to the last state when AC power is removed.▶ OFF Do not power on system when AC power is back. (Default Value)

Plug and Play Configuration

		AMI EAS	SY Setup Utility		
Main	Adv anced	Security	Boot	Exi	it
	Plug and Play Co	nfiguration			[Setup Help]
PCI Slot	1/5 IRQ Priority		Auto		
PCI Slot	2/6 IRQ Priority		Auto		
PCI Slot	3 IRQ Priority		Auto		
	4 IRQ Priority		Auto		
IRQ 3			PCI/PnP		
IRQ 4			PCI/PnP		
IRQ 5			PCI/PnP		
IRQ 7			PCI/PnP		
IRQ 9			PCI/PnP		
IRQ 10			PCI/PnP		
IRQ 11			PCI/PnP		
IRQ 14			PCI/PnP		
IRQ 15			PCI/PnP		
F1: Help Esc: Exit	↑↓: Sele ←→: Se	ect Item lect Menu	+ -: Change Value Enter: Select		•

Figure 2-4: Plug and Play Configuration

Plug & Play Configuration

This option describes the configuration of PCI bus system, or Personal Conputer Interconnect, is a system which allows I/O devices to operate at a speeds nearing the speed the CPU itself uses when communicating with its own special components. This section covers some technical items and it is stongly recommended that only experienced users can make changes to the default settings.

▶ PCI Slot 1/5 IRQ Priority

Select PCI Slot 1/5 IRQ Priority.

➤ Auto Auto assign IRQ to PCI 1/5 (Default Value)

▶ 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 1/5

▶ PCI Slot 2/6 IRQ Priority

Select PCI Slot 2/6 IRQ Priority.

Auto Auto assign IRQ to PCI 2/6 (Default Value)

▶ 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 2/6

▶ PCI Slot 3 IRQ Priority

Select PCI Slot 3 IRQ Priority.

→ Auto Auto assign IRQ to PCI 3 (Default Value)

▶ 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 3

▶ PCI Slot 4 IRQ Priority

Select PCI Slot 4 IRQ Priority.

→ Auto Auto assign IRQ to PCI 4 (Default Value)

▶ 3, 4, 5, 7, 9, 10, 11 Set 3, 4, 5, 7, 9, 10, 11 to PCI 4

▶ IRQ 3, 4, 5, 7, 9, 10, 11, 14, 15

This option allows a user to set if let BIOS detect the IRQ events. When the BIOS detects an IRQ trigger event being actived, the system will wake up and resumes its activities.

Option: PCI/PnP (Default Value); ISA

Peripheral Configuration

			SY Setup Utility		
Main	Adv anced	Security	Boot	Exi	t
	Peripheral Config	uration			[Setup Help]
OnBoa	rd IDE		Both		
OnBoa	rd FDC		Enabled		
OnBoa	rd Serial Port A		3F8/COM1		
OnBoa	rd Serial Port B		2F8/COM2		
OnBoa	OnBoard Parallel Port		378		
Pa	rallel Port Mode		ECP		
Pa	rallel Port IRQ		7		
Pa	rallel Port DMA		3		
USB F	unction		Enabled		
USB L	egacy		Disabled		
Port 64	Port 64/60 Emulation		Disabled		
F1: Help			+ -: Change		·
Esc: Exi	t ←→: Se	elect Menu	Enter: Selec	t ▶ Sı	ıb-Menu F10: Save&Exit

Figure 2-5: Peripheral Configuration

☞ Peripheral Configuration

▶ OnBoard IDE

Option: Both (Default Value), Primary, Secondary, Disabled

▶ OnBoard FDC

▶ Enabled Select "Enabled" to active Onboard Floppy Controller. (Default Value)

→ Disabled Disable this function.

OnBoard Serial Port A

This option specifies the base I/O port address of serial prot A.

▶ 3F8/COM1 Enable onboard serial port A and set I/O address to 3F8/COM1. (Default value)
 ▶ 2F8/COM2 Enable onboard serial port A and set I/O address to 2F8/COM2.
 ▶ 3E8/COM3 Enable onboard serial port A and set I/O address to 3E8/COM3.
 ▶ 2E8/COM4 Enable onboard serial port A and set I/O address to 2E8/COM4.

▶ OnBoard Serial Port B

This option specifies the base I/O port address of serial prot B.

→ 3F8/COM1 Enable onboard serial port A and set I/O address to 3F8/COM1.
 → 2F8/COM2 Enable onboard serial port A and set I/O address to 2F8/COM2. (Default value)
 → 3E8/COM3 Enable onboard serial port A and set I/O address to 3E8/COM3.
 → 2E8/COM4 Enable onboard serial port A and set I/O address to 2E8/COM4.

► OnBoard Parallel Port

This option specifies the base I/O address of the parallel prot on the motherboard.

▶ 378 Enable onboard LPT port and set I/O address to 378. (Default value)

▶278 Enable onboard LPT port and set I/O address to 278
 ▶3BC Enable onboard LPT port and set I/O address to 3BC

▶ Parallel Port Mode

This option specifies the parallel mode.

Normal The normal parallel pro is used.

▶ Bi-Directional Use this setting to support bi-directional transfers on the parallel port.

▶ EPP The parallel port can be used with devices that adhere to the

enhanced Parallel Port (EPP) specifications. EPP uses the existing parallel port signal to provide asymmetric bi-directional

data transfer driven by the host device.

▶ECP The parallel port can be used with devices that adhere to the

extended Capabilities Port specifications. ECP uses the DMA protocol to achieve data transfer rate up to 2.5Mbit/s. ECP provides the symmetric bi-directional communication. (Default value)

▶ Parallel Port IRQ

This option is to select Parallel Port IRQ Option: 7 (Default Value), 5

▶ Parallel Port DMA

This option iallows user to select Parallel Port DMA.

Option: 3 (Default Value), 1

▶ USB Function

This option allows user to enable USB host controller.

► Enable USB host controller. (Default Value)

▶ Disabled Disable this function.

▶ USB Legacy Support

This option allows user to function support for legacy USB.

▶ Enable Enable support for legacy USB.

▶ Disabled Disable support for legacy USB. (Default value)

▶ Port 64/60 Emulation

This option allows user to enable or disable the Port 64/60 Emulation function.

▶ Enable Enables the Port 64/60 Emulation function▶ Disabled Disable this function. (Default Value)

Hardy	ware Monito	r Configu	ıration		DIO3 3014
		AMI EAS	SY Setup Utility	У	
Main	Adv anced	Security	Boot	Exit	
Hardw a	are Monitor Configur	ation			[Setup Help]
CPU T	emperature		+39°C/+10	2°F	
System	n Temperature		+39°C/+10	2°F	
CPU_F	AN Speed		RPM		
SYS_F	AN1 Speed		RPM		
SYS_F	AN2 Speed		RPM		
SYS_F	AN3 Speed		RPM		
SYS_F	AN4 Speed		RPM		
VCC_P			1.952V		
VCC 2.	.5		0.000V		
VCC 3			0.000V		
VCC 5			0.000V		
VCC 12	2		0.000V		
VBAT			0.000V		
5VSB			0.000V		
Hardw a	are Monitor Alarm		Disabled		
SYS_T	EM. Buzzer Alarm		Disabled		
CPU_F	AN1 Buzzer Alarm		Disabled		
SYS_F	AN1 Buzzer Alarm		Disabled		
SYS_F	AN2 Buzzer Alarm		Disabled		
SYS_F	AN3 Buzzer Alarm		Disabled		
SYS_F	AN4 Buzzer Alarm		Disabled		
VCC_F	Buzzer Alarm		Disabled		
Case C	Open Alarm		Disabled		
Case C	Open Status		Close		
Reset (Case Open Status		No		
F1: Help Esc: Exit	1↓: Sel t ←→: Se	ect Item elect Menu	+ -: Change Enter: Sele		F5: Setup Defaults Menu F10: Save&Exit

Figure 2-6: Hardware Monitor Configuration

☼ Hardware Monitor Configuration

This section provides the system hardware health information to user for reference.

▶ CPU Temperature

This field only displlays the current CPU temperature.

▶ System Temperature

This field only displlays the current system temperature.

▶ CPU FAN Speed

This field indicates the RPM (Ratio Per Minute) of current CPU speed.

▶ SYS FAN 1 / 2 / 3 / 4 Speed

This field indicates the RPM (Ratio Per Minute) of System Fan 1/2/3/4 speed.

▶ VCC_P / VCC 2.5 / VCC 3 / VCC5 / VBAT/12V/5VSB

This field only displays the current CPU / System voltage.

► Hardwae Monitor Alarm

This field allows user to monitor and to ser the set the warning values to protect the system hardware health. Enable this function to active the following desired items.

► SYS_TEM. Buzzer Alarm

Enable this function is protecting the System temperature is under the set value. System will alarm when the system temperature is over the set value.

▶ Enabled Enable system temperature buzzer alarm. It will alarm if the system

temperature is over 55°C

→ Disabled Disable this function.

► CPU_TEM. Buzzer Alarm

Enable this function is protecting the CPU temperature is under the set value. System will alarm when the CPU temperature is over the set value.

▶ Enabled Enable CPU temperature buzzer alarm. System will alarm if the CPU

temperature is over 85°C.

▶ Disabled Disable this function.

► CPU_FAN and SYS_FAN1/2/3/4 Buzzer Alarm

When this function is enabled, system will alarm when CPU and System FAN1/2/3/4 stop.

▶ Enabled Enable CPU FAN and System FAN 1/2/3/4 buzzer alarm.

▶ Disabled Disable this function.

▶ VCC_P Buzzer Alarm

Enable this function is protecting the system voltage is under the set value. System will alarm when the voltage is over the set value.

▶ Enabled Enable VCC_P buzzer alarm.

→ Disabled Disable this function.

▶ Case Open Alarm

This optionallows user to set the case open alarm by physical warning alert. Once the chassis is opened, the system will rise warning beep to alarm user to close the case properly.

▶ Enabled Enable Case Open alarm.▶ Disabled Disable this function.

Case Status

This item displays the status of system case.

► Reset Case Open Status

This function provides user to stop the case open warning beep. Once the case is opened, the system will rise waring alert. To stop the beep, user is required to enter the setup menu and rest the case open status to "Yes" option.

Security

		AMI EASY	Setup Utility		
Main	Adv anced	Security	Boot	Exit	
					[Setup Help]
Set Supervis	sor Password	[Enter]			
Set User Pa	issw ord	[Enter]			
Password C	Check	Setup			
F1: Help	↑ ↓: Se	lect Item	+ -: Chan	ge Values	F5: Setup Defaults
Esc: Exit	←→: S	elect Menu	Enter: Se	lect ▶ Sub	o-Menu F10: Save&Exit

Figure 3: Security

d About This Section: Security

In this section, user can set either supervisor or user passwords, or both for different level of password securities. In addition, user also can set the virus protection for boot sector.

Set Supervis or Pass word

You can install and change this options for the setup menus. Type the password up to 6 characters in length and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password or press <Enter> key to disable this option.

⇔Set User Password

You can only enter but do not have the right to change the options of the setup menus. When you select this function, the following message will appear at the center of the screen to assist you in creating a password.

Type the password up to 6 characters in lengh and press <Enter>. The password typed now will clear any previously entered password from the CMOS memory. You will be asked to confirm the entered password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a specified password.

Password Check

Setup will check password while invlolking setup.

Always will check the password while involking setup as well as on each boot. Option: Setup (Default Value), Always

Boot

		AMI EAS	SY Setup Utility			
Main	Adv anced	Security	Boot	Exit		
						[Setup Help]
Boot Dev	ice Priority					
Floppy:	1.44 MB 3 ^{1/2}					
CD/DVD	C-540E					
IDE-0: S	T380021A					
OnBoard	82540 LAN Boot I	ROM	Enabled			
OnBoard	82550 LAN Boot I	ROM	Enabled			
OnBoard	SCSI ROM		Enabled			
F1: Help	↑↓: Sele	ect Item	+ -: Change	Values	F5:	: Setup Defaults
Esc: Exit	←→: Se	lect Menu	Enter: Selec	t ▶ Sub-M	enu	F10: Save&Exit

Figure 4: Boot

d About This Section: Boot

The "Boot" menu allows user to select among four possible types of boot devices listed using the up and down arrow keys. By applying <+> and <Space> key, you can promote devices and by using the <-> key, you can demote devices. Promotion or demotion of devices alerts the priority that the system uses to search for boot device on system power on.

⇔ Boot Device Priority

▶ 1st / 2nd / 3 rd Boot Device

These three fields determines which type of device the system attempt to boot from after **AMIBIOS Post** completed. Specifies the boot sequence from the available devices. If the first device is not a bootable device, the system will seek for next available device.

The Choice for 1st Boot Device: Removable Device (Default Value), ATAPI CDROM, Hard Disk, Disabled.

The Choicefor 2nd Boot Device: Removable Device , ATAPI CDROM (Default Value) , Hard Disk. Disabled.

The Choice for 3rd Boot Device: Removable Device, ATAPI CDROM, Hard Disk (Default Value), Disabled.

▶ OnBoard 82540 LAN Boot ROM

▶ Enabled Enable OnBoard 82540 LAN Boot ROM. (Default Value)

→ Disabled Disable this function.

▶ OnBoard 82550 LAN Boot ROM

► Enabled Enable OnBoard 82550 LAN Boot ROM. (Default Value)

Disabled Disable this function.

▶ OnBoard SCSI ROM

▶ Enabled Enable OnBoard SCSI Boot ROM. (Default Value)

→ Disabled Disable this function.

Exit

		AMI EAS'	Y Setup Utility		
Main	Advanced	Security	Boot	Exit	
					[Setup Help]
Ex it Sav in	g Changes	Enter		-	
Exit Discar	ding Changes	Enter			
Load Defau	ult Settings	Enter			
Load Origin	nal Values	Enter			
F1: Help	↑↓: Sele		+ -: Change		F5: Setup Defaults
Esc: Exit	←→: Se	lect Menu	Enter: Selec	t ▶ Sub-I	Menu F10: Save&Exit

Figure 5: Exit

d About This Section: Security

Once you have changed all of the set values in the BIOS setup, you should save your changes and exit BIOS setup program. Select "Exit" from the menu bar, to display the following sub-menu.

- **◆** Exit Saving Changes
- **◆** Exit Discarding Changes
- **◆** Load Default Settings
- ◆ Load Original Values

▽Exit Saving Changes

This option allows user to exit system setup with saving the changes.

Press <Enter> on this item to ask for the following confirmation message:

Pressing Y' to store all the present setting values that user made in this time into CMOS.

Therefore, when you boot up your computer next time, the BIOS $\mbox{\em will}$

re-configure your system according data in CMOS.

▽Exit Discarding Changes

This option allows user to exit system setup without changing any previous settings values in CMOS. The previous selection remain in effect.

This will exit the Setup Utility and restart your compuetr when selecting this option.

Press < Enter> on this item to ask for confirmation message.

□ Load Default Settings

When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:

[Load Default Settings]
Press [Enter] to continue
Or [ESC] to Abort

□ Load Original Values


When you press <Enter> on this item, you will get a confirmation dialog box with a message as below:

[Load Original Values]
Press [Enter] to continue
Or [ESC] to Abort

Press [Enter] to load the default values that are factory settings for optimal performance system operations.

Chapter 4 Technical Reference

Block Diagram




Chapter 5 Appendix

Appendix A: Intel 82540EM 82550PM Network Driver Installation

(For example: Driver CD Ver.: 1.0)


Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show a series of Setup Wizard dialog boxes. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.



Step 4. Note that user can select either **Typical** or **Custom** Setup Types. **Typical** setup type allows users to install basic connectivity and the adapter management utility. **Custom** setup type embraces installing features and subfeatures user selects, including modern utilities, manage ment components and drivers. Recommended for advanced users.

GA-8EGXR Series Motherboard







(7)



Appendix B: ATI Rage XL VGA Driver Installation


Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.





(2)






Appendix C: Adaptec SCSI Driver Installation

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.





Appendix D: Utilities Installation

Insert the driver CD-title that came with your motherboard into your CD-ROM driver, the driver CD-title will auto start and show the installation guide. If not, please double click the CD-ROM device icon in "My computer", and execute the setup.exe.

The Utilities item contains the utility of DirectX 8.1, Adabe Acrobate Reader V.5.0, and Norton Internet Security 2002





(1)

(2)

Appendix E: About Updating latest version of BIOS

To update the latest BIOS version, please go to Gigabyte Networking official web site: **Http://networking.gigabyte.com.tw**

Appendix G: Acronyms

Acronyms	Meaning	
ACPI	Advanced Configuration and Power Interface	
APM	Advanced Power Management	
AGP	Accelerated Graphics Port	
AMR	Audio Modem Riser	
ACR	Advanced Communications Riser	
BBS	BIOS Boot Specification	
BIOS	Basic Input / Output System	
CPU	Central Processing Unit	
CMOS	Complementary Metal Oxide Semiconductor	
CRIMM	Continuity RIMM	
CNR	Communication and Networking Riser	
DMA	Direct Memory Access	
DMI	Desktop Management Interface	
DIMM	Dual Inline Memory Module	
DRM	Dual Retention Mechanism	
DRAM	Dynamic Random Access Memory	
DDR	Double Data Rate	
ECP	Extended Capabilities Port	
ESCD	Extended System Configuration Data	
ECC	Error Checking and Correcting	
EMC	Electromagnetic Compatibility	
EPP	Enhanced Parallel Port	
ESD	Electrostatic Discharge	
FDD	Floppy Disk Device	
FSB	Front Side Bus	
HDD	Hard Disk Device	
IDE	Integrated Dual Channel Enhanced	
IRQ	Interrupt Request	
I/O	Input / Output	
IOAPIC	Input Output Advanced Programmable Input Controller	
ISA	Industry Standard Architecture	
		to be continued

Acronyms	Meaning
LAN	Local Area Network
LBA	Logical Block Addressing
LED	Light Emitting Diode
MHz	Megahertz
MIDI	Musical Instrument Digital Interface
MTH	Memory Translator Hub
MPT	Memory Protocol Translator
NIC	Network Interface Card
OS	Operating System
OEM	Original Equipment Manufacturer
PAC	PCT A.G.P. Controller
POST	Power-On Self Test
PCI	Peripheral Component Interconnect
RIMM	Rambus in-line Memory Module
SCI	Special Circumstance Instructions
SECC	Single Edge Contact Cartridge
SRAM	Static Random Access Memory
SMP	Symmetric Multi-Processing
SMI	System Management Interrupt
USB	Universal Serial Bus
VID	Voltage ID
ZCR	Zero Channel RAID

Customer/Country:		Company	:	Phone No.:	
Contact Person:		E-mail Add. :		· ·	
		•			
Model name/Lo	t Number:			PCB revision:	
BIOS version:		O.S./A.S.:			
Hardware	Mfs.	Model name	Size:	Driver/Utility:	
Configuration					
CPU					
Memory					
Brand					
Video Card					
Audio Card					
HDD					
CD-ROM /					
DVD-ROM					
Modem					
Network					
AMR/CNR					
Keyboard					
Mouse					
Power supply					
Other Device					
Problem Descri					