

SPARC M10 システム はじめにお読みください

Fujitsu M10/SPARC M10 Systems Getting Started Guide

SPARC M10 システムドキュメントファイルへのアクセス

SPARC M10 システムのドキュメントは、以下のウェブサイトからご覧いただけます。

SPARC M10 システムマニュアル

日本語サイト <http://jp.fujitsu.com/platform/server/sparc/manual/>

グローバルサイト <http://www.fujitsu.com/global/services/computing/server/sparc/downloads/manual/>

Oracle Solaris などのオラクル社製ソフトウェア関連マニュアル

<http://www.oracle.com/documentation/>

注 - SPARC M10 システムのハードウェア、ファームウェア、ソフトウェア、ドキュメントに関する最新情報は、上述のウェブサイトに掲載された『SPARC M10 システム プロダクトノート』を参照してください。

注 - SPARC M10 システムは、Fujitsu M10 という製品名でも販売されています。SPARC M10 システムと Fujitsu M10 は、同一製品です。

マニュアルへのフィードバック

本書に関するご意見、ご要望がございましたら、マニュアル番号、マニュアル名称、ページおよび具体的な内容を次のウェブサイトからご連絡ください。

日本語サイト <http://jp.fujitsu.com/platform/server/sparc/manual/>

グローバルサイト <http://www.fujitsu.com/global/services/computing/server/sparc/downloads/manual/>

SPARC M10 システムのドキュメント

SPARC M10 システムに関連するドキュメントは、以下のとおりです。

注 - SPARC M10 システムを理解していただくために、仕様や概要をわかりやすく説明した『SPARC M10 システム 早わかりガイド』を用意いたしました。SPARC M10 システムの導入マニュアルとしてご活用ください。

注 - 掲載されるマニュアルは、予告なく変更される場合があります。

• SPARC M10 システム プロダクトノート

ハードウェア、ソフトウェアおよびマニュアルに関する重要かつ最新の情報を記載しています。導入前に、必ず確認してください。

• SPARC M10 システム はじめにお読みください (本書)

SPARC M10 システムに関連するドキュメントとその参照方法を記載しています。

- **Fujitsu M10/SPARC M10 Systems Important Legal and Safety Information**
ソフトウェア・ライセンス契約書、使用許諾契約書、安全のための注意事項を記載しています。ソフトウェア製品のパッケージを開封したり、筐体を設置したりする前に確認してください。
- **Fujitsu M10/SPARC M10 Systems Safety and Compliance Guide/ 安全に使用していただくために**
筐体の設置にあたっての注意事項を記載しています。筐体を設置する前に確認してください。
- **Software License Conditions for Fujitsu M10/SPARC M10 Systems/ ソフトウェアライセンス使用許諾条件**
SPARC M10 システムで使用しているソフトウェアのライセンス使用許諾条件を記載しています。
- **SPARC M10 Systems Security Guide**
SPARC M10 システム使用にあたってのセキュリティガイドラインを記載しています。
- **SPARC M10 システム/SPARC Enterprise/PRIMEQUEST 共通 設置計画マニュアル**
SPARC M10 システム、SPARC Enterprise および PRIMEQUEST を設置するための、設置計画および設備計画に必要な事項や考え方を説明しています。
- **SPARC M10 システム 早わかりガイド**
システム仕様やシステム構成などの概要と、SPARC M10 システムの導入から拡張・保守までの作業と各作業で使用するマニュアルについて説明しています。ほかのマニュアルを読む前に確認してください。
- **SPARC M10 システム インストールガイド**
筐体を設置する前の環境条件、導入時の設置および初期設定手順、運用開始後の増設・減設手順を説明しています。
- **SPARC M10 システム システム運用・管理ガイド**
運用開始後の管理・保守作業に関連する項目を説明しています。ドメイン設定については『SPARC M10 システムドメイン構築ガイド』、Field Replaceable Unit (FRU) ごとの保守手順については『SPARC M10-1 サービスマニュアル』、『SPARC M10-4/M10-4S サービスマニュアル』、『SPARC M10 システム版 PCI ボックス サービスマニュアル』をそれぞれ参照してください。
- **SPARC M10 システムドメイン構築ガイド**
システム運用・管理作業のうち、物理パーティションや論理ドメインを構築・管理するうえで必要な知識や手順を説明しています。
- **SPARC M10-1 サービスマニュアル**
SPARC M10-1 のシステム保守にあたって確認すべき情報や Field Replaceable Unit (FRU) ごとの保守手順を説明しています。
- **SPARC M10-4/M10-4S サービスマニュアル**
SPARC M10-4/M10-4S のシステム保守にあたって確認すべき情報や Field Replaceable Unit (FRU) ごとの保守手順を説明しています。
- **SPARC M10 システムクロスパーボックス サービスマニュアル**
クロスパーボックスのシステム保守にあたって確認すべき情報や Field Replaceable Unit (FRU) ごとの保守手順を説明しています。
- **SPARC M10 システム版 PCI ボックス サービスマニュアル**
PCI ボックスのシステム保守にあたって確認すべき情報や Field Replaceable Unit (FRU) ごとの保守手順を説明しています。
- **SPARC M10 システム PCI カード搭載ガイド**
SPARC M10 システムに搭載される PCI カードの搭載ルールについて説明しています。
- **SPARC M10 システム XSCF リファレンスマニュアル**
SPARC M10 システムに搭載されている XSCF ファームウェアで提供されるコマンドの使用方法を説明しています。
- **SPARC M10 システム RCIL ユーザーズガイド**
富士通のストレージシステム ETERNUS などの I/O デバイスの電源を、SPARC M10 システムから管理するための Remote Cabinet Interface over LAN (RCIL) 機能について説明しています。
- **SPARC M10 システム XSCF MIB・Trap 一覧**
SPARC M10 システムで使用する XSCF SNMP エージェント機能の Management Information Base (MIB) の値および MIB Trap の値について一覧形式で説明しています。
- **SPARC M10 システム用語集**
マニュアル中で使用される用語とその解説です。

Accessing the Documentation Files

Documents on SPARC M10 Systems are available on the following websites.

SPARC M10 Systems manuals

Japanese site	http://jp.fujitsu.com/platform/server/sparc/manual/
Global site	http://www.fujitsu.com/global/services/computing/server/sparc/downloads/manual/

Manuals related to Oracle Solaris or other Oracle software products

<http://www.oracle.com/documentation/>

Note – For the latest information regarding hardware, software, and documents of the SPARC M10 Systems, see the *Fujitsu M10/SPARC M10 Systems Product Notes* on the websites listed above.

Note – Fujitsu M10 is sold as SPARC M10 Systems by Fujitsu in Japan. Fujitsu M10 and SPARC M10 Systems are identical products.

Documentation Feedback

If you have a comment or request regarding this manual, please take a moment to share it with us by indicating the manual code, manual title, and page, and stating your points specifically through the following websites.

Japanese site	http://jp.fujitsu.com/platform/server/unix/manual/
Global site	http://www.fujitsu.com/global/services/computing/server/sparc/downloads/manual/

SPARC M10 Systems Documentation

The following table lists documents related to the SPARC M10 systems.

Note – The *Fujitsu M10/SPARC M10 Systems Quick Guide* has been prepared with easy-to-understand descriptions of specifications and an overview to facilitate readers' understanding of the SPARC M10 Systems. Use it as an installation manual for the SPARC M10 Systems.

Note – The listed manuals are subject to change without notice.

- **Fujitsu M10/SPARC M10 Systems Product Notes** describes important information and the latest information regarding the hardware, software, and their manuals. Before installation, be sure to check this document.
- **Fujitsu M10/SPARC M10 Systems Getting Started Guide (this document)** describes the documents related to the SPARC M10 Systems and how to reference them.
- **Fujitsu M10/SPARC M10 Systems Important Legal and Safety Information** describes the software license agreement, product license agreement, and notes on safety. Read this document before opening the software product package or installing a cabinet.
- **Software License Conditions for Fujitsu M10/SPARC M10 Systems** lists public licenses and conditions for the SPARC M10 Systems.

- **Fujitsu M10/SPARC M10 Systems Safety and Compliance Guide** describes notes on cabinet installation. Before installing a cabinet, be sure to check this document.
- **Fujitsu M10/SPARC M10 Systems Security Guide** provides general security guidelines for the SPARC M10 Systems.
- **Fujitsu M10/SPARC M10 Systems/SPARC Enterprise/PRIMEQUEST Common Installation Planning Manual** describes the requirements and concepts of installation and facility planning pertaining to Fujitsu M10/SPARC M10, SPARC Enterprise, and PRIMEQUEST installation.
- **Fujitsu M10/SPARC M10 Systems Quick Guide** provides an overview of SPARC M10 Systems including system specifications and configurations, the operations from installation of SPARC M10 Systems to their expansion and maintenance, and the manuals used for each operation. Check this document before reading other manuals.
- **Fujitsu M10/SPARC M10 Systems Installation Guide** describes the prerequisite environmental conditions for chassis installation, the installation and initial setting procedures used during installation, and the procedures for installing and removing components after operation has begun.
- **Fujitsu M10/SPARC M10 Systems System Operation and Administration Guide** describes items related to the management and maintenance work after operation has begun. For information on domain settings, see the Fujitsu M10/SPARC M10 Systems Domain Configuration Guide. For information on the maintenance procedures of individual field replaceable units (FRUs), see the Fujitsu M10-1/SPARC M10-1 Service Manual, the SPARC M10-4/M10-4S Service Manual, and the PCI Expansion Unit for SPARC M10 Systems Service Manual respectively.
- **Fujitsu M10/SPARC M10 Systems Domain Configuration Guide** describes the knowledge and procedures required to configure and manage physical partitions or logical domains during system operation management.
- **Fujitsu M10/SPARC M10-1 Service Manual** describes the information to be checked for system maintenance of the SPARC M10-1 and the maintenance procedures for each component.
- **Fujitsu M10-4/Fujitsu M10-4S/SPARC M10-4/SPARC M10-4S Service Manual** describes the information to be checked for system maintenance of the SPARC M10-4/M10-4S and the maintenance procedures for each component.
- **Crossbar Box for Fujitsu M10/SPARC M10 Systems Service Manual** describes the information to be checked for system maintenance of the crossbar box and the maintenance procedures for each component.
- **PCI Expansion Unit for Fujitsu M10/SPARC M10 Systems Service Manual** describes the information to be checked for system maintenance of PCI Expansion Unit and the maintenance procedures for each component.
- **Fujitsu M10/SPARC M10 Systems PCI Card Installation Guide** describes the mounting rules for PCI cards mounted in the Fujitsu M10 systems.
- **Fujitsu M10/SPARC M10 Systems XSCF Reference Manual** explains how to use the commands provided with the XSCF firmware mounted on the SPARC M10 Systems.
- **Fujitsu M10/SPARC M10 Systems RCIL User Guide** provides information on the Remote Cabinet Interface over LAN (RCIL) used to manage the power supply to I/O devices, such as the Fujitsu storage system ETERNUS, from the Fujitsu M10 systems.
- **Fujitsu M10/SPARC M10 Systems XSCF MIB and Trap Lists** provides lists of Management Information Base (MIB) and MIB Trap values of the XSCF SNMP agent function used with the Fujitsu M10 systems.
- **Fujitsu M10/SPARC M10 Systems Glossary** contains the terms used in the manuals and their explanations.