Customer Instructions
Ridgid #300 Pipe Threader

Warning: **Always use eye protection. Use of gloves could be hazardous-use gloves at your own risk. Avoid loose fitting clothing, long hair & jewelry that may get caught up in machinery.**

Operating Instructions

1. Open tripod legs. Be sure to lock them out. Attach carriage assembly, clamping handle to support rod. Place pan & oiler directly under power head jaws on carriage assembly side.
2. Plug in power cord. Using selector switch, choose direction. Then apply foot switch to operate.
3. Open front jaw, which is a guide device, not a gripping jaw. Slide material through power head into the jaws centering & clamping it down, allowing you to use the threader/cutter/reamer.
4. Remember that when you are threading, you MUST use the oiler & oil, keeping a constant flow of oil over the cutting teeth.
5. Cleaning: do NOT pressure wash this equipment. Blow unit off with compressed air, and wipe down with a rag.

Disclaimer:
These instructions are intended as a helpful reminder. They do not replace the full operating instructions found in the owners manual, which is available at the rental counter.

A to Z Equipment Rentals & Sales - 4 locations in the Phoenix Arizona Metro Area
If you like this piece of equipment, inquire about purchasing it !
If equipment does not work properly, notify office at once -
• Phoenix, 602-955-5100 • North Valley, 602-992-1150 • East Valley, 480-539-8700 • West Valley, 623-925-0200 •