

TRiSTAR MX-4202 Hand Mixer Instruction Manual

Contents

1 TRiSTAR MX-4202 Hand Mixer
2 Instruction manual
2.1 SAFETY
3 PARTS DESCRIPTION
4 BEFORE THE FIRST USE
5 USE
6 CLEANING AND MAINTENANCE
7 Documents / Resources
7.1 References
8 Related Posts

TRiSTAR MX-4202 Hand Mixer



Instruction manual

SAFETY

- By ignoring the safety instructions the manufacturer cannot be held responsible for the damage.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Never move the appliance by pulling the cord and make sure the cord cannot become entangled.
- The user must not leave the device unattended while it is connected to the supply.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- This appliance shall not be used by children aged less than 8 years. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children unless older than 8 and supervised.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- Do not allow children to use the device without supervision.
- Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
- Always disconnect the device from the supply if it is left unattended and before assembling, disassembling or cleaning.
- It is absolutely necessary to keep this appliance clean at all times, because it comes into direct contact with food.
- This appliance is intended to be used in household and similar applications such as:

- Staff kitchen areas in shops, offices and other working environments.
- By clients in hotels, motels and other residential type environments.
- Bed and breakfast type environments.
- Farm houses.

PARTS DESCRIPTION

1. Control knob
2. Turbo button
3. Housing
4. Eject button
5. Dough hook
6. Beater



BEFORE THE FIRST USE

- Before using your appliance for the first time, wipe off all removable parts with a damp cloth. Never use abrasive products.
- When the device is turned on for the first time, a slight odour will occur. This is normal, ensure adequate ventilation. This smell is only temporary and will soon fade.
- The max operation time per time shall be less than 5 minutes. Minimum 20 minutes rest time must be maintained between continuous two cycles.

USE

- Insert the beaters or dough hooks into place until they are locked.
- Plug in the appliance.
- Place the ingredients in an appropriate container. Depending on the quantity to be prepared.
- Plunge the beaters or hooks into the container and start the appliance by turning the control knob to the right.

- Turn the control knob to the right in position “1” till “6” see the attached mixing guide for some recommendations.
- The appliance is equipped with a turbo button, which allows your appliance to generate more power.
- When you have finished using it, reset the control knob to position “0”.
- Unplug the appliance.
- Eject the beaters or dough hooks by pushing the eject button.

Mixing guide

- 1 This is a good starting speed for bulk and dry foods such as flour, butter and potatoes.
- 2 Best speed to start liquid ingredients for mixing salad dressings.
- 3 For mixing cakes and quick breads.
- 4 For creaming butter and sugar, beating uncooked candy, desserts, etc.
- 5 For beating eggs, cooked icings, whipping cream, etc.
- TURBO Same speed “6”

CLEANING AND MAINTENANCE

- Clean the appliance with a damp cloth. Never use harsh and abrasive cleaners, scouring pad or steel wool, which damages the appliance.
- Never immerse the electrical appliance in water or any other liquid. The appliance is not dishwasher proof.
- Wash the beaters and the dough hooks in a warm soapy water. Rinse and dry the parts thoroughly. Only these parts are dishwasher safe.

ENVIRONMENT
This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

Support
You can find all available information and spare parts at **www.tristar.eu!**

WWW.TRISTAR.EU
Tristar Europe B.V. | Swaardvenstraat 65 5048 AV Tilburg | The Netherlands

Documents / Resources

	TRiSTAR MX-4202 Hand Mixer [pdf] Instruction Manual MX-4202, Hand Mixer, MX-4202 Hand Mixer, Mixer

References

- *** Tristar | Household appliances - Unbeatable basics for your home

Manuals+,