


I am not robot!

# Desobry dvd player manual

© 1996-2015, Amazon.com, Inc. or its affiliates © 1996-2015, Amazon.com, Inc. oder Tochtergesellschaften © 1996-2015, Amazon.com, Inc.




This symbol indicates the presence inside the appliance of hazardous voltages capable of causing an electric shock or injury. This symbol means that important instructions are included with the appliance. NOTE: THIS PLAYER USES AN INVISIBLE LASER BEAM THAT COULD EXPOSE THE USER TO HAZARDOUS RADIATION IF DIRECTED TOWARD THE EYES. ALWAYS USE THE PLAYER AS INDICATED IN THE OPERATING INSTRUCTIONS; WARNING To minimize the risk of fire or electric shock, never expose the player to rain or other forms of moisture. NOTE THIS APPLIANCE USES A LASER. ANY OPERATION OR USE OF CONTROLS AND SETTINGS OTHER THAN AS INDICATED IN THIS MANUAL MAY RESULT IN EXPOSURE TO HAZARDOUS RADIATION. NEVER OPEN THE CASE OR ATTEMPT TO REPAIR THE PRODUCT YOURSELF. ALWAYS ENTRUST REPAIRS TO A QUALIFIED TECHNICIAN. Precautions for use  Always switch the player off before connecting other devices o it Never move the player while a disc is playing. Doing so could scratch or break the disc and damage the player’s intimal components. Do not place water-filled vases or small metal objects on the player. Never poke your fingers into the disc tray. Never place anything other than the disc in the disc tray. External interference – e.g. lightning or static electricity — can affect the product’s operation. In the event of interference, press the POWER button to switch the DVD player off and then on again, or unplug the power cord from the wall outlet and then plug it in again. The product will function normally again. Always remove the disc and switch the player off after use. Unplug the power cord from the wall outlet if you do not intend to use the player for an extended period. If you need to clean a disc, wipe it in a straight movement from the center toward the edge. Disc storage Take care to avoid damaging your discs, as the data they contain is very sensitive to environmental conditions. Avoid exposing discs to direct sunlight. Store in a cool, well-ventilated place. Store discs vertically. Keep in a clean dust case or sleeve. Accessories HDMI cable USB cable Remote Control AC adapter User Manual :Player Description 0pen or Close the disc cover Pause/Play Previous next Repeat switch DVD/USB mode Power ON/OFF LED display Remote control receiving window Volume adjustment Earphone /AUX out port TF card port UsB port AV OUT port HDMI OUT port Power port :Remote control POWER (Power ON/OFF) Mute Volume Up/Down Play/Pause Previous/Next chapter Stop. Reverse Fast forward Direction Enter System Setup. DVD root menu and Playback control (PBC) Access the various repetition or cycle modes The slow play Source selection (Disc or USB) Zoom out/Zoom in Select Audio Select subtities Left channel/right channel Set a sleep time Display disc data and playback times. DVD title menu (provided that the discs includes this function) Select angle Cyclic repetition between A & B points (A-B) PNO O AN It plays discs Can play disc type type| Storage format| Mu| Matters needing attention ---|---|---|--- DVD Video DVD-R DVD4R DVD-RW DVD+RW| Voice  Image| 12 Cm 8 Cm| VCD| Voice  Image| 12 Cm| VCCD Forat (Ver1.120) only CD-R Produced Xvid| Voice image| 12 Cm| Renewable CODECXvid 3/4/5, Renewable file extensionsavi/mpg/mpeg The text format that can be generatedsmi CDCD-R CD-RW| Voice| 1 2 cm 8Cm| Do not use intermediate or special characters (/=+) Renewable disk DVD, VCD, MUSIC CD, MP3, WMA, CD-R, CD-RW, DVD-R, DVD-RW, DVD+R, DVD+RW Congratulations on purchasing this player. Setup menu How to configure the player DMain menu: Use the left and right arrow ( €/ buttons to move the cursor SRS ( (o highiight the header of the main menu’s submenu.

Submenu Press PLAY to enter the submenu. Pressing the < button exits the submenu and returns you to the main menu. Press the A/’¥ buttons to browse the various submenu options. (3/Option menu Select the option that you want to configure and then press PLAY or » to enter the option’s setup menu. Use the A/ buttons to select the required setting and then press PLAY to enable t. Pressing < returns you to the submenu. TV Display: You can adjust the screen format (aspect ratio) according to the type of TV that you use. 4:3 Ps: The central section of anamorphic widescreen images is visible on a 4:3 TV, but the left and right edges are truncated. 4:3 Lb: Anamorphic widescreen images are visible in their entirety on a 4:3 TV, but there are black bands at the top and bottom of the screen. 16:9 : Select this option if you are connecting the player to a widescreen TV. However, you will not be able to view DVDs recorded in 4:3 as complete 16:9 images even if you select this option. Angle Mark ON: The screen will show the angle mark icon. (If an angle option is available). OFF: The screen will not display the Angle Mark. NOTE: Not all discs contain above features. The above features are disc dependent. OSD Language Select your preferred language for the onscreen display and setup menu Audio: Selects the preferred language for DVD soundtracks.

The selected language is assigned high priority and can therefore be adopted automatically when the player begins playing a disc. Languages vary between discs, depending on the DVD disc.




This symbol indicates the presence inside the appliance of hazardous voltages capable of causing an electric shock or injury. This symbol means that important instructions are included with the appliance. NOTE: THIS PLAYER USES AN INVISIBLE LASER BEAM THAT COULD EXPOSE THE USER TO HAZARDOUS RADIATION IF DIRECTED TOWARD THE EYES. ALWAYS USE THE PLAYER AS INDICATED IN THE OPERATING INSTRUCTIONS; WARNING To minimize the risk of fire or electric shock, never expose the player to rain or other forms of moisture. NOTE THIS APPLIANCE USES A LASER. ANY OPERATION OR USE OF CONTROLS AND SETTINGS OTHER THAN AS INDICATED IN THIS MANUAL MAY RESULT IN EXPOSURE TO HAZARDOUS RADIATION. NEVER OPEN THE CASE OR ATTEMPT TO REPAIR THE PRODUCT YOURSELF. ALWAYS ENTRUST REPAIRS TO A QUALIFIED TECHNICIAN. Precautions for use  Always switch the player off before connecting other devices o it Never move the player while a disc is playing. Doing so could scratch or break the disc and damage the player’s intimal components. Do not place water-filled vases or small metal objects on the player.




or its affiliates © 1996-2015, Amazon.com, Inc.




or its affiliates © 1996-2015, Amazon.com, Inc. or its affiliates © 1996-2015, Amazon.com, Inc. oder Tochtergesellschaften DESOBRY MD115B Mini DVD Player User Manual Safety Instructions TO MINIMIZE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THIS PRODUCT'S COVER (OR REAR PANEL). THIS PRODUCT CONTAINS NO USER-SERVICEABLE PARTS, ALWAYS ENTRUST REPAIRS TO A QUALIFIED TECHNICIAN. This symbol indicates the presence inside the appliance of hazardous voltages capable of causing an electric shock or injury. This symbol means that important instructions are included with the appliance. NOTE: THIS PLAYER USES AN INVISIBLE LASER BEAM THAT COULD EXPOSE THE USER TO HAZARDOUS RADIATION IF DIRECTED TOWARD THE EYES. ALWAYS USE THE PLAYER AS INDICATED IN THE OPERATING INSTRUCTIONS; WARNING To minimize the risk of fire or electric shock, never expose the player to rain or other forms of moisture. NOTE THIS APPLIANCE USES A LASER. ANY OPERATION OR USE OF CONTROLS AND SETTINGS OTHER THAN AS INDICATED IN THIS MANUAL MAY RESULT IN EXPOSURE TO HAZARDOUS RADIATION. NEVER OPEN THE CASE OR ATTEMPT TO REPAIR THE PRODUCT YOURSELF. ALWAYS ENTRUST REPAIRS TO A QUALIFIED TECHNICIAN. Precautions for use  Always switch the player off before connecting other devices o it Never move the player while a disc is playing. Doing so could scratch or break the disc and damage the player's intimal components. Do not place water-filled vases or small metal objects on the player. Never poke your fingers into the disc tray. Never place anything other than the disc in the disc tray.




THIS PRODUCT CONTAINS NO USER-SERVICEABLE PARTS, ALWAYS ENTRUST REPAIRS TO A QUALIFIED TECHNICIAN. This symbol indicates the presence inside the appliance of hazardous voltages capable of causing an electric shock or injury.
This symbol means that important instructions are included with the appliance. NOTE: THIS PLAYER USES AN INVISIBLE LASER BEAM THAT COULD EXPOSE THE USER TO HAZARDOUS RADIATION IF DIRECTED TOWARD THE EYES.
ALWAYS USE THE PLAYER AS INDICATED IN THE OPERATING INSTRUCTIONS; WARNING To minimize the risk of fire or electric shock, never expose the player to rain or other forms of moisture. NOTE THIS APPLIANCE USES A LASER.
ANY OPERATION OR USE OF CONTROLS AND SETTINGS OTHER THAN AS INDICATED IN THIS MANUAL MAY RESULT IN EXPOSURE TO HAZARDOUS RADIATION. NEVER OPEN THE CASE OR ATTEMPT TO REPAIR THE PRODUCT YOURSELF. ALWAYS ENTRUST REPAIRS TO A QUALIFIED TECHNICIAN. Precautions for use  Always switch the player off before connecting other devices o it Never move the player while a disc is playing. Doing so could scratch or break the disc and damage the player's intimal components. Do not place water-filled vases or small metal objects on the player. Never poke your fingers into the disc tray. Never place anything other than the disc in the disc tray. External interference – e.g. lightning or static electricity — can affect the product's operation. In the event of interference, press the POWER button to switch the DVD player off and then on again, or unplug the power cord from the wall outlet and then plug it in again. The product will function normally again. Always remove the disc and switch the player off after use. Unplug the power cord from the wall outlet if you do not intend to use the player for an extended period. If you need to clean a disc, wipe it in a straight movement from the center toward the edge. Disc storage Take care to avoid damaging your discs, as the data they contain is very sensitive to environmental conditions. Avoid exposing discs to direct sunlight. Store in a cool, well-ventilated place.
Store discs vertically. Keep in a clean dust case or sleeve. Accessories HDMI cable USB cable Remote Control AC adapter User Manual :Player Description 0pen or Close the disc cover Pause/Play Previous next Repeat switch DVD/USB mode Power ON/OFF LED display Remote control receiving window Volume adjustment Earphone /AUX out port TF card port UsB port AV OUT port HDMI OUT port Power port :Remote control POWER (Power ON/OFF) Mute Volume Up/Down Play/Pause Previous/Next chapter Stop. Reverse Fast forward Direction Enter System Setup.
DVD root menu and Playback control (PBC) Access the various repetition or cycle modes The slow play Source selection (Disc or USB) Zoom out/Zoom in Select Audio Select subtitles Left channel/right channel Set a sleep time Display disc data and playback times. DVD title menu (provided that the discs includes this function) Select angle Cyclic repetition between A & B points (A-B) PNO O AN It plays discs Can play disc type type| Storage format| Mu| Matters needing attention ---|---|---|--- DVD Video DVD-R DVD4R DVD-RW DVD+RW| Voice  Image| 12 Cm 8 Cm| VCD| Voice  Image| 12 Cm| VCCD Forat (Ver1.120) only CD-R Produced Xvid| Voice image| 12 Cm| Renewable CODECXvid 3/4/5, Renewable file extensionsavi/mpg/mpeg The text format that can be generatedsmi CDCD-R CD-RW| Voice| 1 2 cm 8Cm| Do not use intermediate or special characters (/=+) Renewable disk DVD, VCD, MUSIC CD, MP3, WMA, CD-R, CD-RW, DVD-R, DVD-RW, DVD+R, DVD+RW Congratulations on purchasing this player. Setup menu How to configure the player DMain menu: Use the left and right arrow ( €/ buttons to move the cursor SRS ( (o highiight the header of the main menu's submenu.
Submenu Press PLAY to enter the submenu. Pressing the < button exits the submenu and returns you to the main menu. Press the A/'¥ buttons to browse the various submenu options. (3/Option menu Select the option that you want to configure and then press PLAY or » to enter the option's setup menu. Use the A/ buttons to select the required setting and then press PLAY to enable t. Pressing < returns you to the submenu. TV Display: You can adjust the screen format (aspect ratio) according to the type of TV that you use.
4:3 Ps: The central section of anamorphic widescreen images is visible on a 4:3 TV, but the left and right edges are truncated. 4:3 Lb: Anamorphic widescreen images are visible in their entirety on a 4:3 TV, but there are black bands at the top and bottom of the screen. 16:9 : Select this option if you are connecting the player to a widescreen TV. However, you will not be able to view DVDs recorded in 4:3 as complete 16:9 images even if you select this option. Angle Mark ON: The screen will show the angle mark icon. (If an angle option is available). OFF: The screen will not display the Angle Mark. NOTE: Not all discs contain above features. The above features are disc dependent. OSD Language Select your preferred language for the onscreen display and setup menu Audio: Selects the preferred language for DVD soundtracks. The selected language is assigned high priority and can therefore be adopted automatically when the player begins playing a disc. Languages vary between discs, depending on the DVD disc. You can also select altemative languages by pressing the AUDIO button on the remote control handset. Screen Saver: ON: If the player remains idle for more than a few minutes, an animated image (known as a screensaver) is displayed. The purpose of this function is to protect your TV screen. OFF: If you disable this option, the player will not display the screensaver image. Note: The player automatically disables the screensaver function during playback. Last Memory: ON: The player can automatically begin playing the disc (DVD or CD) from the point where you last enabled this function. OFF: If you disable this function, the player will always play discs from the start. Audio Setup Page Speaker Setup Downmix RIGHT/LEFT Channel: Mixes a 5.1ch audio signal to 2 audio channels and then outputs to the left and right speakers Stereo: Outputs a stereo signal to the left and right speakers. Dolby digital setup Dual mono STEREO: Left/Right channel audio will be played back by the LeftRight speakers. L-MONO: Playback of Left channel audio only. R-MONO: Playback of Right channel audio only. MIX-MONO: Both Left/Right channels are mixed to one mono channel Dynamic Use this mode to level all sound channels to ensure even sound levels. Video Setup Page Configure the image quality by adjusting the sharpness, brightness, contrast TV Type Used for settings the Video format output if the player is connected to an external display. PAL: Video output is PAL only. AUTO: Video output is as per source material.
NTSC: Video output is NTSC only. ( Note: This should be set without disc in the player.) Audio subtitle and disc menu Sets the default audio,sublitle and disc menu language of DVDs played on this player. Note: Audio, Subtitle and Disc Menu settings are subject the availability of your selection on the DVD. Default: Select "Default" in preference page to make the setting return to the factory- set mode. Troubleshooting In the event of a technical problem, check the following points before taking the player to the after-sales service.
1f you are unable to cure the problem by following our advice, contact your dealer or repair center. WARNING: Never attempt to repair this appliance yourself. Problem Possible cause Solution The POWER light does not come on| The power cord is not plugged in| Plug the power cord into a wall outlet No picture| You have not selected the video input connected to your TV| Select the appropriate video input format on your TV, in order to receive the player's output signals The video cable is not connected correctly| Fully insert the plugs on the video cable into the corresponding jacks No sound| The audio cable is not connected correctly| Fully insert the plugs on the audio cable into the corresponding jacks. You have not selected the correct audio output| Select the correct audio output in the setup menu Distorted picture| The disc is dirty.| Remove and clean the disc The player is in Cue or Review mode.| Some distortion may occur during Cue and Review operations. This is normal. Flickering or unstable brightness| Disruption caused by a copy protection system.| Connect the player directly to your TV The player does not operate| There is no disc in the player| Load a disc Incompatible disc| Load a compatible disc (check the disc's format and color signal coding standard). The disc has been loaded upside down| Check that the disc is correctly positioned The disc is not correctly positioned in the tray| Check that the disc is correctly positioned The disc is dirty.| Clean the disc The player is not configured correctly| Use the setup menu to modify the setup Parental control mode is active| Disable the parental control function or change the restriction level Note: This appliance uses copyright protection technology covered by claims under the terms of various US patents and other intellectual property rights of Macrovision Corporation and other holders. Use of the aforementioned copyright protection technology is subject to consent by Macrovision Corporation and s intended solely for private use or restricted broadcasting, unless otherwise authorized by Macrovision Corporation. Reverse engineering and disassembly prohibited. It may not be possible to play certain discs on this player, owing to the condition of the recording system or the CD-R/RW or DVD + RIRW disc itself. Product Features Video Output HDMI 1.4 Power Supply 5V Current>=2A Dimensions 155(mm) X 150(mm) X32(mm) Net weight 0.5kg Supported Disc DVD/SVCDNCD/CD/MP3/Kodak Picture/Photo CD **/ DivX** Supported USB FORMAT VIDEO CODE AUDIO CODE RESOLUTION MPG MPEG-1V / MPEG-2V MP2 720*576(MAX) VOB MPEG-2V AC3 720*576(MAX) FLV Sorenson H.263 MP3 720*576(MAX) AVI XVID / DX50 I DIVX PCM / MP2 I MP3 /AC3 720*576(MAX) DAT MPEG-1V MP2 / MP3 704•576(not smooths) 352'288 DIVX DX50 MP3 720*576(MAX) NOTE:Player Does't Support MP4/MOV MKVMMV/ASF/MPEG files.Do Not Support AVC1/MPEG/MJPG/DIV2/MP43NMV2 video codes in AVI format. 1f you have any questions about the products you received, please feel freeto contact us via email. E-Mail : desobry-service@outlook.com Download This Manual (PDF format) Download this manual  >> © 1996-2014, Amazon.com, Inc. or its affiliates