

Mandis Sharp GA771WJSA Replacement Remote Control Instructions

Contents

1 Mandis Sharp GA771WJSA Replacement Remote Control
2 Product Information
3 Product Usage Instructions
4 FAQ
5 REPLACEMENT PARTS
6 Documents / Resources
6.1 References
7 Related Posts

Mandis

Mandis Sharp GA771WJSA Replacement Remote Control



Product Information

Specifications

- Model: Sharp GA771WJSA
- Compatibility: Sharp TVs
- Power Source: 2 AAA batteries (not included)
- Dimensions: Not specified
- Weight: Not specified

Product Usage Instructions

Power and Channel Controls

To turn on the TV, press the “Power” button. Use the number buttons (1-9, 0) to directly access a channel. Press the “Ch” button to change channels. Use the “Vol+” and “VolMute” buttons to adjust the volume

Menu Navigation

Use the arrow buttons (Up, Down, Right, Left) to navigate through the menu options. Press the “OK” button to select an option. Use the “Exit” button to go back to the previous screen.

AV and Input Selection

Press the “AV” button to switch to the AV input. Use the “Shift + Smart” buttons to access smart features. Press the “TV/R” button to switch between TV and radio modes.

Additional Functions

The remote control offers additional functions such as accessing the EPG (Electronic Program Guide), activating the sleep timer, and controlling the 3D menu. Refer to the user manual for detailed instructions on using these functions.

FAQ

- **Q:** How do I replace the batteries in the remote control?
- **A:** The remote control requires 2 AAA batteries. To replace the batteries, open the battery compartment on the back of the remote control and insert the new batteries following the polarity markings.
- **Q:** Can this remote control be used with non-Sharp TVs?
- **A:** The Sharp GA771WJSA remote control is specifically designed for use with Sharp TVs. It may not be compatible with other

REPLACEMENT PARTS



Originale	Sostituto	Originale	Sostituto
Power	Power	▼/O)/I/II/I+II	Dual
1	1	Vol+	Vol +
2	2	Vol-	Vol -
3	3	Mute	Mute
4	4	P+	Ch +
5	5	P-	Ch -
6	6	P.Info	Info
7	7	[i+]	List
8	8	AV Mode	Format
9	9	[<>]	Eject
0	0	Eco	3D
Recall	Pre Ch	Menu	Menu
Source	AV	Up	Up
ATV	Shift + Smart	Down	Down
DTV	Smart	Right	Right
EPG	Guide	Left	Left
Radio	TV/R	OK	Ok





Originale	Sostituto
End	Exit
Back	Back
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
[≡]	Text
[≡?]	Shift + Subt
[...]	Subt
[≡+]	Shift + Options
[≡o]	Shift + Dual
[≡♦]	Shift + TV/R
Sleep	Sleep
Power Aquos Link	Shift + Power
<<	<<
Play	Play
>>	>>

Originale	Sostituto
Option	Options
Rec	Rec
Rec Stop	Shift + Stop
Stop	Stop



https://tutti-i-telecomandi.it/it/Sharp/1055079-30416-telecomando-di-sostituzione-per-Sharp-GA771WJSA.html

---

Documents / Resources

	Mandis Sharp GA771WJSA Replacement Remote Control [pdf] Instructions Sharp GA771WJSA Replacement Remote Control, Sharp GA771WJSA, Replacement Remote Control, Remote Control, Control

References

- Telecomando sostituto di SHARP GA771WJSA
- User Manual

Manuals+, Privacy Policy