

I am not robot!

Uniden powermax 5.8 manual

QUICK START GUIDE[1] Q UI CK S TA RT G UI DE INSTALL THE HANDSET BATTERY Remove the cover.Plug in the battery pack connector tothe socket.Make sure the RED and BLACK wiresmatch the RED and BLACK engraving on the phone cace. Replace the cover. PLUG INTO AC POWER Plug the AC adapter cord into the base unit and then to a standard AC outlet.Place the handset in the base. Note: You must charge the battery pack continuously for 15-20 hoursbefore using the phone. Step 1Charging the BatteryStep 2ConnectingStep 4Setting up Answering System CONNECT TO A PHONE LINE When the handset battery pack is fully charged, plug the telephone cord into the base unit and then into a telephonesocket on the wall. TURN THE ANSWERING SYSTEM ON/OFF Each time answer on/off is pressed, theanswer mode is switched between On andOff. SET GREETING MESSAGE Press and hold greeting until youhave an announcement.Release greeting .Start recording your message.Position yourself as near to the baseas possible. When finished, press greeting or . MAKE A CALL Pick up the handset and press talk/flash .Dial the phone number.ORDial the phone number then press talk/flash .To hang up, press end , or place thehandset on the base. ANSWER A CALL Handset on the base: Remove the handset from the base,or remove the handset from the baseand press talk/flash . Handset off the base: Press any number key, * /tone or # (Any key Answer), or press talk/flash and speak. Hands - free: Pick up the handset, press spkr andspeak. Speaker Phone: Press (Talk) on the base andspeak.To hang up, press end , or place thehandset on the base.To hang up Speaker Phone on thebase, press (Talk). Step 3 Making and Receiving a Call User Manual: TRU9280 Open the PDF directly: View PDF .Page Count: 3 Directly view this document at