

Basic Configuration – Overview




Displays and Controls

Recorder Faceplate



Controller Faceplate



Sideways Scroll





Down Scroll



Raise and Lower







Function Key



Alarm acknowledge; Auto-tune; Pen lift/ lower; Profile Control; Local/Remote or 'Home' – See *Programming Guide, 'Advanced Configuration'*

Pen Lift



(Recorder Only) Raises and lowers the chart pen.

Auto/Manual



(Controller Only) Switches between automatic and manual control modes.

Note. All programming is carried out using the faceplate keys and displays.

The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.

© ABB 2005

Printed in UK (07.05)

ABB Limited
Howard Road, St. Neots
Cambridgeshire, PE19 8EU
UK
Tel: +44 (0)1480 475321
Fax: +44 (0)1480 217948

ABB Inc.
125 E. County Line Road
Warminster, PA 18974
USA
Tel: +1 215 674 6000
Fax: +1 215 674 7183

IM/C1900–QC
Issue 3

COMMANDER 1900 Controller – Quick Reference Guide

OGC

Operating Guide

Alarms
Acknowledge 16, 36
LED status 16, 36
Auto-tune 21
Enable/disable 23
Setup 21
Status 23
Auto/manual select 12
Chart 4
Control
Cascade 12
Heat/cool 11, 12
On/off 26, 30
Output adjust 13
Standard 10, 26
Displays & controls ... 5, 6, 34, 35
Fault-finding 2, 9, 24, 38
Auto-tune diagnostics 24
Input error messages 9
Power up error codes 2
Manual tuning 28
Pen – fitting 4
Process variable 13
Profile control 12
Program select 19
Reset 19
Skip segment 19
Status 15
Security Access
Configuration level 18
Password 18
Tune level – access 18
Self-test 2
Set point
Bias 14
Ratio 14
Type selection 14
Time/date 15
Totalizer 17, 37

PGC

Programming Guide


Alarms 10
Analog outputs 21
Auto/manual select enable 45
Bargraph increment 45
Chart set up 9
Configuration
Basic 3
Control 29
Advanced 48
Control 37
Action on input fail 43
Action on power fail 39
Digital outputs 19
Function keys 49
Inputs (PV, RSP, P-FB) 4
Assign 53
Logic equations 50
Logic inputs 23, 46, 47
Passwords 24
Pen 8, 9
Functions 52
Scale adjust 26, 27
Position feedback – *see Inputs*
Process variable – *see Inputs*
Relays 16, 17
Remote set point – see input .....
Retransmission outputs – *see Analog Outputs*
Scale Adjust (span/offset) 26
Set point 30–33, 45
Spot calibration – *see Scale Adjust*

INS

Installation Guide

Accessories 2
Electrical Installation 6
Siting 3
Mounting/Dimensions 4
Power Supplies 12
Inputs/Outputs 7

Setting Analog Input Links








Fig. 1 Input Links – Channel 1



Warning. Ensure that the unit is isolated from all power supplies before removing I/O boards.


Fig. 2 Input Links – Channels 2 to 4 (If fitted)

Configuring Analog Inputs



Information. The alphabet used to display page and parameter titles is as follows:

A – A	M – -
B – b	N – n or n
C – C or c	O – O or o
D – d	P – P
E – E	Q – Q
F – F	R – r
G – G	S – S
H – H or h	T – t
I – I	U – U
J – J	V – U
K – K	Y – y
L – L	



Select Channel – Choose the input channel to be configured

Input type – _A_P (mA), U.OLt (V), _U.Lt (mV), tCPL (Thermocouple), rtd (RTD) and LO OH (< 750 Ohms) HI OH (> 750 Ohms).


Linearizer: If using a thermocouple set to J, K., B, n, E, -, S, R. Other options are 5/2, 3/2, SQ.rt, rtd or NONE.

Range High: For a 4 to 20mA current input, set this to 20.00, or for 0 to 5V, set to 5.0. The frame does not appear if tCPL or rtd are used.

Range Low: Set the low end of the electrical input range, e.g. 4.00, for 4 to 20mA, or 0.0 for 0 to 5V.

Units: Select NONE if the input is not temperature, otherwise select dEG F or dEG C.

Engineering Range High: Select the highest engineering value that will be displayed when the input is at its maximum value – e.g. for an engineering range of 0 to 300.0 °F set to 3000.



Decimal Point: Select the decimal point position for the process variable, e.g. 300.0.

Engineering Range Low: Select the lowest engineering value that will be displayed when the input is at its minimum value – e.g. for an engineering range of 0 to 300.0 °F set to 0.0.

Broken Sensor Drive: Determine pen action when the input signal fails: NONE – pen follows failed input; UP – pen driven to full scale; dn – pen driven to zero scale.

Fault Detection Drive: Determine maximum input travel outside engineering range before an error is detected. E.g. for a 0 to 300°F range, a 10% fault level will trigger at 330°F.

Input Filter: Adjust the instrument response time from 0 to 60 seconds in one second increments to reduce pen jump & dampen out noisy signals.