Service Training

Fendt CARGO 3X front loader (Standard),
Fendt CARGO 4X/5X front loader (Standard and Profi),
Fendt CARGO R rear loader



epcatalogs.com

AGCO GmbH - Johann-Georg-Fendt-Str. 4 D-87616 Marktoberdorf
FENDT is a worldwide brand of AGCO
© AGCO 2013

July 2013
No. X990.005.461.013
4134-XX (M000238)
English

epcatalogs.com

All relevant accident prevention regulations and all generally accepted safety, health and road traffic regulations must be strictly observed. The manufacturer does not accept liability for damage resulting from unauthorised modifications.

Changes and additions reserved!

Property of AGCO GmbH.
Distribution to third parties is prohibited, regardless of whether it is provided for a fee or free of charge.

© PSD / 07.2013
X990.005.461.013 (4134-en)
AGCO GmbH, Marktoberdorf, Germany

Fendt CARGO 3X, 4X and 5X front loader

0000 General

1 Serial number . . . 3
2 Maintenance instructions . . . 4
3 Bolt tightening torques . . . 5
4 Lubrication points . . . 6
5 Implement range . . . 8
6 Operation with pallet fork . . . 11
7 Tractor ballasting . . . 13

Fendt CARGO 3X front loader (Standard)

8900 Hydraulics

1 Remove and attach the CARGO front loader (3X) . . . 3
2 Remove and attach implement . . . 8
3 Technical data: FENDT "CARGO 3X" front loader and add-on consoles . . . 10
4 Series change (from June 2013) on the CARGO front loader 3X . . . 17
5 Front loader add-on console and "CARGO Lock" locking system . . . 19
6 Hydraulic circuit diagram for Cargo front loader 3X (Standard) — 334.890.000.001 . . . 28
7 Hydraulic circuit diagram for Cargo front loader 3X (Standard) — 334.890.000.001_b . . . 32
8 Front loader 3X pressure protection . . . 36
9 Technical drawing: "Cassette" valve block . . . 41
10 Technical drawing: "Cassette" valve block (version 2) CARGO 3X . . . 44
11 Technical drawing: "Front loader suspension" valve block, CARGO 3X . . . 45
12 Technical drawing: T1/T2 lift cylinder and LBS1 pipe rupture safety feature . . . 46
13 Technical drawing: DA cylinder (tip cylinder) . . . 48
14 Technical drawing: DBV MK pressure-limiting valve (320 [bar]) . . . 50
15 Technical drawing: SDRV1 flow cut-off valve . . . 52
16 Multi-coupler (piping and wiring) . . . 53
17 CARGO front loader 3X, remove and fit valve block mounting . . . 63
18 Install valve block 1.1/1.2 . . . 80

9000 Electrical system

1 Front loader: Electrical wiring on the tractor (FENDT 200 Vario) . . . 85
2 Front loader: Electrical wiring on the tractor (FENDT 300 Vario) . . . 88
3 A072 control panel, CARGO front loader (F300 Vario) . . . 96
4 CARGO control panel (retrofit): version A . . . 109
5 Retrofit CARGO control panel: version B . . . 116

Fendt CARGO 4X/5X front loader (Standard and Profi)

8900 Hydraulics

1 Technical data: FENDT "CARGO" front loader . . . 3
2 Series change (from June 2013) on the CARGO front loader 4X/5X (hydraulics) . . . 10
3 Comparison of CARGO Standard and CARGO Profi front loaders . . . 13
4 Attach and detach CARGO front loader (Standard and Profi) . . . 16
5 Hydraulic implement lock; attaching and removing implements . . . 21
6 Hydraulic circuit diagram for Cargo front loader 4X/5X — 725.891.000.001 . . . 25
7 Hydraulic circuit diagram for Cargo front loader 4X/5X — 725.891.000.001_b . . . 28
8 Technical drawing: "Cassette" valve block . . . 32
9 Technical drawing: "Cassette" valve block (version 2) CARGO 4X/5X . . . 34
10 Technical drawing: "Thermo DBV" valve block, CARGO 4X/5X . . . 36
11 Technical drawing: Lift cylinder . . . 37
12 Technical drawing: Tip cylinder . . . 38
13 Technical drawing: Tipping cylinder (version 2) . . . 40
14 Technical drawing: Tipping cylinder (version 2) with sensor B214 "CARGO Profi" . . . 42
15 Technical drawing: Implement lock cylinder . . . 44
16 Technical drawing: DBV3 pressure-limiting valve (320 bar) . . . 45
17 Technical drawing: LBS1 front loader pipe rupture safety feature . . . 46
18 Multi-coupler for the CARGO front loader (4X/5X) . . . 47
19 CARGO front loader 4X/5X, install and remove valve block mounting . . . 59

epcatalogs.com

Fendt CARGO 4X/5X front loader (Standard and Profi)

8910 Mounting frame
1 Front loader add-on console and "CARGO Lock" locking system . . . 81
8915 Hydraulic equipment actuation
1 Removing the valve block mounting . . . 91
2 Installing valve block for hydraulic Tool lock . . . 93
8955 Hydraulics — 3rd and 4th circuit
1 Removing the valve block mounting . . . 95
2 Installing the cable sets . . . 97
3 Installing changeover valves for 3rd + 4th operating circuits . . . 100
8970 Piping (front loader suspension)
1 Hydr. valves and piping on the front loader . . . 103
2 Removing the valve block mounting . . . 108
3 Removing the front loader pipe rupture safety feature . . . 110
4 Installing the front loader suspension system . . . 111

Front loader/Multi-coupler

8958 FENDT 300 Vario Tier III
1 Multi-coupler assignment on the CARGO front loader . . . 3
2 Hydraulic multi-coupler on the CARGO front loader . . . 4
3 Install valve lock 1.1/1.2 . . . 8
8958 FENDT 400/700/800 Vario Tier III
1 Multi-coupler assignment on the CARGO front loader . . . 15
2 CARGO front loader multi-coupler, FENDT 400 Vario . . . 16
3 CARGO front loader multi-coupler, FENDT 700/800 Vario . . . 20
8958 Fendt 300/500/700 Vario SCR (Tier 3b)
1 Hydraulic multi-coupler (FENDT 300 Vario SCR) . . . 23
2 Hydraulic multi-coupler (FENDT 500 Vario SCR) . . . 26
3 Hydraulic multi-coupler (FENDT 700 Vario SCR) . . . 30

Electrical system/overall system

9000 FENDT 300/400/700/800 Vario COM III
1 Equipment variants: "CARGO" front loader/tractor . . . 3
2 Electrical circuit diagrams for front loader (FENDT 300 Vario COM III) . . . 7
3 Electrical circuit diagrams for front loader (FENDT 400/700/800 Vario COM III) . . . 12
4 Front loader: electrical wiring on the tractor . . . 19
5 Front loader: electrical wiring on the CARGO front loader . . . 29
6 CARGO front loader A072 control panel . . . 31
7 CARGO control panel (retrofit): version A . . . 44
8 Retrofit CARGO control panel: version B . . . 51
9 Front loader Gr.3 / 3S / 3SX . . . 63
10 Front loader Gr.3/3S/3SX (FENDT 400/700/800 Vario COM III) . . . 69
11 CARGO - front loader 4X / 5X . . . 72
9000 FENDT 300/500/700 Vario SCR Tier 3b
1 FENDT 300 Vario SCR electrical wiring diagram . . . 81
2 FENDT 500 Vario SCR Power electrical wiring diagram . . . 83
3 FENDT 700 Vario SCR Profi/ProfiPlus (version 1) electrical wiring diagram . . . 85
4 FENDT 500/700 Vario SCR Profi/ProfiPlus (version 2) electrical wiring diagram . . . 87
9000 CARGO Profi front loader
1 Position of the electrical components (CARGO Profi front loader 4X/5X) . . . 89
2 Calibration codes 8020, 8021, 8022, 8023 (CARGO Profi front loader) . . . 95
3 Cargo Profi front loader: Operation . . . 110
4 Measure and check A139 front loader "job computer" ECU (Cargo Profi socket, sensors and solenoid valves) . . . 125
5 Remove and refit A139 front loader "job computer" ECU . . . 142

epcatalogs.com

Fendt CARGO R rear loader

8900 Hydraulics

1 Serial number . . . 3
2 Technical data. . . . 4
3 Attach headstock . . . 5
4 Attach front loader fork . . . 9
5 Remove front loader fork . . . 10
6 Remove headstock. . . . 14
7 Attach and remove headstock with front loader fork . . . 16
8 3rd and 4th hydraulic circuits . . . 17
9 CARGO R suspension . . . 19
10 FENDT Cargo R: Mounting frame, multi-coupler, hydraulic coupling plate . . . 20

9000 Electrical system

1 FENDT Cargo R: Electrical wiring diagram/measure and test components . . . 25
2 FENDT Cargo R: Lighting . . . 34

Appendix

Electrical and hydraulic circuit diagrams in DIN A3

1 Electrical circuit diagrams in Fendt CARGO 4X / 5X (Profi) front loader
2 Hydraulic circuit diagrams Fendt CARGO 3X (Standard) front loader
3 Hydraulic circuit diagrams Fendt CARGO 4X / 5X (Standard and Profi) front loader

epcatalogs.com

Buy now

Fendt Front Loader Cargo 3X/4X/5X, R Service Training Manual PDF With Instant Download