Service Training

Linde IC Engined Truck
H 12/16/18/20 D-03/T-03
Series 350
with Linde Hydraulic Control (LHC)
and Linde Truck Control (LTC)



H01 / Chapter 1
350 804 4701.1204

epcatalogs.com

This training material is only provided for your use and remains the exclusive property of
LINDE AG Linde Material Handling Division

epcatalogs.com

Service Training

IC-ENGINED TRUCKS H 12/16/18/20 D-03/T-03, SERIES 350

1	Diesel engine	1
1.1	Engine specifications	1
1.2	Crankshaft	2
1.2.1	Adjusting alternator V-belt tension	2
1.2.2	Removing toothed belt	2
1.3	Fuel injection pump	5
1.3.1	Removal and installation of the fuel injection pump	5
1.3.2	Removing and installing the crankshaft sprocket	7
1.3.3	Check and adjust static injection pump timing	8
1.3.4	Checking engine timing	9
1.3.5	Stop leaks from the adapter of the injection pump	10
1.3.6	Adjust the idling speed and the governed speed (without load)	10
1.4	Fuel injectors	11
1.4.1	Remove and install fuel injectors	11
1.4.2	Servicing fuel injectors	12
1.4.3	Fuel injector parts	12
1.4.4	Check injector needle tip (visual check)	12
1.4.5	Check of fuel pressure	13
1.4.6	Check for leakages	13
1.5	Cylinder head	14
1.5.1	Cylinder head removal	14
1.5.2	Check cylinder head for distortion	14
1.5.3	Markings of cylinder head gaskets	14
1.5.4	Check piston at TDC	15
1.5.5	Fitting the cylinder head	15
1.5.6	Check compression pressure	17
1.5.7	Check hydraulic tappets	18
1.6	Glow plug system	19
1.6.1	Checking the glow plugs	19
1.6.2	Check the glow plugs	19
1.6.3	Glow plugs with burnt electrodes	20
2	Transmission	1
2.1	Digital electric-hydraulic control (LHC)	1
2.1.1	General	1

epcatalogs.com

2.1.2	Electronic control of truck speed		2
2.2	Schematic diagram of the drive unit		4
2.3	Technical data of the travel drive system		5
2.4	Hydraulic circuit diagram		7
2.5	View of the variable pump		11
2.6	Cross sectional view of drive pump		12
2.7	Electric-hydraulic adjustment		13
2.7.1	Hydraulic adjustment with electronic control		15
2.7.2	Electric-hydraulic control		16
2.7.2.1	Begin of pump control		17
2.7.2.2	Swash angle of variable pump		17
2.7.2.3	Hydraulic zero position		17
2.7.2.4	Hydraulic brake valve		18
2.8	Towing device		19
2.9	Drive axle AH 20 -01 with wheel drive, multiple disc brake and hydraulic motor		20
2.9.1	Repairing the reduction gear, multiple disc brake and hydraulic motor		22
2.9.2	Renewing the radial sealing ring of the planetary gear		23
2.9.3	Removing and installing the multiple disc brake and hydraulic motor with swashplate	02.01	26
2.10	Truck diagnostics and troubleshooting (applies only to LHC control)	12.04	30
2.10.1	Electrical system diagnostics	12.04	30
2.10.1.1	Working with the Linde Test Module	12.04	31
2.10.1.2	Diagnostics with a PC and the Linde Interface Converter	12.04	32
2.10.1.2.1	Linde Interface Converter	12.04	33
2.10.1.3.2	Overview of menu windows - LHC Software version 1.1 - 1.3	12.04	37
2.10.1.3.3	Menu windows in detail - LHC Software version 1.1 - 1.3	12.04	38
2.10.1.3.4	Overview of menu windows - LHC Software version 1.4 and 1.5	12.04	58
2.10.1.3.5	Menu windows in detail - LHC Software version 1.4 and 1.5	12.04	59
2.10.1.3.6	Overview of menu windows - LHC Software version 1.6	12.04	93
2.10.1.3.7	Menu windows in detail - LHC Software version 1.6	12.04	94
2.10.2	Hydraulic system diagnostics	12.04	128
2.10.2.1	Circuit diagram and overview for diagnostics	12.04	128
2.10.2.2	Test aids	12.04	130
2.10.2.2.1	Explanations to troubleshooting	12.04	130
2.10.2.3	Power-assisted steering	12.04	132
2.10.2.3.1	Troubleshooting without measurement of boost and maximum pressure	12.04	132
2.10.2.3.2	Troubleshooting with measurement of boost and maximum pressure	12.04	132

epcatalogs.com

2.10.2.4	Hydraulic brake system	12.04	134
2.10.2.4.1	Functional test	12.04	134
2.10.2.4.2	Troubleshooting	12.04	134
2.10.2.5	Hydrostatic travel drive	12.04	137
2.10.2.5.1	Troubleshooting	12.04	137
2.11	Truck diagnostics and troubleshooting (applies only to LTC control)	12.04	142
2.11.1	Electrical system diagnostics	12.04	142
4	Steering system		1
4.1	Schematic diagram of the steering system		1
5	Controls		1
5.1	Pedal stroke adjustment instructions	12.04	2
5.2	Adjustment instructions for the speed control		4
5.3	Engine speed sensor adjustment instructions		6
6	Electrical system		1
6.1	Basic diagram Diesel version, LHC control	12.04	1
6.2	Basic diagram LPG version, LHC control	12.04	7
6.3	Diagram for optional equipment, LHC control	12.04	13
6.4	Layout of electrical installation, LHC control	12.04	21
6.5	Basic diagram Diesel version, LTC control	12.04	23
6.2	Basic diagram LPG version, LHC control	12.04	27
6.3	Diagram for optional equipment, LTC control	12.04	31
6.8	Layout of electrical installation, LTC control	12.04	39
6.9	Composite instrument	12.04	40
7	Hydraulic system		1
7.1	Schematic		1
7.2	Sealing of the control valve		2
7.3	Setting of the pressure-limiting valve		3
9	LPG model of IC-engined fork truck H 12/16/18/20 T-03, series 350		1
9.1	Engine		1
9.1.1	Engine specifications	02.01	1
9.1.2	Toothed belt		2
9.1.2.1	Overall view of toothed belt guard		2
9.1.2.2	Removing, installing, tensioning the toothed belt		3

epcatalogs.com

Buy now

Linde IC Engined Truck H 12/16/18/20 D-03/T-03 Service Training Manual PDF

With Instant Download