ASUS ESC4000 Technical Updates

This is an information update for the user guide that comes with your server system package.

1.1 System package contents *(page 1-2)*

Component	1 x 1600W Redundant Power Supply
Optional Items	1 x 1600W Redundant Power Supply Module

1.3 System specifications *(page 1-5)*

Power Supply	1+1 Redundant 1600W (80+ Platinum) Power Supply (Default with one Power Supply Module)
Power Rating	Input: 1000W: 100–120Vac, 12–10A, 50–60Hz, Class 1 1200W: 120–140Vac, 12–10A, 50–60Hz, Class 1 1620W: 180–240Vac, 10.5–8A, 50–60Hz, Class 1

2.8.2 Redundant power supply units *(page 2-19)*

- The system automatically combines the two power supply modules as a single one. The combined output power varies with input voltages. Refer to the table below for details.

Input Voltage	Max. Output Power (Watt) per PSU
100–120Vac, 12–10A, 50–60Hz	1000W
120–140Vac, 12–10A, 50–60Hz	1200W
180–240Vac, 10.5–8A, 50–60Hz	1620W

- To enable the hot-swap feature (redundant mode), keep the total power consumption of the system under the maximum output power of an individual power supply module.
- For steady power input, use only the power cables that come with the server system package.

15060-150000000

華碩 ESC4000 技術訊息更新

以下為伺服器系統內附的使用手冊之更新的技術訊息。

1.1 產品包裝內容 *(1-2頁)*

硬體組件	1 x 1600W 備援式電源供應器
選購配件	1 x 1600W 備援式電源供應器模組

1.3 產品規格表 *(1-5頁)*

電源供應器	1+1 備援式1600W（80+ Platinum）電源供應器 （預設只安裝一組電源供應器模組）
產品電氣額定值	輸入： 1000W：100 - 120Vac, 12 - 10A, 50 - 60Hz, Class 1 1200W：120 - 140Vac, 12 - 10A, 50 - 60Hz, Class 1 1620W：180 - 240Vac, 10.5 - 8A, 50 - 60Hz, Class 1

2.8.2 備援式電源供應器模組 *(2-19頁)*

- 系統會自動將兩個電源供應器模組合成一個，輸出功率會隨著輸入電壓值而有所不同，請參考下列表格的資訊。

輸入電壓	電源供應器最大輸出電源（瓦特）
100 - 120Vac, 12 - 10A, 50 - 60Hz	1000W
120 - 140Vac, 12 - 10A, 50 - 60Hz	1200W
180 - 240Vac, 10.5 - 8A, 50 - 60Hz	1620W

- 若啟用熱抽換功能（備援模式），請保持系統的總電源功率在單顆電源供應器模組的最大輸出電源以下。
- 為了穩定的電源輸出，請使用伺服器系統包裝內附的電源線連接。

华硕 ESC4000 技术信息更新

以下为服务器系统内附的用户手册之更新的技术信息。

1.1 产品包装内容 *(1-2页)*

硬件组件	1 x 1600W 备援式电源（PSU）
选购配件	1 x 1600W 备援式电源（PSU）模块

1.3 产品规格表 *(1-5页)*

电源（PSU）	1+1 备援式1600W（80+ Platinum）电源（PSU） （默认只安装一组电源（PSU）模块）
产品电气额定值	输入： 1000W：100 - 120Vac, 12 - 10A, 50 - 60Hz, Class 1 1200W：120 - 140Vac, 12 - 10A, 50 - 60Hz, Class 1 1620W：180 - 240Vac, 10.5 - 8A, 50 - 60Hz, Class 1

2.8.2 备援式电源（PSU）模块 *(2-19页)*

- 系统会自动将两个电源（PSU）模块合成一个，输出功率会随着输入电压值而有所不同，请参考下列表格的信息。

输入电压	电源（PSU）最大输出电源（瓦特）
100 - 120Vac, 12 - 10A, 50 - 60Hz	1000W
120 - 140Vac, 12 - 10A, 50 - 60Hz	1200W
180 - 240Vac, 10.5 - 8A, 50 - 60Hz	1620W

- 若启用热插拔功能（备援模式），请保持系统的总电源功率在单颗电源（PSU）模块的最大输出电源以下。
- 为了稳定的电源输出，请使用服务器系统包装内附的电源线连接。