

Original	Substituto	Original	Substituto
Power	Power	Menu	Menu / Home
Mute	Mute / Dimmer	Up	Up
Text / Play/Pause	Play / Slow	Left	Left
Text / Play/Pause	Pause / Step / Freeze	Enter	OK
Text / Play/Pause	Text / Goto	Right	Right
Still / Stop	Stop / Hold	Down	Down
Radio	TV/Radio /	Info	Info / Angle
Aspect / Size	Zoom / Size	Exit	Exit / Cancel / Clear
Red / <<	<< / Tune-	Vol +	Vol+
Red / <<	Red / Netflix / Search	Index	Display / Media
Green / >>	Green / APP / Repeat	CH +	CH+ / Page+
Green / >>	>> / Tune+	Vol -	Vol-
Yellow / I<<	Yellow / YouTube / Repeat	List	Smart / List
Yellow / I<<	I<< / Preset-	CH -	CH- / Page-
Blue / >>I	>>I / Preset+	1	1
Blue / >>I	Blue / Prime Video / Random	2	2
Source	AV / Input / RDS	3	3





Original		Substituto		Original	Substituto
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
AUDIO I/II	Audio / I/II	LANG I/II AUDIO	Audio / Lang I/II		
0	0	HDMI - SAT 0	0		
DVB	DVB	TOP MENU D.MENU	D.Menu / Top		
♥	FAV	PC FAV MARKER	Fav / Marker / PC		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
↻	Prev. CH.	RETURN BACK	Back / Return		
⊟	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
USB	USB	SHIFT + USB 8	Shift + 8		
●	Rec	REC MODE ●	Rec / Rec Mode		

