OPERATIONS MANUAL

Model: UK BIRD CLOCK

REMOVING PACKAGING

To remove cardboard mount, use a screwdriver to loosen the two back screws counterclockwise. Do not attempt to remove the clock from cardboard while washers and screws are in place.

IMPORTANT! The following instructions must be followed exactly to ensure that the correct bird melody is heard for each hour.

SETTING THE TIME (Remove batteries before beginning)

1) Turn the hand set knob in rear of battery compartment clockwise or counterclockwise to read 10 minutes before 1:00 o'clock. (12:50)
2) Insert 3 "AA" size batteries into the battery compartment. Make sure that the polarity (+/-) is as indicated.
3) Turn the handset knob to adjust to desired time.

Note: Each time the set test (red) button is pressed, this resets the bird melodies to the next hour's bird. If pressed ,you must follow the instructions above to reset properly or you will not hear the correct melody with the correct bird.

HOURLY MELODY

1:00 Chaffinch	7:00 Wren
2:00 Cuckoo	8:00 Blackbird
3:00 Great Tit	9:00 Blue Tit
4:00 Great Spotted Woodpecker	10:00 Nightingale
5:00 Song Thrush	11:00 Robin
6:00 Barn Owl	12:00 Tawny Owl

LIGHT SENSOR

This clock has a silence function controlled by a light sensor positioned above the Tawny Owl.

GENERAL NOTICE

1) To clean the outside surface,use a clean,dry,soft cloth to wipe away fingerprints.Do not use any solvents or abrasive cleaners/polish.
2) Replace the batteries if the timekeeping becomes erratic or the bird sound becomes abnormal,as this may be an indication of battery exhaustion.

HELPLINE

In the event that you need help with this product please telephone the HELPLINE on the following number:

020 8208 1833
Open 9am to 5pm Monday to Friday



Zeon Ltd,
39 Waterloo Road,London,NW2 7TT,
Helpline Tel.Number 0208 208 1833

D0758