

Xtreme 6020 Driftwood Log Set

(sku 94700882)



The logs are made of a ceramic material that is FRAGILE. Carefully handle each log with both hands.

Overview

This log set is for use with an Xtreme 6020 that has been pre-configured for use with the driftwood log set. The four (4) threaded stud plates are pre-installed to suit these instructions.

Packing List

- Rear Left Log
- Rear Right Log
- Front Left Log
- Front Right Log
- Right Side Branch
- Left Twig
- Right Twig
- Center Twig

Log Installation

NOTE: The logs should be installed after the fireplace has been installed and tested for proper operation.

NOTE: The log set affects airflow inside the fireplace. Adjust the air shutters to fully open position prior to placing the glass. After operating the fireplace to insure proper flame performance, the air shutters may be closed slightly if needed.

1. Make sure the stud plates for the driftwood logs are installed. Install the crushed glass media over the perforated steel (see photo below). Make sure the crushed glass covers the stud plates but does not cover the pilot (see manual for complete details).



Xtreme 6020 Driftwood Log Set

(sku 94700882)

2. Place the rear left log along the back of the firebox so the hole on the base of the log inserts over the stud on the fireplace (see photos below). Position the log so it rests against the back wall of the firebox.



3. The rear right log has two holes on the base that insert over the studs at the back of the firebox (see photos below). Slide it to the left so it contacts the rear left log and the back wall of the firebox.





TRAVIS INDUSTRIES
HOUSE OF FIRE

Xtreme 6020 Driftwood Log Set

(sku 94700882)

4. Install the front left log as shown in the photos to the right and below. Make sure the pin on the rear right log inserts into the hole on the bottom of the front left log. When in place, the front left log rests on the ledge near the glass frame with approximately a 1" gap to the glass opening.



5. The front right log has a hole on the base that fits over the last pin on the firebox floor. Position the log as shown below with the front of the log resting on the ledge near the glass frame with approximately 2" gap to the glass opening.





TRAVIS INDUSTRIES
HOUSE OF FIRE

Xtreme 6020 Driftwood Log Set

(sku 94700882)

6. Position the right branch as shown in the photos below. Note how the branch rests on the nook of the front right log and touches the right side of the firebox wall.



7. Position the left twig as shown below. Note how the twig rests on the front left log.





TRAVIS INDUSTRIES
HOUSE OF FIRE

Xtreme 6020 Driftwood Log Set

(sku 94700882)

8. The right twig is placed under the front right log as shown below.



9. Position the center twig as shown below. When in place, the twig will insert under the front left log and line up with the right twig.



10. Replace the glass frame and start the fireplace. Let the fireplace burn for 30 minutes on high and check the logs for sooting. Remove the glass and carefully inspect the areas above the burner for soot accumulation. If any soot is detected, re-adjust the log and repeat this step to insure no sooting occurs.