



TRiSTAR TR-2571 Nose And Ear Trimmer Instruction Manual

[Home](#) » [Tristar](#) » TRiSTAR TR-2571 Nose And Ear Trimmer Instruction Manual 

TRiSTAR TR-2571 Nose And Ear Trimmer Instruction Manual



Contents

1 SAFETY

2 PARTS DESCRIPTION

3 BEFORE THE FIRST USE

4 USE

5 CLEANING AND MAINTENANCE

6 ENVIRONMENT

7 Documents / Resources

7.1 References

8 Related Posts

SAFETY

- By ignoring the safety instructions the manufacturer cannot be held responsible for the damage.
- This appliance is only to be used for household purposes and only for the purpose it is made for.
- Animal clipper, hair clipper, and appliances for manicure and pedicure can be used by children aged 3 years under supervision.
- Shaver, wet shaver, animal clipper, hair clipper, and appliances for manicure and pedicure can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- This appliance is intended for trimming purposes only.
- **WARNING:** Keep the appliance dry



This product complies with conformity requirements of the applicable European regulations or directives.



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local Authority or local store for recycling advice.



The Green Dot is the registered trademark of Der Grüne Punkt –Duales System Deutschland GmbH and is protected as a trademark worldwide. The logo may only be used by customers of DSD GmbH holding a valid trademark usage contract or by engaged waste management companies within the Federal Republic of Germany. This also applies to reproduction of the logo by third parties in a dictionary, an encyclopaedia or an electronic database containing a reference manual.



Separate collection / Check your local municipal guidelines.



The product and packaging materials are recyclable, subject to extended manufacturer responsibility. Dispose it separately, following the illustrated packaging symbols, for better waste treatment. The Triman logo is valid in France only.

PARTS DESCRIPTION



1. Nose, ear, eyebrow trimmer
2. On/off switch
3. Cover

BEFORE THE FIRST USE

- This personal grooming device is designed to trim the nose and earhairs. Do no attempt to use it for any other purpose.
- To place the battery turn the battery cover counter clockwise and remove it, after that insert one AA, R6- battery.
- Place the battery cover back on the device and turn clockwise to secure it.

USE

Turn the switch on and carefully insert the tip of the outer blade into your nostril- or ear hole to trim the nose and ear hairs.

Do not insert the device further into your nostril or an ear hole than the narrow tip on the outer blade. Also, do not press the trimmer forcefully into your nostril, or an ear hole. Do not attempt to use the device if the outer blade frame or blades are deformed or damaged, as injury to your nostril or an ear hole may occur. This trimmer is designed only for cutting nose or ear hairs. Do not attempt to use it for any other purpose. The blades have been precision manufactured. Do not subject them to excessive force, impact, etc. Be sure that the switch is turned off before attempting to clean the blades. If used once a week for approx. 1 min. at a time, the life of the blades is approx 4 years

CLEANING AND MAINTENANCE

- Cleaning the clipper blades regularly will maintain their optimal performance.
- Turn the cutting head anticlockwise and remove it. Briefly rinse off the drive shaft. Use running water to rinse off the stainless steel cutting system and let dry. Replace the cutting head and turn it counterclockwise until it snaps into place. Dry the housing with a soft cloth.

ENVIRONMENT



— This appliance should not be put into the domestic garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling of used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

Support

You can find all available information and spare parts at www.tristar.eu



Documents / Resources



[TRiSTAR TR-2571 Nose And Ear Trimmer](#) [pdf] Instruction Manual
TR-2571 Nose And Ear Trimmer, TR-2571, Nose And Ear Trimmer, And Ear Trimmer, Ear Trimmer

References

- *** [Tristar | Household appliances - Unbeatable basics for your home](#)
- *** [Tristar | Household appliances - Unbeatable basics for your home](#)