

## Safety instructions for ceiling mounting your BenQ projector PE5120, and PB 8 & 7 & 6 series

We want you to have a pleasant experience using your BenQ projector, so we need to bring this safety matter to your attention to prevent damage to person and property.

If you intend to mount your projector on the ceiling, we strongly recommend that you use a proper fitting BenQ projector ceiling mounting kit and that you ensure it is securely and safely installed.

If you use a non-BenQ brand projector ceiling mount kit, you will still need to use a proper screw type for installation.

You must only use the correct gauge and length screws to attach the projector to the adapter plate without the risk of causing damage to the projector or risking safety with an insecure attachment through the use of the wrong gauge or length screws.

The BenQ projector ceiling mounting kit contains the custom fitted adapter plate and the correct screws for safe and secure attachment of the projector to the adapter plate as illustrated (Fig. 1):

1. Projector base
2. Mounting adapter plate
3. M4 screws (max. M4 x 8L)
  - Screw torque limit = 10–12 kg-cm.
  - Screw length = 4–6 mm (threaded insert length)+thickness of the adapter plate




Fig. 1

You can purchase a BenQ projector ceiling mounting kit from the place you purchased your BenQ projector.

BenQ Corporation  
<http://www.BenQ.com>

June 2005

P/N: 46.J9402.001

## BenQ PE5120, PB8 & 7 & 6 系列天花板懸吊裝置安全注意事項

為確保您使用 BenQ 產品的愉快經驗，我們必須讓您知道此一安全注意事項，以避免對您或物品造成傷害。

如果您要將投影機倒掛天花板上，我們強烈建議您使用適合的 BenQ 天花板安裝工具，並請於安裝完成之後檢查懸吊設備是否安裝牢固。

如果您使用的不是 BenQ 品牌的天花板安裝工具，為了適當且安全的與投影機連接，也請你使用適當的螺絲來安裝投影機。

您必須使用正確寬度與長度的螺絲將投影機和投影機適用座緊密的連接，才可避免投影機從天花板掉落損壞，或因連接不穩固造成的安全問題。

如背面的安裝圖 (Fig. 1) 所示，BenQ 的天花板安裝工具包含一個合適的投影機適用座和正確的螺絲幫助您安全且牢固的連接投影機和投影機適用座。

1. 投影機
2. 投影機適用座
3. M4 螺絲 (最大 M4 x 8L)
  - 螺絲扭力限制 = 10–12 kg-cm。
  - 螺絲長度 = 4–6 mm (螺絲鎖入深度) + 投影機適用座的厚度

您可以向您購買 BenQ 投影機的商店購買 BenQ 天花板安裝工具。

明基電通股份有限公司

<http://www.BenQ.com>

2005 年 6 月

## BenQ PE5120, PB8 & 7 & 6 系列天花板懸吊裝置安全注意事項

為確保您使用 BenQ 產品的愉快經驗，我們必須讓您知道此一安全注意事項，以避免對您或物品造成伤害。

如果您要将投影机倒挂天花板上，我们强烈建议您使用适合的 BenQ 天花板安装工具，并请于安装完成之后检查悬吊设备是否安装牢固。

如果您使用的不是 BenQ 品牌的天花板安装工具，为了适当且安全的与投影机连接，也请你使用适当的螺丝来连接投影机和投影机适用座。

您必须使用正确宽度与长度的螺丝将投影机和投影机适用座紧密的连接，才可避免投影机从天花板掉落损坏，或因连接不稳固造成的安全问题。

如背面的安装图 (Fig. 1) 所示，BenQ 的天花板安装工具包含一个合适的投影机适用座和正确的螺丝帮助您安全且牢固的连接投影机和投影机适用座。

1. 投影机
2. 投影机适用座
3. M4 螺丝 (最大 M4 x 8L)
  - 螺丝扭力限制 = 10–12 kg-cm。
  - 螺丝长度 = 4–6 mm (螺丝锁入深度) + 投影机适用座的厚度

您可以向您购买 BenQ 投影机的商店购买 BenQ 天花板安装工具。

明基电通信息技术股份有限公司

<http://www.BenQ.com>

2005 年 6 月