

*Cypress
Hills*



ASSEMBLY INSTRUCTIONS

GREYSTONE END TABLE

MODEL # AXCRGREY01





DO NOT RETURN

FOR REPLACEMENT PARTS OR OTHER INQUIRIES
PLEASE CONTACT US AT:

1-800-667-8992

PLEASE ENSURE TO HAVE THE COLLECTION
NAME AND DESCRIPTION FROM THE
PACKAGING OR INSTRUCTION BOOKLET

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

May require 2 people for ease of assembly.

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

CARE and MAINTENANCE

Perhaps the greatest environmental damage to wood furniture comes from wide swings in relative humidity (RH) in our homes. Wood absorbs and desorbs water as relative humidity rises and falls, and in doing so it swells and shrinks. Making matters worse, it expands and contracts unequally along different grain directions. As humidity changes, the components of wooden objects are continually pushing and pulling against each other. This pressure often results in parts of furniture no longer fitting together closely or becoming distorted or breaking from their own internal stresses.

The response to relative humidity changes begins with determining the annual average RH for your particular space. Then try to keep the RH in the space where your furniture is as close to that average as possible, generally within about 10% up or down. De-humidify in the summer and humidify in the winter.

Be aware that raising the temperature lowers the humidity and vice versa. Thus, modern heating systems, which can drive down interior RH in the winter, almost invariably cause problems for furniture. To counteract their effect, you can either modify the RH by keeping furniture containing spaces cooler in the winter or most importantly, have a good working humidifier for your home. A humidistat automatically works to balance the humidity in your home so it is constant. Dry indoor air can suck enough moisture from its surroundings to do permanent damage to wood, causing it to crack or split.

Remember, that not all woods are created equal. Two factors that help determine how rapidly a wood will lose moisture are pore size and surface hardness. A piece made from a dense and hard wood will dry less rapidly than pieces made from softer woods.

Furniture that is sealed and lacquered will lose moisture more slowly than an unfinished piece while pieces with veneer finishes are not only stronger, but lose moisture more slowly than other finishes.

To help protect your wood furniture, take these steps:


- Use a humidifier, preferably one with an automatic control system that can sense the humidity level and adjust itself accordingly. Don't over-humidify; that can damage wood by causing it to expand and contract.
- Keep furniture out of direct sunlight, which can cause it to dry out, crack and warp.
- If you can avoid it, don't put furniture near heating vents. If you must, keep the piece 3 to 4 inches away from the wall, giving the heat and air space to circulate.
- Dust with soft dry cloth.
- Do not use liquid or aerosol products.
- To avoid marking, do not place rubber on surface (foot pads, etc.)
- For soil build-up, wipe with damp cloth & dry.
- Do not use abrasive cleaners.

COMPONENTS-KEY DIAGRAM

MODEL # AXCRGREY01


PART DESCRIPTION

AL




LEFT SIDE
QTY 1

AR




RIGHT SIDE
QTY 1

B




TOP
QTY 1

C




BOTTOM SHELF
QTY 1

D




BACK PANEL
QTY 1

E




DRAWER FRONT
QTY 1

FL




LEFT DRAWER SIDE
QTY 1

FR




RIGHT DRAWER SIDE
QTY 1

G



DRAWER BACK
QTY 1

H



DRAWER BOTTOM
QTY 1


NEED HELP? For help with assembly or if you are missing a part,
Please call customer service at 1-800-667-8992.

COMPONENTS-KEY DIAGRAM

MODEL # AXCRGREY01

HARDWARE DESCRIPTION

1



ALLEN KEY SCREW
M6 X 30mm
QTY 8

2




ALLEN KEY
QTY 1

3




CAM LOCK PIN
CAM LOCK
QTY 14 SETS

4





HANDLE
M4 X 25mm
QTY 1 SET




Required -
Flathead screwdriver
Phillips screwdriver
Not Included

NEED HELP? For help with assembly or if you are missing a part,
Please call customer service at 1-800-667-8992.




STEP-1




1. Attach four Cam Lock Pins (3) to back of Drawer Front (E).
2. Align Cam Lock Pins with pre-drilled holes and attach Drawer Sides (FL, FR).
3. Insert two Cam Locks (3) into pre-drilled holes on each Drawer Side (FL, FR).
4. Use flathead screwdriver to secure Cam Locks.

STEP-2





1. Slide Drawer Bottom (H) firmly into slots on Drawer Sides (FL, FR) and Drawer Front (E).

STEP-3




1. Align Drawer Back (G) with Drawer Bottom (H) and press firmly into slot.
2. Attach back using two Allen Key Screws (1) through pre-drilled holes on each side.
3. Use Allen Key (2) to tighten Screws. Do not over-tighten.

STEP-4




NOTE: The screwdriver is not included in the hardware pack.

1. Use phillips screwdriver to attach Handle (4) to Drawer Front (E).




STEP-5




1. Attach five Cam Lock Pins (3) to each Side (AL, AR) using guide holes.
2. Align Cam Lock Pins with pre-drilled holes on Bottom Shelf (C) and Back Panel (D).
3. Insert ten Cam Locks (3) into pre-drilled holes on Bottom Shelf (C) and Back Panel (D).
4. Use flathead screwdriver secure Cam Lock.

STEP-6



1. Attach Top (B) to Sides (AL), (AR) using four Allen Key Screws (1) (two screws on each Side).
2. Use Allen Key (2) to tighten. Do not over-tighten.

STEP-7



1. Insert assembled drawer into glides on assembled table.
Note: Levelers on bottom of legs can be adjusted if floor is uneven.