

INCLUDED

- 10,000mAh power bank
- Micro USB charging cable
- Instruction manual


GETTING STARTED CHARGING YOUR POWER BANK

Use the included charging cable to fully charge the power bank before first use.

- The white LED will blink while the power bank is charging
- The white LED will remain ON once charging is complete
- Unplug the power bank once it is fully charged
- Four white LEDs will remain ON when charging is complete

CHARGING YOUR DEVICE

Connect your device to the power bank using the included micro USB charging cable; charging will commence. White LEDs will display the current battery life of the power bank while it is charging.



SPECIFICATIONS

Battery capacity: 10 000mAh Micro Input: 5V == 2A USB Input: 5V == 2A IQ USB Input: 5V == 2A IQ Input charging time: ~7 hours Total Output: 5V/3A

Dimensions: 90.5 x 63.5 x 22.6 mm

Weight: $182g \pm 5g$

WARNING

- While charging, the power bank's casing may become warm, which is normal. Use it in a well-ventilated area when charging
- Keep the power bank away from heat sources, direct sunlight, humidity, water or other liquids
- DO NOT operate the power bank if wet or damaged to prevent electric shock, explosion and/or injury. Improper repairs of this device may place the user at risk
- DO NOT use the power bank with wet hands
- DO NOT use this power bank if it is damaged or modified, as it may exhibit unpredictable behaviour resulting in fire, explosion or injury
- DO NOT use this unit for anything other than its intended use



BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY

Contact your local hazardous waste management authorities for information on recycling or disposal programs in your area.

CAN ICES-3(B)/CAN NMB-3(B)



THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of twelve (12) months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

