



Model: WMCS05

4-in-1 Magnetic Wireless Charging Dock with Removable 5000mAh Power Bank



User Manual v1.1

In the box




- 1 x Wireless Charging Dock
- 1 x Watch Magnetic Charger
- 1 x Wireless Magnetic Power Bank
- 1 x 30W USB-C PD Wall Charger
- 1 x USB-C to C Charge Cable
- 1 x User Manual

Features

- Wirelessly charge an iPhone 14 / 13 / 12 series, Apple Watch, AirPods or AirPods Pro.
Note: AirPods must have Wireless Charging Case
- MagSafe compatibility ensures perfect alignment of your iPhone for optimum fast wireless charging every time
- Removable Apple Watch magnetic charger
- Removable 5000mAh MagSafe compatible wireless power bank with kick stand can provide one full charge for an iPhone*
- Works with all MagSafe compatible iPhone cases
Note: Does not work with **non-MagSafe** cases
- Full safety protection with temperature control, voltage regulation and short circuit protection
- Includes wall charger and 1.5m USB-C to USB-C cable

* One full charge based on an iPhone 12 Pro

Product Diagram



1. Wireless Charging Dock

2. Pogo-Pins

3. AirPods Charge Indicator LED

4. Wireless Charge area for AirPods

5. Watch Charging Input Port

6. USB-C Power Input Port

7. USB-A Output Port

8. Magnetic Phone charge area

9. Power Bank Capacity Indicator LEDs

10. Power Bank Kickstand

11. Removable Apple Watch Charger



12. Watch Charge Indicator LED

Assembly

Out of the box assemble your wireless charging stand and detachable Power Bank. Simply insert the watch module into the female USB-C port **5** and check the Power Bank is securely in the dock and touching the Pogo-Pins **2**. The magnetic phone charge module should be facing outward. Connect one end of the included USB-C cable to the included wall charger. Connect the other end to the USB-C Power Input Port on the back of the dock **6**. Once power is connected a steady Red LED will illuminate on the base of the dock and a steady green LED will illuminate on the watch module to indicate the dock is in standby.

Charging Your Devices

You can use the dock to charge your iPhone, AirPods and Apple Watch at the same time. Device charging starts automatically once any device is connected. To charge your iPhone, simply place your iPhone near the Magnetic charging area of the Power Bank **8** and the magnets will snap your iPhone securely in place. Charge your AirPods by placing them in the Wireless charge area **4**. Charge your watch by placing it on the watch module **11**. You can also charge another device using a USB-A cable (not included) in the USB-A port on the back of the dock **7**.



Removable Power Bank



When you are ready to go out, you can take the Power Bank with you for on the go charging. Simply slide the Power Bank out of the dock

The 5000mAh Power Bank can provide one full charge to an iPhone before needing recharging*

The Power Bank can provide charge to your iPhone using the MagSafe wireless charging system. Place your iPhone near the Magnetic charging area of the Power Bank and the magnets will snap your iPhone securely in place

The Power Bank can also provide charge via a cable to other mobile devices (not included) using its USB-C port.

The handy kick stand allows you to use the power bank as a portable phone stand while you recharge. Your phone can be charged in either Portrait or Landscape orientation



The Power Bank has an On/Off switch on the side. Press this button once to turn the Power Bank On and Press the button twice to turn the Power Bank Off

Charging the Power Bank

At the end of the day, always place your Power Bank back in the dock and it will automatically re-charge

The Power Bank can also be recharged separately using a USB wall charger and USB-C cable connected to the top of the Power Bank

LED Status

Docking Station Base LED

Solid Red: Powered Standby

Solid Green: AirPods Charging

Red / Green Flashing: Obstruction

Watch Charger LED

Solid Green: Powered Standby

Slow Pulsing Green: Watch Charging

Power Bank LED

3 x Solid Green: Power Bank Fully Charged

Flashing Green: Power Bank Charging

1st LED Flashing: 1% - 33% Charged

2nd LED Flashing: 33% - 66% Charged

3rd LED Flashing: 66% - 100% Charged

Power Bank Wireless Charging LED

Slowly Pulsing Blue: Wirelessly Charging iPhone

Flashing Blue: Obstruction

Power Bank Specifications

- Battery Capacity: 5000mAh
- Watt Hour: 19.25Wh
- USB-C Input: 5V/2.4A 9V/2A 12V/1.5A
- USB-C Output: 5V/2.4A 9V/2.22A 12V/1.5A (Max 20W)
- Wireless iPhone Output: 10W / 7.5W / 5W
- Total Output: 20W

Docking Station Specifications

- Wireless Standard: WPC/Qi (v1.2.4)
- Input: USB-C 30W
- Wireless iPhone Output: 10W / 7.5W / 5W
- Apple Watch USB-C Input: 5V/1A (5W)
- Apple Watch Output: 2W
- Wireless AirPods Output: 5W
- USB-A Output: 5V/1A (5W)
- Total Output: 17W
- Working Frequency: 110 to 205KHz
- Charging Distance: Up to 6mm
- Charging Efficiency: >70%
- Size: 166mm (H) x 127mm (W) 127mm
- Weight: 556g
- Certifications: RCM, RoHS

Important Safety Instructions

- When wirelessly charging a device, the wireless charger and your device may feel warm. This is a normal operating condition and should not be cause for concern.
- Only use the original wall charger and cable that was supplied with the charging dock
- Only use the product for the specified purpose of use
- Do not get wet to avoid causing short circuit damage and leakage
- Do not use in extreme hot, humid or corrosive environments to avoid short circuit damage and leakage
- Do not place too close to magnetic strip or chip ID card to avoid magnetic failure
- Do not place within 20cm of implantable medical devices (pacemaker, cochlear implant etc.) to avoid potential interference
- Do not clean with harmful chemicals or detergents
- Misuse, dropping or excessive force may cause damage to the charging dock
- Do not use the product if it is damaged or emits a suspicious odour
- Unplug the product from power sources when not in use

CAUTION

- Do not drop, misuse or apply excessive force to your power bank. Power banks contain batteries and a circuit board with fragile components that can be damaged if misused. If you drop or damage your power bank, discontinue use immediately.
- If crushed, punctured, exposed to fire or high temperatures or disassembled, batteries may catch fire, explode or cause burns.
- If your power bank swells or bulges, stop use immediately and dispose of the power bank in an appropriate manner. Continued use may cause the power bank to catch fire or explode.
- Do not charge the power bank and your device at the same time. It may cause the power bank to overheat.
- Store power bank in a cool and dry place. Do not store in hot or humid environments. Eg. In a car or directly in the sun.
- Power bank usage by children should be supervised.
- Do not put your power bank in a handbag, backpack or other bag where small metal objects can cause a short circuit.
- Do not dispose of power bank in heat or fire.
- All Comsol power banks have safety power cut off features to stop overcharging & overheating. However, we recommend disconnecting the power bank once it is fully charged and removing all cables.
- When charging a device, the power bank may feel warm, this is a normal operating condition & should not be cause for concern.
- In normal conditions, battery performance will decline over several years.
- Operating temperature should be between 0°C to 45°C.

iPhone, AirPods and Apple Watch are trademarks of Apple Inc., registered in the U.S. and other countries.
USB-C is a trademark of USB Implementers Forum.

www.comsol.com.au



Made in China