



 Position the USB camera on the top of TV.



2 Secure the lower part of the mount to the back cover of the TV and plug the USB cable into one of the USB ports on the



Open the cover slider and start using the USB camera

Tip: You may keep the cover slider closed when you are not using the USB camera to protect the lens from dust.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This accessory is compatible with TCL Google TV and TCL Android TV models

## Usage

- Ensure the normal connection between the USB camera and TV while using this product.
- The USB camera powers on automatically when you start corresponding applications on TV.
- The USB camera powers off automatically when you exit corresponding applications on TV.

 Applications on TV may vary depending on the model.
 To reduce flickering effect when using camera applications on TV, you can change the camera's frequency by pressing 
and on the remote control, and selecting System > Advanced Settings > Camera Flicker Reduction to switch between 50Hz and 60Hz according to the electrical frequency of your environment

## Specification

	•	
	Resolution	1920*1080
	Compression Format	H.264/MJPG/YUY2
	Connection Port	USB (5.0V 200mA)
_	Weight	60a



Appearance

Notice:

Use the privacy cover for extra security

The TV mount base features Sensitive Mics Dual Stereo Mics, with range up to 5 meters (16.4 feet)



Full HD Camera Sharp 1080p resolution

Wide 70-degree field of view



The specification and illustrations are for reference only and may differ from actual product. Changes may be made without prior notice.