



Ohaus Corporation
29 Hanover Road
Florham Park NJ
07932-0900

**INDUSTRIAL ELECTRONIC
WEIGHT INDICATOR
Model I10**

Instruction Manual

TABLE OF CONTENTS

Chapter 1 : Installation	6
Unpacking	7
Assembly	8
Rear Cover Removal	8
Load Receiver Connections	10
Power Options	11
RS232 Cable	12
Internal Switch Functions	13
Memory Mode Enabled	13
Sealing and Mounting	14
Turning the I 10 ON	15
Front Panel Button Functions	16
Chapter 2: Setup Mode	17
Setup Mode and the I 10 Menu Structure	18
Chapter 3: Setting Program Constants	20
Using the Program Constants Menu	21
Legal For Trade	23
Auto-Zero Tracking	24
Zero	25
Calibration Unit	26
Decimal Point Position	27
Graduations	28
Full Scale Point	29
Calibration Point	30
Chapter 4: Setting Program Options	32
Averaging Level	33
Unit Selection	34
Custom Units	35
Parts Counting Error Level	37
Auto Shut-off Timer and RS232 Parameters	39

Chapter 5: Calibration	44
Gain Jumper	45
Linearization Switch	45
Calibration Procedure	46
Chapter 6: Weighing, Parts Counting and Printing	48
Selecting a Weighing Unit or Parts Counting	49
Weighing	49
Taring	49
Parts Counting	51
Printing	53
Chapter 7: RS232 Interface	54
Hardware	55
Output Formats	55
RS232 Commands	55
Chapter 8: Legal For Trade Sealing	58
Setup and Calibration Restrictions	59
Labeling	59
Sealing	59
Chapter 9: Troubleshooting	62
Troubleshooting Chart	63
Error Messages	65
Care and Maintenance	66
Service Information	66
Chapter 10: Specifications, Replacement Parts and Accessories	67
Specifications	68
Replacement Parts	69
Accessories	69
Appendix 1: Common Custom Unit Conversions	70

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : the biggest supplier of cash register and scale manuals on the net