



# ViewSplit (Monitor Screen Split Software) User Guide

**ViewSplit** is a Windows application used to manage a ViewSonic Display to manual adjustment of the window organization. **ViewSplit** allows the selected ViewSonic monitor's desktop to be organized into various predefined or customizable windows layouts and automatically to fill specific regions within a window layout.

## ■ How to Install


Visit the ViewSonic website ([www.viewsonic.com](http://www.viewsonic.com)) and download the latest software for your monitor. This software has been designed specifically for ViewSonic monitors only.

## ■ How to Use

1. Connect the **ViewSonic** monitor and then double-click on the **ViewSplit** shortcut icon on the desktop, or click on the notification tray icon.



2. Select a predefined template.



3. The screen split layout is applied.
4. Open windows dragged into each zone will position and resize automatically.




# ViewSplit (Monitor Screen Split Software) User Guide

5. To create a customizable template:

5.1 Click the **Manual Adjust** icon:



5.2 Select a predefined template and then drag the Red-Line for the new custom layout.



5.3 Click Save icon, the size and position of the windows is saved as a customizable template layout.



6. To delete a customizable template:

6.1 Click the **Manual Adjust** icon:




6.2 Select a customizable template.

6.3 Click Delete icon, the selected customizable template is deleted.



7. Mini-View User Interface:



When a template is selected, ViewSplit Mini-View User Interface at the bottom right of the screen is pop out.

Click the Home icon can return to the main ViewSplit User Interface.

