

# ABI PRISM<sup>®</sup> 7700

Sequence Detection System

## User's Manual

© Copyright 2000, Applied Biosystems

**For Research Use Only. Not for use in diagnostic procedures.**

Printed in the U.S.A.

**Notice to Purchaser: Limited License**

A license under U.S. Patents 4,683,202, 4,683,195 and 4,965,188 or their foreign counterparts, owned by Roche Molecular Systems, Inc. and F. Hoffmann-La Roche, Ltd. ("Roche"), for use in research, has an up-front fee component and a running-royalty component. The purchase price of the TaqMan® Allelic Discrimination Demonstration Kit (P/N 402874) includes limited, non-transferable rights under the running-royalty component to use only this amount of the product to practice the Polymerase Chain Reaction ("PCR") and related processes described in said patents solely for the research activities of the purchaser when this product is used in conjunction with a thermal cycler whose use is covered by the up-front fee component. Rights to the up-front fee component must be obtained by the end user in order to have a complete license. These rights under the up-front fee component may be purchased from Applied Biosystems or obtained by purchasing an authorized thermal cycler. Further information on purchasing licenses to practice the PCR process may be obtained by contacting the Director of Licensing at Applied Biosystems, 850 Lincoln Centre Drive, Foster City, California 94404 or at Roche Molecular Systems, Inc., 1145 Atlantic Avenue, Alameda, California 94501.

**Authorized Thermal Cycler Notice**

This instrument, Serial No. \_\_\_\_\_, is an Authorized Thermal Cycler. Its purchase price includes the up-front fee component of a license under the patents on the Polymerase Chain Reaction (PCR) process, which are owned by Roche Molecular Systems, Inc. and F. Hoffman-La Roche Ltd., to practice the PCR process for internal research and development using this instrument. The running royalty component of that license may be purchased from Applied Biosystems or obtained by purchasing Authorized Reagents. This instrument is also an Authorized Thermal Cycler for use with applications licenses available from Applied Biosystems. Its use with Authorized Reagents also provides a limited PCR license in accordance with the label rights accompanying such reagents. Purchase of this produce does not itself convey to the purchaser a complete license or right to perform the PCR process. Further information on purchasing licenses to practice the PCR process may be obtained by contacting the Director of Licensing at Applied Biosystems, 850 Lincoln Centre Drive, Foster City, California 94404.

Except as provided above, no rights are conveyed expressly, by implication or estoppel to any patents on any other process, including but not limited to 5' nuclease assays, or to any patent claiming a reagent or kit.

ABI PRISM, AmpErase, MicroAmp, and Applied Biosystems are registered trademarks of Applied Biosystems Corporation or its subsidiaries in the U.S. and certain other countries.

ABI and Primer Express are trademarks of Applied Biosystems Corporation or its subsidiaries in the U.S. and certain other countries.

GeneAmp and TaqMan are registered trademarks and AmpliTaq Gold is a trademark of Roche Molecular Systems, Inc.

All other trademarks are the sole property of their respective owners.

P/N 904989B

01/2001

# Contents

<b>1</b>	<b><i>Introduction</i></b>	<b><i>1-1</i></b>
	Introduction	1-1
	About This Manual	1-2
	Technical Support	1-4
<b>2</b>	<b><i>Overview of Sequence Detection Software</i></b>	<b><i>2-1</i></b>
	Introduction	2-1
	Overview of Sequence Detection Software	2-2
	Run Types and Plate Types	2-4
	Features of the Sequence Detection Plate Document	2-5
	Sequence Detection Help	2-8
<b>3</b>	<b><i>Setup and Operation for Real Time Quantitation</i></b>	<b><i>3-1</i></b>
	Introduction	3-1
	Quick Review of Setup and Operation	3-3
	Turning on Power to the Sequence Detector	3-5
	Background Calibration	3-7
	Pure Dye Spectra Calibration	3-9
	Selecting a Run Type and a Plate Type	3-13
	Assigning Sample Types to Plate Wells in the Setup View	3-14
	Describing Sample Attributes	3-17
	Defining Thermal Cycler Conditions	3-19
	Entering Comments on the Setup View	3-22
	Saving the Completed Setup	3-23
	Preparing for Sequence Detector Operation	3-24
	Operating the Sequence Detector	3-31
<b>4</b>	<b><i>Setup and Operation for Allelic Discrimination</i></b>	<b><i>4-1</i></b>
	Introduction	4-1
	Running an Allelic Discrimination Assay	4-2
	Analyzing the Data	4-4
	Mathematical Transformations	4-8
	Making Manual Calls	4-9

<b>5</b>	<b><i>SR Plates, Plus/Minus Scoring, and IPCs</i></b>	<b>5-1</b>
	Introduction	5-1
	Single Reporter Plates and Plus/Minus Scoring	5-2
	Setting Up a Single Reporter Plate with an IPC Dye Layer	5-7
<b>6</b>	<b><i>Troubleshooting and Maintenance</i></b>	<b>6-1</b>
	Introduction	6-1
	Macintosh and General Troubleshooting	6-2
	7700 Sequence Detection System Troubleshooting	6-4
	System Requirements and Known Software Bugs	6-6
	Quick System Tests	6-8
<b>A</b>	<b><i>Guidelines to Master Mix Preparation</i></b>	<b>A-1</b>
	Introduction	A-1
	Guidelines for Master Mix Preparation	A-2
	Master Mix Preparation and Delivery Procedures	A-3
<b>B</b>	<b><i>Purification of DNA</i></b>	<b>B-1</b>
	Introduction	B-1
	Background and Requirements	B-2
	Preparation of Reagent Solutions and Samples	B-5
	Purifying DNA: The GenePure BaseBinder Procedure	B-8
	Purifying DNA: The QIAamp Procedure	B-11
	Determining DNA Quality	B-12
<b>C</b>	<b><i>Sequence Detection Software Reference</i></b>	<b>C-1</b>
	Overview	C-1
	General Plate Document Information	C-3
	Setup View Features	C-6
	Analysis View Features	C-10
	Shortcuts	C-14
	File Menu	C-16
	Edit Menu	C-22
	Setup Menu	C-24
	Instrument Menu	C-40
	Analysis Menu	C-48
	Graph Features	C-59
	Windows Menu	C-62

***D Theory of Operation . . . . .D-1***

Overview . . . . .	D-1
Fluorescence Detection on the ABI PRISM 7700 Instrument . . . . .	D-3
TaqMan Probe Design and Function . . . . .	D-7
Factors That Influence Performance . . . . .	D-9
Designing Probes . . . . .	D-11
Allelic Discrimination . . . . .	D-13
Single Reporter . . . . .	D-13
Multicomponenting . . . . .	D-15
Guidelines to Assay Development on the Sequence Detector . . . . .	D-17
References . . . . .	D-22

***E Limited Warranty Statement . . . . .23***

***Index***



# Introduction

---

# 1

## Introduction

---

**Overview** This chapter provides general information about the manual, special user attention words, safety, a summary of manual chapters, and technical support information.

---

**In This Chapter** This chapter contains the following topics:

Topic	See Page
About This Manual	1-2
General	1-2
User Attention Words	1-2
Safety	1-2
Summary of Manual Sections	1-2
Technical Support	1-4
Contacting Technical Support	1-4
To Contact Technical Support by E-Mail	1-4
Hours for Telephone Technical Support	1-4
To Contact Technical Support by Telephone or Fax	1-4
To Reach Technical Support Through the Internet	1-7
To Obtain Documents on Demand	1-7

---

## About This Manual

---

**General** This manual provides procedures for operating the ABI PRISM® 7700 Sequence Detector, describes instrument and software features, and presents some theory and guidelines to operation.

---

**User Attention Words** Throughout the *ABI PRISM® Sequence Detection System User's Manual*, four kinds of information are set off from the regular text. Each User Attention Word requires a particular level of observation or action that is significant to the user's safety or to proper instrument operation.

**Note** Used to call attention to information.

**IMPORTANT** Indicates information that is necessary for proper instrument operation.

**CAUTION** Indicates damage to the instrument or a potentially hazardous situation could occur and cause minor or moderate injury if you ignore this information.

**! WARNING !** Indicates serious physical injury to the user or other persons could result if these precautions are not implemented.

---

**Safety** Instrument and chemical safety issues which may need addressing during use of this instrument are covered in an accompanying document, the *ABI PRISM® 7700 Sequence Detection System Site Preparation and Safety Guide*. The guide provides the information needed to operate the instrument safely, including a description of safety alert symbols marked on the instrument, a discussion of laser safety issues, and necessary chemical safety information. Chemical safety information includes an MSDS for TaqMan® PCR Core Reagents supplied with the instrument.

---

**Summary of Manual Sections** **Chapter 1, Introduction.** A summary of the contents of the user manual, and where to call for technical support.

**Chapter 2, Overview of Sequence Detection Software.** Briefly describes the key features of the Sequence Detection software and the Sequence Detection Guide, an online help file.

**Chapter 3, Setup and Operation.** Presents all the procedures necessary to setup a plate of samples, run the Sequence Detector and analyze the data.

**Chapter 4, Allelic Discrimination.** Describes the setup, analysis, and graphs of the Allelic Discrimination Plate type.

**Chapter 5, Plus/Minus Scoring.** Describes how to perform runs using Plus/Minus Scoring.

**Chapter 6, Troubleshooting.** Describes common problems and possible solutions.

**Appendix A, Guidelines to Master Mix Preparation.** Provides guidelines and procedures needed to prepare the Master Mix.

**Appendix B, Purification of DNA.** Provides two methods for purifying DNA.

**Appendix C, Sequence Detection Software Reference.** Presents details on all the software features of the Sequence Detection software.



**Appendix D, Theory of Operation.** Describes the ABI PRISM Sequence Detection System, principles of fluorogenic probes, and their applications on the ABI PRISM 7700 Sequence Detector.

**Appendix E, Limited Warranty Statement.** The Applied Biosystems instrument warranty.

**Index.** An alphabetical listing of key words and features with their corresponding page numbers.

---

## Technical Support

**Contacting Technical Support** You can contact Applied Biosystems for technical support by telephone or fax, by e-mail, or through the Internet. You can order Applied Biosystems user documents, MSDSs, certificates of analysis, and other related documents 24 hours a day. In addition, you can download documents in PDF format from the Applied Biosystems Web site (please see the section "To Obtain Documents on Demand" following the telephone information below).

**To Contact Technical Support by E-Mail** Contact technical support by e-mail for help in the following product areas:

Product Area	E-mail address
Genetic Analysis (DNA Sequencing)	galab@appliedbiosystems.com
Sequence Detection Systems and PCR	pcrlab@appliedbiosystems.com
Protein Sequencing, Peptide and DNA Synthesis	corelab@appliedbiosystems.com
Biochromatography, PerSeptive DNA, PNA and Peptide Synthesis systems, CytoFluor®, FMAT™, Voyager™, and Mariner™ Mass Spectrometers	tsupport@appliedbiosystems.com
Applied Biosystems/MDS Sciex	api3-support@sciex.com
Chemiluminescence (Tropix)	tropix@appliedbiosystems.com

**Hours for Telephone Technical Support** In the United States and Canada, technical support is available at the following times:

Product	Hours
Chemiluminescence	8:30 a.m. to 5:30 p.m. Eastern Time
Framingham support	8:00 a.m. to 6:00 p.m. Eastern Time
All Other Products	5:30 a.m. to 5:00 p.m. Pacific Time

**To Contact Technical Support by Telephone or Fax** In North America To contact Applied Biosystems Technical Support, use the telephone or fax numbers given below. (To open a service call for other support needs, or in case of an emergency, dial **1-800-831-6844** and press **1**.)

Product or Product Area	Telephone Dial...	Fax Dial...
ABI PRISM® 3700 DNA Analyzer	1-800-831-6844, then press 8	1-650-638-5981
DNA Synthesis	1-800-831-6844, then press 21	1-650-638-5981
Fluorescent DNA Sequencing	1-800-831-6844, then press 22	1-650-638-5981
Fluorescent Fragment Analysis (includes GeneScan® applications)	1-800-831-6844, then press 23	1-650-638-5981
Integrated Thermal Cyclers (ABI PRISM® 877 and Catalyst 800 instruments)	1-800-831-6844, then press 24	1-650-638-5981

Product or Product Area	Telephone Dial...	Fax Dial...
ABI PRISM® 3100 Genetic Analyzer	1-800-831-6844, then press 26	1-650-638-5981
BioInformatics (includes BioLIMS™, BioMerge™, and SQL GT™ applications)	1-800-831-6844, then press 25	1-505-982-7690
Peptide Synthesis (433 and 43X Systems)	1-800-831-6844, then press 31	1-650-638-5981
Protein Sequencing (Procise® Protein Sequencing Systems)	1-800-831-6844, then press 32	1-650-638-5981
PCR and Sequence Detection	1-800-762-4001, then press 1 for PCR, 2 for the 7700 or 5700, 6 for the 6700 or dial 1-800-831-6844, then press 5	1-240-453-4613
Voyager™ MALDI-TOF Biospectrometry and Mariner™ ESI-TOF Mass Spectrometry Workstations	1-800-899-5858, then press 13	1-508-383-7855
Biochromatography (BioCAD® Workstations and Poros® Perfusion Chromatography Products)	1-800-899-5858, then press 14	1-508-383-7855
Expedite™ Nucleic acid Synthesis Systems	1-800-899-5858, then press 15	1-508-383-7855
Peptide Synthesis (Pioneer™ and 9050 Plus Peptide Synthesizers)	1-800-899-5858, then press 15	1-508-383-7855
PNA Custom and Synthesis	1-800-899-5858, then press 15	1-508-383-7855
FMAT™ 8100 HTS System and Cytofluor® 4000 Fluorescence Plate Reader	1-800-899-5858, then press 16	1-508-383-7855
Chemiluminescence (Tropix)	1-800-542-2369 (U.S. only), or 1-781-271-0045	1-781-275-8581
Applied Biosystems/MDS Sciex	1-800-952-4716	1-650-638-6223

#### Outside North America

Region	Telephone Dial...	Fax Dial...
<b>Africa and the Middle East</b>		
Africa (English Speaking) and West Asia (Fairlands, South Africa)	27 11 478 0411	27 11 478 0349
South Africa (Johannesburg)	27 11 478 0411	27 11 478 0349
Middle Eastern Countries and North Africa (Monza, Italia)	39 (0)39 8389 481	39 (0)39 8389 493
<b>Eastern Asia, China, Oceania</b>		
Australia (Scoresby, Victoria)	61 3 9730 8600	61 3 9730 8799
China (Beijing)	86 10 64106608	86 10 64106617

Region	Telephone Dial...	Fax Dial...
Hong Kong	852 2756 6928	852 2756 6968
Korea (Seoul)	82 2 593 6470/6471	82 2 593 6472
Malaysia (Petaling Jaya)	60 3 758 8268	60 3 754 9043
Singapore	65 896 2168	65 896 2147
Taiwan (Taipei Hsien)	886 2 22358 2838	886 2 2358 2839
Thailand (Bangkok)	66 2 719 6405	66 2 319 9788
Europe		
Austria (Wien)	43 (0)1 867 35 75 0	43 (0)1 867 35 75 11
Belgium	32 (0)2 712 5555	32 (0)2 712 5516
Czech Republic and Slovakia (Praha)	420 2 61 222 164	420 2 61 222 168
Denmark (Naerum)	45 45 58 60 00	45 45 58 60 01
Finland (Espoo)	358 (0)9 251 24 250	358 (0)9 251 24 243
France (Paris)	33 (0)1 69 59 85 85	33 (0)1 69 59 85 00
Germany (Weiterstadt)	49 (0) 6150 101 0	49 (0) 6150 101 101
Hungary (Budapest)	36 (0)1 270 8398	36 (0)1 270 8288
Italy (Milano)	39 (0)39 83891	39 (0)39 838 9492
Norway (Oslo)	47 23 12 06 05	47 23 12 05 75
Poland, Lithuania, Latvia, and Estonia (Warszawa)	48 (22) 866 40 10	48 (22) 866 40 20
Portugal (Lisboa)	351 (0)22 605 33 14	351 (0)22 605 33 15
Russia (Moskva)	7 095 935 8888	7 095 564 8787
South East Europe (Zagreb, Croatia)	385 1 34 91 927	385 1 34 91 840
Spain (Tres Cantos)	34 (0)91 806 1210	34 (0)91 806 1206
Sweden (Stockholm)	46 (0)8 619 4400	46 (0)8 619 4401
Switzerland (Rotkreuz)	41 (0)41 799 7777	41 (0)41 790 0676
The Netherlands (Nieuwerkerk a/d IJssel)	31 (0)180 331400	31 (0)180 331409
United Kingdom (Warrington, Cheshire)	44 (0)1925 825650	44 (0)1925 282502
All other countries not listed (Warrington, UK)	44 (0)1925 282481	44 (0)1925 282509
Japan		
Japan (Hacchobori, Chuo-Ku, Tokyo)	81 3 5566 6230	81 3 5566 6507
Latin America		
Del.A. Obregon, Mexico	305-670-4350	305-670-4349

To Reach Technical  
Support Through the  
Internet

We strongly encourage you to visit our Web site for answers to frequently asked questions and for more information about our products. You can also order technical documents or an index of available documents and have them faxed or e-mailed to you through our site. The Applied Biosystems Web site address is

**<http://www.appliedbiosystems.com/techsupp>**

To submit technical questions from North America or Europe:

Step	Action
<b>1</b>	Access the Applied Biosystems Technical Support Web site.
<b>2</b>	Under the Troubleshooting heading, click Support Request Forms, then select the relevant support region for the product area of interest.
<b>3</b>	Enter the requested information and your question in the displayed form, then click Ask Us RIGHT NOW (blue button with yellow text).
<b>4</b>	Enter the required information in the next form (if you have not already done so), then click Ask Us RIGHT NOW.  You will receive an e-mail reply to your question from one of our technical experts within 24 to 48 hours.

To Obtain Documents  
on Demand

Free, 24-hour access to Applied Biosystems technical documents, including MSDSs, is available by fax or e-mail or by download from our Web site.

To order documents...	Then...
by index number	<ol style="list-style-type: none"> <li>Access the Applied Biosystems Technical Support Web site at <a href="http://www.appliedbiosystems.com/techsupp">http://www.appliedbiosystems.com/techsupp</a></li> <li>Click the Index link for the document type you want, then find the document you want and record the index number.</li> <li>Use the index number when requesting documents following the procedures below.</li> </ol>
by phone for fax delivery	<ol style="list-style-type: none"> <li>From the U.S. or Canada, call 1-800-487-6809, or from outside the U.S. and Canada, call 1-858-712-0317.</li> <li>Follow the voice instructions to order the documents you want.</li> </ol> <p><b>Note</b> There is a limit of five documents per request.</p>
through the Internet for fax or e-mail delivery	<ol style="list-style-type: none"> <li>Access the Applied Biosystems Technical Support Web site at <a href="http://www.appliedbiosystems.com/techsupp">http://www.appliedbiosystems.com/techsupp</a></li> <li>Under Resource Libraries, click the type of document you want.</li> <li>Enter or select the requested information in the displayed form, then click Search.</li> <li>In the displayed search results, select a check box for the method of delivery for each document that matches your criteria, then click Deliver Selected Documents Now (or click the PDF icon for the document to download it immediately).</li> <li>Fill in the information form (if you have not previously done so), then click Deliver Selected Documents Now to submit your order.</li> </ol> <p><b>Note</b> There is a limit of five documents per request for fax delivery but no limit on the number of documents you can order for e-mail delivery.</p>



# Overview of Sequence Detection Software

# 2

## Introduction

**General** The Sequence Detection application program allows you to set up sample and experimental information, and run the thermal cycler while measuring and analyzing fluorescence from your 96-well reaction plate. This section describes the salient features of the Sequence Detection application program.


Appendix C, "Sequence Detection Software Reference," provides detailed descriptions of the Sequence Detection application program. Appendix D, "Theory of Operation," presents more specific information about 5' nuclease assays with TaqMan® PCR reagents.

**In This Chapter** The contents of the chapter are as follows:

Topic	See Page
Overview of Sequence Detection Software	2-2
General	2-2
Software Control of the Instrument and the Experiment	2-3
Analyzed Data: The Terminology	2-3
Run Types and Plate Types	2-4
General Assumption	2-4
Run Types	2-4
Plate Types	2-4
Features of the Sequence Detection Plate Document	2-5
General	2-5
Setup View	2-5
Analysis View	2-6
Dye Layers	2-7
Sequence Detection Help	2-8
How to use	2-8

## Overview of Sequence Detection Software

**General** The Sequence Detection software program runs on a Macintosh computer connected to the ABI PRISM® 7700 Sequence Detector by a serial communication cable, as shown in Figure 2-1:



**Figure 2-1** Interconnection of the Sequence Detector and Macintosh

The application program manages all communication with the instrument to perform the following tasks during Real Time and End Point runs:

- ◆ Set up sample and experimental information
- ◆ Operate the thermal cycler
- ◆ Collect and analyze fluorescence data
- ◆ Display data in graphic charts
- ◆ Export data and print reports of the results

An experiment performed completely on the ABI PRISM 7700 Sequence Detector goes through three phases: Setup, Run, and Analysis:

- a) Setup - defining experiment setup and Thermal Cycler conditions
- b) Run - performing Thermal cycling with real-time collection of fluorescent signal changes
- c) Analysis - applying Multicomponenting algorithms to fluorescence data

**IMPORTANT** In the Plate Read run mode, PCR may occur on the 7700 or an external thermal cycler, but only end-point analysis is performed and the benefits of real-time analysis are foregone. As you read this manual, keep in mind that much of the material is intended to support use of the instrument in its Real Time run mode where the full instrument capabilities are used.

*continued on next page*



---

**Software Control of the Instrument and the Experiment**

On the monitor screen, the Sequence Detection application mimics the 96-well plate you use to perform your experiment. Use the application to record the dyes and samples in each well of the 96-well plate, the thermal cycler parameters you use during the experiment, and then start the sequence detector.

During the Polymerase Chain Reaction (PCR), use the application to examine changes in fluorescence after PCR is complete, analyze the fluorescence data and generate a Standard Curve. Finally, you can save the plate setup information and acquired data as an electronic record of your experiment.

---

**Analyzed Data:  
The Terminology**

---

**Real Time Runs**

In Appendix D, "Theory of Operation," you can find a thorough description of the TaqMan fluorescent probe, its performance during PCR, and how the increase in fluorescence signal can be used to quantitate samples. Briefly, data analysis on the Sequence Detection application uses three terms to express results:  $R_n$ ,  $\Delta R_n$ , and  $C_T$ .

$R_n$ , or the normalized reporter signal, represents the fluorescence signal of the reporter dye divided by the fluorescence signal of the passive reference dye. During PCR,  $R_n$  increases as amplicon copy number increases until the reaction approaches a plateau. When using the instrument in its Plate Read mode, the fluorescence signal is read at a single point in time after the completion of PCR rather than continuously during the course of PCR.

$\Delta R_n$  represents the normalized reporter signal minus the baseline signal established in the first few cycles of PCR. Like  $R_n$ ,  $\Delta R_n$  increases during PCR as amplicon copy number increases until the reaction approaches a plateau.

$C_T$ , or threshold cycle, represents the PCR cycle at which an increase in reporter fluorescence above a baseline signal can first be detected. The Sequence Detection software generates a Standard Curve of  $C_T$  vs. (LogN) Starting Copy Number for all standards and then determines the starting copy number of unknowns by interpolation.

In a PCR system with 100% efficiency, the threshold cycle decreases by one cycle as the concentration of template doubles.

---

## Run Types and Plate Types

---

**General Assumption** This manual assumes you have a basic understanding of the polymerase chain reaction (PCR) and some experience setting up PCR experiments.

---

**Run Types** The Sequence Detection application provides two Run types, Real Time and Plate Read. A Real Time run occurs when you use the ABI PRISM 7700 Sequence Detection System to collect data during each cycle of PCR. A Plate Read run collects only one reading, after PCR is completed, also known as an end-point reading.

**Table 2-1** Features of Run Types on the Sequence Detection Application

	Real Time	Plate Read
<b>Data Collection</b>	User-defined, possible at any Stage of PCR	Only end-point
<b>Fluorescence Detection</b>	At each PCR cycle	Only end-point
<b>Analysis Results</b>	$R_n$ and $\Delta R_n$ at each cycle $C_T$ and Standard Curve Estimated starting copy number for each sample	$R_n$ and $\Delta R_n$ at end point +/- detection of template AD Score Allele called for each sample

**Plate Types** Plate Types on the Sequence Detection application are closely related to your experiment's design and the Run Type you choose.

**Table 2-2** Features of Plate Types on Sequence Detection Application

Run Type	Plate Type	Analysis Results
Real Time	Single Reporter	$C_T$ and Standard Curve $R_n$ and $\Delta R_n$ at each cycle Estimated starting copy number for each sample
	Background	Background component
	Pure Spectra	Pure Dye component
Plate Read	Single Reporter	$R_n$ and $\Delta R_n$ at end point +/- detection of template
	Allelic Discrimination	$R_n$ and $\Delta R_n$ at end point +/- detection of template Allele called for each sample

---

## Features of the Sequence Detection Plate Document

**General** The 96-well plate on the monitor screen has two views: Setup and Analysis. Each view contains tools for performing specific tasks. Both views have one or more “dye layers.” Each dye layer corresponds to the reporter dye on any probe.

**Setup View** The Setup View appears when you first start up the Sequence Detection software or open a new plate. In the Setup view, you can:

- ◆ Assign a Sample Type to each well
- ◆ Assign names to replicate samples
- ◆ Define the Thermal Cycler Conditions
- ◆ Indicate when data is collected during PCR
- ◆ Enter comments about the plate or the experiment

Chapter 3, “Setup and Operation for Real Time Quantitation,” tells how to perform these tasks for a real time run. Chapter 4, “Setup and Operation for Allelic Discrimination,” tells how to perform these tasks for an Allelic Discrimination (Plate Read) run.

When you have entered all the information about the experiment in the Setup view, you switch to the Analysis view and run the experiment from the instrument. See page C-6 for a detailed description of the features on the Setup view.

Thermal Cycler Conditions button

Plate type

Sample Information

Toggle to Analysis view

96 sample wells

The screenshot displays the 'Setup View' of the Sequence Detection software. At the top, there's a title bar 'Install Kit, Taqman Gold'. Below it, the 'Sample Information' section includes 'Sample Type' (STND - Standard), 'Sample Name' (B4), 'Replicate' (2), and 'Quantity' (5.0e+03). To the right, the 'Thermal Cycler Conditions' section is visible, and further right, the '7700 Single Reporter' section with a 'Comment' field. Below these, there's a 'Show Analysis' button and a 'Dye Layer' dropdown set to 'FAM'. The main area is a 96-well plate grid with columns 1-12 and rows A-H. The grid contains sample names (e.g., NTC A1, STND B1) and numerical values (e.g., 1.0e+03, 5.0e+03). The well B4 is highlighted with a red border. Labels with leader lines point to various UI elements: 'Thermal Cycler Conditions button' points to the button above the grid; 'Plate type' points to the '7700 Single Reporter' section; 'Sample Information' points to the top-left section; 'Toggle to Analysis view' points to the 'Show Analysis' button; and '96 sample wells' points to the grid itself.


	1	2	3	4	5	6	7	8	9	10	11	12
A	NTC A1	NTC A2	NTC A3	NTC A4	STND A5	STND A6	STND A7	STND A8	STND A9	STND A10	STND A11	STND A12
B	STND B1	STND B2	STND B3	STND B4	STND B5	STND B6	STND B7	STND B8	STND B9	STND B10	STND B11	STND B12
C	UNKN C1	UNKN C2	UNKN C3	UNKN C4	UNKN C5	UNKN C6	UNKN C7	UNKN C8	UNKN C9	UNKN C10	UNKN C11	UNKN C12
D	UNKN D1	UNKN D2	UNKN D3	UNKN D4	UNKN D5	UNKN D6	UNKN D7	UNKN D8	UNKN D9	UNKN D10	UNKN D11	UNKN D12
E	UNKN E1	UNKN E2	UNKN E3	UNKN E4	UNKN E5	UNKN E6	UNKN E7	UNKN E8	UNKN E9	UNKN E10	UNKN E11	UNKN E12
F	UNKN F1	UNKN F2	UNKN F3	UNKN F4	UNKN F5	UNKN F6	UNKN F7	UNKN F8	UNKN F9	UNKN F10	UNKN F11	UNKN F12
G	UNKN G1	UNKN G2	UNKN G3	UNKN G4	UNKN G5	UNKN G6	UNKN G7	UNKN G8	UNKN G9	UNKN G10	UNKN G11	UNKN G12
H	UNKN H1	UNKN H2	UNKN H3	UNKN H4	UNKN H5	UNKN H6	UNKN H7	UNKN H8	UNKN H9	UNKN H10	UNKN H11	UNKN H12

Figure 2-2 The Setup View

*continued on next page*

**Analysis View** In the Analysis view, you can:

- ◆ Start the Sequence Detector
- ◆ Collect fluorescence signals
- ◆ Analyze raw data, after all data is collected



**Figure 2-3** The Analysis View

With Real Time run data, you can:


- ◆ Examine real-time changes in  $R_n$  and  $\Delta R_n$  at each PCR cycle
- ◆ Generate a Standard Curve
- ◆ View graphs of raw spectra for each cycle
- ◆ View graphs of  $R_n$ ,  $\Delta R_n$ , and  $C_T$  for each sample after analysis
- ◆ View multiple spectral components in each well
- ◆ Export tab-delimited data

With a Plate Read run, you can collect and analyze end-point data to calculate  $R_n$  and  $\Delta R_n$  for each sample after the final PCR cycle.

See page C-10 for a detailed description of the features of the Analysis view.


*continued on next page*

**Dye Layers** Both the Setup and the Analysis views can display up to eight dye “layers,” each of which corresponds to a reporter dye. The example in Figure 2-4 shows three dye layers: FAM, HEX, TET.



**Figure 2-4** Graphic representation of dye layers in setup and analysis windows

The 96-well plate on the computer screen displays the contents of each well according to the dye-labeled probe associated with each sample. For example, all samples that have a fluorogenic probe labeled with the FAM reporter are visible in the FAM layer. You can view each dye layer by using the pop-up menu of dyes (Figure 2-5).



**Figure 2-5** Use the Dye Pop-up Menu to Switch between Dye Layers


When your experiment includes more than one fluorogenic probe and a different fluorescent reporter is attached to each probe, the wells displayed in each dye layer vary accordingly. You associate the samples to the appropriate dye-labeled probe in the Sample Type Setup dialog box. See page C-33 for more information about the Sample Type Setup dialog box.



## Sequence Detection Help

**How to use** The Sequence Detector Guide is an on-line help file designed to help you use the Sequence Detection application. It complements the *ABI PRISM 7700 Sequence Detection System User's Manual* by providing on-line instructions and answers to your questions about how the Sequence Detection application works.

**Note** To use the Sequence Detector Guide, your computer must use System 7.5.1 operating system or later.

To see the Sequence Detection Software Guide:

- ◆ While the Sequence Detection software is open on your computer, choose Sequence Detector Guide from the  menu in the top right corner of the monitor.



If you cannot open the Sequence Detector Guide, follow these steps.

Step	Action
1	Open the Extensions folder in the System folder on your computer.
2	Does the Extensions folder contain Apple Guide 2.0, Quick Time Power Plug 2.1, and Quick Time 2.1? <ul style="list-style-type: none"><li>◆ If yes, go to step 3.</li><li>◆ If no, re-install these extensions. You can find them on the 7700 Installer CD. Then go to step 3.</li></ul>
3	Open the Control Panels in the Apple menu, then open the Extensions Manager.
4	Turn on Apple Guide, Quick Time Power Plug, and Quick Time.
5	Restart your computer to start these extensions. You can now open the Sequence Detector Guide.

# Setup and Operation for Real Time Quantitation

# 3

## Introduction

**General** This chapter describes how to use the Sequence Detection software to set up your experiment, run the Sequence Detector, and monitor PCR.

**In This Chapter** This chapter contains the following topics:

Topic	See Page
Quick Review of Setup and Operation	3-2
Main Steps of Setup	3-3
Preparing for Sequence Detector Operation	3-4
Main Steps of Operation	3-4
Turning on Power to the Sequence Detector	3-4
General	3-5
Connecting the Application to the Instrument	3-5
Background Calibration	3-6
General	3-7
Generating a Background Component File	3-8
Pure Dye Spectra Calibration	3-9
General	3-10
Generating Pure Spectra Data	3-11
Extracting Component Pure Spectra	3-12
Selecting a Run Type and a Plate Type	3-13
General	3-14
Procedure	3-14
Assigning Sample Types to Plate Wells in the Setup View	3-14
General	3-15
Listing Sample Types	3-15
Procedure	3-16
Describing Sample Attributes	3-17
General	3-17
Procedures	3-17
Defining Thermal Cycler Conditions	3-19
Introduction	3-19

<b>Topic</b>	<b>See Page</b>
Viewing the Method	3-20
Viewing Data Collection	3-21
Entering Comments on the Setup View	3-22
Saving the Completed Setup	3-23
General	3-23
Procedure	3-23
Preparing for Sequence Detector Operation	3-24
General	3-24
Printing a 96-Well Sample Map	3-24
Preparing 96-Well Sample Trays for the Sequence Detector	3-25
Placing the 96-Well Sample Trays on the Sequence Detector	3-29
Closing the Cover on the Sample Block	3-30
Checking the Software Connection	3-30
Operating the Sequence Detector	3-31
General	3-31
Stopping the Sequence Detector	3-32
Opening the Cover after a Hold at 4°C	3-32

---








## Quick Review of Setup and Operation

### Main Steps of Setup

The table below provides you with a quick, graphic review of how to use the Sequence Detection software to set up and run your experiment on the Sequence Detector and monitor the reaction.

**IMPORTANT** During the installation of the ABI PRISM® 7700 Sequence Detector, data files for Background and Pure Dye Spectra are created in the Preferences folder. These files must be on your computer before you can set up an experiment with the Sequence Detection application program.

To set up the sequence detector, follow this procedure:

Step	Action	What it looks like...	Do this...
1	Turning on power to the Sequence Detector		Turn on power at least 10 min. before starting a run. See page 3-5.
2	Selecting a Run Type and a Plate Type		Choose New Plate in the File menu. See page 3-13.
3	Designating dyes		Choose Edit Sample List in the Sample Type pop-up menu See page 3-14.
4	Assigning Sample Types to plate wells		Choose Sample Type Palette in the Setup menu. See page 3-14.
5	Defining Thermal Cycler Conditions		Click the Thermal Cycler Conditions button on the Setup view. See page 3-19.

Step	Action	What it looks like...	Do this...
6	Entering comments on the Setup view		Type in the Comments field. See page 3-22.
7	Saving the completed setup		Choose Save As... in the File menu. See page 3-23.

### Preparing for Sequence Detector Operation

After you have set up and saved a plate document on the Sequence Detection software, load samples on the sample tray and place the sample tray in the sample block (see page 3-29).

**IMPORTANT** Always use MicroAmp® Optical Caps with either the MicroAmp® Optical 96-Well Reaction Plate or MicroAmp® Optical Tubes (in a tray/retainer) on the ABI PRISM 7700 Sequence Detector.

You can begin the Sequence Detector run after you tighten the sample block cover in place.

### Main Steps of Operation


The following table provides a quick review of how to operate the Sequence Detection software to acquire and save data.

To operate the Sequence Detector, follow this procedure:

Step	Action	What it looks like...	Do this...
1	Toggle to Analysis view		Click Show Analysis button in the Setup view. See page 3-31
2	Start Sequence Detector run		Click Run button in Analysis view. See page 3-31.
3	Monitor PCR progress		Thermal cycler status is shown in the Analysis View during a run.

## Turning on Power to the Sequence Detector

**General** Turn on the power to the Sequence Detector at least ten minutes before using it to run a PCR experiment. When the power switch is in the off position, the cover to the sample block is not heated. When you turn on the power, the temperature of the sample block cover begins to rise. We do not recommend running the Sequence Detector until the temperature of the heated cover is approximately 105 °C.



**Figure 3-1** Location of Power Switch on the ABI PRISM 7700 Sequence Detector

On position

To turn on the power to the Sequence Detector, press the power switch to the On position, represented by a vertical line.

### Connecting the Application to the Instrument

#### Two Things Required for Communication

To communicate between the Sequence Detector application program and the Sequence Detector, you need the following two things:

- ◆ A Macintosh serial cable used with the custom adapter (see page 2-2) between the computer and the instrument, and
- ◆ A software connection to establish communication, as described in "Procedure to Establish Communication" on page 3-6.

#### Stand-alone and Connected Modes


The Sequence Detection application program on the ABI PRISM® 7700 Sequence Detection System can be used in one of two modes: "stand-alone" or "connected" to the instrument.

- ◆ Stand-alone (when the application is not connected to the Sequence Detector) - use the application program to design PCR experiments or re-analyze previously collected data.
- ◆ Connected (when the application program is connected to the instrument) - use the software to design PCR experiments, run them on the instrument, then collect and analyze data.

**Note** The application program can be disconnected from the instrument, even when the serial cable is in place, by deselecting the “Online Document” checkbox in the Preferences dialog box under the Edit menu (shown in the figure in step 1 below).

### Procedure to Establish Communication

To connect the Sequence Detection application to the Sequence Detector:

Step	Action
1	<p>Choose the Preferences command in the Edit menu.</p>  <p>The Preferences dialog box opens.</p>
2	<p>Click the “Online Document” checkbox. By default, all new plate documents are now automatically connected to the Sequence Detector when this checkbox is selected.</p>
3	<p>Is a plate document currently open? If yes, save the open plate document. Go to step 4. If no, you are done.</p>
4	<p>Do you want to apply the new Preferences to the open plate document? If yes, close the open plate document and then re-open it. If no, you are done.</p>

**Note** The Preferences are stored in the System folder (Preferences:SDS:SDS Preferences).

For more information about Preferences, see page C-22.

# Background Calibration

**General** Spectra signals collected by the Sequence Detection application include signal inherent in the system or “background.” This background signal can interfere with the sensitivity of the Sequence Detection application and its ability to determine  $C_T$ . To overcome this interference, you must generate a Background component file.

## Generating a Background Component File

### Requirements

Use TE Buffer or sterile, filtered water and the Background Plate Type to generate a Background data file. All wells on the Background Plate Type are automatically labeled “BKGND.”



Use the conditions specified in Table 3-1:

**Table 3-1** Thermal Cycling Conditions


	Hold 1
Temperature (°C)	60.00
Time (min:sec)	2:00

### Procedure

To generate a background data file:


Step	Action
1	<p>In the File menu, choose New Plate.</p>  <p>The New Plate dialog box appears.</p>
2	<p>In the Plate Type pop-up, choose Background. The desired instrument, the 7700 Sequence Detector is the default choice.</p> <p>Click OK to close the dialog box and open a Background plate document, like that shown below.</p> 

To generate a background data file: *(continued)*

Step	Action
3	Open the Thermal Cycling Conditions and enter the recommended Hold (see Table 3-1).
4	Deliver 50 $\mu$ L of TE Buffer or water to each MicroAmp Optical Tube on a 96-well plate and cover all tubes with MicroAmp Optical Caps.
5	Place the 96-well plate in the Sequence Detector sample block, slide the cover over the block, and tighten the lid.
6	<p>In the Analysis view of the Sequence Detection application, click the Run button</p>  <p>The screenshot shows a software interface with the following elements:         <ul style="list-style-type: none"> <li><b>Sample Type:</b> A dropdown menu currently showing "NTC - No Template Cont..."</li> <li><b>Sample Name:</b> A text input field.</li> <li><b>Replicate:</b> A text input field.</li> <li><b>Quantity:</b> A text input field.</li> <li><b>Buttons:</b> A grey "RUN" button and a red "STOP" button.</li> <li><b>Status:</b> "Status: Idle"</li> <li><b>Temperatures:</b> "Cov. Temp: 0.0°C" and "Smp1. Temp: 0.0°C"</li> <li><b>Time:</b> "Remaining: 00:00:00"</li> <li><b>Progress:</b> "Stage: 0", "Repetition: 0", "Time: 00:00:00", and "Step: 0"</li> </ul> </p>
7	<p>When the run is complete, choose Calibrate from the Instrument menu. Choose Extract Background Component.</p> <p>This step creates the background component that the Sequence Detection application subtracts from each pure dye spectra.</p>
8	Save the plate document with an identifying name, such as Background.
9	Quit the application for the new calibration to take effect.

## Pure Dye Spectra Calibration

**General** The Sequence Detection application features real-time monitoring of signal generated during PCR by fluorescent dyes FAM, TET, HEX, JOE, TAMRA, and ROX. Pure spectra information for these dye standards are collected during a 2-minute hold at 60 °C as part of the instrument installation procedure. The spectra data files are stored on the computer and used by the Sequence Detection application algorithm during data analysis. When a plate document is saved after data analysis, the pure spectra information is saved with the rest of the collected fluorescent data for that experiment.



**Figure 3-2** Pure Spectra of Six Fluorescent Dyes

Figure 3-2 shows an example of the pure spectra for each of the dyes in the TaqMan Spectral Calibration Kit. The Y (vertical) axis represents spectral fluorescence normalized to an area of 1. You can view the Pure Spectra saved on your computer by choosing Edit Pure Spectra under the Calibrate command in the Instrument menu (see page C-40).

You can repeat the spectral calibration procedure to update the pure spectra data files or to test instrument performance. First, you must generate a Pure spectra data file, then extract each component dye spectrum from the collected data.

**IMPORTANT** You must generate a Background Component file before you can perform a Pure Dye Spectra Calibration.

*continued on next page*

## Generating Pure Spectra Data

### Requirements

Use the TaqMan Spectral Calibration Kit (P/N 401930), which contains six dye standards: FAM, TET, HEX, JOE, TAMRA, and ROX.


Use the conditions specified in Table 3-2:

**Table 3-2** Thermal Cycling Conditions

	Hold 1
Temperature (°C)	60.00
Time (min:sec)	2:00

### Procedure

To generate a spectra data file:

Step	Action
1	<p>In the File menu, choose New Plate.</p>  <p>The New Plate dialog box appears.</p>
2	<p>In the Plate Type pop-up menu, choose Pure Spectra. The desired instrument (7700 Sequence Detector) and Run type (Real Time) are the default choices.</p> <p>Click OK to close the dialog box and open a Pure Spectra plate document.</p>
3	Enter the Thermal Cycling Conditions shown above (Table 3-2).
4	On the plate document, designate four wells for each of the dye standards: FAM, TET, HEX, JOE, TAMRA, and ROX (using the plate setup shown in step 1 of the procedure on the next page for Extracting Spectra).
5	Deliver 50 $\mu$ L of each dye standard to four MicroAmp Optical Tubes apiece on a 96-well plate. Use the same order designated on the Setup view of the Pure Spectra plate. Cover all tubes with MicroAmp Optical Caps.
6	Place the 96-well plate in the Sequence Detector sample block and tightly close the lid.
7	<p>In the Analysis view of the Sequence Detector application, click the Run button.</p> <p>When the run is finished, you can look at the raw spectra by double-clicking on any well in the Analysis view.</p>
8	<p>When the run is complete, save the plate document and data with an identifying name, such as Pure Spectra.</p> <p>After you generate the pure spectra data, continue by calibrating each component dye (using the Extraction procedure on the next page).</p>



*continued on next page*




## Extracting Component Pure Spectra

Use the Analysis view of the Sequence Detection application to extract each pure dye spectrum from the collected Pure spectra data file. You must extract dye spectra for the reporter dye on each TaqMan probe (FAM, JOE, HEX or TET), the quencher on each TaqMan probe (TAMRA), and the passive reference (ROX).

To extract component pure spectra:

Step	Action
1	<p>In the Analysis view, select the first set of wells that contain the same dye (FAM in our example).</p> 
2	<p>In the Instrument menu, choose Calibrate, then choose Extract Spectra Component and Pure Spectra, or use the keyboard shortcut, ⌘ J.</p>  <p>The Pure Spectra Extraction dialog box appears.</p> <p>The dye name attached to the selected wells appears in the field labeled “Pure Spectra Name.” You can edit this dye name.</p> <p>You can also change the color assigned to the Pure Spectra by double-clicking the color and using the Color Wheel dialog box (page C-35).</p>
3	<p>Click OK to close the Pure Spectra Extraction dialog box.</p> <p>The Extract Pure Spectra dialog box opens and displays a graph of the dye spectra for each selected well. Background component has been subtracted from the spectra on the display and each spectra has been normalized to an area of 1.</p>

To extract component pure spectra: *(continued)*

Step	Action
	<div data-bbox="451 709 539 737" data-label="Text">Spectra</div> 
4	Click the boxes in the scroll box labeled “Sample (Well)” to turn off and on each well's spectra in the graph.
5	<p>Below the graph, you can select and discard wells that contain spectra you want to eliminate from the pure dye spectra.</p> <p>As a general rule, discard spectra that have shapes that do not fit the shape of the other spectra. Differences in spectra amplitude are not significant if the shape is a good fit.</p>
6	<p>If you want to save the dialog box with your changes, click OK.</p> <p>If you want to close the dialog box without saving your changes or any of the dye spectra, click Cancel.</p>
7	Return to step 1 and repeat this procedure for each dye you need to extract.
8	When all dyes have been extracted, quit the application for the new calibration to take effect.

## Selecting a Run Type and a Plate Type

**General** When you first start the Sequence Detection application, a new plate document appears on the monitor screen. By default, the new plate document uses the Single Reporter Plate Type. In the Preferences dialog box, you can change the default Run Type and Plate Type. See page C-22 for a description of Preferences.

Choose a Run Type and a Plate Type that supports your experiment's design and function. Choices available include


- ◆ Single Reporter Real Time or Plate Read plates
- ◆ Allelic Discrimination (AD) plate

See page 2-4 for more information on Run Types and Plate Types.

**IMPORTANT** During the installation of the ABI PRISM 7700 Sequence Detector, data files for both Background and Pure Dye Spectra are created by the computer. These files must be on your computer before you can set up an experiment with the Sequence Detection software. See page 3-7 and page 3-10 for information on creating these files.

You can also use the New Plate dialog box to override the Preferences and choose another Plate Type.


**Procedure** To use the New Plate dialog box:

Step	Action
1	If a plate document is already open, close it.
2	Choose New Plate in the File menu.  The New Plate dialog box opens.
3	Select a Plate Type in the Plate Type menu (the 7700 Sequence Detector is chosen as a default).
4	In the Run pop-up menu, select the appropriate Run Type.
5	Click OK to close the dialog box and open a new plate document. The new plate document assumes the characteristics of the selected Run and Plate Types.

# Assigning Sample Types to Plate Wells in the Setup View

**General** For real-time fluorescence monitoring and data analysis, each well in the Setup view must contain accurate sample type information.

Sample type information appears in the Sample Type Palette, the Sample Type pop-up menu, or the Sample Type Setup dialog box (Figure 3-3). You can use either the Sample Type Palette or the Sample Type pop-up menu to assign sample information to the wells in the Setup View. See "Sample Type Setup Dialog Box" on page C-33 to read how to edit the sample list.



**Figure 3-3** Sample Information appears in Three Objects



Although either the Sample Type pop-up menu or the Sample Type Palette can be used to assign the Sample Type to wells selected in the Setup View, the Sample Type pop-up menu has an additional capability. After you have collected and analyzed data, you can instruct the software analysis routine to ignore data by designating one or more wells as "Not in Use" by selecting this item on the pop-up menu. The data so designated will be ignored on the next re-analysis but can be restored by redesignating "Not in Use" wells with a functional acronym.

**Listing Sample Types** Each entry on the Sample Type Palette is identified by an acronym and a Reporter dye. The Reporter dye indicates which dye is attached to the fluorogenic probe that specifically anneals to that Sample Type during the PCR. The list of items in the Sample Type Palette corresponds to the list on the Sample Type Setup dialog box.

*continued on next page*

**Procedure** The procedure below is used to assign sample types in the Setup View.

To assign a sample to one or more wells with the Sample type Palette:

Step	Action
1	<p>Choose Sample Type Palette in the Setup menu.</p>  <p>Sample type —</p> <p>Reporter dye —</p> <p>Update button —</p> <p>Use to edit Sample List —</p>
2	<p>Compare the entries in the Sample Type Palette to the samples you are using in your experiment. Make sure each Sample Type has the right Reporter Dye assigned to it.</p> <p>If the palette contains all the Sample types you need and they each have the appropriate Reporter Dye, you can now assign the Sample Types to the wells in the Plate window.</p> <p>If you need to edit an entry in the Sample Type Palette, use the Sample Type Setup dialog box. See "Sample Type Setup Dialog Box" on page C-33.</p>
3	<p>Click a well on the Setup view to select it.</p> <p>A selected well is outlined in black.</p> <ul style="list-style-type: none"> <li>Click and drag across the plate to select multiple contiguous wells.</li> <li>Press the Command (c)key and click on wells to select multiple discontinuous wells. Click on a row or column label (A–H, 1–12) to select an entire row or column of wells.</li> </ul>  <p>Selected well —</p>

To assign a sample to one or more wells with the Sample type Palette: *(continued)*

Step	Action
4	<p>In the Sample Type Palette, click the check box next to the acronym for the sample you want to put in the selected well(s).</p> <p>If the Sample Type Palette does not contain all the samples you need, see "Sample Type Setup Dialog Box" on page C-33.</p> <p><b>Note</b> To generate a Standard Curve with the Sequence Detection software, use at least 5 standards or samples of known template amount. The range of known copy numbers should bracket the anticipated copy numbers of the unknown samples on the same plate.</p>
5	<p>Click the Update button on the Sample Type Palette to assign the sample to the selected well.</p> <p>The selected well now displays the acronym for the sample you've selected. If you have added more than one sample+probe system, use the dye pop-up menu to look at each dye layer. (See "Dye Layers" on page 2-7.)</p> <p><b>Note</b> Use at least five Standards to generate a Standard curve.</p>

---

## Describing Sample Attributes

**General** In addition to assigning a Sample Type, you can further describe the sample in a well or group of wells by typing in the entry fields labeled Sample Name, Replicate and Quantity. When you group two or more wells that contain the same sample and designate them as a replicate, the Sequence Detection software calculates the mean starting quantity and its standard deviation and displays it in the Experiment Report. (For more information on the Experiment Report, see "Experiment Report" on page C-62.

The screenshot shows a software window with the following fields and a plate layout:

- Sample Type:** A dropdown menu showing "UNKN-Unknown".
- Sample Name:** A text field containing "Unknown 3".
- Replicate:** An empty text field.
- Quantity:** An empty text field.
- Show Analysis:** A dropdown menu showing "FAM".

Below these fields is a 2x5 grid representing a plate layout:

	1	2	3	4	5
A	NTC A1	NTC A2	NTC A3	NTC A4	UNKN A5
B	UNKN Unknown 3	UNKN Unknown 3	UNKN Unknown 3	UNKN Unknown 3	UNKN B5

Three lines point from the labels "Sample Name field", "Replicate field", and "Quantity" to their respective input fields.

**Figure 3-4** Assigning Sample Information

### Procedures Sample Names and Replicates fields:

The procedures for designating Sample Names and Replicates, are provided below:

To designate Sample Name:

Step	Action
1	Select a well or group of wells that contain the same sample.
2	Click the Sample Name entry field and enter a sample name.  The contents of this entry field appear in the selected wells. The middle line in the well displays the first 10 characters of the Sample Name, replacing the letter-number combination (A1, C3, etc.).

To designate Replicates:

Step	Action
1	Select the wells that contain the same sample.
2	Click the Replicate entry field and enter the name of the replicate.
3	The information in the Replicate entry field appears on the Experiment Report.

### Quantity Unit Field

The field is used only on plates used to generate a Standard Curve. Use the Preferences in the Edit menu to designate the unit used for values entered in the Quantity entry field (page C-6). By default, the unit is copy number.

**Note** The same quantity unit applies to all wells in the same plate. Use the Quantity entry field to designate the known quantity of Standard sample types. To generate a Standard Curve, you must assign a quantity to each Standard on the plate

To designate sample quantity:

**IMPORTANT**

Step	Action
1	Select wells that contain the same concentration or copy number of template.
2	Click the Quantity entry field and enter a number. Do not use commas to separate integers.
3	Press the Tab key.  The number you enter is automatically converted to scientific notation. (See "Entry Fields" on page C-6 for an explanation of scientific notation).

If you know that Standard 1 has a copy number of approximately 1000, use copy number as the quantity unit for all standards. All results for Unknowns are expressed in the same quantity unit as the Standards.


---




## Defining Thermal Cycler Conditions

**Introduction** The Thermal Cycler Conditions dialog box contains two views. Use the first view (the Time and Temperature view) to define the thermal cycler method plus the Sample Volume. Use the second view (the Data Collection view) to indicate where you want the Sequence Detection software to collect data during the PCR run.

To open the Thermal Cycler Conditions dialog box, click the Thermal Cycler Conditions button on the Setup view. The dialog box will open in the first view shown below:



Define thermal cycler method in this view (Time and Temperature view)



Define data collection in this view (Data Collect View)

**Figure 3-5** Two Thermal Cycler Conditions Views

To change views in the Thermal Cycler Conditions dialog box:

Step	Action
1	Click the button labeled "Show Data Collection" to define data collection.
2	Click the button labeled "Show Time and Temp" to define the method.

## Viewing the Method **Graphic Representation of a Method**

The upper illustration in Figure 3-5 provides a graphic representation of a method. A method contains all the information about time and temperature changes that occur during a complete sequence detector run.

There are several ways to edit the features in a method. You can:

- ◆ Add or remove Steps, Cycles, or Holds
- ◆ Change the temperature or time associated with any Step
- ◆ Adjust the ramp time between two Steps
- ◆ Define an Auto Increment for time and temperature

**IMPORTANT** Do not enter a value less than 30 seconds (00:30) for an extension step in a Cycle. See page C-30 for more information on extension time.

See "Setting Up Thermal Cycler Conditions" on page C-24 for more information on thermal cycler setup.

### Designating Sample Volume

In the Thermal Cycler Conditions dialog box, you can indicate the volume of sample in each well on the 96-well plate. Sample, in this case, refers to the entire contents of any well, including buffer blank, or any combination of master mix and nucleic acids. The default sample volume, 50  $\mu$ L, can be modified in the Preferences dialog box (see page C-22).

**Note** All wells on one plate should contain the same volume of sample. Performance specifications on the ABI PRISM 7700 are based on 50  $\mu$ L of sample in each well.

### Ramp Times

The ramp time between two Steps in the Thermal Cycler Conditions is the time needed to go from one temperature to the next. When the ramp time is set to the minimum ramp time of zero, the rate of temperature change on the thermal cycler is approximately 1 °C/second. For example, the shortest possible time necessary to ramp from 50 °C to 95 °C is approximately 45 seconds. The maximum ramp time is 9 minutes and 59 seconds. See page C-29 for information on changing ramp times.

### Auto Increment and Decrement


The Auto Increment feature appears in the Thermal Cycler Conditions dialog box. With this feature, you can automatically increase or decrease the time or temperature associated with any Step by a fixed amount with each Cycle repetition. For example, you can increase the extension time of a Cycle to accommodate the increased amount of amplicons produced as PCR progresses.

**IMPORTANT** The temperature range of the thermal cycler sample block is 4.0 to 99.9 °C. The Sequence Detection software does not accept an auto-increment value that would eventually cause the temperature of the sample block to exceed this range.

See page C-30 for more information on the Auto Increment feature.

### Viewing Data Collection

The Data Collect view, shown below, displays the same method you created in the Time and Temperature view. You must put a Data Collection icon on this method wherever you want the Sequence Detection software to collect data during a run. For meaningful real-time data analysis, *there must be a Data Collection icon on the extension step.*



**Figure 3-6** Using a Data Collect Icon

To add or remove a Data Collection icon:

- ◆ Click once on a plateau in the Data Collection view to add an icon.
- ◆ Click once on a Data Collection icon to remove the icon.

See Data Collection on page C-31 for more details about data collection during a run.

See "Instrument Menu" on page C-40 for information on how collected data is analyzed.

**Note** The 7700 Sequence Detector does not collect data on temperature ramps.

## Entering Comments on the Setup View

You can attach notes or comments about the experiment in the Comment entry field, in the top right corner of the Setup view. The comments entered in the Setup view also appear in the Comments field of the Analysis view and the Experiment Report.

**Beta Actin Install Kit**

**Thermal Cycler Conditions**

**7700 Single Reporter**

**Comment:**  
This plate contains all beta-actin standards.

5	6	7	8	9	10	11	12
STND A5 2.0e+03	STND A6 2.0e+03	STND A7 5.0e+03	STND A8 5.0e+03	STND A9 1.0e+04	STND A10 1.0e+04	STND A11 2.0e+04	STND A12 2.0e+04
STND B5 2.0e+03	STND B6 2.0e+03	STND B7 5.0e+03	STND B8 5.0e+03	STND B9 1.0e+04	STND B10 1.0e+04	STND B11 2.0e+04	STND B12 2.0e+04
UNKN C5 1.2e+04	UNKN C6 1.1e+04	UNKN C7 1.2e+04	UNKN C8 1.2e+04	UNKN C9 1.1e+04	UNKN C10 1.1e+04	UNKN C11 1.1e+04	UNKN C12 1.1e+04
UNKN D5 1.2e+04	UNKN D6 1.0e+04	UNKN D7 1.2e+04	UNKN D8 9.9e+03	UNKN D9 1.2e+04	UNKN D10 1.1e+04	UNKN D11 1.1e+04	UNKN D12 1.1e+04
UNKN E5 1.1e+04	UNKN E6 1.1e+04	UNKN E7 1.1e+04	UNKN E8 1.1e+04	UNKN E9 1.1e+04	UNKN E10 1.1e+04	UNKN E11 1.1e+04	UNKN E12 1.1e+04
UNKN F5 5.9e+03	UNKN F6 6.4e+03	UNKN F7 6.1e+03	UNKN F8 6.5e+03	UNKN F9 6.0e+03	UNKN F10 6.5e+03	UNKN F11 6.5e+03	UNKN F12 6.5e+03
UNKN G5 6.1e+03	UNKN G6 6.6e+03	UNKN G7 6.0e+03	UNKN G8 6.1e+03	UNKN G9 5.7e+03	UNKN G10 5.9e+03	UNKN G11 5.9e+03	UNKN G12 5.9e+03
UNKN H5 6.1e+03	UNKN H6 6.2e+03	UNKN H7 5.8e+03	UNKN H8 6.6e+03	UNKN H9 6.1e+03	UNKN H10 6.0e+03	UNKN H11 6.0e+03	UNKN H12 6.0e+03

**Experiment Report**

**Applied Biosystems**

**Sequence Detection System**

**File Name:** Beta Actin Install Kit  
**User:**  
**Date:** Sat, Jul 26, 1997  
**Comments:** This plate contains all beta-actin standards

**Plate Type:** 7700 Single Reporter  
**PCR Volume:** 50

**Thermal Cycle Conditions**

Cycle	Temperature	Time	Repeat	Ramp Time	Auto Inc
Hold	50.00	2:00		Auto	
Hold	95.00	10:00		Auto	
Cycle	95.00	0:15	40	Auto	
	60.00	1:00		Auto	
Hold	4.00	95:00		Auto	

**Standard Curve**

**Slope:** -3.85  
**Intercept:** 37.21  
**Fit R:** 0.98

**Threshold:** 0.01  
**Baseline Range:** (3, 15)

**Sample Information**

Well	Type	Sample Name	Replicate	Ct	Quantity	Std. Dev.
A7	STND	AZ		25.78	1.0e+03	0.00

Setup View

Experiment Report

**Figure 3-7** Comments on Setup View appear in Experiment Report

- ◆ To enter comments in the Setup view, click the cursor in the Comments entry field and type your comments.

The comments field may contain up to 255 characters.

You can modify comments on the Setup view, but not on the Analysis view or the Experiment Report.

## Saving the Completed Setup

**General** You can save the Setup using a unique, descriptive name. This name appears on the Experiment Report as the File Name.


You can also choose to save the Setup as a normal file or as a stationery file. A normal file saves all information on the plate document, including acquired data, but not analyzed data. Changes you make to a normal file remain in the file.

The stationery file saves the following user-defined information and is used as a template for experiments that you plan to repeat frequently:

- ◆ Run Type and Plate Type
- ◆ Sample Types in each well
- ◆ Thermal Cycler Conditions

When you open a stationery file, Sequence Detection software opens a copy of the file for you to use. Changes you make to the copy do not affect the original stationery plate file. When you save or close the copy, you can save it as a normal file or re-name it as another stationery file. The Sequence Detection software labels stationery plate files with a unique icon.

**Procedure** To save the Setup:

Step	Action
1	<p>Choose Save in the File menu and enter a descriptive name in the directory dialog box.</p> 
2	<p>Click a format icon.</p> <ul style="list-style-type: none"><li>◆ Choose the Stationery format icon to create a stationery file.</li><li>◆ Choose the Normal format icon to create a normal file.</li></ul>

## Preparing for Sequence Detector Operation


**General** Once you have set up your experiment on the Setup view, you can print a map of the 96-well plate with the samples listed in each well. Refer to the sample map to distribute your samples on the 96-well sample tray. (Also, see Appendix B, Purification of DNA.)

**Printing a 96-Well Sample Map** A sample map shows how samples and standards are distributed. You can print this map for your paper records and to help you set up your experiment. The full-sized, rectangular map is wider than 8.5 inches. Use the Page Setup dialog box to determine the size and orientation of the printed sample map.

NTC A1	NTC A2	NTC A3	NTC A4	STND A5 1.0e+03	STND A6 1.0e+03	STND A7 1.0e+03	STND A8 1.0e+03	STND A9 2.0e+03	STND A10 2.0e+03	STND A11 2.0e+03	STND A12 2.0e+03
STND B1 5.0e+03	STND B2 5.0e+03	STND B3 5.0e+03	STND B4 1.0e+04	STND B5 1.0e+04	STND B6 1.0e+04	STND B7 1.0e+04	STND B8 1.0e+04	STND B9 2.0e+04	STND B10 2.0e+04	STND B11 2.0e+04	STND B12 2.0e+04
UNKN C1 1.0e+04	UNKN C2 8.7e+03	UNKN C3 1.2e+04	UNKN C4 1.0e+04	UNKN C5 1.1e+04	UNKN C6 1.1e+04	UNKN C7 1.0e+04	UNKN C8 1.1e+04	UNKN C9 9.9e+03	UNKN C10 9.1e+03	UNKN C11 8.7e+03	UNKN C12 1.0e+04
UNKN D1 9.8e+03	UNKN D2 1.1e+04	UNKN D3 1.0e+04	UNKN D4 1.2e+04	UNKN D5 1.1e+04	UNKN D6 8.8e+03	UNKN D7 9.6e+03	UNKN D8 1.1e+04	UNKN D9 9.7e+03	UNKN D10 9.4e+03	UNKN D11 9.4e+03	UNKN D12 9.4e+03
UNKN E1 1.2e+04	UNKN E2 1.0e+04	UNKN E3 1.1e+04	UNKN E4 1.0e+04	UNKN E5 1.1e+04	UNKN E6 1.1e+04	UNKN E7 9.0e+03	UNKN E8 9.9e+03	UNKN E9 1.0e+04	UNKN E10 7.6e+03	UNKN E11 9.2e+03	UNKN E12 1.0e+04
UNKN F1 5.1e+03	UNKN F2 5.4e+03	UNKN F3 4.4e+03	UNKN F4 4.8e+03	UNKN F5 5.3e+03	UNKN F6 5.2e+03	UNKN F7 4.1e+03	UNKN F8 5.1e+03	UNKN F9 4.7e+03	UNKN F10 5.1e+03	UNKN F11 5.1e+03	UNKN F12 4.7e+03
UNKN G1 5.1e+03	UNKN G2 4.6e+03	UNKN G3 5.2e+03	UNKN G4 5.6e+03	UNKN G5 5.0e+03	UNKN G6 5.3e+03	UNKN G7 4.5e+03	UNKN G8 4.8e+03	UNKN G9 4.9e+03	UNKN G10 4.5e+03	UNKN G11 4.7e+03	UNKN G12 5.0e+03
UNKN H1 5.2e+03	UNKN H2 4.1e+03	UNKN H3 4.7e+03	UNKN H4 4.8e+03	UNKN H5 4.3e+03	UNKN H6 4.7e+03	UNKN H7 3.9e+03	UNKN H8 4.9e+03	UNKN H9 4.6e+03	UNKN H10 4.7e+03	UNKN H11 4.7e+03	UNKN H12 3.8e+03

**Figure 3-8** A reduced view of a sample map

To print a 96-well sample map:

Step	Action
1	With the Setup view displayed on your computer monitor, choose Page Setup in the File menu.  <p style="text-align: right;">Landscape orientation</p>
2	The Page Setup dialog box appears.
3	Click the Landscape orientation icon. You can also reduce the map in the Reduce or Enlarge entry field. Click OK to close the Page Setup dialog box.
4	Choose Print from the File menu. Click the Print button to print.


*continued on next page*

## Preparing 96-Well Sample Trays for the Sequence Detector


### Two 96-Well Plate Formats

A 96-well plate can be comprised of either a MicroAmp Optical 96-Well Reaction Plate and MicroAmp Optical Caps, as shown in Figure 3-9, or of individual MicroAmp Optical Tubes placed in a MicroAmp 9600 tray and then capped with MicroAmp Optical Caps as shown in Figure 3-10.

The Sequence Detector sample block accommodates a 96-well plate with MicroAmp Optical Caps, in either format. Use a 96-well plate, in one of these formats to set up your experiment. Remove the base before placing the 96-well plate in the Sequence Detector sample block.



**Figure 3-9** Assembly of MicroAmp® Optical 96-Well Reaction Plate and MicroAmp® Optical Caps on Optical Support Base



**Figure 3-10** Assembly of Sample Tray, Optical Tubes and Caps on Optical Support Base

**IMPORTANT** Remove the Optical Support base before placing the tray on the sample block.

The 96-well plate and optical caps have been especially designed to work with the system of fiber optics and CCD (charged-couple device) camera that monitors fluorescence during PCR.

**IMPORTANT** For accurate fluorescence detection, always use the MicroAmp 96-well plate and Optical Caps on the ABI PRISM 7700 Sequence Detector. Do not attach sticky labels to the tubes or caps or mark them with ink.


The design of the MicroAmp Optical Cap incorporates a thin-walled optically clear dome that allows transmission of fluorescent signals.

**IMPORTANT** Use the MicroAmp® Cap-installing Tool (N801-0438) to securely tighten the MicroAmp® Optical Caps onto the MicroAmp® Optical Tubes.




## Procedure

To prepare your 96-well plate for analysis:

Step	Action
1	<ul style="list-style-type: none"> <li>◆ If you are using the 96-well reaction plate, place the plate on the Optical Support support base as shown in Figure 3-11.</li> <li>◆ If you are using the assembly shown in Figure 3-10, assemble the components as shown in the figure and place the assembly on the Optical Support Base as shown in Figure 3-11.</li> </ul>
2	Add the samples for your experiment to wells as indicated on your printed sample map.
3	<p>Hold a strip of MicroAmp Optical Caps over a row of tubes and use the blunt end of the cap installing tool to push and seat each cap firmly in place (Figure 3-11).</p>  <p><b>Figure 3-11</b> Pushing the Caps in Place with the MicroAmp® Cap-installing Tool (N801-0438)</p>

To prepare your 96-well plate for analysis: *(continued)*

Step	Action
4	<p>After all the caps are in place, with moderate force, use the roller end of the tool to roll over all caps (Figure 3-12).</p>  <p><b>Figure 3-12</b> Reinforcing Cap Placements with the Roller End</p>


*continued on next page*

### Placing the 96-Well Sample Trays on the Sequence Detector

- ◆ Place the 96-well sample tray on the Sample Detector Sample Block as shown in Figure 3-13.

The 96-well sample tray fits on the sample block in only one position. An opening on the left side of the tray fits onto a protrusion on the surface of the sample block. When the tray has been correctly placed in the sample block, the A1 position on the sample tray sits in the upper left-hand corner of the sample block (Figure 3-13).

**CAUTION** The Sequence Detector does not operate properly when the sample tray is improperly positioned on the sample block.



**Figure 3-13** Placing a 96-Well Tray on the Sequence Detector Sample Block

**CAUTION** DO NOT analyze radioactive samples on the ABI PRISM 7700 Sequence Detector. If radioactivity leaks onto the sample block, the entire block must be removed for a lengthy decontamination process. This decontamination process is not covered by the instrument's Limited Warranty.

**Note** The upper right-hand corner of a 96-well plate (near A-12) is usually indicated with a triangular cut. This is the industry standard indicator for the proper orientation of a 96-well plate.


*continued on next page*

**Closing the Cover on the Sample Block**

After the 96-well plate is in place, do the following:

Step	Action
1	Slide the sample block cover back over the sample block.
2	Turn the large knob on top of the cover clockwise to tighten the lid in place, referring to Figure 3-14.

When the cover is properly tightened, the white area of the ring on top of the large knob faces the front of the instrument.



**Figure 3-14** Tighten the Knob on the Sample Block Cover

**Checking the Software Connection**


When you are ready to run the Sequence Detector, check that the Sequence Detection application is connected to the instrument.

To check the connection to the Sequence Detector:

Step	Action
1	Click the Show Analysis button to toggle the plate document to the Analysis view.
2	Verify that the Status field displays the word "Idle."  If the Status field displays the word "Offline," the application is not connected to the instrument (see page 3-6).

## Operating the Sequence Detector

**General** After all the sample wells are labeled on the Setup view, the sample tray has been placed in the sample block and the sample block cover tightly closed, you are ready to perform the PCR. Use the Analysis view to run the Sequence Detector and monitor thermal cycler status. The view button just above the wells in the Plate window lets you toggle between the Setup and Analysis views.



**Figure 3-15** Two Plate Document Views

To run the Sequence Detector:

Step	Action
1	Click the Show Analysis button to toggle to the Analysis view.
2	Click the button labeled "Run" at the top of the Analysis view.  As the Sequence Detector begins to run, the Status field displays the word Waiting and the LED display light labelled "Comm" blinks green as the run information is transferred from the computer to the Sequence Detector.

**IMPORTANT** If the Status display reads “Offline”, the Sequence Detection application is not connected to the Sequence Detector and the run information cannot be transferred from the computer. See page 3-6 for how to connect the application to the instrument.

After the run begins, the Status fields display thermal cycler temperatures and run progress in the space under the Run button. See page C-12 for details on the Status values.

**IMPORTANT** If a power failure occurs during a run, fluorescence data collected before the power failure will be saved. After power is restored, you can recover the saved data by importing the temporary file saved in the “Spooled Items” folder within the SDS Preferences folder (System folder).

---

### Stopping the Sequence Detector

To stop the sequence detector during a run:

- ◆ Click the Stop button on the Analysis view at any time during PCR.

If you click the Stop button before the run is complete, a dialog box opens and asks if you want to save the collected data. See page C-11 for more information on saving collected data.

When you click the Stop button, a shutter closes to block out the laser signal, the temperature of the sample block begins to return to 25 °C, and the cover interlocks are defeated so that you can open the sequence detector cover.

**! WARNING ! EXTREMELY HOT SURFACES.** The temperature of the sample block cover may be as high as 105 °C. Avoid touching the sample block or the heated cover.

**CAUTION** DO NOT perform manual hot starts on the ABI PRISM 7700 Sequence Detector. Manual hot starts can cause random splashes of fluorescence-laden solution onto the sample block. This contamination interferes with the performance of the fiber optic system and can cause erroneous results. Always keep the wells on the 96-well plate tightly capped while they are on the sample block and throughout PCR.

---

### Opening the Cover after a Hold at 4°C

After a long Hold at 4 °C, the MicroAmp® Optical Caps may stick to the cover of the sample block, making it difficult to slide the cover back. To avoid this problem, stop the run and wait about 5 min until the temperature of the sample block returns to 25 °C before attempting to open the sample block cover.

An additional solution is to gently screw down the knob a little further, then release completely and slide the cover back.

**CAUTION** Opening the heated cover after starting a run defeats the cover interlocks, closes the shutters, and no fluorescence data will be collected.

---

# Setup and Operation for Allelic Discrimination

# 4

## Introduction

**Overview** The TaqMan® Allelic Discrimination Demonstration Kit shows how to use the ABI PRISM® 7700 Sequence Detection System to discriminate between the two alleles provided in the kit. Besides the two allele standards, the kit consists of heterozygous control DNA and a pre-made master mix of reagent intended for both robust chemistry and ease of use. The kit contains sufficient reagents to perform 200 reactions.

**Allele 1 and Allele 2** Allele 1 and Allele 2 probes supplied in the Reagent Master Mix can be used with the specific Genomic Control DNA included in the kit. Custom probes must be designed for detection of any other templates. The design of these probes should follow the “Guidelines for the Design of Allelic Discrimination Primers and Probes” on page 15 of the *TaqMan® Allelic Discrimination Kit Protocol*.

**Purpose of This Chapter** This chapter uses the TaqMan Allelic Discrimination Demonstration Kit as a model of how to perform allelic discrimination on the ABI PRISM 7700 Sequence Detection System. When this kit is used on the ABI PRISM 7700 instrument, direct detection of PCR product is accomplished with no downstream processing. This method permits the analysis of thousands of samples per day with high sample-to-sample reproducibility. The example provided here demonstrates the software capabilities of the instrument while also providing a practical example of how to perform an allelic discrimination assay on the instrument.

**In This Chapter** This chapter contains the following topics:

Topic	See Page
Running an Allelic Discrimination Assay	4-2
Setting Up a Plate	4-2
Run a Two-probe AD Assay	4-3
Analyzing the Data	4-4
Reading a Plate	4-4
Analyzing a Plate	4-4
Listing of Allelic Discrimination View Features	4-6
Mathematical Transformations	4-8
Overview	4-8
List of Mathematical Transformations	4-8

Topic	See Page
Making Manual Calls	4-9
Background	4-9
Procedure	4-10

## Running an Allelic Discrimination Assay


**Setting Up a Plate** When running an allelic discrimination (AD) assay, set up a plate as described below. Later, you can adapt the procedure to set up a plate template for your own assay:

To set up an allelic discrimination assay, follow this procedure:

Step	Action																																																																																																																									
1	<p>Choose New Plate in the File menu and then select the Allelic Discrimination plate type. Click Ok to open a new plate document.</p> <p><b>Note</b> This procedure assumes Preferences were set for the 7700. If Preferences have not been set, select the 7700 as the Instrument Type.</p>																																																																																																																									
2	<p>Assign sample types to the wells as shown in the example below. Later, when you are developing your own allelic discrimination assay, you can modify the Sample Type assignments.</p> <table border="1"><tr><th></th><th>1</th><th>2</th><th>3</th><th>4</th><th>5</th><th>6</th><th>7</th><th>8</th><th>9</th><th>10</th><th>11</th><th>12</th></tr><tr><th>A</th><td>NTC A1</td><td>NTC A2</td><td>NTC A3</td><td>NTC A4</td><td>NTC A5</td><td>NTC A6</td><td>NTC A7</td><td>NTC A8</td><td>AL1 A9</td><td>AL1 A10</td><td>AL1 A11</td><td>AL1 A12</td></tr><tr><th>B</th><td>AL1 B1</td><td>AL1 B2</td><td>AL1 B3</td><td>AL1 B4</td><td>AL2 B5</td><td>AL2 B6</td><td>AL2 B7</td><td>AL2 B8</td><td>AL2 B9</td><td>AL2 B10</td><td>AL2 B11</td><td>AL2 B12</td></tr><tr><th>C</th><td>UNKN C1</td><td>UNKN C2</td><td>UNKN C3</td><td>UNKN C4</td><td>UNKN C5</td><td>UNKN C6</td><td>UNKN C7</td><td>UNKN C8</td><td>UNKN C9</td><td>UNKN C10</td><td>UNKN C11</td><td>UNKN C12</td></tr><tr><th>D</th><td>UNKN D1</td><td>UNKN D2</td><td>UNKN D3</td><td>UNKN D4</td><td>UNKN D5</td><td>UNKN D6</td><td>UNKN D7</td><td>UNKN D8</td><td>UNKN D9</td><td>UNKN D10</td><td>UNKN D11</td><td>UNKN D12</td></tr><tr><th>E</th><td>UNKN E1</td><td>UNKN E2</td><td>UNKN E3</td><td>UNKN E4</td><td>UNKN E5</td><td>UNKN E6</td><td>UNKN E7</td><td>UNKN E8</td><td>UNKN E9</td><td>UNKN E10</td><td>UNKN E11</td><td>UNKN E12</td></tr><tr><th>F</th><td>UNKN F1</td><td>UNKN F2</td><td>UNKN F3</td><td>UNKN F4</td><td>UNKN F5</td><td>UNKN F6</td><td>UNKN F7</td><td>UNKN F8</td><td>UNKN F9</td><td>UNKN F10</td><td>UNKN F11</td><td>UNKN F12</td></tr><tr><th>G</th><td>UNKN G1</td><td>UNKN G2</td><td>UNKN G3</td><td>UNKN G4</td><td>UNKN G5</td><td>UNKN G6</td><td>UNKN G7</td><td>UNKN G8</td><td>UNKN G9</td><td>UNKN G10</td><td>UNKN G11</td><td>UNKN G12</td></tr><tr><th>H</th><td>UNKN H1</td><td>UNKN H2</td><td>UNKN H3</td><td>UNKN H4</td><td>UNKN H5</td><td>UNKN H6</td><td>UNKN H7</td><td>UNKN H8</td><td>UNKN H9</td><td>UNKN H10</td><td>UNKN H11</td><td>UNKN H12</td></tr></table> <p>Allelic Plate assignments for the current example are as listed below:</p> <table><tr><td>NTC to wells A1 through A8</td><td>Allele 1 standard to wells A9 through B4</td></tr><tr><td>Allele 2 standard to wells B5 through B12</td><td>UNKN assigned to remainder of B5 through B12wells</td></tr></table>		1	2	3	4	5	6	7	8	9	10	11	12	A	NTC A1	NTC A2	NTC A3	NTC A4	NTC A5	NTC A6	NTC A7	NTC A8	AL1 A9	AL1 A10	AL1 A11	AL1 A12	B	AL1 B1	AL1 B2	AL1 B3	AL1 B4	AL2 B5	AL2 B6	AL2 B7	AL2 B8	AL2 B9	AL2 B10	AL2 B11	AL2 B12	C	UNKN C1	UNKN C2	UNKN C3	UNKN C4	UNKN C5	UNKN C6	UNKN C7	UNKN C8	UNKN C9	UNKN C10	UNKN C11	UNKN C12	D	UNKN D1	UNKN D2	UNKN D3	UNKN D4	UNKN D5	UNKN D6	UNKN D7	UNKN D8	UNKN D9	UNKN D10	UNKN D11	UNKN D12	E	UNKN E1	UNKN E2	UNKN E3	UNKN E4	UNKN E5	UNKN E6	UNKN E7	UNKN E8	UNKN E9	UNKN E10	UNKN E11	UNKN E12	F	UNKN F1	UNKN F2	UNKN F3	UNKN F4	UNKN F5	UNKN F6	UNKN F7	UNKN F8	UNKN F9	UNKN F10	UNKN F11	UNKN F12	G	UNKN G1	UNKN G2	UNKN G3	UNKN G4	UNKN G5	UNKN G6	UNKN G7	UNKN G8	UNKN G9	UNKN G10	UNKN G11	UNKN G12	H	UNKN H1	UNKN H2	UNKN H3	UNKN H4	UNKN H5	UNKN H6	UNKN H7	UNKN H8	UNKN H9	UNKN H10	UNKN H11	UNKN H12	NTC to wells A1 through A8	Allele 1 standard to wells A9 through B4	Allele 2 standard to wells B5 through B12	UNKN assigned to remainder of B5 through B12wells
	1	2	3	4	5	6	7	8	9	10	11	12																																																																																																														
A	NTC A1	NTC A2	NTC A3	NTC A4	NTC A5	NTC A6	NTC A7	NTC A8	AL1 A9	AL1 A10	AL1 A11	AL1 A12																																																																																																														
B	AL1 B1	AL1 B2	AL1 B3	AL1 B4	AL2 B5	AL2 B6	AL2 B7	AL2 B8	AL2 B9	AL2 B10	AL2 B11	AL2 B12																																																																																																														
C	UNKN C1	UNKN C2	UNKN C3	UNKN C4	UNKN C5	UNKN C6	UNKN C7	UNKN C8	UNKN C9	UNKN C10	UNKN C11	UNKN C12																																																																																																														
D	UNKN D1	UNKN D2	UNKN D3	UNKN D4	UNKN D5	UNKN D6	UNKN D7	UNKN D8	UNKN D9	UNKN D10	UNKN D11	UNKN D12																																																																																																														
E	UNKN E1	UNKN E2	UNKN E3	UNKN E4	UNKN E5	UNKN E6	UNKN E7	UNKN E8	UNKN E9	UNKN E10	UNKN E11	UNKN E12																																																																																																														
F	UNKN F1	UNKN F2	UNKN F3	UNKN F4	UNKN F5	UNKN F6	UNKN F7	UNKN F8	UNKN F9	UNKN F10	UNKN F11	UNKN F12																																																																																																														
G	UNKN G1	UNKN G2	UNKN G3	UNKN G4	UNKN G5	UNKN G6	UNKN G7	UNKN G8	UNKN G9	UNKN G10	UNKN G11	UNKN G12																																																																																																														
H	UNKN H1	UNKN H2	UNKN H3	UNKN H4	UNKN H5	UNKN H6	UNKN H7	UNKN H8	UNKN H9	UNKN H10	UNKN H11	UNKN H12																																																																																																														
NTC to wells A1 through A8	Allele 1 standard to wells A9 through B4																																																																																																																									
Allele 2 standard to wells B5 through B12	UNKN assigned to remainder of B5 through B12wells																																																																																																																									



To set up an allelic discrimination assay, follow this procedure: *(continued)*

Step	Action
3	<p>a. Use the Page Setup command to bring up the dialog box shown below:</p> <p>b. Set up printing for the plate and Experiment Report by choosing the “Landscape” orientation (the second orientation in the figure) and by setting the percentage of the print to 95%.</p>  <p>c. Click OK to set up the plate with your settings.</p>
4	<p>To aid you in placing standards and samples in the 96-Well plate, print a copy of the plate setup using the Print command. This copy can be used as a “sample map” to aid you in loading the 96-Well plate.</p>

#### Run a Two-probe AD Assay

See the *TaqMan Allelic Discrimination Demonstration Kit Protocol* (P/N 402875) for instructions on performing a two-probe allelic discrimination assay.

## Analyzing the Data


**Reading a Plate** This procedure describes how to read a plate on the 7700 system.

To do a plate read, follow this procedure:



Step	Action
1	Open the “Allelic Demonstration” Stationery file from the 7700 application. This will open the plate shown in “Setting Up a Plate” on page 4-2.
2	Click on the Show Analysis button to change to the Analysis view.
3	Click on the Post-PCR Read button to perform a plate read.
4	Use the Save command to save the Allelic Demonstration Stationery plate with a descriptive name of your choice.

**Analyzing a Plate** This procedure describes how to analyze the Plate read data to generate Allele calls for all the samples defined as unknowns (UNKN).

To analyze allelic discrimination results, follow this procedure:

Step	Action
1	This procedure starts with the plate document used to gather Plate read information for the Allelic Discrimination Kit example. If it is not open, open the plate.
2	Click the Show Analysis button to change to the Analysis view. The view for the current allelic discrimination example appears as shown below: 

To analyze allelic discrimination results, follow this procedure: *(continued)*

Step	Action
3	<p>Click Analyze (Analyze menu). This will initiate analysis and the view shown above will update to appear like this:</p>  <p><b>Note</b> Analyzed data has the “hole” in the center.</p>
4	<p>Choose View Allelic Discrimination (Analysis menu) to produce the Allelic Discrimination Map for the run:</p> 

To analyze allelic discrimination results, follow this procedure: *(continued)*

Step	Action
5	Choose Experimental Report (Window menu) to display the experimental report for the run. Samples run from the template included with this kit should all receive heterozygote (Allele 1, Allele 2) calls.

Well	Sample	Call
A1	NTC	No Amp
A2	NTC	No Amp
A3	NTC	No Amp
A4	NTC	No Amp
A5	NTC	No Amp
A6	NTC	No Amp
A7	NTC	No Amp
A8	NTC	No Amp
A9	AL1	1
A10	AL1	1
A11	AL1	1
A12	AL1	1
B1	AL1	1
B2	AL1	1

### Listing of Allelic Discrimination View Features

This section describes the Allelic Discrimination view, shown in the figure, to aid you in evaluating allelic discrimination data. Presented here are 1) the general details of the view and 2) how to view the data in three graphs available in the display area:




Figure 4-1 Allelic Discrimination Map View Features

### Main Features of the Allelic Discrimination View

- ◆ Graphs of the data in three views in the graphical display area (see Table 4-1).
- ◆ A table of results in 9 columns in the middle of the viewer (see Table 4-1).
- ◆ A table of Allele calls for each plate position at the bottom of the viewer (see Table 4-1).

**Table 4-1** Listing of Features of the Allelic Discrimination View

Main Features	Column/Allele Call Descriptor	Description
Graphs	—	Dye components - TET $R_n$ , FAM $R_n$
	—	Allele components - NTC <sub>m</sub> , T1 <sub>m</sub> , T2 <sub>m</sub>
	—	Normalized - T1 <sub>n</sub> , T2 <sub>n</sub>
Graphical view selector	—	This is a pop-up menu used to move between the three graphs.
Graphical Tools	—	These tools are used to select wells, change the scale, and reposition the viewing area. See "Graphical Tools" on page C-51 for more information on using these tools.
Allele Call Selector	—	This is a pop-up menu used in manual calling of alleles. Using this pop-up, data selected in the Allele components graph can be reassigned to one of the allele calls listed in the Legend of Table 4-1.
Table of Results	Col. 1 - Well	Well position in the 8x12 matrix
	Col. 2 - Sample	Sample name
	Col. 3 - FAM $R_n$	Normalized FAM reporter signal
	Col. 4 - TET $R_n$	Normalized TET reporter signal
	Col. 5 - TAM $R_n$	Normalized TAMRA signal
	Col. 6 - NTC <sub>m</sub>	No Template Control component
	Col. 7 - T1 <sub>m</sub>	Allele 1 component
	Col. 8 - T2 <sub>m</sub>	Allele 2 component
	Col. 9 - T1 <sub>n</sub>	Allele 1 component normalized for extent of reaction
	Col. 10 - T2 <sub>n</sub>	Allele 2 component normalized for extent of reaction
	Col. 11 - Call	This is the allele call for the well
Table of Allele Calls	1	Allele 1 controls and samples called as homozygous for Allele 1
	2	Allele 2 controls and samples called as homozygous for Allele 2
	1 and 2	Heterozygous call for samples
	No Amp	NTCs and samples which did not amplify
	X	Undetermined, no call could be made

## Mathematical Transformations

---

**Overview** The 7700 system collects spectral data that ranges from 500nm to 660nm. We refer to this data as Raw Data. This data can be displayed graphically in the raw data view.

When running an Allelic Discrimination Analysis, the SDS software will run several mathematical transformations on the raw data. These transformations are used to generate a more direct measure of how the spectra changes relate to the control reactions (NTCs, Allele 1 and Allele 2 controls).

---

### List of Mathematical Transformations

#### Transforming Raw Data into Dye Components

The first transformation made to the Raw Data is the same multicomponenting algorithm that is used for all SDS analysis.

This transformation takes the Raw data which is expressed in terms of Fluorescent Signal vs. Wavelength and, using the calibrated pure dye shapes as known, re-expresses the unknown sample in terms of the pure dye components.

In the allelic discrimination example we transform the raw data into the FAM, TET, TAMRA (TAM), and ROX components. The data is then all normalized by the ROX component and shown as FAM Rn, TET Rn, and TAM Rn in the allelic discrimination table as well as graphically (choose the Dye Component Graph within the allelic discrimination viewer).

#### Transforming Dye Component Data into Allele Components

The Second transformation allows us to correlate the spectra of the unknown samples into how much the spectra looks like our controls (NTCs, Allele 1 and Allele 2 controls). By measuring these controls we can determine what the spectra shape for each of these controls looks like, and by doing the first transformation we can even say what the dye components look like for each of the three control types.

By using the controls as inputs to our multicomponenting analysis, we can now transform the unknown sample data from how much the spectral shape looks like the dyes into how much the spectra looks like the controls.

These quantitative measures of the spectral shape are shown as  $NTC_m$ ,  $T1_m$ , and  $T2_m$  in the table and graphically (choose the Allele Components Graph within the allelic discrimination viewer).

#### Normalizing for the Extent of the Reaction

Our final mathematical transformation allows us to take an unknown sample and, based on the quantitative measure of how much the spectra looks like a No Template Control Reaction, we can scale the Allele 1 and Allele 2 components to create a measure of how much the reaction would look like Allele 1 and Allele 2 if all the reactions had the same amount of amplification occur.

These normalized components are shown as  $T1_n$  and  $T2_n$  in the table and graphically (choose the Normalized graph within the Allelic Discrimination viewer). The allele call (Homozygous 1, Homozygous 2 or Heterozygous) is determined from these normalized components.

#### Autocalling

Both the vertical and horizontal thresholds are calculated from the T-distribution using a 99.7% confidence level. The horizontal variation in the Allele 2 controls determines the vertical threshold and the vertical variation in the Allele 1 controls determines the horizontal threshold. The calls are made according to the following four zones:


- ◆ Allele1 call is made for data less than the horizontal threshold and greater than the vertical threshold.

- ◆ Allele 2 call is made for data greater than the horizontal threshold and less than the vertical threshold.
  - ◆ Heterozygous 1/2 is made for data greater than both thresholds.
  - ◆ No call is made for data less than both thresholds.
- 

## Making Manual Calls

**Background** You may choose to make manual calls for those wells that are labeled undetermined by the autocalling routine. You may also make manual calls for those data sets which have poor controls or an insufficient number of controls and the application will not autocall the data. By using the selector buttons in the Allele call selector you can manually select a group of data (or individual wells) and designate the allele call.

For data sets for which no autocalling is done, all the manual calls need to be made from the Dye Components View. There will be no data available in the other two views. For example, if the following event log was presented after analysis, you would know that autocalling had failed:




**Note** Whenever less than three controls are correctly identified, the system will present a log like that shown above. For information on how to use the tools in the Allelic Discrimination view as described in the following procedure, see "Allelic Discrimination" on page C-50.


*continued on next page*

**Procedure** This procedure is used to make manual calls whenever less than three controls are correctly identified.

To make manual calls when no autocalling was done:

Step	Action
1	After you have analyzed your data (using the Analyze command from the Analysis menu), choose the Allelic Discrimination command (Analysis menu). You will be presented with an Allelic Discrimination view with no data shown.
2	Use the Graphical view selector to choose the Dye Components view (no data will be shown in the other two views). 
3	Click the Plus Zoom button and then click the graphic view several times to zoom in and separate the data into distinct clumps.  If you click too many times, moving some data out of the view, click the Minus Zoom control and then click the graphical view again. You can also use the Position button to reposition displayed data while preserving the selected magnification.
4	Identify the data by clicking on a data point with the Individual data point selector or by selecting a data clump with the Group selector. The corresponding wells in the plate will be indicated below.  <b>Note</b> To select a data clump using the Group selector, position the selector near the clump, depress the mouse button, and draw a circle around the data.
5	After identifying data, make manual calls by selecting a data point or clump and then choose the proper call from the Allele call selector. The call you choose will be reflected for selected data in the plate matrix below the graphical view. (An alternative way to make calls for selected data is to use the Allele Calls command from the Analysis menu).
6	You will know you have correctly made calls when the assignments for Allele 1 and Allele 2 correspond to how you loaded the plate.  Your plate will look like Figure 4-2 after manual calling has been performed.





**Figure 4-2** A Manually Called Allelic Discrimination Plate

**Note** The data represented as “?” (question marks) in the table and by X in the graphical view represents the failed control wells which necessitated the manual calling.

If any manual calls are made to your data, a note indicating that manual calls were made will be placed in your Experimental Report.



# *SR Plates, Plus/Minus Scoring, and IPCs*

---

# 5

## Introduction

---

**General** The Single Reporter (SR) Plate type is designed to report the presence or absence of a specific nucleic acid sequence in a test sample (Plus/Minus or +/- scoring). By using probes labeled with different reporters, a positive control for the PCR chemistry may be included in any amplification reaction. This Internal Positive Control (IPC) ensures that a failed PCR is not mistaken for a negative test result.

---

**In This Chapter** This chapter contains the following topics:

Topic	See Page
Single Reporter Plates and Plus/Minus Scoring	5-2
Sample Type Setup	5-2
Statistics Settings	5-2
Analyzing Data	5-3
Reviewing Data	5-4
Experiment Report	5-5
Setting Up a Single Reporter Plate with an IPC Dye Layer	5-7
Sample Type Setup	5-7
Statistics Settings/Analyzing Data	5-7
Reviewing Data	5-8
Experiment Report	5-9

---

## Single Reporter Plates and Plus/Minus Scoring

### Unknowns Compared to No Template Controls

The Single Reporter Plate type will determine if amplification occurs for the Sample Types labeled unknown (UNKN) by comparing the normalized reporter value for these samples with the normalized reporter values measured from the Sample Types labeled No Template Control (NTC).

**Note** You must include at least eight positions labeled NTC in the Setup view of your plate document (all the remaining positions can be labeled UNKN).

The NTC wells contain everything required for your TaqMan PCR reaction except the target template. The normalized reporter signal for these wells will not increase because no PCR will occur. The signals from these wells will be used to generate a normalized reporter threshold which will be used to determine whether or not PCR has occurred for your samples labeled UNKN.

### Statistics Setting Criteria for Threshold

The magnitude of the threshold will depend upon the following criteria:

- ◆ Number of NTCs
- ◆ Mean and standard deviation of the NTC's Normalized reporter signal
- ◆ Confidence level set under Statistics Settings (Analysis menu)

The threshold is calculated using the one-tailed T-distribution listed in Table 5-1.

**Table 5-1** One-Tailed T-Distribution Table


Sample Size	Degrees of Freedom	95%	99%	99.5%	99.7%	99.9%
3	2	2.920	6.965	9.925	12.852	22.328
4	3	2.353	4.541	5.841	6.994	10.214
5	4	2.132	3.747	4.604	5.321	7.173
6	5	2.015	3.365	4.032	4.570	5.894
7	6	1.943	3.143	3.707	4.152	5.208
8	7	1.895	2.998	3.499	3.887	4.785
9	8	1.860	2.896	3.355	3.705	4.501
10	9	1.833	2.821	3.250	3.573	4.297
11	10	1.812	2.764	3.169	3.472	4.144
12	11	1.796	2.718	3.106	3.393	4.025
13	12	1.782	2.681	3.055	3.330	3.930
14	13	1.771	2.650	3.012	3.278	3.852
15	14	1.761	2.624	2.977	3.234	3.787
16	15	1.753	2.602	2.947	3.197	3.733
17	16	1.746	2.583	2.921	3.165	3.686
18	17	1.740	2.567	2.898	3.138	3.646
19	18	1.734	2.552	2.878	3.113	3.610
20	19	1.729	2.539	2.861	3.092	3.579
21	20	1.725	2.528	2.845	3.073	3.552
22	21	1.721	2.518	2.831	3.056	3.527

**Table 5-1** One-Tailed T-Distribution Table *(continued)*

Sample Size	Degrees of Freedom	95%	99%	99.5%	99.7%	99.9%
23	22	1.717	2.508	2.819	3.041	3.505
24	23	1.714	2.500	2.807	3.027	3.485
25	24	1.711	2.492	2.797	3.014	3.467
26	25	1.708	2.485	2.787	3.003	3.450
27	26	1.706	2.479	2.779	2.992	3.435
28	27	1.703	2.473	2.771	2.982	3.421
29	28	1.701	2.467	2.763	2.973	3.408
30	29	1.699	2.462	2.756	2.965	3.396
31	30	1.697	2.457	2.750	2.957	3.385
32 to 41	40	1.684	2.423	2.704	2.902	3.307
42 to 61	60	1.671	2.390	2.660	2.849	3.232
62 to 121	120	1.658	2.358	2.617	2.798	3.160
122 and above	Infinite	1.645	2.326	2.576	2.748	3.090

**Procedure**

To change the confidence level from the default value of 99.7%:

Step	Action
1	Choose Statistics Settings (Analyze menu) to bring up the dialog box shown below.  
2	Click the new confidence level value.
3	Click OK to close this dialog box.  The new confidence level will be used when you analyze the plate.

**Initiating Analysis** When you have collected your data and set your desired confidence level, you are ready to initiate analysis.

♦ To analyze data, choose Analyze from the Analysis menu.

**Note** Information regarding the analysis is recorded automatically in the Event Log.

*continued on next page*


**Reviewing Data** After PCR is complete and your data is collected and analyzed, the Sequence Detection application program provides both graphic views of the data and an Experiment Report with the normalized reporter signal values, as well as a +/- PCR call for all your unknowns.

**Table 5-2** Where to Find Data in the Sequence Detection Application Program

Available Data	Graphic View	Analysis Plate View	Experiment Report
Raw data	Raw Spectra	—	—
Replicate Calculations	—	—	Mean & Deviation.
+/- results	—	—	+/- listed for all wells
$\Delta R_n$ or $R_n$	—	Values and intensities	Values

### Raw Spectra Graph

Raw data is available for viewing before or after analysis and is viewed in the Raw Spectra view.



**Figure 5-1** Raw Spectra View

The Raw Spectra view displays the 32 discrete wavelength intensities measured for each selected sample well. You can view the data from a single well or from multiple wells. For more information on viewing options, see Raw Spectra on page C-55.

### Analysis Plate View (Target Dye Layer)

After analyzing the data, the intensity of each circle corresponds to the  $R_n$  value. You can modify the intensity controls using the  $R_n$  range controls (max and min).

To change the display from Sample Type to  $R_n$  (normalized reporter signal) for each well, choose  $R_n$  under Display in the Analysis menu.



*continued on next page*

**Experiment Report**

**General**  
The Experiment Report displays relevant setup information and the calculated values listed below for all wells of the plate document.

- ◆ PCR call: results indicated by a “+” (PCR detected) or “–” (no PCR detected)
- ◆  $R_n$ : the normalized reporter
- ◆ Standard deviation of each replicate group
- ◆ Mean value of each replicate group


The Experiment Report is only available after analyzing (choosing Analyze from the Analysis menu). When you close the plate document, the analyzed data is not saved, so you must reanalyze the data each time you open the plate document to regenerate the Experiment Report.

**Viewing, Printing, and Exporting the Experiment Report**

You can view, print, and export the Experiment Report.  
To view the Experiment Report, choose Experiment Report from the Window menu.



As shown in Figure 5-2, the Experiment Report window opens and becomes the active window on the computer screen. You can scroll through the contents of the window to review the report, but you cannot edit the text.



**Figure 5-2** Single Reporter Experiment Report

**Note** The Experiment Report above did not include an IPC dye layer. See Figure 5-6 for the information which is added when an IPC layer is present.

To print the Experiment Report, do the following :

Step	Action
1	Click the Experiment Report window to make it active.
2	Choose Page Setup from the File menu.
3	Click the Landscape orientation icon and reduce the size of the page to 95%.
4	Click OK to close the Page Setup dialog box.
5	Choose Print from in the File menu and click Print.

To export the Experiment Report, do the following:

Step	Action
1	Choose Experiment Report from the Export options under File menu.
2	In the File dialog box, give the report a descriptive name and click OK.

---



## Setting Up a Single Reporter Plate with an IPC Dye Layer

**Sample Type Setup** A Single Reporter IPC experiment uses two TaqMan probes and therefore requires sample setup on two dye layers. The Sample Type setup for the target probe dye layer is identical to that of a standard Single Reporter plate (refer to the previous setup for the target layer). The IPC probe layer requires the IPC+ and IPC– sample types.

You must include at least eight positions labeled IPC– on the IPC dye layer (all the remaining positions on this layer can be labeled IPC+). The application program will determine if amplification of the IPC occurs for the Sample Types labeled IPC+ by comparing the normalized reporter value for these samples with the normalized reporter values measured from the Sample Types labeled IPC–.

The IPC– wells contain everything required for your TaqMan PCR reaction except the IPC template. The normalized reporter signal for the IPC dye layer for these wells will not increase because no amplification of the IPC will occur. The signals from these wells will be used to generate a normalized reporter threshold which will be used to determine whether or not PCR has occurred for your samples labeled IPC+.

	1	2	3	4	5	6	7	8	9	10	11	12
A	IPC- 0	IPC- 0	IPC- 0	IPC- 0	IPC- 0	IPC- 0	IPC- A7	IPC- A8	IPC+ 0	IPC+ 0	IPC+ 0	IPC+ 0
B	IPC+ 2690	IPC+ 2690	IPC+ 2690	IPC+ 2690	IPC+ 2690	IPC+ 2690	IPC+ 380	IPC+ 380	IPC+ 380	IPC+ 380	IPC+ 380	IPC+ 380

**Figure 5-3** Typical IPC Layer setup

**Note** You may either add the IPC– and IPC+ Sample Types to a standard Single Reporter Plate document (see Guidelines for IPC on page C-39) or you may open the Single Reporter IPC Stationery document. For the analysis to work properly, you must correspond exactly to our acronym naming conventions.

### Statistics Settings/Analyzing Data

#### Criteria for Thresholds

The magnitude of the thresholds will depend upon the following criteria:

- ◆ Number of NTCs and number of IPC– controls
- ◆ Means and standard deviations of the corresponding Normalized reporter signals for the NTCs and IPC– controls
- ◆ Confidence level set under Statistics Settings (Analysis menu)

The thresholds are calculated using the same T-distribution table (see Table 5-1 on page 5-2).

To change the confidence level from the default value of 99%, choose Statistics Settings (Analyze menu). See page 5-2 for information on setting Statistics.

## Initiating Analysis

When you have collected your data and set your desired confidence level, you are ready to initiate analysis. To analyze data, choose Analyze from the Analysis menu, or use the keyboard shortcut **⌘ L**.

**Note** Information regarding the analysis will automatically be presented in the Event Log.

## Reviewing Data

After PCR is complete and your data is collected and analyzed, the Sequence Detection application program provides graphic views of the data and an Experiment Report with the normalized reporter signal values as well as a +/- /No Amp PCR call for all your unknowns. A false negative, indicated by a “No Amp” or “?” call, is a reaction where PCR did not occur on either the target or the IPC layers. A true negative, indicated by “-”, is a reaction where PCR did not occur on the target but did occur on the IPC layer.

**Table 5-3** Where to Find Data in the Sequence Detection Application Program

Available Data	Graphic View	Analysis Plate View	Experiment Report
Raw data	Raw Spectra	—	—
Replicate calculations	—	—	Mean & std. dev.
+/- results	—	+/-/? calls shown on IPC layer	+/-/? or No Amp listed for all wells
$\Delta R_n$ or $R_n$	—	Values and intensities shown on the target layer	Values

## Raw Spectra Graph

See the Single Reporter description on page 5-8.

## Analysis Plate View

Before starting a plate read, all active wells are displayed as solid colored circles. After a plate read, the display of all the active wells changes to a solid color whose intensity corresponds to the fluorescence data collected.

## Target Dye Layer

After analyzing the data, the intensity of each circle corresponds to the  $R_n$  value. You can modify the intensity controls using the  $R_n$  range controls (max and min).

To change the display from Sample Type to  $R_n$  (normalized reporter signal) for each well, choose  $R_n$  under Display in the Analysis menu.



**Figure 5-4**  $R_n$  in the Analysis View





# Troubleshooting and Maintenance

# 6

## Introduction

**General** This section provides two tables. Use the first table when either your Macintosh computer or the Sequence Detection application program will not run. Use the second table when the application program launches but will not run properly.

**In This Chapter** This chapter covers the following topics:

Topic	See Page
Macintosh and General Troubleshooting	6-2
Troubleshooting Table	6-2
7700 Sequence Detection System Troubleshooting	6-4
Troubleshooting Table	6-4
System Requirements and Known Software Bugs	6-6
Software and Firmware Revisions	6-6
Power Macintosh Specifications	6-6
System Noise	6-6
9600 Specifications	6-6
Reporting Software Bugs	6-7
Quick System Tests	6-8
Fluorescence Tests (Signal Throughput)	6-8
Blackboard Tests (Background Signal)	6-9
9600 Tests	6-10

## Macintosh and General Troubleshooting


**Troubleshooting Table** Use this table if you are having problems with your Macintosh computer or the Sequence Detection application program will not run:

Symptom	Problem	Solution
<p>SDS software will not launch. The software crashes/freezes the computer or shows an error message.</p> <p>Several potential problems in running the SDS software could cause these symptoms. Follow the solutions listed for one or more of the listed problems until the trouble symptom goes away:</p> <p>Sequence Detection application program will not launch (continued).</p>	The Preferences file may be corrupted and need to be replaced.	<ol style="list-style-type: none"> <li>Locate the "SDS Preferences" file on your computer (System Folder:Preferences:SDS:SDS Preferences). Drag the file to the trash and empty the trash.</li> <li>Be careful NOT to throw out your Spectra Components folder. If you do, you will need to perform special calibration before you can proceed.</li> <li>Launch the application program. The application program will create a new version of the SDS Preferences file and your computer should operate normally.</li> </ol>
	The Macintosh desktop may need rebuilding:	<ol style="list-style-type: none"> <li>Restart the computer while holding down the "Command" and "Option" keys.</li> <li>When the computer asks if you want to rebuild your desktop, choose OK. Your desktop will be rebuilt and the computer should operate normally.</li> </ol>
	The Finder Preferences file may be corrupted and need to be replaced.	<ol style="list-style-type: none"> <li>Locate the "Finder Preferences" file on your computer (System Folder:Preferences:Finder Preferences).</li> <li>Drag the file to the trash and empty the trash.</li> <li>Boot the computer. A new Finder Preferences file will be created during backup.</li> <li>Launch the application program. Your computer should operate normally.</li> </ol>
	The Macintosh Parameter RAM may be corrupted and needs to be reset.	<ol style="list-style-type: none"> <li>Restart the computer while holding down the "option," "p," and "r" keys.</li> <li>When the screen flashes on and off, let go of the keys. The computer will reboot and should operate normally.</li> </ol>

Symptom	Problem	Solution
Sequence Detection application program will not launch (continued).	Does the Macintosh use Mac OS 7.6.1? If not, you need to update to this version.	<ul style="list-style-type: none"> <li>a. Check to see if you are using Mac OS 7.6.1 by selecting the "About This Macintosh" menu item in the Apple Menu.</li> <li>b. If you are not running Mac OS 7.6.1, contact Applied Biosystems for information on how to update to this version.</li> </ul>
	The Macintosh may have an extension conflict. Proceed with these steps:	<ul style="list-style-type: none"> <li>a. Disable all extensions by restarting the computer while holding down the "shift" key. Run the application program and notice if you still have any difficulties.  If the computer or the SDS application program still exhibits the same problem, try one of the other actions.  If the application program now runs normally, you have an extension conflict. Proceed with step b.</li> <li>b. Find the "Extensions Manager" control panel and systematically disable groups of extensions and then reboot the computer after each extension change until you find the offending extension.</li> </ul>
The following message is presented whenever you attempt to run the software: "There is more than 50 megabytes of data in the SDS Runs folder..."	This indicates that your backup data files have exceeded the recommended size and should either be off-loaded to a backup device/server or discarded if they are no longer needed.	<p>Open the "SDS Runs" folder on the hard disk and drag the files to the trash or to a storage device/server.</p> <p>The message should no longer appear once this is accomplished.</p>
The message "Could not complete the "—" command because there is not enough memory" appears when trying to _____.	This is the application's generic error message. If this occurs, follow these steps:	<ul style="list-style-type: none"> <li>a. Save your work, restart the application, and try again.</li> <li>b. If the command fails the second time, follow the actions listed for the first Symptom (Sequence Detection application program will not launch.)</li> </ul>

## 7700 Sequence Detection System Troubleshooting

**Troubleshooting Table** Use this table when you have been running the ABI PRISM® 7700 Sequence Detection System and the listed symptom occurs:

Symptom	Problem	Solution
Application program will not connect to the 7700 instrument.	The cable connection between the computer and instrument is faulty or the cable is disconnected:	Check the cable connection.
	The open plate document may not be an "online" document.	Make sure the document is an "online" document by going to "Preferences" (Edit Menu) and activating the "Online Document" checkbox.
The computer seems to "freeze" periodically while running the Sequence Detection application program.	Updating to Mac OS 7.6.1 helps reduce freezes or system lockups on a Macintosh running earlier operating systems.	<ol style="list-style-type: none"> <li>Check to see if you are using Mac OS 7.6.1 by selecting the "About This Macintosh" menu item in the Apple Menu.</li> <li>If you are not running Mac OS 7.6.1, contact Applied Biosystems for information on how to update to this version.</li> </ol>
The Experiment Report is empty.	Only raw data is saved in the plate document, so you must re-analyze the plate to see report data.	Re-analyze data each time you open a plate document to generate the Experiment Report.
When launching the program, the following dialog box appears:	The necessary Pure Dye files for FAM, TAMRA, and ROX are not available.	<p>You need to measure and extract Pure Dye files for FAM, TAMRA, and ROX. See calibration procedure on page 3-10.</p> <div data-bbox="688 1209 1198 1461">  <p>Could not Open document because needed pure spectra are missing (FAM, TAMRA). New pure spectra must be extracted.</p> <p>OK</p> </div>
Specific wells consistently read incorrectly.	The Sample Block is dirty.	Using a cotton swab, wipe the wells with a 10% bleach solution. Using a second swab, dry by swabbing with 95% ethanol.
Raw spectra signal is flat at an intensity of 10,000.	The sample has too high of a concentration.	Dilute your sample.





## System Requirements and Known Software Bugs

<b>Software and Firmware Revisions</b>	<hr/> <p>SDS Software Revision 1.0 or 1.6 (“b”, “d”, or “fc” versions are <b>not</b> supported).</p> <p>Firmware M13 (EPROM) or M14 (EPROM <u>or</u> downloaded to battery backed-up RAM).</p> <p><b>Note</b> Unreleased or developmental versions of the SDS Application are not supported by Applied Biosystems personnel (Technical Support and Field Applications Specialists): use only released software versions when servicing the 7700.</p> <hr/>
<b>Power Macintosh Specifications</b>	<hr/> <p><b>RAM</b></p> <p>At least 24 MB of RAM (DIMMs).</p> <p><b>IMPORTANT</b> DIMMs (Dual in-line memory modules) must be matched for speed (in MHz).</p> <p><b>IMPORTANT</b> Do not use Virtual Memory to make up for missing DIMMs. Virtual Memory must not be used during data collection.</p> <p><b>Macintosh Operating System</b></p> <p>Version 7.6.1</p> <p><b>IMPORTANT</b> Macintosh O.S. 7.5.2 can cause serious operational problems.</p> <hr/>
<b>System Noise</b>	<hr/> <p>Maximum signal of 1200 on any optical fiber when running the LabView-based 7700 Service Diagnostics with a clean Blackboard or a new 96-well tray of water.</p> <hr/>
<b>9600 Specifications</b>	<hr/> <p><b>EPROMs</b></p> <p>The 9600 portion of the 7700 instrument must use special EPROMs: see “Service of the Thermal Cycler” in the Service Procedures section of this manual for more information.</p> <p><b>Voltage and Frequency Configuration</b></p> <p>The thermal cycler operates on 230Vac (supplied from the Vac Distribution Assembly) but it must be configured for the proper frequency (either 50 or 60 Hz). A 36-pin voltage select plug is inserted into J-13 on the AC-Control PCB in the 9600: the plug has 5 jumpers with each wire connecting 2 pins. <b>The 230V/50 Hz plug has pins 2/5, 9/17, 28/34, 31/36, and 33/35 jumpered. The 230V/60 Hz plug has pins 2/5, 9/16, 28/34, 31/36, and 33/35 jumpered.</b></p> <p><b>CAUTION</b> Damage to the 9600 instrument electronics or firmware could occur if the wrong voltage configuration plug is inserted into J-13. Always check the wiring of the 9600 instrument voltage configuration plug before installing it.</p> <p><b>Temperature Verification</b></p> <p>The thermal cycler conforms to the 9600 Temperature Verification Specifications as described in the 9600 Service Manual. See that service manual for more information.</p> <p><b>Note</b> Thermal cycler service should be done only by ABD-trained, 7700 instrument trained, service personnel. 9600 service training does not cover all aspects of servicing the 7700 instrument’s thermal cycler.</p> <hr/>

*continued on next page*

## Reporting Software Bugs

---

The following is a list of known software bugs that can be encountered when using SDS Version 1.6 Software. If other bugs are discovered, always try to reproduce the bug. Report any bugs to Applied Biosystems SDS Technical Support.

- ◆ After generating the Background Component, you must quit the SDS application before generating the Pure Dyes file or the background will not be recognized.
  - ◆ If a dialog box appears at launch stating “Could not start application because a file has been left in use” or some other similar message, then trash the SDS Preferences (System Folder: Preferences: SDS) and re-launch the application.
  - ◆ If the instrument Status is “Waiting...” do not attempt to stop the instrument until “Ramping” or “Holding” is seen in the Status display. If you stop the instrument during this time, the instrument will begin to “beep” and you will have to reset the instrument and computer to correct the problem.
  - ◆ When editing the “Advanced Options” dialog box and click “OK” to exit, another dialog box stating “You must restart for changes to take effect” appears. This is **only** true if you change the checkboxes for “Analysis: Spectra Components”:
    - If you change other options, those changes will take effect immediately.
  - ◆ A “Firmware Version Conflict” will be noted if the instrument boots off the EPROM (Firmware versions M12 and M13) OR if the 7700's battery is dead: keep the 7700 instrument turned ON to prevent the loss of firmware stored in the 7700's RAM.
  - ◆ The “Spooled Items” folder (System Folder: Preferences: SDS) is now used **ONLY** to store data that would otherwise be lost in the event of a powerfail.
-

## Quick System Tests


### Fluorescence Tests (Signal Throughput)

#### Fluorescent Tests (Red Fluorescent Source)

If a T-6222 test tray is not available, then quick results can also be obtained by scanning any fluorescent source for 1 minute at 25 degrees C: results will vary depending on the type of tray being scanned.

**IMPORTANT** Blue test trays or paper can be used to confirm signal throughput, but they should NOT be used to confirm laser alignment.

**Note** Signal heights of the fibers will vary depending on the well position, the specific 7700 instrument being used, and type of tray being used and the temperature of the test tray.



**Figure 6-1** Fluorescent results using a red test tray (example)


*continued on next page*

---

**Blackboard Tests  
(Background Signal)**

The background signal of the system can be investigated in many different ways. When using a Blackboard or some other black test tray (also, scanning the CCD with either the shutters closed or the MUX at position #0), the results obtained will give you an indication of the background from the test tray, lenses, fibers, and the CCD.

**Note** Signal heights of the fibers will vary depending on the well position, the specific 7700 instrument being used, and the temperature of the test tray. Results obtained from using a blackboard do not take into account any interference from the sample block or real PCR samples.



**Figure 6-2** Fluorescent results using a Blackboard (black test tray example - 1 minute, 25 °C)


**Note** Instrument System tests are done using the Functions Test dialog box. See "Functions Test" on page C-45 for more information.

---

*continued on next page*

---

**9600 Tests** The easiest way to check the thermal cycler is to look at a run's thermal cycler profile found whenever you view Raw Data or Multicomponent Data.



**Figure 6-3** Thermal cycler profile (example)

---

# Guidelines to Master Mix Preparation

---



## Introduction

---

**Definition and Contents** A Master Mix contains the correct proportions of most of the components for a particular reaction in a volume that is large enough to accommodate multiple reactions. For PCR experiments on the Sequence Detector, Master Mixes often contain all reaction components—buffer, salts, primers, fluorogenic probe, deoxynucleotides, enzymes—except the template that is to be amplified.

**CAUTION** Do not use mineral oil, wax beads, or glycerin on the ABI PRISM® 7700 Sequence Detector.

---

**In This Appendix** This appendix describes the following procedures and guidelines:

Topic	See Page
Guidelines for Master Mix Preparation	A-2
Value of Using Master Mix	A-2
Guidelines for Preparation	A-2
Guidelines for Component Volumes	A-2
Master Mix Preparation and Delivery Procedures	A-3
Combining Components	A-3
Delivering Master Mix	A-3
Working with Many Templates	A-4

---

## Guidelines for Master Mix Preparation

---

**Value of Using Master Mix** Performance specifications on the ABI PRISM 7700 Sequence Detector are based on 50  $\mu\text{L}$  of sample in each well, although the instrument supports a sample volume range of 10–100  $\mu\text{L}$ . With such small volumes, the use of a Master Mix markedly reduces the number of reagent transfers per sample and minimizes reagent loss and sample-to-sample variations due to pipetting errors. You may also need to calculate the standard deviation among replicate results, as with the Install Kit (TaqMan Plate Reader Reagents - P/N 402853). For precise and consistently reliable calculations, the use of Master Mixes becomes essential.

The *ABI PRISM® 7700 Sequence Detection System User's Manual* lists the components of a Master Mix. Use the following guidelines and procedures to ensure optimum Master Mix preparation.

---

**Guidelines for Preparation** Follow these guidelines in handling reagents:

- ◆ Remove all reagents, except enzymes, from freezer just before you begin Master Mix preparation to allow thawing.
- ◆ Make sure buffer is at room temperature and thoroughly dissolved before pipetting. Gently rock the buffer solution to mix.
- ◆ Briefly vortex, then centrifuge individual tubes of buffer,  $\text{MgCl}_2$  solution, primers, probes, dNTPs, and template to ensure thorough mixing and to collect small isolated drops off the inner walls of the tubes before pipetting.
- ◆ Gently tap enzyme tubes to mix and centrifuge them to collect small isolated drops off the inner walls of the tubes before pipetting. Avoid vortexing or shaking enzyme solutions, which can result in denaturation.

---

**Guidelines for Component Volumes** Follow these guidelines for mixing reagents:

- ◆ Before performing the combination procedure, determine a multiplier for each reagent component that assures sufficient Master Mix for all samples.  
  
The total volume of Master Mix needed will be dependent upon the number of templates and the method used to deliver Master Mix to the reaction tubes. If you use the other procedure, which dilutes template with water, adjust the volume of the Master Mix accordingly.  
  
Your determination should include sufficient excess to discourage the formation of air bubbles when pipetting. For convenience, the total volume necessary for any reagent should be evenly divisible by available pipettor sizes.

**Note** You may dilute template with water for easier handling. Decrease the total volume of water in Master Mix accordingly.

- ◆ When combining Master Mix components, use a screw-top tube that is large enough to accommodate all components with room for gentle mixing. Prepare Master Mix in a DNA-free environment, if one is available.
- ◆ Use positive displacement pipettors with disposable tips to minimize contamination and improve precision.

**Note** Positive displacement pipettors with disposable tips provide contamination control with precision in pipetting. Aerosol control tips may be used as a contamination control with regular pipettes but provide decreased pipetting accuracy.

---



## Master Mix Preparation and Delivery Procedures

### Combining Components

Use the following procedure to combine components:

Step	Action
1	Deliver components to the Master Mix tube. Always add enzymes last.
2	Replace the screw-on cap on the Master Mix tube after each component is added to minimize contamination.
3	Deliver each reagent directly into the solution. Avoid delivering down the inner sides of the Master Mix tube.
4	When all components but the enzymes have been added to the Master Mix, replace the screw-on cap and vortex the Master Mix briefly at a low speed.
5	Slowly deliver enzymes, which tend to be viscous, directly into the Master Mix with the disposable tip in the solution. When you have delivered all enzyme, keep the tip in the solution and slowly pump the pipettor twice to rinse out the tip.
6	When all components except the template have been added, screw the cap tightly on the Master Mix tube and gently rock the tube to mix.

### Delivering Master Mix

#### General

Researchers have devised many methods for delivering Master Mix among 96 sample tubes. The criteria for determining the most appropriate method are subjective and highly personal. The following two methods have been used successfully in our research labs.

#### Working with Few Templates

This first method works well when fewer than ten templates are being distributed across a 96-well plate, as with the Install Kit. In this method, divide Master Mix among as many tubes as there are templates and controls. The following procedure uses the Install Kit as an example, though it can be applied to other experiments.;

To deliver the Master Mix to fewer than ten templates, follow this procedure:

Step	Action
1	Label one tube for each template. With the Install Kit, there are five standards, one No Template control, and two Unknowns, so label eight tubes, one for each template plus the No Template control.
2	Divide the Master Mix among the eight tubes, according to the directions in the Install Kit. The volume in each tube should allow 45 $\mu$ L for each sample replicate plus sufficient extra volume to avoid bubble formation while pipetting.  With the Install Kit, you must add 4 x 45 $\mu$ L plus extra dead volume for each DNA Template and for the No Template control. For each of the unknowns, add 36 x 45 $\mu$ L, plus extra dead volume.
3	Add each template to the appropriately labeled tube. The volume of template added should be sufficient to maintain the 5:45 (template-to-Master Mix) volume ratio.
4	Work with template solutions of low concentrations before working with more concentrated template solutions. Cap each tube as soon as you finish adding template to deter contamination from more concentrated solutions.

To deliver the Master Mix to fewer than ten templates, follow this procedure: *(continued)*

Step	Action
5	Slowly deliver template, which may be viscous, directly into the Master Mix with the disposable tip in the solution. When you have delivered all template, keep the tip in the solution and slowly pump the pipettor twice to rinse out the tip.
6	Screw the caps tightly on each tube of template solution and gently rock the tubes to mix.
7	Set up all reaction tubes in the tube holder. Make sure sample tube A1 is in the upper-left corner of the sample tube holder.
8	Use a repeater pipette with a disposable displacement tip to deliver 50 $\mu$ L of each template solution to a reaction tube.

### Working with Many Templates

This second method has been suggested for experiments that have more than ten templates on a 96-well plate. In this method, you first deliver the appropriate amount of diluted template to each sample tube. Then you deliver Master Mix solution on top of the diluted template. Because the Master Mix solution has a higher density than the template solution, the two solutions mix somewhat as the Master Mix is added.

**Note** You may dilute template with water for easier handling. Decrease the total volume of water in Master Mix accordingly.

When using this method, calculate in advance of preparing the Master Mix how much water you will use to dilute all the templates. Subtract this volume of water from the total amount of water needed to prepare the Master Mix.

To deliver Master Mix and diluted templates for more than ten templates, follow this procedure:

Step	Action
1	Prepare the Master Mix, adjusting the total volume of water for the amount of water needed to dilute all templates.
2	Dilute each template.
3	Make sure sample tube A1 is in the upper-left corner of the sample tube holder.
4	Deliver diluted templates to appropriate sample tubes.
5	Use a positive displacement pipettor with disposable tips to deliver Master Mix to sample tubes.

# *Purification of DNA*

---

# B

## Introduction

---

**General** This appendix covers the use of the GeneBinder and QIAmp procedures to purify DNA. For RNA, an extraction method that provides sufficiently clean RNA for PCR should be adequate for the 5' nuclease assay.

---

**In This Appendix** The following topics are included in this appendix:

Topic	See Page
Background and Requirements	B-2
Recommendation of Two Procedures	B-2
GenePure BaseBinder	B-2
QIAmp Protocol	B-2
Purification	B-2
Required Equipment	B-3
Required Reagents	B-3
Preparation of Reagent Solutions and Samples	B-5
Instructions for Preparing Reagents	B-5
Preparing Samples for Purification	B-6
Preparing Cultured Cells	B-7
Preparing Tissue Samples	B-7
Purifying DNA: The GenePure BaseBinder Procedure	B-8
Lysing and Digesting Cells	B-8
Isolating Genomic DNA with BaseBinder	B-8
Purifying DNA: The QIAmp Procedure	B-11
General	B-11
Procedures	B-11
Determining DNA Quality	B-12
UV Spectroscopy	B-12

---

## Background and Requirements

---

**Recommendation of Two Procedures** Because of the variety of DNA sample preparation procedures currently in use in the molecular biology laboratory, we recommend two DNA sample preparation methods for human and animal tissues: the GenePure BaseBinder protocol, an Applied Biosystems developed method; and a modification of the Qiagen QIAamp® blood/tissue protocol.

---

### **GenePure BaseBinder**

#### **Description**

The GenePure BaseBinder is a silica-based reagent system designed for cell lysis and manual purification of small samples of genomic DNA. Samples purified with the GenePure BaseBinder are sufficiently pure for use with TaqMan® Core Reagents on the ABI PRISM® 7200 and 7700 Sequence Detection Systems.

The GenePure BaseBinder extraction technique separates freely suspended nucleated cells from tissue matrix. Following cell lysis and digestion, genomic DNA is bound to activated silica beads. The DNA is isolated by elution into a small volume of buffer of low ionic strength. This purification protocol is optimized to remove PCR inhibitors that can interfere with the 5' nuclease assay, without the use of toxic phenol/chloroform.

#### **Protocol**

The GenePure BaseBinder protocol has been developed as a manual method specifically for use with the ABI PRISM 7200 and 7700 Sequence Detection Systems. PCR is sensitive to inhibitors that may be present in the sample matrix, such as heme and EDTA. This procedure effectively removes these inhibitors so that undiluted sample can be applied directly to the PCR reaction mix. The yields of nucleic acid are typically greater than 50 percent for both 250 µL and 25 µL blood samples.

### **QIAamp Protocol**

The QIAamp protocol is a well-established method for the purification of genomic DNA from a variety of tissues. The method uses a simple spin-column procedure. With the ABI PRISM 7200 Sequence Detection System, prior separation of leukocytes is necessary. Purification requires no phenol or chloroform extraction and utilizes a short digestion step. The procedure is further modified to include an additional wash step before the final elution of DNA from the spin column.

The Qiagen protocol has been adapted for use with the ABI Prism 7200 and 7700 Sequence Detection Systems. This modified procedure produces DNA of comparable yield and quality to the GenePure BaseBinder protocol. The preparation time with this method is approximately 25 percent shorter but the frequency of samples showing some inhibition is greater, particularly with micropreparatory sample volumes (25 µL).

### **Purification**

Use either the GenePure BaseBinder or the QIAamp procedure for purifying the following samples:

- ◆ Whole blood, 25–250 µL
- ◆ Tissue cultures, <10<sup>7</sup> cells
- ◆ Tissue, <1 mg

**IMPORTANT** As a precaution, avoid using heparinized blood. Heparin is a PCR inhibitor.

---

*continued on next page*

**Required Equipment** The required equipment is listed in Table B-1:

**Table B-1** List of Required Equipment

Item	Source
Microcentrifuge, large capacity, 1.5-mL tube	Brinkman Model 5416 (P/N 22-62-200-5, with 24 place fixed angle rotator (P/N 22-63-220-5), or equivalent
Heater-shaker, (combination vortex and heating block) multi-sample, temperature range: ambient to 95 °C	Brinkman Model 5436
Tissue grinder, disposable	Kimble/Kontes (P/N 95050-99) or equivalent
Pipettor, repeater, delivery volume: 25 $\mu$ L–1000 $\mu$ L	Eppendorf Model 4780
Microcentrifuge tubes, sterile, 1.5 mL	Eppendorf (P/N 2236-411-1), or equivalent
Pipette tips, sterile aerosol filter, 200 $\mu$ L and 1000 $\mu$ L	Major Laboratory Suppliers (MLS)
Pipette reservoir, sterile repeater, 5 and 12.5 mL	Eppendorf Combtips (P/N 23-49-515-1, 22-49-520-8)
Pipettes, sterile graduated transfer, 1 mL	SAMCO (P/N 212-205)
Pipettes, sterile extended fine tip transfer	SAMCO (P/N 232-205)
QIAamp Blood Kit (optional)	Qiagen, Chatsworth, CA (P/N 29106)
QIAamp Tissue Kit (optional)	Qiagen (P/N 29306)

**Required Reagents** The required reagents are listed in Table B-2:

**Note** Use analytical-reagent (AR) grade buffer salts and reagents, or their equivalents.

For chemicals required for this instrument but not manufactured or sold by Applied Biosystems, obtain the MSDSs from their manufacturers. For an MSDS for TaqMAN® PCR Core Reagents supplied with the instrument, see the *ABI PRISM® 7700 Sequence Detection System Site Preparation and Safety Guide*.

**Table B-2** List of Required Reagents

Item	Source
Water, distilled, deionized (18 MOhm, or equivalent), autoclaved. Use in preparation of all buffers and solutions in this procedure.	Major Laboratory Suppliers (MLS)
Ammonium chloride (NH <sub>2</sub> Cl)	MLS
Dibasic sodium phosphate (Na <sub>2</sub> HPO <sub>4</sub> )	MLS
Monobasic potassium phosphate (KH <sub>2</sub> PO <sub>4</sub> )	MLS
Potassium chloride (KCL)	MLS
Sodium bicarbonate (NaHCO <sub>3</sub> )	MLS
Sodium chloride	MLS
Tris-HCl	MLS
GenePure 2X Lysis Buffer	Applied Biosystems (P/N 400676)

**Table B-2** List of Required Reagents *(continued)*

Item	Source
Proteinase K	Applied Biosystems (P/N 400457)
BaseBinder Resin	Applied Biosystems (P/N 401380)
Ethanol, 95%, not denatured	MLS
Isopropanol, 100% AR/sequinal grade	MLS
Intercalator dye	PicoGreen dsDNA quantitation reagent, Molecular Probes, or equivalent

---

## Preparation of Reagent Solutions and Samples

---

### Instructions for Preparing Reagents

The instructions for preparing reagent solutions are provided below.

**Note** Use autoclaved, 18 mOhm, distilled, deionized water to prepare the following buffer and solutions.

#### Elution Buffer

Sterilize 20 mM Tris-HCl (pH 8.0) by passing it through a 0.2  $\mu$ m filter. Store at room temperature and discard after six months.

#### PBS Buffer

Prepare a solution of 137 mM sodium chloride, 2.7 mM potassium chloride, 10 mM dibasic sodium phosphate, and 1.8 mM monobasic potassium phosphate. Sterilize by autoclave. Store at room temperature and discard after three months.

#### Proteinase K solution

Solubilize the lyophilized Proteinase K in 4 mL of 20 mM Tris-HCl buffer (pH 8.0). Aliquot 500  $\mu$ L of the solution into 1.5-mL microcentrifuge tubes and store at -15 to -25°C.

#### Red Blood Cell (RBC) Lysis Buffer

Prepare a solution of 140 mM ammonium chloride, 1 mM sodium bicarbonate. Sterilize the solution by passing it through a 0.2  $\mu$ m filter. Store at room temperature and discard after 3 months.

#### Sodium Chloride Solution

Autoclave a 4M sodium chloride solution. Store at room temperature.

#### Wash Buffer

Prepare a solution of 200 mM NaCl and 20 mM Tris-HCl (pH 8.0). Add 95% ethanol to a final concentration of 70% v/v. Sterilize by passing it through a 0.2  $\mu$ m filter. Store at room temperature and discard after six months.

---

*continued on next page*

## Preparing Samples for Purification


Read these procedures carefully before beginning. These procedures include volumes for both 250  $\mu\text{L}$  and 25  $\mu\text{L}$  (micropreparatory amounts) of whole blood.

**Note** Micropreparatory amounts are represented in bold type and parentheses.

**! WARNING ! BIOHAZARD.** Tissue samples have the potential to transmit infectious diseases. Follow the latest guidelines published by the Centers for Disease Control (CDC) and National Institutes of Health (NIH) concerning the principles of risk assessment, biological containment, and safe laboratory practices for activities involving clinical specimens. These principles can be found in the U.S. Department of Health and Human Services (HHS) publication, *Biosafety in Microbiological and Biomedical Laboratories* (publication number 93-8395, stock number 017-040-523-7). The biosafety Level-2 containment elements are consistent with the Occupational Health and Safety Administration (OSHA) requirements contained in the HHS *OSHA Bloodborne Pathogen Standard 29 CFR*, part 1910.1030.

**IMPORTANT** Avoid using heparinized blood. Heparin is a PCR inhibitor.

To prepare whole blood, follow this procedure:

Step	Action
1	Aliquot 1.0 mL (1.0 mL) of RBC lysis buffer into 1.5-mL microcentrifuge tubes.
2	Thoroughly mix blood samples preserved with EDTA or acid citrate dextrose (ACD-A).
3	Pipette 250 $\mu\text{L}$ (25 $\mu\text{L}$ ) blood into each microcentrifuge tube and gently mix by pumping the pipettor 3–5 times.
4	Cap tubes and further mix by inverting the tubes 3–5 times. Let the tubes stand at room temperature for 10 minutes.
5	Centrifuge at 4500 rpm (1700 $\times g$ ) for 4 minutes.  The white blood cell (WBC) pellet appears as a white or opaque spot, 1–3 mm in diameter, at the bottom or side of the microcentrifuge tube.
6	Use a fine-tip transfer pipette to remove and discard the supernatant, including the layer of RBC “ghosts.” Take care not to disturb the WBC pellet. (figure below).   <p>Sample preparation from whole blood</p>
7	Add 200 $\mu\text{L}$ (100 $\mu\text{L}$ ) PBS buffer to the WBC pellet and completely resuspend the cells by vortexing 5–10 seconds at maximum speed.  The cells in the pellet must be completely dispersed throughout the solution.

*continued on next page*



---

### Preparing Cultured Cells

The following procedure is used to prepare cultured cells for purification.

To prepare cultured cells, follow this procedure:

Step	Action
1	Use a hemacytometer to assess cell yield. For 4–6 $\mu\text{g}$ DNA, you need to start with approximately $10^6$ cells.
2	Aliquot an appropriate volume of cultured cells into a 1.5 mL microcentrifuge tube.
3	Centrifuge at 4500 rpm (1700 x $g$ ) for four minutes.
4	Remove and discard the supernatant.
5	Add 200 $\mu\text{L}$ PBS buffer to the pellet and resuspend the cells by vortexing 5–10 seconds at maximum speed.

---

### Preparing Tissue Samples

The following procedure is used to prepare tissue samples for purification.

To prepare tissue samples, follow this procedure:

Step	Action
1	Use a tissue grinder to disrupt fresh and frozen tissues in PBS buffer.
2	Centrifuge the homogenate at 4500 rpm (1700 x $g$ ) for 10 minutes to isolate a nuclear pellet.
3	Remove and discard the supernatant.
4	Add 200 $\mu\text{L}$ PBS buffer to the pellet and resuspend the cells by vortexing 5–10 seconds at maximum speed.

---

## Purifying DNA: The GenePure BaseBinder Procedure

### Lysing and Digesting Cells

This procedure shows how to purify DNA with GenePure BaseBinder.

To lyse and digest cells, follow this procedure:

Step	Action
1	Mix cell suspension with 250 $\mu\text{L}$ (100 $\mu\text{L}$ ) GenePure Lysis Buffer and vortex 2–3 seconds at maximum speed.
2	Incubate at 55° C for five minutes.
3	Add 25 $\mu\text{L}$ (10 $\mu\text{L}$ ) proteinase K (12 mg/mL) and mix by gentle vortexing.
4	Incubate at 55° C for one hour.

### Isolating Genomic DNA with BaseBinder




This procedure illustrates the process of isolating genomic DNA.

**Note** Micropreparatory amounts are represented in bold type and parentheses.

To isolate genomic DNA with BaseBinder, do the following:

Step	Action
1	Cool samples to ambient temperature and add 250 $\mu\text{L}$ (100 $\mu\text{L}$ ) of 4M NaCl solution.
2	Mix by vortexing at high speed for 2 seconds.
3	Vortex the BaseBinder tube until the resin appears as a uniform slurry.
4	Pipette 20 $\mu\text{L}$ ( <b>10 <math>\mu\text{L}</math></b> ) of BaseBinder into each sample tube and vortex at high speed for 2 seconds.
5	Add 750 $\mu\text{L}$ ( <b>300 <math>\mu\text{L}</math></b> ) isopropanol, cap the tube, and vortex vigorously. <b>Note</b> For optimum DNA recovery, vigorously vortex at this step to ensure adequate shearing of DNA.
6	Centrifuge at 7000 rpm (4300 xg) for two minutes.

To isolate genomic DNA with BaseBinder, do the following: *(continued)*

Step	Action
7	<p>Use a fine-tip transfer pipette to carefully discard supernatant, as shown in figure below.</p> <div><p>Isolation Step: Resuspended cell pellet—&gt;lysis/digest (1 hr)—&gt; DNA +BaseBinder.</p><p>Wash Steps: Resuspend and wash pellet.</p><p>Elution Steps: Elute DNA from resin.</p><p>Collect supernatant.</p></div>

To wash BaseBinder, follow this procedure:

Step	Action
1	Resuspend pellet in 1.0 mL (500 $\mu$ L) Wash Buffer.
2	Vortex at high speed until the pellet is completely suspended.
3	Centrifuge at 7000 rpm (4300 x <i>g</i> ) for two minutes.
4	Carefully remove all remaining wash buffer with a fine-tip transfer pipette. Discard supernatant.
5	Place open sample tubes in 55° C heating block for 5 minutes. to evaporate residual ethanol.

To elute DNA, do the following:

Step	Action
1	Resuspend pellet in 500 $\mu$ L (100 $\mu$ L) Elution Buffer.
2	Warm to 55° C for 2 minutes.
3	Centrifuge at 7000 rpm (4300 x <i>g</i> ) for 2 minutes.
4	Transfer supernatant to a clean microcentrifuge tube. Store at -15 to -25° C.

---

## Purifying DNA: The QIAamp Procedure

---

**General** Refer to the Qiagen handbook: QIAamp Blood Kit and QIAamp Tissue Kit protocols for descriptions of AL Lysis Buffer, Proteinase K Stock Solution or Qiagen Protease, and Buffer AW supplied by Qiagen.

Prepare whole blood as described in “Preparing Samples for Purification” on page B-6.

**IMPORTANT** Do not use heparinized blood. Heparin is a PCR inhibitor.

---

**Procedures** These procedures use the QIAamp Procedure to purify samples.

**Note** Micropreparatory amounts are represented in bold type and parentheses.

To lyse and digest cells, follow this procedure:

Step	Action
1	Mix cell suspension with 200 $\mu\text{L}$ (100 $\mu\text{L}$ ) AL Lysis Buffer plus 25 $\mu\text{L}$ (15 $\mu\text{L}$ ) protease or Proteinase K Stock Solution and vortex 2-3 sec at maximum speed.
2	Incubate at 70° C for 10 minute.
3	Add 210 $\mu\text{L}$ ( <b>100 <math>\mu\text{L}</math></b> ) of isopropanol (100%) and mix again by vortexing.

To isolate and wash genomic DNA on the QIAamp spin column, follow this procedure:

Step	Action
1	Transfer sample lysate to a spin column, cap the column tube, and centrifuge at 8200 rpm (6000 xg) for 1 minutes. Discard the filtrate in the collection tube and place the spin column in a clean 2-mL collection tube.
2	Carefully open the spin column and add 500 $\mu\text{L}$ (500 $\mu\text{L}$ ) of Buffer AW and centrifuge at 8200 rpm (6000 xg) for 1 minute. Discard the filtrate in the collection tube and place the spin column in a clean collection tube.
3	Carefully open the spin column and add another 500 $\mu\text{L}$ (500 $\mu\text{L}$ ) of Buffer AW. Centrifuge at 8200 rpm (6000 xg) for 1 minute.
4	Repeat step 3. Centrifuge at 8200 rpm (6000 xg) for 1 minute and at full speed for an additional 2 minutes.

To elute DNA, follow this procedure:

Step	Action
1	Place the spin column in a clean 1.5-mL microcentrifuge tube using the caps removed. Discard the collection tube containing the filtrate.
2	Elute DNA by adding 200 $\mu\text{L}$ ( <b>100 <math>\mu\text{L}</math></b> ) of distilled water or using the Elution Buffer.
3	Centrifuge at 8200 rpm (6000 xg) for 1 minute.
4	Remove and discard spin column. Cap collection tube or transfer eluate to a suitable storage vial. Store at -20° C.

---

## Determining DNA Quality

---

**UV Spectroscopy** The purity of DNA can be assessed by measurement of its absorbency spectrum from 200–300 nm. Accurate quantitation of DNA from small starting samples ( $<10^5$  cells) by spectrophotometry is difficult. The use of a dye intercalator such as PicoGreen is an alternative quantitative method that is accurate to a concentration of 50 pg/mL.


The concentration of DNA is spectrophotometrically determined in a 1-cm path cuvette with the use of the formula:  $A_{260} \times 50 = \text{ng DNA}/\mu\text{L}$ .  $A_{260}/A_{240}$  and  $A_{260}/A_{280}$  are characteristic absorbency ratios measurements for DNA purity. Values greater than 1.2 and 1.9, respectively, are indicative of high quality DNA for use in PCR.

**Note** Contact your local Applied Biosystems sales representative for information on Applied Biosystems spectrophotometers.

---

# Sequence Detection Software Reference

---



## Overview

---

**Introduction** This appendix gives detailed descriptions of the features of the Sequence Detection application, including each view in the plate document and all the commands.

---

**In This Appendix** This appendix has the following content:

Topic	See page
General Plate Document Information	C-3
General	C-3
Main Differences between Setup Views	C-4
Types of Plate Documents	C-5
Setup View Features	C-6
General	C-6
Entry Fields	C-6
Buttons	C-7
Pop-Up Menus	C-7
96 Sample Wells	C-9
Analysis View Features	C-10
General	C-10
Analytical Plate Differences	C-10
Entry Fields	C-11
Shortcuts	C-14
File Menu	C-16
General	C-16
New Plate	C-16
Open Plate	C-17
Save/Page Setup/Print/Quit	C-17
Save As Dialog Box	C-17
File Formats	C-17
Export	C-18
Import	C-20
Edit Menu	C-22
General	C-22

<b>Topic</b>	<b>See page</b>
Undo/Cut/Copy/Paste/Clear/Select All	C-22
Preferences	C-22
Setup Menu	24C-
General	C-24
Setting Up Thermal Cycler Conditions	C-24
Editing a Method.	C-26
Sample Type Palette	C-33
Sample Type Setup Dialog Box	C-33
Editing Sample Attributes	C-34
The Sample List	C-36
Sample Types/Plate Types.	C-37
Adding Sample List Information	C-38
Guidelines for IPC	C-39
Instrument Menu	C-40
General	C-40
Run	C-40
Stop	C-40
Calibrate	C-40
Diagnostics	C-43
Functions Test	C-45
Instrument Verification	C-47
Analysis Menu	C-48
Purpose of Menu	C-48
Display	C-48
Options	C-49
Statistics/Allele Settings	C-49
Allelic Discrimination	C-50
Amplification Plot	C-52
Multicomponent	C-54
Raw Spectra.	C-55
Standard Curve	C-57
Graph Features	C-59
General	C-59
Changing Spectra Displayed	C-59
Changing Graph Display Features	C-60
Windows Menu	C-62
General	C-62
Experiment Report	C-62
Event Log	C-63



## General Plate Document Information

**General** The plate document has two views (shown in Figure C-1 and Figure C-2). Each view has features you need to set up your experiment, run the Sequence Detector, and collect and analyze data. These views will be described in detail in this appendix and differences between plate types pointed out.

Install Kit, Taqman Gold												
Sample Type: <span>STND - Standard</span>				Thermal Cycler Conditions				7700 Single Reporter				
Sample Name: B4								Comment:				
Replicate:												
Quantity: 5.0e+03												
Show Analysis				Dye Layer: <span>FAM</span>								
	1	2	3	4	5	6	7	8	9	10	11	12
A	NTC A1	NTC A2	NTC A3	NTC A4	STND A5 1.0e+03	STND A6 1.0e+03	STND A7 1.0e+03	STND A8 1.0e+03	STND A9 2.0e+03	STND A10 2.0e+03	STND A11 2.0e+03	STND A12 2.0e+03
B	STND B1 5.0e+03	STND B2 5.0e+03	STND B3 5.0e+03	STND B4 5.0e+03	STND B5 1.0e+04	STND B6 1.0e+04	STND B7 1.0e+04	STND B8 1.0e+04	STND B9 2.0e+04	STND B10 2.0e+04	STND B11 2.0e+04	STND B12 2.0e+04
C	UNKN C1 1.0e+04	UNKN C2 8.7e+03	UNKN C3 1.2e+04	UNKN C4 1.0e+04	UNKN C5 1.1e+04	UNKN C6 1.1e+04	UNKN C7 1.0e+04	UNKN C8 1.1e+04	UNKN C9 9.9e+03	UNKN C10 9.1e+03	UNKN C11 8.7e+03	UNKN C12 1.0e+04
D	UNKN D1 9.8e+03	UNKN D2 1.1e+04	UNKN D3 1.0e+04	UNKN D4 1.2e+04	UNKN D5 1.1e+04	UNKN D6 8.8e+03	UNKN D7 9.6e+03	UNKN D8 1.1e+04	UNKN D9 9.7e+03	UNKN D10 9.4e+03	UNKN D11 9.4e+03	UNKN D12 9.4e+03
E	UNKN E1 1.2e+04	UNKN E2 1.0e+04	UNKN E3 1.1e+04	UNKN E4 1.0e+04	UNKN E5 1.1e+04	UNKN E6 1.1e+04	UNKN E7 9.0e+03	UNKN E8 9.9e+03	UNKN E9 1.0e+04	UNKN E10 7.6e+03	UNKN E11 9.2e+03	UNKN E12 1.0e+04
F	UNKN F1 5.1e+03	UNKN F2 5.4e+03	UNKN F3 4.4e+03	UNKN F4 4.8e+03	UNKN F5 5.3e+03	UNKN F6 5.2e+03	UNKN F7 4.1e+03	UNKN F8 5.1e+03	UNKN F9 4.7e+03	UNKN F10 5.1e+03	UNKN F11 5.1e+03	UNKN F12 4.7e+03
G	UNKN G1 5.1e+03	UNKN G2 4.6e+03	UNKN G3 5.2e+03	UNKN G4 5.6e+03	UNKN G5 5.0e+03	UNKN G6 5.3e+03	UNKN G7 4.5e+03	UNKN G8 4.8e+03	UNKN G9 4.9e+03	UNKN G10 4.5e+03	UNKN G11 4.7e+03	UNKN G12 5.0e+03
H	UNKN H1 5.2e+03	UNKN H2 4.1e+03	UNKN H3 4.7e+03	UNKN H4 4.8e+03	UNKN H5 4.3e+03	UNKN H6 4.7e+03	UNKN H7 3.9e+03	UNKN H8 4.9e+03	UNKN H9 4.6e+03	UNKN H10 4.7e+03	UNKN H11 4.7e+03	UNKN H12 3.8e+03

Figure C-1. The Setup view of the Plate document (Single Reporter Real Time)

Install Kit, Taqman Gold												
Sample Type: <span>STND - Standard</span>				<div> <div>RUN</div> <div>STOP</div> </div>				7700 Single Reporter				
Sample Name:				<div> <div>Status: Checking...</div> <div>Cov. Temp:</div> <div>Smp. Temp:</div> <div>Remaining:</div> </div>				Comment:				
Replicate:				<div> <div>Stage:</div> <div>Time:</div> </div>				<div> <div>Repetition:</div> <div>Step:</div> </div>				
Quantity:				<div> <div>Rn range: -1.0</div> <div>1000</div> </div>				<div> <div>Cycle #: 1.0</div> </div>				
Show Setup				Dye Layer: <span>FAM</span>								
	1	2	3	4	5	6	7	8	9	10	11	12
A	NTC	NTC	NTC	NTC	STND	STND	STND	STND	STND	STND	STND	STND
B	STND	STND	STND	STND	STND	STND	STND	STND	STND	STND	STND	STND
C	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN
D	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN
E	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN
F	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN
G	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN
H	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN	UNKN

Figure C-2. The Analysis view of the Plate document (Single Reporter Real Time)

*continued on next page*

## Main Differences between Setup Views

Although both plate views (Setup and Analysis) differ for types of analysis plates, differences between Setup views are easier to explain. Figure C-3 and Figure C-4 illustrate the main differences between Setup views of the analytical plate documents.

Differences in the Analysis view of the different plate types will be discussed in the detailed description of the Analysis view.

Dye layer pop-up

	1	2	3	4	5	6	7	8	9	10	11	12
A	NTC A1	NTC A2	NTC A3	NTC A4	STND A5	STND A6	STND A7	STND A8	STND A9	STND A10	STND A11	STND A12
B	STND B1 5.0e+03	STND B2 5.0e+03	STND B3 5.0e+03	STND B4 5.0e+03	STND B5 1.0e+04	STND B6 1.0e+04	STND B7 1.0e+04	STND B8 1.0e+04	STND B9 2.0e+04	STND B10 2.0e+04	STND B11 2.0e+04	STND B12 2.0e+04
C	UNKN C1 1.0e+04	UNKN C2 8.7e+03	UNKN C3 1.2e+04	UNKN C4 1.0e+04	UNKN C5 1.1e+04	UNKN C6 1.1e+04	UNKN C7 1.0e+04	UNKN C8 1.1e+04	UNKN C9 9.9e+03	UNKN C10 9.1e+03	UNKN C11 8.7e+03	UNKN C12 1.0e+04
D	UNKN D1 9.8e+03	UNKN D2 1.1e+04	UNKN D3 1.0e+04	UNKN D4 1.2e+04	UNKN D5 1.1e+04	UNKN D6 8.8e+03	UNKN D7 9.6e+03	UNKN D8 1.1e+04	UNKN D9 9.7e+03	UNKN D10 9.4e+03	UNKN D11 9.4e+03	UNKN D12 9.4e+03
E	UNKN E1 1.2e+04	UNKN E2 1.0e+04	UNKN E3 1.1e+04	UNKN E4 1.0e+04	UNKN E5 1.1e+04	UNKN E6 1.1e+04	UNKN E7 9.0e+03	UNKN E8 9.9e+03	UNKN E9 1.0e+04	UNKN E10 7.6e+03	UNKN E11 9.2e+03	UNKN E12 1.0e+04
F	UNKN F1 5.1e+03	UNKN F2 5.4e+03	UNKN F3 4.4e+03	UNKN F4 4.8e+03	UNKN F5 5.3e+03	UNKN F6 5.2e+03	UNKN F7 4.1e+03	UNKN F8 5.1e+03	UNKN F9 4.7e+03	UNKN F10 5.1e+03	UNKN F11 5.1e+03	UNKN F12 4.7e+03
G	UNKN G1 5.1e+03	UNKN G2 4.6e+03	UNKN G3 5.2e+03	UNKN G4 5.6e+03	UNKN G5 5.0e+03	UNKN G6 5.3e+03	UNKN G7 4.5e+03	UNKN G8 4.8e+03	UNKN G9 4.9e+03	UNKN G10 4.5e+03	UNKN G11 4.7e+03	UNKN G12 5.0e+03
H	UNKN H1 5.2e+03	UNKN H2 4.1e+03	UNKN H3 4.7e+03	UNKN H4 4.8e+03	UNKN H5 4.3e+03	UNKN H6 4.7e+03	UNKN H7 3.9e+03	UNKN H8 4.9e+03	UNKN H9 4.6e+03	UNKN H10 4.7e+03	UNKN H11 4.7e+03	UNKN H12 3.8e+03

Figure C-3. Dye Layer Pop-up on Single Reporter Setup View

The main differences between the Single Reporter Real Time (SRRT) setup view (shown in Figure C-1) and the Allelic Discrimination (AD) setup view (shown in Figure C-4) is that the SRRT setup view has a quantity entry field and multiple dye layers while the AD setup view does not. Any discussion of the dye layers and the dye pop-up menu do not apply to the Allelic Discrimination plate type. The Single Reporter Read Only plate (not shown) is a mixture of both plate types since it does not have a quantity field but does have multiple dye layers.

	1	2	3	4	5	6	7	8	9	10	11	12
A	NTC A1	NTC A2	NTC A3	NTC A4	NTC A5	NTC A6	NTC A7	NTC A8	AL1 A9	AL1 A10	AL1 A11	AL1 A12
B	AL1 B1	AL1 B2	AL1 B3	AL1 B4	AL2 B5	AL2 B6	AL2 B7	AL2 B8	AL2 B9	AL2 B10	AL2 B11	AL2 B12
C	UNKN C1	UNKN C2	UNKN C3	UNKN C4	UNKN C5	UNKN C6	UNKN C7	UNKN C8	UNKN C9	UNKN C10	UNKN C11	UNKN C12

Figure C-4. Differences in the Setup view for the Allelic Discrimination plate

*continued on next page*

---

**Types of Plate Documents**

There are four types of plate documents which may be opened, Two of these, Background and Pure Spectra, are used in setting up the instrument but not for general operation (see "Background Calibration" on page 3-7 and "Pure Dye Spectra Calibration" on page 3-9 for more information on using these types of plates.


The two types of plates used for analysis are the Allelic Discrimination plate and the Single Reporter plate. This appendix will point out the differences in the interfaces between these types of plates. For information on using these plate types for different applications, see Chapter 3, "Setup and Operation for Real Time Quantitation," Chapter 4, "Setup and Operation for Allelic Discrimination" and Chapter 5, "Setup and Operation for Plus/Minus Scoring."

---

# Setup View Features

**General** As Figure C-5 shows, the Setup view contains:

- ◆ Entry fields for sample information and comments
- ◆ Buttons for entering/displaying the Thermal Cycler Conditions and toggling the view
- ◆ Pop-up menus for Dye layers and Sample Types
- ◆ 96 sample wells



**Figure C-5.** Setup View for the Single Reporter Plate for Real Time Quantitation

**Entry Fields** The Setup view contains three entry fields: Sample Name, Replicate, and Comments. The sample being described may be any sample type. You may use a field to describe the contents of one well or many sample wells selected together. These three fields can hold up to 255 characters each.

- Sample Name.** Enter a number or text that identifies the sample.
- Replicates.** A replicate is a way to group samples. Select the wells that you would like to group and then enter a number or text in the Replicate field.
- During data analysis,** the Sequence Detection application calculates the mean and the Standard Deviation of the replicate group. The Experiment Report displays these replicate values.
- Quantity.** Enter a number that represents the quantity of the standard sample types. The number you enter is automatically converted to scientific notation.
- The Quantity entry field** is open for entry only when wells are designated as STND (Standard).

In scientific notation, the exponential factor is converted to the term “e+”. For example, 1000, which can be represented as  $10^3$ , becomes 1.0 e+03 in scientific notation.

Number	As Exponent	In Scientific Notation
1000	$10^3$	1.0e+03
2000	$2 \times 10^3$	2.0e+03
5000	$5 \times 10^3$	5.0e+03
10000	$10^4$	1.0e+04
20000	$2 \times 10^4$	2.0e+04

**IMPORTANT** Do not type commas in the Quantity entry field.

The same unit of quantity is assigned to all wells on any one plate document. You can determine the default unit assigned to quantity in the Preferences dialog box (page C-22).

Comments. The Comments entry field, on the top right side of the Setup view, holds up to 255 characters. The contents of this entry field also appear on the Analysis view and the Experiment Report. You can edit the comments field in either the Setup view or the Analysis view. Comments entered in this field are presented on the Experiment Report.

---

## Buttons Thermal Cycler Conditions

Click the Thermal Cycler Conditions button to open the Thermal Cycler Conditions dialog box. See page C-24 for more information about Thermal Cycler Conditions.

### View Toggle

Click the Show Analysis button to see the Analysis view of the plate document.

Click the Show Setup button to return to the Setup view of the plate document.

---

**Pop-Up Menus** The following pop-up menus are provided in a plate document.

### Dye Layer.


Click the Dye Layer pop-up menu to look at another dye layer in the plate document. The plate document may have up to eight dye layers.

**Note** The Dye Layer pop-up menu is not available in Allelic Discrimination type plates.

You can change the contents of the Dye Layer pop-up menu by removing or adding dyes.


◆ To remove a dye from the Dye Layer pop-up menu, see page C-42.

- ◆ To add a dye to the Dye Layer pop-up menu, proceed as follows:

Step	Action
1	<p>Choose Calibrate in the Instrument menu, then choose Setup Pure Spectra.</p>  <p>The Setup Pure Spectra dialog box opens.</p>
2	<p>Click the Show All button.</p> <p>All available pure spectra now appear in the dialog box.</p>
3	<p>Is the dye you want to add to the Dye Layer pop-up menu available?</p> <p>If no, perform a Pure Dye Spectra calibration of the dye. See “Pure Dye Spectra Calibration” on page 3-9 for the Pure Dye Spectra Calibration procedure. Then return to step 1 of this procedure.</p> <p>If yes, continue to step 4.</p>
4	<p>Check the checkbox next to the dye to make it an active dye.</p>
5	<p>Click OK to close the dialog box.</p> <p>The Dye Layer pop-up menu now contains the new active dye.</p>

### Sample Type.

Use the Sample Type pop-up menu to assign a sample type to a selected well or group of wells. The items that appear in the Sample Type pop-up menu vary according to the dye layer you are viewing. For example, when you are looking at the FAM dye layer, you only see sample types that have been labeled with FAM as the Reporter dye in the Sample Type Setup dialog box.



**Figure C-6.** Sample Pop-up Menus for the three plate types

See page C-33 for information on the Sample Type Setup dialog box.

To assign a sample to one or more wells with the Sample Type pop-up:

Step	Action
1	Select one or more wells that contain the same sample.
2	Click the Sample Type pop-up menu and select a sample type. <ul style="list-style-type: none"><li>◆ Select Edit Sample List to open the Sample Type Setup dialog box.</li><li>◆ Select Not in Use to delete sample information in a selected dye layer and well</li></ul>

96 Sample Wells

Figure C-7 illustrates the labeling of wells on a simulated 96-well plate: “1–12” horizontally, across the top of the plate, and “A–H” vertically, on the left side of the plate. Each of the 96 wells has a unique label combining the vertical and horizontal labels, such as A1, C4, F10, and G12 which appear on the Experiment Report and graphs of data.




Figure C-7. Examples of information displayed in wells

On the Setup view, each well can display three lines of information. The top line displays the Sample Type you selected from either the Sample Type pop-up menu or the Sample Type Palette. The middle line displays either the well label or the information in the Sample Name field. The bottom line displays the information in the Quantity field.

To select wells on a plate document:

- ◆ To select multiple contiguous wells, hold down the mouse button as you click and drag the cursor across the plate.




Figure C-8. Selecting multiple contiguous wells

- ◆ To select multiple discontinuous wells, hold down the Command (⌘) key and click on wells.
- ◆ To select an entire row or column of wells, click on a row or column label (A–H, 1–12).

Selected wells are outlined in black.


# Analysis View Features

**General** As Figure C-9 shows, the Analysis view contains:

- ◆ Entry field for Comments
- ◆ Button for toggling the view
- ◆ Pop-up menu for dye layers
- ◆ 96 sample wells
- ◆ Read buttons
- ◆ Stop button
- ◆ R<sub>n</sub> range and Cycle indicators and controls

**Note** The first four items operate the same way in the Analysis view as described for the Setup view.

**Analytical Plate Differences** Figure C-9 illustrates the differences between Single Reporter (Real Time) and Allelic Discrimination plate types:



**Figure C-9.** Comparison of Single Reporter and Allelic Discrimination Analysis Views



**Entry Fields** The information entered on the Setup view in the sample information and comments appears on the Analysis view. This information can also be edited in the Analysis view.

### Run and Stop Buttons



The Sequence Detector is ready to run when:

- ◆ All the parameters of the experiment have been defined on the Setup view
- ◆ The 96-well plate has been placed on the sample block, and
- ◆ The cover of the sample block has been tightened.

To run the Sequence Detector:

- ◆ Click the Run button on the Analysis view of the plate document or use the keyboard shortcut, Cmd R.


As the Sequence Detector starts the run, the adjoining Status field flashes the word Success, followed by the word Waiting.

The Sequence Detector does not begin running until the temperature of the sample block cover reaches 105 °C. The adjoining Status field flashes the word Ramping as the temperature of the sample block increases.

To stop the sequence detector:

- ◆ Click the Stop button.

If you are stopping a run before it has completed all the Stages defined in the Thermal Cycler Conditions, a dialog box opens when you click the Stop button.



**Figure C-10.** Data Handling dialog box


Use this dialog box to either save or discard the data already acquired.

To handle acquired data before stopping a run:

Step	Action
1	Select one of the two data handling options.
2	Click OK to abort the run. Click Cancel to continue the run and collect more data

## Sequence Detector Status Fields

Use the status fields on the Analysis view to track the progress of a run. The information displayed in the top fields relates the condition of the thermal cycler and the time remaining in the entire run. The fields below display information about the particular Stage the thermal cycler is currently running. The Stage number corresponds to the Stage numbers found in the Thermal Cycler Conditions dialog box. See page C-25 for a description of Stages.



**Figure C-11.** Status Fields

**Status.** The field labeled “Status” displays the following one-word status reports on the thermal cycler:

Status	Interpretation
Offline	Sequence Detection application is not connected to the instrument
Idle	Instrument is not running, but application is connected to the instrument
Success	Run button has been clicked
Waiting	Data being transferred from Plate Reader to the computer
Ramping	Temperature of sample block is increasing or decreasing
Holding	Temperature of sample block is constant
Aborting	Run has been stopped

The other status fields function as described below:

Item	Description
Cov. Temp	Displays the temperature of the heated cover. During PCR, this temperature is approximately 105 °C.
Smpl. Temp	Displays the temperature of the samples in the sample block. This temperature correlates to the temperature plateaus defined in the Thermal Cycler Conditions dialog box.
Remaining	<p>Displays how much time is left to complete the run, as defined in the Thermal Cycler Conditions dialog box. If the last Stage of the run contains a Hold with a time greater than 95 minutes (<math>\infty</math> or “forever”), the time remaining does not include that Hold. See “Changing Temperature and Time” on page C-28 for details on setting <math>\infty</math> or “forever”.</p> <p>When the run begins a “forever” Hold, the Remaining field acts as a timer and counts the amount of time that has elapsed since the forever Hold began. This counting stops when you press the Stop button.</p>

Item	Description
Stage	Displays the number of the Stage of the run currently being performed. The Stage numbers correspond to the Stage numbers that appear in the Thermal Cycler Conditions dialog box. See page for a discussion of Stages.
Time	Displays the time remaining until the end of the Stage.
Repetition	Counts the number of cycle repetitions that have been performed during one Stage. During a Hold, no numbers appear in this field.
Step	Displays the number of the Step currently being performed. In a typical two-step Cycle of one melting step followed by an anneal-extension step, the Step number is 1 during a melting step and 2 during anneal-extension.

---

## Shortcuts

Once you become familiar with the Sequence Detection application, you can use these combinations to perform tasks you would normally perform with the mouse. The list of shortcuts in Table C-1 uses the following conventions:

This	Means
⌘	Command key
⌘ K	Hold down the Command key and the letter “k” simultaneously
Double-click	Press the mouse button twice rapidly

**Table C-1** Keyboard Shortcuts in the Sequence Detection Application

Shortcut	Action
⌘ N	Opens New Plate dialog box
⌘ O	Opens directory to choose and open saved plate
⌘ W	Closes the plate document
⌘ S	Saves the plate document
⌘ E	Exports Extension data in tab-delimited format
⌘ H	Exports Results data in tab-delimited format
⌘ P	Opens Print dialog box
⌘ Q	Quits Sequence Detection application
⌘ J	Extracts Pure Spectra
⌘ R	Starts Sequence Detector
⌘ F	Opens Function Test dialog box
⌘ T	Opens Thermal Cycler Conditions dialog box
⌘ L	Analyzes data
⌘ 3	Opens Experiment Report
⌘ 4	Opens Event Log
⌘ A	Selects all wells or elements in a window
⌘ C	Puts a copy of the selection in the Clipboard
⌘ D	Opens Standard Curve window
⌘ G	Opens Amplification Plot view
⌘ V	Takes selection out of Clipboard and places it at cursor
⌘ X	Puts selection in the Clipboard
⌘ Y	Opens Raw Spectra View
⌘ Z	Reverses last performed action

You can also use the mouse button to click on features in the Sequence Detection application for additional shortcuts.

Shortcut	Action
Click any color box	Opens color wheel dialog box
Click row label on plate document	Selects entire row
Click column label on plate document	Selects entire column
Double-click well of analyzed data	Opens Raw Spectra view

---

# File Menu

File		
New plate	⌘N	
Open plate...	⌘O	
Close	⌘W	
Save	⌘S	
Export...		▶
Import...		▶
Page Setup...		
Print...	⌘P	
Quit	⌘Q	

## General

All experiments you setup and run with the Sequence Detection application use a plate document to display sample wells and their associated data. Use the commands in the File menu to open, save and close plate documents, input format or setup files, export collected data, and handle printing tasks.

## New Plate

**General**  
Opens a new plate document.




Figure C-12. New Plate dialog box

The New Plate dialog box contains three pop-up menus, labeled “Plate Type,” “Instrument,” and “Run.” The terms on the dialog box are described in the table below:

Item	Description
Plate Type	Four plate types are available, corresponding to the types of plates you need to run experiments on the instrument: Single Reporter, Allelic Discrimination, Background and Pure Spectra.
Single Reporter	Use this plate type when all probes in your experiment are labeled with the same reporter, either with or without an IPC layer.
Allelic Discrimination	Use this plate type to run an experiment that distinguishes between two alleles.
Background	Use this plate type to generate a background component (see page C-40 and page 3-7).
Pure Spectra	Use this plate to generate pure dye components (see page C-41 and page 3-10).

## Data Acquisition

Data acquisition is controlled by choices made for the following two parameters:

**Instrument.** The software supports two instruments, the 7200 and the 7700. Choose the “7700 Sequence Detector” for the present instrument.

**Run.** Two types of data acquisition runs are available: Real Time, which collects data at every cycle of the PCR; and Plate Read, which collects only one set of data after PCR is complete.

*continued on next page*

---


**Open Plate** Opens a plate document that has previously been used and saved.

---

**Save/Page Setup/Print/Quit** These commands have the normal Macintosh computer functions. Only commands which differ in some way from those on a standard File menu are discussed.

---

**Save As Dialog Box** Assigns a name and file format while saving the active plate document. A plate document can be saved in either Normal or Stationery file format.



**Figure C-13.** Save As dialog box1

---

## File Formats Normal File Format



A plate document saved in normal file format contains the following information:

- ◆ Sample types in each well
- ◆ All information in the Thermal Cycler Conditions dialog box

If you save a plate document in normal file format after PCR data has been collected, the saved document also contains:

- ◆ All collected data, but without analyzed data
- ◆ Background and pure spectra components



## Stationery File Format

A plate document saved in stationery file format contains:

- ◆ Sample types in each well
- ◆ All information in the Thermal Cycler Conditions dialog box

You can save plate documents as stationery files for those experiments that you plan to repeat frequently. When you open a stationery file, the Sequence Detection application opens a copy of the file for you to use. Changes you make to the copy do not affect the original stationery plate file. When you save or close the copy, you can save it as a normal file or re-name it as another stationery file. The Sequence Detection application labels stationery plate files with a unique icon.

---

*continued on next page*

**Export** You can export raw or analyzed data in tab-delimited format for all 96 wells or for a selected group of wells on a plate. You can open these exported files with any application that reads tab-delimited text.

Exported data files contain records of temperature changes and relevant data collected at each designated data collection point. Table C-2 describes specific data collected for each export option. A spectral bin represents a portion of the complete range of measured wavelength, from approximately 500–660 nm.

**Table C-2** Exported Data Options

Export Option	Produces	Data vs. Plate Type		
		(RT)	PR	AD)
Raw Spectra	One unique data file for each well selected. Contains data collected at each of 32 spectral bins throughout all Stages of PCR that have been labeled with Data Collection icons in the Thermal Cycler Conditions dialog box. A data point is collected approximately once every 7 seconds.	X	X	X
Pure Spectra	Pure dye component data, one data point for each of 32 spectral bins, and 96 wells of background data for each spectral bin.	X	N/A	N/A
Multicomponent	The calculated amount of each dye component in any well throughout all Stages of PCR that have been labeled with Data Collection icons in the Thermal Cycler Conditions dialog box. A data point is collected approximately once every 7 seconds. Also contains pure spectra component data, the calculated inverse matrix, and single values of the inverse matrix.	X	X	X
Clipped	The average of the last 3 data points collected during the extension phase of each cycle repetition for each selected well.	X	N/A	N/A
Extension	One extension step data point for each of 32 spectral bins, at each cycle repetition, for each well.	X	N/A	N/A
Results	For a Real Time run, results include Ct, Quantity, and Mean (except NTCs), and Standard Deviation for replicates for each well selected. The only data for NTCs is Ct.  Other Real Time data includes Standard Curve information such as slope, intercept, fit, threshold, and baseline range.  For a Plate Read run, results include data at a single end point for each well. A Single reporter type Plate Read provides $R_n$ and $\Delta R_n$ at end point and +/- detection of template. An Allelic Discrimination type Plate Read provides allele calls for each sample (Allele 1 homozygous, Allele 2 homozygous, or Allele 3 heterozygous).	X	X	



To export data in tab-delimited format:

Step	Action
1	<p>Select the entire plate (click upper left corner of well area) to select all wells or select a group of wells and then choose Export in the File menu and choose the type of data to export.</p> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <b>File</b>  New Plate    %N  Open Plate...    %O  Close    %W    Save    %S  Save As...    Export...  Import...    Page Setup...  Print...    %P    Quit    %Q </div> <div style="margin-right: 20px;"> Export choices before analysis </div> <div style="margin-right: 20px;"> Export choices after analysis </div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>Raw Spectra...</b>  <b>Pure Spectra...</b> </div> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>Raw Spectra...</b>  <b>Pure Spectra...</b>    <b>MultiComponent...</b>  Clipped...  Extension Phase...    %E  Results...    %H  Experimental Report... </div> </div> <p><b>Note</b> After analysis the full range of choices shown to the right above are available for export.</p>
2	<p>Then choose the type of data to export.</p> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 10px; margin-right: 20px;"> <div style="display: flex; justify-content: space-between;"> <span>Data ▼</span> <span>Synth</span> </div> <div style="display: flex;"> <div style="flex: 1;"> <ul style="list-style-type: none"> <li><input checked="" type="checkbox"/> Allelic Plate (w/Data)</li> <li><input checked="" type="checkbox"/> Blue/Orange 1.0.5d6 6/19/96</li> <li><input checked="" type="checkbox"/> Dye for Karen w/JOE</li> <li><input checked="" type="checkbox"/> Install Kit, Taqman Gold</li> <li><input checked="" type="checkbox"/> PP2</li> <li><input type="checkbox"/> Pure Dye</li> <li><input type="checkbox"/> Raw Spectra.text.w0</li> <li><input type="checkbox"/> Raw Spectra.text.w1</li> </ul> </div> <div style="flex: 1; text-align: right;"> Eject  Desktop  New <input type="checkbox"/>  Cancel  Export </div> </div> </div> <div style="margin-top: 10px;"> Export raw spectra data as:  <div style="border: 1px solid black; padding: 2px; display: inline-block;">Raw Spectra.text</div> </div> <div style="margin-top: 10px;"> <input checked="" type="radio"/> Export All Wells  <input type="radio"/> Export Selected Wells  <input checked="" type="checkbox"/> Export Dark Reading (Well 0) </div> </div> <div style="margin-left: 20px;"> <p>(AmpliTaQ Gold™)</p> <p>Selected by default</p> <p>Click to export raw spectra data for a selected group of wells.</p> <p>This is the signal from the detection system with no light input.</p> </div>
3	<p>Indicate where the data file should be stored and type the file name in the entry field.</p>
4	<p>Export All Wells is available as a default, allowing you to export the data from all 96 wells. Select Export Selected Wells if you want to export data only from wells you selected in step 1.</p>
5	<p>Click Export to complete data export.</p>

*continued on next page*

<b>File</b>	
New plate	⌘N
Open plate...	⌘O
Close	⌘W
Save	⌘S
Save As...	
Export...	▶
Import...	▶
	Import Lab View Format File... ⌘I
	Import Setup File... ⌘B
Page Setup...	
Print...	⌘P
Quit	⌘Q

The ABI PRISM 7700 system can import a Setup file. A Setup file allows you to electronically transfer position, sample type, and sample name from a tab-delimited text file into your plate document. The major benefit of this feature is the ability to transfer existing sample names into a new plate document without retyping, as shown in Figure C-15.

A1	BUFFER		Bob
A2	UNKN		Fred
A3	NTC	Sue	
4	NAC	Mary	
5	BUFFER	Joan	
6	UNKN	David	
7	NTC	110594	
A8	NAC	110489	
9	BUFFER	11049	
10	UNKN	12213	
11	NTC	55567	
A12	NAC	Oingo Boingo	
B1	BUFFER	Identity Crisis	
14	UNKN	68593	
15	NTC	4_1_a_998	
B4	NAC	Cesar	
B5	BUFFER	Tony	
B6	UNKN	Eighteen	
19	NTC	Shana	
20	NAC	Hillary	
21	BUFFER	Ada	
22	UNKN	Jerry	
23	NTC	Alfred	
B12	NAC	Paul	
25	BUFFER	Daniel	
26	UNKN	Ringo	
27	NTC	George	
28	NAC	John	
29	BUFFER	Hamlet	
30	UNKN	Charles	


BUFFER Bob	UNKN Fred	NTC Sue	NAC Mary	BUFFER Joan	UNKN David	NTC 110594	NAC 110489	BUFFER 11049	UNKN 12213	NTC 55567	NAC Oingo Boi...
BUFFER Identity ...	UNKN 68593	NTC 4_1_a_9...	NAC Cesar	BUFFER Tony	UNKN Eighteen	NTC Shana	NAC Hillary	BUFFER Ada	UNKN Jerry	NTC Alfred	NAC Paul
BUFFER Daniel	UNKN Ringo	NTC George	NAC John	BUFFER Hamlet	UNKN Charles						

## C-20 Sequence Detection Software Reference

The tab-delimited text file (which can be created in programs such as Word and Excel) must contain the following information:

- ◆ Position —this can be entered as a number (1-96) or the well position (A1-H12).
- ◆ Sample Type —you must enter the exact acronym as shown in the Sample Type setup of the plate you are importing into. (You can always label all your samples as UNKN and then modify the Sample Type later.)
- ◆ Sample Name — any alphanumeric name up to 255 characters.

**Note** Columns 1 (Position) and Column 2 (Sample Type Acronym) are required and Columns 3 and 4 (Sample Name and Quantity or amount) are optional.



**Figure C-16.** Choosing a file to import

To import a Setup file, follow this procedure:

Step	Action
1	From the File menu, choose New Plate.
2	From the File menu, choose the Import Setup file command.
3	In the dialog box that appears, choose the file to import.

# Edit Menu

**General** Use the commands in the Edit menu to modify text and graphical elements in the plate document. You cannot use commands in the Edit menu to modify data. Use the Preferences in the Edit menu to define default parameters, such as the quencher and passive reference dyes.

Edit	
Undo	⌘Z
Cut	⌘H
Copy	⌘C
Paste	⌘V
Clear	
Select All	⌘A
Preferences...	

Some commands in the Edit menu use the Clipboard on your Macintosh computer. For more information on the Clipboard, see the Macintosh Guide, an on-line help file distributed with all Macintosh computers.

**Undo/Cut/Copy/  
Paste/Clear/  
Select All** These commands have the normal Macintosh functions. Only commands which differ in some way from those on a standard File menu are discussed.

**Preferences** The features you choose in Preferences are applied by default to every new plate you open.




Figure C-17. Preferences dialog box

**IMPORTANT** After you make changes to the Preferences, you must close the plate document that is currently open and re-open it to apply the new Preferences.

## New Document Defaults.


Offers the same options displayed in the New Plate dialog box. These options are applied to the plate document that automatically opens when you open the Sequence Detection application. The choices available in the dialog box are described below:

Item	Description
Plate “types”	With the next parameter, Instrument, set to “7700 Sequence Detector,” the choices are Single Reporter, Allelic Discrimination, Background, or Pure Spectra. For descriptions of Plate Types, see “New Plate” on page C-16. The Background and Pure Spectra plates are used to generate these types of data when setting the instrument up or when re-generating these types of data files (see “Background Calibration” on page 3-7 and “Pure Dye Spectra Calibration” on page 3-9).
Instrument “types”	From the Instrument pop-up, choose “7700 Sequence Detector” as the sequence detection system you are using with the Sequence Detection application, enabling either real-time or plate read Run types:

Item	Description <i>(continued)</i>
Data Acquisition	The Run pop-up menu displays two options for the 7700 system: Real Time or Plate Read. Use Real Time to monitor and collect fluorescent signal data at every cycle. Use Plate Read to collect end-point data after PCR is complete.

### Document Settings

Five choices are available: the “Online Document” checkbox, Default PCR Volume, User Name, Unit of Measure, and the “Show Threshold” check to automatically establish a connection between the Sequence Detection application and the Sequence Detector. These parameters are used as described in the table below:

Item	How to Use				
“Online Document” checkbox	<table border="1"> <thead> <tr> <th>Step</th><th>Action</th></tr> </thead> <tbody> <tr> <td>1</td><td>Click the “Online Document” checkbox to automatically</td></tr> </tbody> </table> <p><b>IMPORTANT</b> The “Online Document” checkbox must be selected to run the Sequence Detector and collect data.</p> <p><b>Note</b> All wells on one plate should contain the same volume of sample. Performance specifications on the ABI PRISM 7700 system are based on 50 <math>\mu</math>L of sample in each well.</p> <p>When the checkbox is not selected, you can use the Sequence Detection application for data analysis or to design plate documents.</p>	Step	Action	1	Click the “Online Document” checkbox to automatically
Step	Action				
1	Click the “Online Document” checkbox to automatically				
Default PCR Volume	<p>Enter the default volume of every well on the 96-well plate.</p> <p>The volume refers to the entire contents of any well, including the buffer blank, or any combination of Master Mix and template. The ABI PRISM® 7700 Sequence Detector can support a sample volume range of 10–100 <math>\mu</math>L.</p>				
User Name	<p>Type in the name you want to appear on the Experiment Report.</p> <p>You cannot edit any text on the Experiment Report.</p>				
Unit of Measure.	<p>Choose a default unit to describe the quantity of nucleic acid in solution. This unit is applied to all wells on the plate document.</p> <p>The choices available are shown in a pop-up menu like that shown to the left.</p> 				
Show Threshold . . .	<p>Click the checkbox to enable presentation of the Amplification Plot after analyzing a Single Reporter Real Time run. See "Amplification Plot" on page C-52.</p>				

# Setup Menu

## General


Setup
Thermal Cycler Conditions... %T
Sample Type Palette

Use the commands in the Setup menu with the Setup view of the plate document to define your samples and assign sample types to wells.

## Setting Up Thermal Cycler Conditions

### Two Views


The Thermal Cycler Conditions dialog box contains two views (Figure C-18, one view for defining the method, the second view for defining data collection points.



**Figure C-18.** Thermal Cycler Conditions contains two views

A method (defined by the upper Thermal Cycler Conditions view) contains all the information about time and temperature changes that occur during a complete thermal

cycle run. The Time and Temperature view (shown immediately above) displays a graphic representation of a method (see Figure C-19).



**Figure C-19.** A graphic representation of a method

### Stages.

A Stage is one division of a method; a Stage can be either a Hold or a Cycle. The method shown in Figure C-19 consists of three Stages: two Holds, followed by a Cycle. Vertical lines mark where one Stage ends and the next Stage begins.

During PCR on the ABI PRISM 7700 Sequence Detector, the Analysis view of the plate document tracks the progress of the reaction and displays the number of the Stage that is currently running (page C-12).

### Holds, Cycles, and Steps.

A Step is a temperature plateau preceded by a ramp. In Figure C-19, a ramp is represented by a slanting line that connects two temperature plateaus. By default, each ramp represents the shortest amount of time needed to go from one temperature plateau to the next.

A Hold contains one or more Steps that are performed only once. During the Hold in Stage1 in Figure C-19, UNG digestion of amplified DNA occurs at 50 °C, followed by a Hold in Stage 2, a denaturation of nuclear material at 95 °C. The final Hold, in Stage 4, is a cooling step for storing samples.

A Cycle contains two or more Steps that are repeated numerous times within a method. The Cycle shown in Stage 3 in Figure C-19 is repeated 40 times. A typical two-temperature cycle for PCR with TaqMan probes consists of a denaturation, or melting, step at 95 °C for 15 sec, followed by an anneal-extension step at 60 °C for 1 minute.

---

*continued on next page*

**Editing a Method.** There are several ways to edit the features in a method. You can:

- ◆ Add or remove Steps, Cycles, or Holds
- ◆ Change the temperature or time associated with any Step
- ◆ Adjust the ramp time between two Steps
- ◆ Define an Auto Increment for time and temperature

#### Adding to a Method with Insert Bars

To add a Step, Cycle or Hold, you must click a step to bring up an Insert bar. the Insert bar appears as a thick vertical line at either the end or the beginning of a selected Step. A selected Step appears as a colored line.

**Note** You cannot add a Step, Cycle, or Hold after a step with a time greater than 89:59 minutes ( $\infty$ ).

To add a Step, Cycle, or Hold:


Step	Action
1	Click the Thermal Cycler Conditions button to display the current method.
2	<p>Click on a Step.</p> <div data-bbox="548 1213 652 1239" style="display: inline-block; vertical-align: middle;">Insert bar</div>  <p>An Insert bar appears either at the end or at the beginning of the selected Step. Click on one side or the other of the Insert bar to determine its relative position.</p>
3	<p>Do one of the following to add to a method:</p> <ul style="list-style-type: none"> <li>◆ Click the appropriate button to add a new Step, Cycle, or Hold.</li> <li>◆ Click the Add Step button to add a new Step.</li> <li>◆ Click the Add Cycle button to add a new Cycle.</li> <li>◆ Click the Add Hold button to add a new Hold.</li> </ul>

Table C-3 shows the default temperatures and times assigned to new Steps, Cycles, and Holds.



**Table C-3** Default Configuration of New Steps, Cycles, and Holds

	Step	Cycle		Hold
Temperature (°C)	54.0	95.0	60.0	50.0
Time (min:sec)	01:00	00:15	01:00	01:00

Where the new Step, Cycle or Hold appears depends on whether the Insert bar appears to the right or left of the selected step, as Table C-4 illustrates. A Step inserted in a Hold or Cycle becomes part of that Hold or Cycle.


**Table C-4** Placement of New Steps, Cycles and Holds

Location of Insert Bar	Step	Hold	Cycle
Left of Hold	Beginning of Hold	Beginning of Hold	Beginning of Hold
Right of Hold	End of Hold	End of Hold	End of Hold
Left of Cycle	Beginning of Cycle	Beginning of Cycle	Beginning of Cycle
Middle of Cycle	Middle of Cycle	End of Cycle	End of Cycle
Right of Cycle	End of Cycle	End of Cycle	End of Cycle

**Note** You cannot insert a Hold or Cycle in the middle of a Cycle.

### Deleting Items Positioned by Insert Bars

To delete a Step, Cycle or Hold:

Step	Action
1	 <p>Click the Thermal Cycler Conditions button in the Setup view to display the current method.</p>

To delete a Step, Cycle or Hold: *(continued)*


Step	Action
2	Click on the Step you want to delete. If you want to delete a series of Steps, click on the last Step on the right in the series of Steps.  An Insert bar appears at the end of the temperature plateau.
3	Drag the cursor from the Insert bar to the left across the Step, Cycle, or Hold to select the Steps to be deleted.
4	Drag the cursor from the Insert bar to the left across the Step, Cycle, or Hold to select the Steps to be deleted.
5	In the Edit menu, choose the Clear command.

### Changing Temperature and Time

The temperature range of the sample block is 4.0–99.9 °C. The Sequence Detection application does not permit a temperature greater than 99.9 °C or less than 4 °C in any Temperature field.

The Sequence Detection application collects a full 96-well plate of fluorescence data approximately once every 7 seconds. The application's algorithm averages the last three data points collected during the extension step and uses that average to represent extension step fluorescence. For best results, the extension step should be at least 30 seconds to allow collection of sufficient data.

**Note** Do not enter a value less than 30 seconds (00:30) for the extension step, the second Cycle step in a two-step PCR.



**Figure C-20.** Changing temperature or time

**IMPORTANT** The Thermal Cycler Conditions window will accept a 4° C hold at the end of thermal cycling. At this time, however, since all real-time data has already been collected at that point and because 4° C holds can cause excessive water condensation in the sample tray area, 4° C holds are usually not needed.

To change the temperature or time associated with a Step:


Step	Action
1	Click in the time or temperature field you wish to change and drag the cursor across the numbers to select them.


Step	Action
2	<p>Enter a new value.</p> <p>A period (.) automatically appears after you enter the first two digits in the Temperature field. A colon (:) automatically appears after you enter the first two digits in the Time field.</p> <ul style="list-style-type: none"> <li>◆ To enter 9 minutes in any Time field, type 09:00.</li> <li>◆ To enter a value less than a minute in any time field which already is set to 1 minute or more, do the following: <ul style="list-style-type: none"> <li>a) Select the portion of the field after the colon and type in the new value in seconds (5 seconds is the minimum value allowed),</li> <li>b) then select the two digits before the colon and type "00".</li> </ul> </li> <li>◆ To enter a ∞ (forever) time for the last hold, do the following: <ul style="list-style-type: none"> <li>a) Select the time field and type 89:59,</li> <li>b) select the initial 8 and then type 9,</li> <li>c) then click OK to put an ∞ symbol in the time field.</li> </ul> </li> </ul> <p><b>Note</b> The procedure immediately above is required because you cannot directly enter a value greater than 89:59 in a Time field. After you type the first 9 in the time field, no further entry is allowed unless you proceed as listed above.</p>
3	Press the Tab key to move the cursor to the next field.

### Adjusting Ramp Time

The ramp time between two Steps in the Thermal Cycler Conditions is the time needed to go from one temperature to the next. When the ramp time is set to the minimum ramp time of zero, the rate of temperature change on the thermal cycler is approximately 1 °C/second. For example, the shortest possible time necessary to ramp from 50 °C to 95 °C is approximately 45 seconds. The maximum ramp time is 9 minutes and 59 seconds.

To adjust the ramp time between two Steps:

Step	Action
1	Click the Thermal Cycler Conditions button to display the current method.
2	<p>Click on the Step that contains the ramp time you want to modify. By definition, the ramp precedes the temperature plateau in a Step.</p> <p>An Insert bar appears at the end of the Step.</p>
3	<p>Click the Set Ramp Time button.</p> <div style="text-align: center;">  </div> <p>The Ramp Time dialog box appears.</p>
4	<p>Click the up or down arrows to adjust the ramp time.</p> <p>The adjusted ramp time appears in the box between the pairs of arrows.</p>

Step	Action
5	<p>Click the OK button.</p>  <p>The modified ramp time appears on the ramp in the Thermal Cycler Conditions box.</p>

### Auto Incrementing and Decrementing


You can automatically increase or decrease the time or temperature associated with any Step by a fixed amount with each Cycle repetition. For example, you can increase the extension time of a Cycle to accommodate the increased amount of amplicons produced as PCR progresses.

The Auto Increment feature appears in the Thermal Cycler Conditions dialog box. With this feature you can:

- ◆ Increase or decrease any time or temperature in a Cycle
- ◆ Modify both time and temperature for one or more Steps in a Cycle

**IMPORTANT** The temperature range of the thermal cycler sample block is 4.0–99.9 °C. The Sequence Detection application does not accept an auto-increment value that would eventually cause the temperature of the sample block to exceed this range.

To Auto Increment Time or Temperature:

Step	Action
1	<p>Click on the time or temperature you want to increase or decrease.</p> <p>An Insert bar appears, the selected Step changes color, and the Auto Increment feature becomes active at the bottom of the Thermal Cycler Conditions dialog box.</p>  <ul style="list-style-type: none"> <li>◆ Enter a number in the entry field labeled “°C” to increment temperature.</li> <li>◆ Enter a number in the entry field labeled “Seconds” to increment time.</li> <li>◆ Enter a negative number to decrement time or temperature.</li> </ul>
2	<p>Click another entry field or press the Tab key.</p> <p>A small arrow, an increment indicator, appears next to the field you just modified.</p>
3	<p>Repeat steps 2 and 3 for each Auto Increment or decrement.</p>

### Data Collection

A Sequence Detection plate document can contain data collected for each dye spectra used in the experiment, for each well on a 96-well plate, and for each cycle. If you choose, the application can collect data for each temperature plateau and ramp in a method. The Sequence Detection application uses only the data from the extension (or anneal-extension) step to perform analysis.

**Note** For accurate real-time data analysis, the Sequence Detection application must collect data during the extension step of PCR.


In the Data Collection view in the Thermal Cycler Conditions dialog box, a Data Collection icon appears on a plateau or ramp to indicate where data collection occurs during PCR.

- ◆ If the Data Collection icon is on a plateau or ramp associated with a Hold, 96 wells of spectra data—once every 7 seconds of the Hold—will be collected at that site for the duration of the Hold.

**IMPORTANT** Do not collect data on an ∞ (forever) read.

- ◆ If the Data Collection icon is on a plateau or ramp associated with a Cycle, then multiple sets of data spectra, one set for each cycle repetition, will be collected at that site.

The more data collection points there are in a method, the larger the corresponding data file for that run.



**Figure C-21.** Data Collection Icon

To add or remove a Data Collection icon:

- ◆ Click once on a plateau in the Data Collection view to add an icon.
- ◆ Click once on a Data Collection icon to remove the icon.

You may remove all Data Collection icons in the Data Collection view if you want to use the ABI PRISM 7700 Sequence Detector for only thermal cycling. The Sequence Detection application does not collect fluorescent data during PCR when the Data Collection view shows no Data Collection icons.

**Note** When the Data Collection view contains no icons, the Sequence Detection application does not collect data during a run. Also, data is not collected on ramps.


See "Instrument Menu" on page C-40 for more information on how collected data is analyzed.

---

*continued on next page*

**Sample Type Palette** The Sample Type Palette (shown on the left below) is a floating window that displays all the Sample Types you can assign to the wells on the plate document. You can move a floating window around on the monitor screen. To use the Sample Type Palette to assign samples to wells, see page 3-17.

Every Sample Type that appears in the Sample Type Setup also appears in the Sample Type Palette. If you want more sample types on the Sample Type Palette, you must edit the Sample Type Setup.



**Figure C-22.** Sample Type Palette

**Note** The Sample Type Palette allows you to set up and view multiple dye layers for the selected wells.


To edit the list of samples on the Sample Type Palette:

- ◆ Click the Edit Sample List button.

The Sample Type Setup dialog box opens. Modify the list of samples in the Sample Type Setup dialog box to change the list of samples in the Sample Type Palette. See page C-38.

### Sample Type Setup Dialog Box

The Sample Type Setup dialog box displays each item in the Sample List with its associated Acronym, Name, Color and Reporter. In this dialog box, you can add or remove samples or edit the sample's attributes.



**Figure C-23.** Sample Type Setup dialog box

*continued on next page*

## Editing Sample Attributes

### Acronym and Name

The sample's Acronym appears in several locations in the Sequence Detection application program: on the Sample Type Palette, across the top of the wells on the plate document, and in the Type column on the Experiment Report. It can hold a maximum of 6 characters.

To successfully import a setup file, the setup file must use an identical acronym to those present in the Sample type setup of the target plate document.


The sample's Name can be more descriptive than its Acronym and contains up to 64 characters.

To change the sample Acronym or Name, follow this procedure:

Step	Action
1	Select the Name or Acronym and type the change in the entry field.
2	Click OK to close the Sample Type Setup dialog box

### Color

The sample's Color appears on the plate document, applied to the wells that contain the sample. To change the sample Color, follow this procedure:

Step	Action
1	<p>Double-click the sample's color in the Sample Type Setup dialog box.</p> <p>A dialog box displays a color wheel.</p> 
2	Choose a new color for the sample and click OK.
3	Click OK to close the Sample Type Setup dialog box.

### Reporter and Quencher

The reporter dye attached to the fluorogenic probe that specifically anneals with the sample. A sample's Reporter is changed as described in the procedure on the next page.


**Note** All dye pop-up menus display only the dyes that are active. See page C-42 for a discussion of active dyes.

Designate the one Quencher dye attached to all fluorogenic probes on one plate. TAMRA is the default Quencher dye.



**Note** For proper analysis of a Single Reporter Plate type, you must use UNKN and NTC sample types. For proper analysis of a Allelic Discrimination Plate type, you must use AL1, AL2, and NTC sample types. If these acronyms are not present, analysis will not work properly.

To change the associated Reporter or Quencher dye, follow this procedure:

Step	Action
1	 <p>Choose the appropriate dye for the Reporter or Quencher from the pop-up menu.</p>
2	Click OK to close the Sample Type Setup dialog box.

**Note** If you change the reporter dye for NPC from FAM to JOE, NPC will no longer be present on the FAM layer in the Sample Type pop-up menu but will now be present in the Sample Type pop-up menu on the JOE layer.

### Reference

The passive reference dye that is added to all samples on the plate to normalize reporter signal. ROX is always used as the Reference dye.

**Note** You cannot edit the Acronyms or Names of the first two entries in the sample list, STND or UNKN.

You cannot directly modify the lists in the Sample Type Palette or in the Sample Type pop-up menu. You must modify them indirectly, by making changes in the Sample Type Setup dialog box.


*continued on next page*

**The Sample List** The list of Sample Types in the Sample Type Setup is a master list of all samples you might incorporate in your experiment. The entries in the Sample Type Setup also appear in the Sample Type Palette (page C-33) and in the Sample Type pop-up menu (page C-8).

**Note** The sample types that appear in the Sample Type pop-up vary according to the dye layer displayed on the plate document.

You cannot directly modify the lists in the Sample Type Palette or in the Sample Type pop-up menu.

You cannot directly modify the lists in the Sample Type Palette or in the Sample Type pop-up menu. They must be modified in one of the two ways shown in Figure C-24:



**Figure C-24.** Modifying Sample Type Palette lists

**Note** The Sample Type Palette, Sample Type pop-up, and Sample Type Setup windows are different for each type of plate. This is discussed in the next subsection, “Sample Types/Plate Types.”

The Sample Type pop-up menu contains the complete sample list displayed in the Sample Type Setup dialog box. The samples shown in the Sample Type pop-up menu vary according to the dye layer currently visible on the plate document.

For example, when FAM is the visible dye layer on the plate document, the Sample Type pop-up menu only displays those sample types that use the FAM Reporter in the Sample Type Setup dialog box.

*continued on next page*

**Sample Types/Plate Types.**

The sample types available and required for each plate type are listed in Table C-5.

**Table C-5** Sample Types for Each Plate Type

Plate Types	Default Sample Types	Minimum Setup Required for Analysis
Pure Dye Spectra	<div> FAM - Pure Dye  HEX - Pure Dye  TAMRA - Pure Dye  TET - Pure Dye  JOE - Pure Dye  ROX - Pure Dye  UNKN DYE - New Dye  Sample Type Setup...  • Not In Use </div>	<ul style="list-style-type: none"> <li>At least one tube of FAM</li> <li>At least one tube of TET</li> <li>At least one tube of TAMRA</li> <li>At least one tube of ROX</li> </ul> <p>We suggest using four tubes for each dye.</p>
Single Reporter	<div> UNKN - Unknown  NTC - No Template Control  NAC - No Amplification Control  NPC - No Probe Control  BUFFER - Buffer Blank  Sample Type Setup...  • Not In Use </div>	<ul style="list-style-type: none"> <li>At least eight tubes of NTC</li> </ul> <p>All the rest of your samples can be designated as UNKNs.</p>
Single Reporter with IPC	The default sample types are the same as shown above. You must add an IPC+ and IPC- sample type (or use the Stationery file provided).	<p>On the target layer:</p> <ul style="list-style-type: none"> <li>At least eight tubes of NTC</li> </ul> <p>All the rest of your samples can be designated as UNKNs.</p> <p>On the IPC layer:</p> <ul style="list-style-type: none"> <li>At least eight tubes of IPC-</li> </ul> <p>All the rest of your samples can be designated as IPC+</p>
Allelic Discrimination	<div> AL1 - Allele 1  AL2 - Allele 2  NTC - No Template Control  NAC - No Amplification Control  UNKN - Unknown  BUFFER - Buffer Blank  Sample Type Setup... </div>	<ul style="list-style-type: none"> <li>Eight tubes of AL1</li> <li>Eight tubes of AL2</li> <li>Eight tubes of NTCs</li> </ul> <p>All of the rest of your samples can be designated as UNKN.</p>

The Sample List can hold over 50 entries. You can customize the list so that the entries match the samples you use in your experiment. You cannot remove STND or UNKN, the first two entries on the Sample List.

*continued on next page*


## Adding Sample List Information

The following procedures are provided:

- ◆ A procedure for adding a sample to the Sample Type Setup
- ◆ A procedure for removing a sample from the Sample Type Setup
- ◆ Guidelines for IPC/starting with the appropriate Stationery file for your assay (the next subsection)

### Adding a Sample

To add a sample to the Sample Type Setup, follow this procedure:

Step	Action
1	<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>Add new sample attributes here</p> <p>Add button</p> </div>  </div> <p>Click the Add button on the Sample Type Setup dialog box.</p> <p>An empty row of entry fields appears at the bottom of the sample list. Note that the default color for the new sample is black.</p>
2	Enter an Acronym and Name for each new entry. See page C-33 for more information.
3	Double-click the Color field to change the sample color. See z for more information.
4	Select the appropriate Reporter dye in the Dye pop-up menu.
5	Click OK to close the Sample Type Setup dialog box.

### Removing a Sample

To remove a sample in the Sample List, follow this procedure:

Step	Action
1	Select the sample and click the Remove button.
2	Click OK to close the Sample Type Setup dialog box
	<b>Note</b> Do not remove the Sample types required for analysis.

*continued on next page*

---

**Guidelines for IPC**

If you are interested in including an IPC in your assay, start with a Stationery file for Single Reporter IPC. This plate already has the IPC+ and IPC– Sample Types designated and assigned to the suggested wells. The details of how to set up a plate for IPC are covered in Chapter 3, “Setup and Operation.” How to interpret IPC results is covered in Chapter 4, “Reviewing Data.”

In general, rather than setting up a plate starting with the “New Plate” command, it is preferable to start by opening the appropriate Stationery file for your assay and then modifying the plate as needed. Available Stationery files for the ABI PRISM 7700 system include the following:

- ◆ Pure Spectra
  - ◆ Allelic Discrimination
  - ◆ Single Reporter
  - ◆ Single Reporter IPC
-

## Instrument Menu

Instrument	
Run	⌘R
Stop	⌘K
Calibrate	▶
Diagnostics	▶

**General** The Instrument menu contains commands for starting and stopping the Sequence Detector, calibrating background and pure dye spectra, performing some diagnostic tests, and downloading firmware

**Run** Starts the Sequence Detector run defined in the Thermal Cycler Conditions dialog box.

When you choose the Run command, the field labeled Status, adjacent to the Run Button, flashes the word Success, followed by the word Waiting. See page C-11 for more on the Status field.


**Stop** Stops the Sequence Detector run.

When you choose the Stop command before a run is complete, a dialog box opens. Use this dialog to choose whether or not to save the data that has already been acquired during the run. See page C-11 for a description of this dialog.

### Calibrate General

The Calibrate command provides features for calibrating Pure Spectra and Background signal.

During instrument installation, an Applied Biosystems Service Representative uses these commands and the TaqMan Spectral Calibration Kit (P/N 401930) to calibrate the pure dye spectra. As a result of pure dye spectra calibration, the Sequence Detection application creates spectra component files. Both Background and Pure Spectra components are used by the Sequence Detection application during multicomponenting to determine the contribution of each fluorescent dye to the raw spectra.



Dye pop-up menu


The dye pop-up menu on the plate document displays the names of those pure spectra that are calibrated and active. See page C-42 for a discussion of active dyes.

### Extract Background Component

Creates a Background Component file. The Sequence Detection application refers to this file during multicomponenting, to determine the contribution of background signal in each of the 96 wells. See "Background Calibration" on page 3-7 for a description of Background calibration.

### View Background Component

Displays Background signal for one or more selected wells during Background calibration.



**Figure C-25.** Example of a Background component for one well, D5

This command is active only during Background calibration.

To see the background component in any well after data analysis, use the Multicomponent view. See "Multicomponent" on page C-54 for a description of the Multicomponent view.


### Extract Spectra Component

Creates a spectral component file. When calibrating pure dye spectra, you must use this command once for each dye you are calibrating. See "Pure Dye Spectra Calibration" on page 3-9 for a description of Pure Dye Spectra Calibration.

### Edit Pure Spectra

Displays pure dye spectra components available for multicomponenting. The graph represents the normalized fluorescence of each component vs. wavelength.

Use the Pure Spectra Editor to review the pure spectra and discard spectra components. When a spectra component is discarded, it is no longer available for use by the Sequence Detection application. If you need to replace a discarded spectra component, you must follow the Pure Dye Spectra Calibration procedure on page 3-9.



**Figure C-26.** Pure Spectra Editor

**IMPORTANT** When you use the Pure Spectra Editor to discard a spectra component, you cannot reverse the discard. You must create a new spectra component by performing a Pure Dye Spectra Calibration.

To use the pure spectra editor to discard pure spectra components:

Step	Action
1	Choose Calibrate in the Instrument menu, then choose Edit Pure Spectra.
2	Review the graphic representation of spectra components.
3	In the Pure Spectra List, select the dye you wish to discard.
4	Click the right arrow (=>) to move the selected dye to the Discard List. Click the left arrow (<=) to move a selected dye from the Discard List back into the Pure Spectra List.
5	Click OK to complete the discard and close the dialog box. The discarded dye is no longer available for multicomponenting.


### Setup Pure Spectra

Distinguishes active pure spectra from all available spectra. All available pure spectra appear in the Pure Spectra Editor (page C-41). Only active pure spectra appear in the dye pop-up menus on the plate document and in the Sample Type Setup dialog box. The dye pop-up menus can display up to eight dyes.

If you have created more than eight dye components, you can designate which pure spectra are active and appear in the dye pop-up menu.



To designate active spectra for dye pop-up menus:

Step	Action
1	<div>Choose Calibrate in the Instrument menu and choose Setup Pure Spectra.</div> <div></div> <div>Active pure spectra appear in the Setup Pure Spectra dialog box preceded by a checked checkbox.</div>
2	Click the Show All button to see a list of all available pure spectra.
3	<div>Click the checkbox associated with a pure spectra to make it active.</div> <div>Only eight pure spectra can be active at one time.</div>


**Diagnostics    Advanced Options**

Use the Advanced Options dialog box to:



- ◆ Add display features to the Raw Spectra and Multicomponent views
- ◆ Select the background and pure spectra components
- ◆ Set exposure time

The options you choose in Advanced Options remain active until you turn them off.



**Figure C-27.** Advanced Options dialog box

The checkbox options available from this dialog box are listed and described in the following table.

Item	How to Use/Description														
Display mse (MSE) and best fit checkboxes	<p>To view MSE and best Fit:</p> <table border="1"> <thead> <tr> <th>Step</th><th>Action</th></tr> </thead> <tbody> <tr> <td>1</td><td>Choose Diagnostics in the Instrument menu, then choose Advanced Options.</td></tr> <tr> <td>2</td><td>In the section titled Viewer, click the appropriate checkboxes to select MSE or Fit.</td></tr> <tr> <td>3</td><td>Click OK to close the dialog box. When only one well is selected, the MSE appears in the Multicomponent view and the Fit appears in the Raw Spectra view.</td></tr> </tbody> </table> <p>The MSE (mean squared error) in the Multicomponent view is a factor tied to the multicomponenting algorithm (see page C-54). When the appropriate pure dye spectra and background components are associated with the plate document, the MSE is less than 200 and remains flat as PCR progresses.</p> <p>The best Fit for the Raw Spectra view is a representation of the appropriate pure spectra components for the selected well. When the appropriate pure dye spectra components are associated with the sample in the well, the Fit closely resembles the Raw Spectra curve.</p>	Step	Action	1	Choose Diagnostics in the Instrument menu, then choose Advanced Options.	2	In the section titled Viewer, click the appropriate checkboxes to select MSE or Fit.	3	Click OK to close the dialog box. When only one well is selected, the MSE appears in the Multicomponent view and the Fit appears in the Raw Spectra view.						
Step	Action														
1	Choose Diagnostics in the Instrument menu, then choose Advanced Options.														
2	In the section titled Viewer, click the appropriate checkboxes to select MSE or Fit.														
3	Click OK to close the dialog box. When only one well is selected, the MSE appears in the Multicomponent view and the Fit appears in the Raw Spectra view.														
Use background and pure spectra Components checkboxes (optionally Reanalyze data)	<p>When the Sequence Detection application saves a plate document that contains collected fluorescence data, it also saves the Background and Pure Spectra components used during data analysis. Whenever you re-open that plate and re-analyze the data, the Sequence Detection application automatically re-uses the original, saved Background and Pure Spectra components.</p> <p>You may recalibrate the Pure Spectra and Background components and then re-analyze data on a saved plate document, using the new components, as described below:</p> <p>To re-analyze data with new spectra components:</p> <table border="1"> <thead> <tr> <th>Step</th><th>Action</th></tr> </thead> <tbody> <tr> <td>1</td><td>Open the plate document you wish to re-analyze.</td></tr> <tr> <td>2</td><td>Choose Diagnostics in the Instrument menu, then choose Advanced Options.</td></tr> <tr> <td>3</td><td>Click the appropriate checkboxes to select the Pure Spectra or Background components currently installed on the computer.</td></tr> <tr> <td>4</td><td>Click OK to close the dialog box.</td></tr> <tr> <td>5</td><td>Choose Analyze in the Analysis menu to re-analyze the data.</td></tr> <tr> <td>6</td><td>To save the re-analyzed data with a new plate document name, choose the Save As command.</td></tr> </tbody> </table>	Step	Action	1	Open the plate document you wish to re-analyze.	2	Choose Diagnostics in the Instrument menu, then choose Advanced Options.	3	Click the appropriate checkboxes to select the Pure Spectra or Background components currently installed on the computer.	4	Click OK to close the dialog box.	5	Choose Analyze in the Analysis menu to re-analyze the data.	6	To save the re-analyzed data with a new plate document name, choose the Save As command.
Step	Action														
1	Open the plate document you wish to re-analyze.														
2	Choose Diagnostics in the Instrument menu, then choose Advanced Options.														
3	Click the appropriate checkboxes to select the Pure Spectra or Background components currently installed on the computer.														
4	Click OK to close the dialog box.														
5	Choose Analyze in the Analysis menu to re-analyze the data.														
6	To save the re-analyzed data with a new plate document name, choose the Save As command.														

Item	How to Use/Description
Set 7700 Exposure Time	<p>By default, the laser beam is directed into each well on the 96-well plate for 25 milliseconds to excite the fluorescent dyes. You may increase this exposure time to increase the ratio of fluorescent signal to noise. The acceptable range of exposure time is 5—255 milliseconds.</p> <p>The fiber optic cables transport both the laser beam into the wells to excite the dyes and the resulting emission out of the wells toward the CCD camera. When you increase the exposure time, you also increase the amount of time between emission collections. Therefore, when you increase the exposure time, fewer data points are collected in a given extension time. To increase the number of data collected during extension, you must increase the extension time.</p> <p><b>IMPORTANT</b> Increasing exposure time above 25 milliseconds may result in a signal that exceeds the measuring capabilities of the optical system.</p>
Use Spectral Compensation for Real Time/Endpoint	The two remaining options, respectively, enable spectral compensation for Real Time data or for Endpoint data (Plate Read type runs).

**Spectral Compensation.** The two remaining options, respectively, enable spectral compensation for Real Time data or for Endpoint data (Plate Read type runs).

**Functions Test** The Functions Test dialog box, shown in Figure C-28, is one of two SDS Application displays which can be used by customers to verify instrument operation or troubleshoot simple problems.

**Figure C-28.** Functions Tests Dialog Box

The various functional areas of the dialog box are described in the first table on the next page. The second table provides a procedure for scanning a fluorescent sample.

## Description of Dialog Box

This dialog box (opened by choosing the Functions Test command from the Instrument/Diagnostics submenu) enables manual control of the following instrument hardware. The various portions of the dialog box function as described in the table below:

Laser Power	This portion of the dialog box is used to turn on the instrument laser and set the laser power level.
	The laser is turned on by clicking the "Run" radio button and idled by clicking the "Idle" radio button. The laser power output is set by entering a value in the "Measured" field. The current status of the laser is displayed at the bottom of the window area.
Multiplexer	This portion of the dialog box is used to move the multiplexer to designated positions or return it to the Home position.
	The multiplexer is moved in either of two ways to the desired position. Either enter the value of the desired position in the entry field and then click the "Move To" radio button or, click the up or down arrow until the desired position is shown in the "Position" indicator. The multiplexer is moved to the "Home" position by clicking the "Home" button.
Shutter	This portion of the dialog box is used to open and close the instrument shutter (showing the current condition of the shutter).
CCD Camera	This portion of the dialog box is used to change to manual CCD (Charge Coupled Device) polling and initiate polling of the CCD.
	Turn to the manual shutter control mode by clicking the "Manual" radio button. Return to the Automatic mode by clicking this radio button. The "Poll CCD" button is used to initiate a CCD Read.
CCD Read area	When polling is initiated, the resulting signal is displayed in this area of the window.
Save CCD . . .	<p>this portion of the window enables saving of CCD Reads to Disk by clicking the "File" button and selecting the desired file in the dialog box which appears. The "Comment" field enables saving a comment with a read. The "Set Integration Time" button makes this setting for a CCD read.</p> <p>The Functions Test dialog box can be used to check signal throughput of the system by scanning a fluorescent sample such as a TaqMan PCR tray or a fluorescent test tray.</p>

To scan a fluorescent sample, proceed as follows:

Step	Action
1	Load a fluorescent sample into a plate position.
2	Click the Run button (Laser power), enter 10 mW in the "Measured" entry field and set this value for laser power by clicking the Set button.
3	Open the shutter by clicking the Shutter button.
4	Move the Multiplexer to the position containing the fluorescent sample either by entering a position number and then clicking the "Move To" button or by repeatedly clicking the up or down arrow.
5	Click the Manual radio button and then click Poll CCD to produce a fluorescent signal for the selected sample well.
	<b>Note</b> You may store the CCD read in a designated file if you desire.


The above test can answer the following questions in troubleshooting the instrument:

- ◆ Is laser light getting to the sample?
- ◆ Do the shutters open?
- ◆ Is the Multiplexer stopping at the correct position?
- ◆ Is the CCD operating properly?

**IMPORTANT** Results obtained from this test menu are dependent upon the quality and reproducibility of the fluorescent test tray and sample used during testing.

## Instrument Verification

The dialog box shown in Figure C-29 is opened using the Instrument Verification command. This window initiates testing of the instrument's electronics, and checks the version of software and firmware being used with the system.




**Figure C-29.** SDS Instrument Verification Dialog Box.

To confirm a problem with your instrument, report the results shown in this window to your Applied Biosystems Service representative.

# Analysis Menu

**Purpose of Menu** Use the commands in the Analysis Menu to display and analyze collected data.



**Figure C-30.** Analysis Menus for the Two Analytical Plate Types

The Analysis menu provides different choices for the two types of analysis plates.

**Note** The above Analysis menus are those presented after Analysis. Before Analysis, the only choice besides “Analyze” is “Raw Spectra.”

**Display** Offers a choice of three data display options:

- ◆ Sample Type
- ◆ Quantity
- ◆  $\Delta R_n$

**Note** Quantity and  $\Delta R_n$  data options are active only after data has been analyzed).


The display options change the text that appears in the 96 wells in the Analysis view of the plate document and are described in the table below:

Item	Description
Sample Type	Displays the sample type assigned on the Setup view.
Quantity	After data has been analyzed, choose Quantity to see the calculated starting quantity appear in each well. Quantity is expressed in scientific notation. (See page C-7 for a discussion of scientific notation.)
$\Delta R_n$ (Delta Normalized Reporter)	<p>Choose <math>\Delta R_n</math> to see the values for normalized reporter minus baseline appear in each well. Normalized reporter is the reporter signal divided by the passive reference signal. If your experiment uses more than one reporter dye, look at each corresponding dye layer on the plate document.</p> <p>If you choose None as the Reference dye, the Reporter signal is not normalized. The Y (vertical) axis on the Amplification Plot of <math>R_n</math> or <math>\Delta R_n</math> vs. Cycle (see page C-52) displays fluorescence emission values, not normalized signal, when you choose None as the Reference dye.</p>

*continued on next page*

---

**Options** This command is used to set Analysis Options. The default settings are as follows:




- ◆ All data analysis is done using the Post-PCR reading only. Deselect the “Analyze using Post Read Data Only” checkbox to subtract the Pre-PCR reading from the Post-PCR reading.
- ◆ The “Show threshold” checkbox applies only to the ABI PRISM 7700 system.
- ◆ The “Automatically compute” checkbox applies only to the ABI PRISM 7700 system.

---

**Statistics/Allele Settings** Both of these Analysis menu (Figure C-30 on page C-48) commands are available for Allelic Discrimination plates. Only the Statistics Settings command is available for a Single Reporter Plate read.

#### Statistics Settings

This command presents the following dialog box, allowing the confidence level to be set. The value shown is the default.



**Figure C-31.** Statistics Settings dialog box

## Allele Settings

This command presents the following dialog box, allowing the allele call designators to be reassigned. The designators shown are the defaults.




Figure C-32. Allele Settings dialog box

## Allelic Discrimination

The window brought up by this command is used to view Allelic Discrimination results.

This command presents a detailed look at the experimental results produced by the Allelic Discrimination assay. This viewer is only active for Allelic Discrimination plate types. After analysis, the command brings up a display like that shown below:




Figure C-33. Information displayed in the Allelic Discrimination View

## Graphical Views

The main features of the Allelic Discrimination viewer are:

- ◆ A graph of the data with three views at the top of the viewer
- ◆ A table of results in 11 columns in the middle of the viewer
- ◆ A table of Allele calls for each plate position at the bottom of the viewer



The graphics viewer has three controls:

- ◆ A graphical view selector to move between the three graphical views
- ◆ Buttons to select a graphics selection tool
- ◆ An Allele call selector to manually change the calls

Three graphical views are presented to display the results from the middle table. These views and the associated data are:

- ◆ Dye components - TET  $R_n$ , FAM  $R_n$
- ◆ Allele components -  $T1_m$ ,  $T2_m$
- ◆ Normalized -  $T1_n$ ,  $T2_n$

### Graphical Tools

The buttons at the top of the viewer allow you to perform a number of operations on the data.



When you click an individual data point(s), or lasso a group of points with a selector button, the corresponding field(s) in the bottom table are highlighted.



Individual data point selector




Group of data points selector

The following buttons allow you to move the graph and change the magnification:



The position button allows you to reposition the displayed data while preserving the magnification.



The zoom buttons are used to change the magnification of the entire graph.

There are two ways to zoom. You can choose your desired zoom button and click on the graph at the point to be centered. Or you can click and drag to create a frame for the area to be magnified.

---

*continued on next page*

**Amplification Plot** When the Show Threshold checkbox is enabled in Preferences, the following version of the Amplification plot is presented automatically after Analysis for Single Reporter plates enabling you to set the threshold value for all Reporter layers.




Figure C-34. Amplification Plot Window, Semilog View

Use of the command after analysis displays analyzed data for each selected well in three different formats:

- ◆ Threshold cycle ( $C_T$ ) vs. well number
- ◆  $R_n$  vs. cycle
- ◆  $\Delta R_n$  vs. cycle

**Note** To display the Y-axis of the Amplification Plot graph in the linear mode, as shown in Figure C-35, double-click on the Y-axis and use the dialog box to select the linear mode:







Figure C-35. Linear Mode Graph

To view the Amplification Plot:

Step	Action
1	In the Analysis view of the plate document, select one or more wells.
2	Choose View and Amplification Plot in the Analysis menu. Sample data can be presented in any of the forms shown on the next page using the Display pop-up.

To view the Amplification Plot: *(continued)*

Step	Action
	<div><p><math>R_n</math> vs. Cycle</p><p><math>\Delta R_n</math> vs. Cycle</p><p><math>C_T</math> vs. Well Number</p><p><b>Note</b> Threshold cycle calibration data in two lower figures has been truncated. Each of the lower figures has the same Threshold Cycle Calibration box as the first.</p><div><div>3</div><div>Use the Display pop-up on the Amplification Plot window to look at data in each of the three plot formats.</div></div><div><div>4</div><div>Use the Dye pop-up on the Amplification Plot window to look at data associated with different reporter dyes.</div></div></div>

**Note** To display the Y-axis in the logarithmic mode, double-click on the Y-axis and use the dialog box to select the mode.

$R_n$ , or normalized reporter, is calculated by dividing the reporter signal by the passive reference signal. During PCR,  $R_n$  increases as target nucleic acid is amplified until the reaction approaches a plateau.

$\Delta R_n$  represents the normalized reporter signal minus the baseline signal established in the first few cycles of PCR. Like  $R_n$ ,  $\Delta R_n$  increases during PCR as target is amplified, until the reaction approaches a plateau.

**Note** If you choose None as the Reference dye in the Sample Type Setup dialog box, the reporter signal is not normalized and the Y axis on the Amplification Plot represents fluorescence emission.

$C_T$ , or threshold cycle, represents the PCR cycle at which an increase in reporter fluorescence above a baseline signal can first be detected. A relationship exists between threshold cycle and template concentration such that the threshold cycle decreases by 1 cycle as concentration of template doubles. The Sequence Detection software generates a Standard Curve of  $C_T$  vs. Log [Starting Copy Number] for all standards and then determines the starting copy number of unknowns by interpolation.

**Well numbers** on the Amplification Plot correspond to a numbering scheme assigned to the plate document wells. Wells are numbered in rows, from left to right and from A to H. In this scheme, well A1=1, well A12=12, well B1=13, well B12=24, well C1=25, well C12=36, and so on, until well H1=85, and well H12=96 (Figure C-36).

	1	2	3	4	5	6	7	8	9	10	11	12
A	1	2	3	4	5	6	7	8	9	10	11	12
B	13	14	15	16	17	18	19	20	21	22	23	24
C	25	26	27	28	29	30	31	32	33	34	35	36
D	37	38	39	40	41	42	43	44	45	46	47	48
E	49	50	51	52	53	54	55	56	57	58	59	60
F	61	62	63	64	65	66	67	68	69	70	71	72
G	73	74	75	76	77	78	79	80	81	82	83	84
H	85	86	87	88	89	90	91	92	93	94	95	96

**Figure C-36.** Well numbers assigned in plate document

---


**Multicomponent** Displays the component dye signals that contribute to the composite signal for a selected well. This command is only available for Single Reporter Real Time runs.

During multicomponenting, an algorithm distinguishes the contribution of each individual dye spectra from the spectra data collected during PCR. The multicomponenting algorithm uses the pure spectra component files defined during Pure Dye Spectra calibration and applies a matrix calculation to determine the contribution of each dye. The algorithm also calculates the mean squared error (MSE) of the fit of each spectral component to the measured curve. See page C-18 for an explanation of the multicomponenting algorithm.

**Note** The Multicomponent view is only available after data has been analyzed.

To open the Multicomponent view of one well:

Step	Action
1	In the Analysis view of the plate document, select a well.
2	Choose View and Multicomponent in the Analysis menu.



The Y (vertical) axis of the Multicomponent View is divided into two sections. The top section of the Y axis represents emission intensity; the bottom section represents temperature. The X (horizontal) axis represents data Readings. By default, a data reading is collected approximately once every 7 seconds.

The area labeled "Component Series" displays each component in the Multicomponent View with its associated checkbox and color. If the TaqMan fluorogenic probe in an experiment is labeled with a reporter dye other than FAM, the FAM component still appears in the Multicomponent view. This is due to the presence of FAM in the passive reference.

## Raw Spectra


Displays reporter fluorescence signal that is not normalized for each cycle of PCR. When you click the best Fit checkbox in the Advanced Options dialog box, the Raw Spectra view also displays a line labelled Fit (page C-44). Fit represents the pure spectra component signal for the selected well and should closely resemble the Raw Spectra curve.

Typically, the fluorescence signals in the first two bins of pure spectra data are too small to be measured and are not included in the Fit calculation. As a result, the Fit line does not start at the Y axis.

To view the Pure Spectra and Fit for any well:

Step	Action
1	After data collection is complete, select a well in the Analysis view of the plate document.

To view the Pure Spectra and Fit for any well: *(continued)*

Step	Action
1	<p>After data collection is complete, select a well in the Analysis view of the plate document.</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <p>Curves for Raw Spectra and Fit</p> <p>Reading indicator</p> </div>  </div> <p><b>Note</b> The Raw Spectra view for an Allelic Discrimination plate will not have the lower portion displayed above, the Temperature graph vs. reading graph.</p>
2	<p>Choose View and Raw Spectra in the Analysis menu.</p> <p>The Raw Spectra view appears on the screen.</p>
3	<p>Drag the Reading indicator across the bottom of the view to see how the Raw Spectra curve changes over time. The time between each Reading is approximately 7 seconds.</p>

You can print the Raw Spectra view for any particular reading and print multiple views to show how the Raw Spectra changed over time.

To print a Raw Spectra view:


Step	Action
1	Move the Reading indicator to find the raw spectra view you wish to print.
2	Choose Page Setup in the File menu.
3	Select the Landscape orientation icon and click OK.

### Correlating the Fit to the Raw Spectra:

In any well, when the Fit curve does not closely resemble the raw spectra curve, there are two possible explanations:

- ◆ The Sample Type in the plate document well has been identified with the incorrect reporter in the Sample Type Setup dialog box.
- ◆ The components of the Pure Dye calibration do not match the signal produced by the dye component in the well.

To determine which of these two explanations applies to your raw spectra graph, first check the sample settings in the Sample Type Setup dialog, then examine other wells with the same combination of dyes and sample.




**Figure C-37.** Process for evaluating raw spectra

**Standard Curve** Displays a Standard Curve, based on the threshold cycle of each well that contained a Standard in the Setup view of the plate document. The Standard Curve displays a graph of threshold cycle ( $C_T$ ) vs. (LogN)Starting Copy Number, as well as the calculated slope, the Y-intercept, and the correlation coefficient of the standard curve. The threshold cycle, or  $C_T$ , occurs where the Sequence Detection software begins to detect an increase in signal associated with exponential growth of PCR product [see “Threshold Cycle (CT)” on page C-12].

To view the Standard Curve:

Step	Action
1	After data collection, choose the Analyze command in the Analysis menu, or use the keyboard shortcut $\text{⌘ L}$ .

To view the Standard Curve: *(continued)*

Step	Action
2	<p>Select any one well on the Analysis view of the plate document and choose the Standard Curve command. The Standard Curve appears on the screen).</p> 

While you cannot select which wells to view, you may change the standard curve by going back to the Setup view of the plate document and removing the Standard sample type from one or more wells and then re-analyzing data.

To re-calculate a Standard Curve:

Step	Action
1	In the Analysis view, select all wells that contain the Standard sample type.
2	Choose View and Amplification Plot in the Analysis menu.
3	Review the $R_n$ and $C_T$ of each well to determine which wells you want to exclude from the standard curve calculations.
4	Toggle the plate document view to the Setup view.
5	Select the wells you want to exclude from the standard curve calculation.
6	In the Sample Type pop-up menu, choose Not In Use.
7	Return to the Analysis view of the plate document.
8	Choose Analyze in the Analysis menu.
9	<p>Select any one well on the plate document. Choose View and Standard Curve in the Analysis menu.</p> <p>The re-calculated Standard Curve appears on the monitor screen.</p>

You may print the Standard Curve when it is in the active window on your screen.

To print the Standard Curve:


Step	Action
1	Click the Standard Curve view to make it the active window.
2	Choose Page Setup in the File menu.
3	Select the Landscape orientation icon and click OK.
4	Choose Print in the File menu.
5	Click Print.



## Graph Features

**General** The graphs in the Raw Spectra, Multicomponent and Amplification Plot views share common features that you can use to change the appearance of the data.

**Changing Spectra Displayed** In the Pure Spectra, Raw Spectra view and Amplification Plot, you can view spectra data from multiple wells simultaneously, while the Multicomponent view displays multiple component spectra for one well. You can use the checkboxes associated with each spectrum to remove and then bring back each line. You can also change the colors associated with each spectrum.



**Figure C-38.** Raw Spectra from Multiple Wells

### Checkbox Toggles

Each graph has a list of displayed spectra, each with a checkbox and a colored square.

View	List name	List entries
Pure Spectra	Sample (Well)	Dyes by well number
Raw Spectra	Data Series	Wells by number
Multicomponent	Component Series	Component spectra
Amplification Plot	Samples	Wells by number

The checkboxes in these areas act like a toggle switch. When a checkbox is selected, the associated spectrum appears; when a checkbox is blank, the spectrum goes away.


To remove spectra in a graphic display:

- ◆ Click the checkbox adjacent to the list entry.

## Colors Assigned to Spectra

The Sequence Detection application automatically assigns colors to spectra when it displays a graph. You can override these color assignments.


To change the color associated with a spectrum:

Step	Action
1	<p>Double-click the color box associated with a spectrum.</p>  <p>A dialog box displays a color wheel.</p>
2	Choose a new color for the spectrum and click OK.


## Changing Graph Display Features

On all the graphs, you can change: the scale of the Y and X axes; the border, area, and grid of the graph area; and the graph type.

To change the scale on an axis:

Step	Action
1	<p>Double-click the numbers on the axis.</p>  <p>Scale options</p> <p>A box appears around the numbers on the axis as the Format Axis dialog box appears.</p>
2	Enter values in the fields labeled "Maximum value," and "Minimum value" to change the scale of the selected axis.
3	Click OK to close the dialog box.

To change the graph area display:

Step	Action
1	<div>Double-click inside the border of the graph.</div> <div></div> <div>The Format Plot Area dialog box appears.</div>
2	Select features in the Border, Area and Grid portions of this dialog box and the click OK to see how the graph display changes.

To change the graph type:

Step	Action
1	Double-click inside the border of the graph to open the Format Plot Area dialog box.
2	Select a Graph Type option and click OK to see how the graph display changes.

---

## Windows Menu

Window	
Toggle Setup/Analysis	⌘1
Experiment Report	⌘3
Event Log	⌘4

**General** Use these commands to switch between the Setup and Analysis views and open the Experiment Report and the Event Log.

**Experiment Report** Displays a summary of the contents of the plate document including:

- ◆ File Name, User Name, Date of experiment, Sequence Detector model number, Plate Type, PCR sample volume, and Comments
- ◆ The method described in the Thermal Cycler Conditions box
- ◆ Standard Curve statistics
- ◆ Contents of each well, calculated threshold cycle, quantity, and replicate mean and standard deviation

Analysis results are available in the Experiment Report only after data is analyzed. When you open a saved plate document, you must re-analyze the data to see analysis results on the Experiment Report.

**Note** Raw data is saved when a plate document is closed, but it must be re-analyzed when the plate is re-opened. Analyzed data is not saved when the plate document is closed.

You cannot edit the values displayed in the Experiment Report. You can change the calculated results by first changing the Setup, either the Sample Type assigned to one or more wells or the spectra components used during data analysis, and then re-analyzing the data.

To change the values on an Experiment Report:

Step	Action
1	Click the Show Setup button to see the Setup view of the plate document.
2	Select one or more wells in the Setup view.
3	Choose Not In Use in the Sample Type pop-up menu.  The selected wells are no longer associated with a sample type. The data associated with that well in that dye layer will not be included in the data analysis.
4	Click the Show Analysis button to go to the Analysis view.
5	Choose Analyze in the Analysis menu.  The wells selected in step 2 are no longer associated to analyzed data.

To view an Experiment Report:

- ◆ Choose the Experiment Report command in the Windows menu.




Figure C-39. Experimental Report window

**Event Log** Lists error messages or events that occur during PCR or data analysis.




Figure C-40. Event Log window

To view the Event Log:

- ◆ Choose Event Log in the Windows menu.

Whenever certain errors occur during PCR or data analysis, the Event Log automatically opens on the monitor screen. The Event Log displays the time the error occurred and briefly describes the error.

**Table C-6** Error Messages Displayed in Event Log

Error Message	Significance
Background spectra not found.	Multicomponenting does not include background component. Analysis is probably wrong.
No standard curve generated--all standards have the same quantity.	In Setup view, all STND sample types have same or no quantity assigned. Quantity of UNKN sample types cannot be determined.
Standard curve generated, no unknowns to interpolate.	No UNKN sample types on Setup view.
SVDCMP: No convergence in 30 iterations.	Two of pure spectra components have same spectra or one spectra component is zero.
Well nn: Background spectra not found	Multicomponenting for one well does not include background component. Analysis is probably wrong.
Well nn: Invalid quantity specified for standard.	One or more of wells with STND sample type has no quantity assigned to it. Those wells excluded from Standard Curve calculation.
Well nn: Invalid threshold cycle for standard.	The calculated CT for a well with STND sample type is either less than 1 or greater than the number of cycle repetitions. That well is excluded from the Standard Curve calculation.
Well nn: Invalid threshold cycle for unknown.	The calculated CT for a well with UNKN sample type is either less than 1 or greater than the number of cycle repetitions. The quantity for the UNKN sample cannot be determined.
Unknowns specified with no standards.	In Setup view, no wells contain STND sample types. Standard Curve cannot be generated and quantity of UNKN sample types cannot be determined.

# Theory of Operation

# D

## Overview

**Introduction** This appendix provides an overview of the TaqMan® PCR chemistry design, optimization, and analysis.

**In This Appendix** This appendix has the following content:

Topic	See page
Fluorescence Detection on the ABI PRISM 7700 Instrument	D-3
General	D-3
Fluorescence Signals Change During PCR	D-3
Normalization of Reporter Signal	D-3
Initial Template Concentration and Cycle Number	D-4
Determination of Initial Concentration of Unknowns	D-5
Kinetic Analysis/Quantitative PCR	D-6
Fluorescence vs. Amplified Product	D-6
TaqMan Probe Design and Function	D-7
General	D-7
Probe Design	D-7
TaqMan Probe Behavior During PCR	D-7
Factors That Influence Performance	D-9
General	D-9
Quenching	D-9
Probe and Primer Hybridization Efficiency	D-10
Efficiency of Cleavage	D-10
Designing Probes	D-11
Probe Length	D-11
Reaction Conditions	D-11
Use of Estimated Melting Temperatures	D-11
Probes Available from Applied Biosystems	D-12
Allelic Discrimination	D-13
Cleavage of Multiple Probes	D-13
Polymorphic nucleotide	D-13
Comparison of Anneal/Extend Temperatures	D-13

<b>Topic</b>	<b>See page</b>
Single Reporter	D-13
The Single Reporter Experiment	D-13
Single Reporter with Internal Positive Controls	D-13
Multicomponenting	D-15
Definition	D-15
Example	D-15
Guidelines to Assay Development on the Sequence Detector	D-17
Nine-step Program	D-17
Identify Target Sequence	D-17
Design Probes and Primers	D-17
Order Reagents	D-18
Quantitate Probes and Primers	D-19
Prepare Master Mix	D-19
Run First Test	D-20
Optimize Primer Concentrations	D-20
Optimize Probe Concentrations	D-21
Run Your Custom Assay	D-21
References	D-22


---



## Fluorescence Detection on the ABI PRISM 7700 Instrument

**General** During PCR, the multiplexer directs an argon ion laser through fiber optic cables that terminate above each position on the 96-well plate. The light passes through the MicroAmp Optical Caps and, for a default time of 25 milliseconds, the laser excites the fluorescent dyes present in each well. The fiber optic cables then collect the fluorescence emission between 500 nm and 660 nm from each of the wells, with a complete collection of data from all wells approximately once every 7 seconds.


A system of lenses, filters, and a dichroic mirror focus the fluorescence emission into a spectrograph. The spectrograph separates the light (based on wavelength) into a predictably spaced pattern across a charge-coupled device (CCD) camera. The Sequence Detection application collects the fluorescent signals from the CCD camera and applies data analysis algorithms.



**Figure D-1. Graphic representation of fluorescence detection system**

### Fluorescence Signals Change During PCR

Figure D-2 shows how the fluorescence signals of reporter, quencher, and passive reference dyes change during PCR for a system with one fluorogenic probe and one target template.



**Figure D-2. Reporter, quencher, and passive reference signal changes during PCR**


### Normalization of Reporter Signal

While Figure D-2 illustrates absolute change in emission intensity, the Sequence Detection application displays cycle-by-cycle changes in normalized reporter signal for the 7700 instrument. Reporter signal is normalized by dividing by the fluorescence signal of the passive reference.

## Initial Template Concentration and Cycle Number

### General

At any given cycle within the exponential phase of PCR, the amount of product is proportional to the initial number of template copies. When one template is diluted several times, as with the Beta-actin target in the TaqMan DNA Template Reagent Kit (P/N 401970), the ratio of template concentration to detectable signal is preserved within the exponential and linear phases for all dilutions (Figure D-3). This relationship appears to change as rate of amplification approaches a plateau.



**Figure D-3. The effect of initial concentration on  $R_n$  vs. cycle number**

### Threshold Cycle ( $C_T$ )

On the graph of  $R_n$  vs. Cycle Number (Figure D-3), the threshold cycle occurs where the Sequence Detection application begins to detect the increase in signal associated with exponential growth of PCR product.

To determine  $C_T$ , the Sequence Detection application collects data from the first few PCR cycles and calculates the average  $R_n$  and the standard deviation of the  $R_n$  of these cycles. In most PCR systems, the first 15 cycles represent the baseline. Next, the algorithm multiplies the standard deviation of the background  $R_n$  by a default factor of 10 to define a threshold. Finally, the algorithm searches the data for a point that exceeds the baseline by the value of the threshold. The cycle at which this point occurs is defined as  $C_T$ .


$C_T$  represents a detection threshold for the Sequence Detector.  $C_T$  is dependent on the starting template copy number, and the efficiency of both the DNA amplification the PCR system and the cleavage of the TaqMan fluorogenic probe. When the starting concentration of a template remains constant as the concentration of other PCR components varies, the most efficient PCR system has the lowest  $C_T$ .

*continued on next page*

---

**Determination of  
Initial  
Concentration of  
Unknowns**

Given a range of five known concentrations of the same template, we can determine the  $C_T$  of each known. We then plot the  $C_T$  vs. (LogN) initial concentration (Figure D-4) to produce a standard curve.



**Figure D-4.  $C_T$  vs. (LogN) initial concentration of five knowns**

As Figure D-4 demonstrates, given the  $C_T$  of any unknown, we can interpolate its initial concentration from a standard curve when the initial concentration of the knowns bracket the concentration of the unknown.

---

*continued on next page*

### Kinetic Analysis/ Quantitative PCR

The ABI PRISM 7700 instrument determines the initial copy number of the target template by analyzing the cycle-to-cycle change in fluorescence signal as a result of the amplification of template during PCR. The fewer cycles it takes to reach a detectable level of fluorescence, the greater the initial copy number.

This form of quantitative PCR analysis, called "kinetic analysis," was first described<sup>9,10</sup> using a non-sequence-specific fluorescent dye, ethidium bromide, to detect PCR product. The Sequence Detection application determines initial copy numbers of unknowns by comparing them to a curve generated from samples of known initial copy number.




Figure D-5. R<sub>n</sub> vs. PCR cycle number

### Fluorescence vs. Amplified Product

With the TaqMan Sequence Detection system of templates and fluorogenic probes, fluorescence emission increases in direct proportion to the amount of specific amplified product. As Figure D-5 demonstrates, the graph of normalized Reporter (R<sub>n</sub>) vs. cycle number during PCR appears to have three stages. Initially, R<sub>n</sub> appears as a flat line because the fluorescent signal is below the detection limit of the Sequence Detector. In the second stage, the signal can be detected as it continues to increase in direct proportion to the increase in the products of PCR. As PCR product continues to increase, the ratio of AmpliTaq Gold™ polymerase to PCR product decreases. When template concentration reaches 10<sup>-8</sup> M, PCR product ceases to grow exponentially. This signals the third stage of R<sub>n</sub> change, which is roughly linear and finally reaches a plateau at about 10<sup>-7</sup> M.<sup>15</sup>


R<sub>n</sub> increases as concentration of amplified product increases. During the exponential growth stage, the relationship of amplified PCR product to initial template can be shown in the following equation:

$$N_c = N (1 + E)^c$$

where N<sub>c</sub> is the concentration of amplified product at any cycle,  
N is the initial concentration of target template,  
E is the efficiency of the system,  
and c is the cycle number.

## TaqMan Probe Design and Function

**General** The unique design of TaqMan® probes, combined with the 5′ - 3′ nuclease activity of AmpliTaq Gold™ polymerase<sup>1, 2, 3, 4</sup> (Figure D-6), allows direct detection of PCR product by the release of a fluorescent reporter during the PCR on the ABI PRISM® 7700 Sequence Detector.<sup>2, 5, 6</sup>



**Figure D-6. Stepwise representation of Taq DNA**

**Note** The figure represents the fork-like, structure-dependent, 5′ to 3′ polymerization-associated nuclease activity of *Taq* DNA polymerase during one extension phase of PCR.<sup>3</sup>

**Probe Design** The TaqMan probe consists of an oligonucleotide with a 5′-reporter dye and a downstream, 3′-quencher dye. The fluorescent reporter dye, such as FAM (6-carboxy-fluorescein), is covalently linked to the 5′ end of the oligonucleotide. TET (tetrachloro-6-carboxy-fluorescein), JOE (2,7-dimethoxy-4,5-dichloro-6-carboxy-fluorescein), and HEX (hexachloro-6-carboxy-fluorescein) may also be used as reporter dyes. Each of the reporters is quenched by TAMRA (6-carboxy-tetramethyl-rhodamine), typically located at the 3′ end.

**TaqMan Probe Behavior During PCR** When the probe is intact, the proximity of the reporter dye to the quencher dye results in suppression of the reporter fluorescence, primarily by Förster-type energy transfer<sup>7, 8</sup>. During PCR, forward and reverse primers hybridize to a specific sequence of the target DNA. The TaqMan probe hybridizes to a target sequence within the PCR product. The AmpliTaq Gold enzyme cleaves the TaqMan probe with its 5′-3′

nuclease activity. The reporter dye and quencher dye are separated upon cleavage, resulting in increased fluorescence of the reporter (Figure D-6 on page D-7). The 3' end of the TaqMan probe is blocked to prevent extension of the probe during PCR.

This process occurs in every cycle and does not interfere with the exponential accumulation of product. The separation of the reporter dyes from the quencher dye results in increase in fluorescence for the reporter. The increase in fluorescence is measured, and is a direct consequence of target amplification during PCR.

Both primer and probe must hybridize to the target for amplification and cleavage to occur. The fluorescence signal is generated only if the target sequence for the probe is amplified during PCR. Because of these requirements, non-specific amplification is not detected. For information on release of a fluorescent reporter during the PCR, refer to Lee *et al.*, 1993, and Livak *et al.*, 1995.

---

## Factors That Influence Performance

---

**General** Three main factors determine the performance of a doubly labeled fluorescent probe in this 5' nuclease assay: quenching of intact probe; hybridization efficiency; and efficiency of cleavage by AmpliTaq Gold polymerase. For other factors which influence performance, see "Guidelines to Assay Development on the Sequence Detector" on page D-17.

---

### Quenching Dye Placement

Fluorescence quenching depends on the spatial proximity of the reporter and quencher dyes. In fact, Förster-type energy transfer efficiency varies with the inverse sixth power of the distance between fluorophores. It was originally thought that the quencher dye must be close to the 5' end in order to achieve adequate quenching.<sup>5</sup> Surprisingly, the quencher dye, TAMRA, can be attached to virtually any nucleotide in a probe and still quench the fluorescence emission of a reporter dye attached to the 5' end.<sup>11</sup> The flexibility of a single-stranded oligonucleotide apparently allows the probe to adopt conformations where the reporter and quencher dyes are close enough to achieve energy transfer.

#### Avoid G at the 5'-end Position

Factors other than dye placement can effect the degree of quenching in a fluorogenic probe. We have found that a G next to the reporter dye causes some quenching, which persists even after cleavage of the fluorogenic probe. Consequently, it is best to avoid G at the 5'-end position of a fluorogenic probe.

#### Other Structures to Avoid

Probes with a reporter dye on the 5' end and TAMRA on the 3' end exhibit sufficient quenching for the fluorogenic 5' nuclease assay. With the TAMRA at the 3' end, quenching appears to be dependent on the flexibility of the single-stranded probe. Any structure that interferes with this flexibility could potentially reduce the degree of quenching observed in the intact probe. Probe structures to be avoided include hairpins, self-complementarity, complementarity to either the reverse or the forward PCR primer, and four or more of a single base in a row, especially Gs.

#### Effect of Probe Purity

Finally, the purity of the probe can have a marked effect on the observed quenching. Any molecule that has a reporter dye but no quencher dye can be a source of contamination. The presence of unquenched reporter raises the initial intensity of the reporter fluorescence, making it difficult to discern the change in reporter fluorescence that is due to probe cleavage. For this reason, the reporter dye is attached to the 5' end using a phosphoramidite, so that any failure (incomplete) sequences generated during the oligonucleotide synthesis are not labeled with the reporter dye.

---

*continued on next page*

---

**Probe and Primer  
Hybridization  
Efficiency**

**General**

Cleavage of a fluorogenic probe requires hybridization to the target sequence. All general rules for the design of hybridization probes also apply to fluorogenic probes. Such general advice includes: avoid secondary structure in probe or target site; and avoid long runs of a single nucleotide.

**Avoid Probe Hybridizing with PCR Primers**

In addition, the probe should not hybridize with either PCR primer. Such hybridization lowers the effective concentration of both probe and primer, reducing PCR hybridization efficiency. Probe-primer hybrids can also be a source of 'primer-dimer' contamination, formed during the amplification reaction.

**Primer and Probe Hybrids**

Both the PCR primers and the fluorogenic probe need to hybridize to the template strands during the annealing step of the PCR amplification reaction. Primer-template hybrids are stabilized when the AmpliTaq Gold enzyme extends the primer in the polymerization reaction. The fluorogenic probe is not extended, so its hybridization is not stabilized. Thus, it follows that the probe-template hybrid must be more stable (have higher  $T_m$ ) than the primer-template hybrids. Also, the  $T_m$  of the probe should be higher than the actual annealing temperature used in the 5' nuclease assay. Please refer to "Guidelines to Assay Development on the Sequence Detector" on page D-17 for further advice on primer/probe selection.

**AmpErase UNG**

The  $T_m$ s of all the oligonucleotides need to be greater than 55 °C, due to the presence of AmpErase® UNG (uracil-N-glycosylase). UNG has significant activity below 55 °C, can degrade amplicons and thereby introduce more variability into the 5' nuclease assay.

---

**Efficiency of  
Cleavage**

Although the effect on quenching may be modest, the placement of the quencher dye can have a major impact on the efficiency of cleavage by the AmpliTaq Gold polymerase. To observe an increase in reporter fluorescence intensity in the fluorogenic 5' nuclease assay, the probe must be cleaved between the reporter and quencher dyes. When dyes are placed on opposite ends of the probe, any cleavage of the probe is detected. When the quencher dye is placed on an internal nucleotide, only cleavages that occur between the reporter and quencher dyes are detected. Therefore, synthesizing an oligonucleotide with a reporter dye on the 5' end and TAMRA attached to the 3' end provides the best chance of having a probe that reliably detects PCR in the fluorogenic 5' nuclease assay.

---



## Designing Probes

---

**Probe Length** When the length of the probe increases beyond 30 nucleotides, two problems arise. First, longer probes reduce the yield of the oligonucleotide synthesis. Second, the longer the probe, the greater the chance of forming inter- or intra-molecular structures that create purification problems, impair the hybridization and cleavage of the probe, or interfere with PCR.

**Note** The primary structural requirement for probes is the  $T_m$ . In order to obtain a probe with a  $T_m$  of 68-70 °C, use Primer Express software.

Probes can be designed to correspond to either strand of the PCR amplicon. When complementary probes have been tested in the 5' nuclease assay, we have observed that one probe usually gives appreciably better performance (higher  $\Delta R_n$  values) than its complement. The critical difference appears to be the C-to-G ratio in the composition of the probe.

Although the percentage G+C content of complementary sequences is identical, in general one strand will have more Cs and the opposite strand will have moreGs. We have found that those probe sequences with the greater number of Cs usually perform better in the 5' nuclease assay.

---

**Reaction Conditions** The fact that a fluorogenic probe is not stabilized by being extended during PCR has consequences for the extension step used in amplification. As previously discussed, successful 5' nuclease assay results require the following four events:

- ◆ primers hybridize and are extended
- ◆ probe hybridizes
- ◆ probe is cleaved, which increases fluorescence signal, and
- ◆ primer extension is completed

Since a fluorogenic probe must be hybridized for cleavage to occur, extension must be carried out at a temperature that ensures probe binding.

**Note** See "Guidelines to Assay Development on the Sequence Detector" on page D-17 for specific reaction conditions.

A two-temperature PCR protocol using a combined annealing/extension temperature below the  $T_m$  of the probe should increase the hybridization and cleavage efficiency of the fluorogenic probes. We have found that on the ABI PRISM 7700 Sequence Detection System, a combined anneal-extension step of 1 minute at 55 °C or higher has been sufficient for amplicons under 1 Kb.

Higher concentrations of  $MgCl_2$  (3.5–9 mM) stabilize probe binding and thus promote the use of higher temperatures during the combined anneal/extension step. Higher temperatures are desirable so that the extension rate of the AmpliTaq Gold enzyme is as high as possible.

---

**Use of Estimated Melting Temperatures** The only way to know the  $T_m$  of an oligonucleotide for sure is to measure it experimentally. To design a probe, though, estimated  $T_m$ s must be used. Although it is not completely accurate, the nearest neighbor method<sup>13</sup> is the best algorithm generally available for estimating  $T_m$ s of oligonucleotides.

In designing a probe for a PCR system that is already optimized, the estimated  $T_m$  of the probe should be at least 5 °C above the annealing temperature. For cases where probe and primers are being designed at the same time, we suggest that the estimated  $T_m$  of the probe be at least 5 °C higher than the matched  $T_m$ s of the PCR primers.

**Note** Primer Express™ software is recommended for choosing TaqMan primers and probes with accurate  $T_m$  prediction. A single user copy of the software is available under P/N 402809.

**Probes Available  
from Applied  
Biosystems**

The three types of TaqMan fluorogenic probes listed in Table D-1 are available from Applied Biosystems. Custom probes ordered by the three Part Numbers are identical except for quantity and are HPLC-purified to minimize the amount of unquenched reporter present and give very reproducible results.

**Table D-1** TaqMan Probes

Part No. *	TaqMan Probes
450025	TaqMan Probe. HPLC purified. 5,000-6,000 pmol. 5' Fluorescent label: HEX, 6-FAM or TET. 3'-label: TAMRA. Labels + HPLC Purification (~ 500 reactions)
450024	TaqMan Probe. HPLC purified. 15,000-25,000 pmol. 5' Fluorescent label: HEX, 6-FAM or TET. 3'-label: TAMRA. Labels + HPLC Purification (~ 2,500 reactions)
450003	TaqMan Probe. HPLC purified. 50,000-100,000 pmol. 5' Fluorescent label: HEX, 6-FAM or TET. 3'-label: TAMRA. Labels + HPLC Purification (~ 10,000 reactions)

\* Part numbers listed are for US only. Contact your Regional Sales Office for local Part numbers and prices (see "To Contact Technical Support by Telephone or Fax" on page 1-4 for a list of telephone and Fax numbers).

## Allelic Discrimination

<b>Cleavage of Multiple Probes</b>	By using different reporter dyes, cleavage of multiple probes can be detected in a single PCR. One application of this multi-probe capability is to use allele-specific probes to distinguish genetic polymorphisms. <sup>5,14</sup> Probes that differ by as little as a single nucleotide will exhibit allele-specific cleavage. This is true even for probes with a reporter on the 5' end and TAMRA on the 3' end. <sup>14</sup>
<b>Polymorphic nucleotide</b>	In designing allele-specific probes, the polymorphic nucleotide should be positioned approximately in the center of the probe because a mismatch in this position is usually the most disruptive to probe-template hybrid stability. If the polymorphism changes the G+C content (for example, a C-to-T change), the probe should be lengthened one or two nucleotides in order to compensate for $T_m$ differences. The other elements of fluorogenic probe design still apply.
<b>Comparison of Anneal/Extend Temperatures</b>	<p>In using the 5' nuclease assay to distinguish alleles, it is usually necessary to compare different anneal/extend temperatures. Lower temperatures produce higher <math>\Delta R_n</math> values, but there may be little discrimination between alleles. Increasing the anneal/extend temperature improves the allele-specific response of the probes, but decreases overall signal. At higher temperatures, some of the signal loss can be regained by increasing the concentration of the PCR primers.</p> <p>The optimum anneal/extend temperature is empirically determined to achieve the best compromise between allele discrimination and signal level.</p>

## Single Reporter

<b>The Single Reporter Experiment</b>	A Single Reporter experiment is designed to report the presence or absence of a specific nucleic acid sequence in a test sample. This assay only requires one TaqMan probe for detection.
<b>Single Reporter with Internal Positive Controls</b>	<p><b>Purpose of Internal Positive Controls</b></p> <p>By using probes labeled with different reporters, a positive control for the PCR chemistry can be included in any amplification reaction. This Internal Positive Control (IPC) ensures that a failed PCR is not mistaken for a negative test result.</p> <p><b>Considerations in Using an IPC</b></p> <p>The IPC consists of a PCR template (DNA or RNA) that is spiked into the amplification reaction at known concentration. Also included in the reaction are primers and probe for detecting amplification of the IPC. The IPC probe is labeled with a different reporter than the probe used for detection of target amplification. Generally, the target probe is labeled with FAM and the IPC probe is labeled with TET or JOE.</p> <p><b>Interpretation of Results</b></p> <p>A positive result with the target probe indicates the target is present in the sample and there is no need to refer to the IPC amplification. On the other hand, a negative result</p>

with the target probe could mean that the sample contains no target or that, for some reason, PCR failed in that well. Referring to the results with the IPC probe can distinguish between these two possibilities. A positive signal with the IPC probe shows that PCR amplification can occur in that well and, thus, the lack of target signal means the sample is a true negative. If amplification of the IPC is not detected, then PCR was inhibited in that tube and it is not possible to determine whether target is present in the sample or not.

#### **Amount of IPC**

The amount of IPC spiked into a reaction depends upon the detection limit desired for the target. The goal is that amplification of the IPC should not interfere with amplification of the target. For example, if a test were designed to detect 100 or more copies of target, then the copy number of IPC would generally be set at 100 or less. In this way, amplification of the IPC will not consume enough reagents to prevent detection of target amplification. Also, the IPC reaction can be optimized to determine the minimum concentrations of primers required for robust amplification.

Using the minimum concentrations reduces the likelihood of interference with the target amplification. Reconstruction experiments should be performed to validate that inclusion of the IPC does not affect target detection.


**Note** If attempting single copy target detection, the level of IPC would not be set at one copy per reaction because of the consequences of Poisson statistics. In attempting to pipet 1-copy aliquots, sampling probability indicates that some samples will have more than one copy and some fraction will actually have no copies. Thus, the minimum level of IPC should be about 10 copies per reaction in order to ensure that all reactions have enough copies for robust detection. Depending on the relative efficiencies of target and IPC amplification, the inclusion of 10 IPC copies may preclude single copy detection of the target.

---

## Multicomponenting

**Definition** Multicomponenting is the term used for distinguishing the contribution each individual dye and background component makes to the fluorescent spectra detected by the ABI PRISM 7700 Sequence Detector.

**Example** Figure D-7 shows one composite spectrum that represents a fluorescent reading of one well that contains a passive reference dye and a fluorogenic probe, labeled with FAM and TAMRA. This figure shows how the overlapping component dye spectra contribute to the composite spectrum. The multicomponenting algorithm on the Sequence Detection application applies matrix calculations to determine the contributions of each component dye spectra.<sup>16</sup>



**Figure D-7. Composite spectrum and three component spectra**


First, during the background and pure dye spectra calibrations, each component is measured across the entire range of measurable fluorescence, from 500–660 nm. As part of the calibration process, a representative signal for each component is generated and stored on the computer by the application. During each subsequent multicomponenting calculation, the application refers back to these stored representative signals and applies an algorithm to solve for a, b, c, and d in the following equation:

$$\text{Measured spectrum} = a(\text{FAM}) + b(\text{TAMRA}) + c(\text{ROX}) + d(\text{Background}) + \text{Error}$$

where a, b, c, and d represent each component's contribution.

The algorithm solves for a, b, c, and d to find the smallest value for mean squared error (MSE). This example calculation assumes that pure dye components exist for

three dyes and for the instrument background. Figure D-8 shows a typical display of the contribution of each component spectra for one well.



**Figure D-8.** The Sequence Detection Application's Multicomponent View

The MSE display is an optional feature. If you want the MSE to appear in the Multicomponent view, see “Advanced Options” on page C-43.

## Guidelines to Assay Development on the Sequence Detector

---

**Nine-step Program** The following steps are recommended for the development of custom 5' nuclease assays.

- ◆ Identify the target sequence.
- ◆ Design the TaqMan probes.
- ◆ Design the forward and reverse Primers.
- ◆ Order reagents.
- ◆ Quantitate the concentrations of the probes and primers.
- ◆ Prepare the Master Mix.
- ◆ Run a first iteration of the test.
- ◆ Optimize the primer concentrations.
- ◆ Optimize the probe concentrations.

---

### Identify Target Sequence

- ◆ A target is a nucleotide sequence, two primers, and a probe.
- ◆ For allelic discrimination, each allele associated with a target will have a probe labeled with its own fluorescent reporter dye.
- ◆ The shortest amplicons work the best. Consistent results are obtained for amplicon ranges from 50–200 bp.

---

### Design Probes and Primers

#### Design Probes

Use the following guidelines:

- ◆ Keep the G-C content in the range of 30–80%.
- ◆ Avoid runs of an identical nucleotide. This is especially true for guanine, where runs of four or more Gs should be avoided.
- ◆ No G on 5' end.
- ◆ Using Primer Express™ software,  $T_m$  should be 10 °C greater than primers.
- ◆ Select the strand that gives the probe with more Cs than Gs.
- ◆ Position the polymorphism site approximately in the center.
- ◆ Adjust probe length so that both probes have the same  $T_m$ .

#### Design Primers

Use the following guidelines:

- ◆ Keep the G-C content in the range 30–80%.
- ◆ Avoid runs of an identical nucleotide. This is especially true for guanine, where runs of four or more Gs should be avoided.
- ◆ Using Primer Express™ software,  $T_m$  should be 58–60 °C.
- ◆ The five nucleotides at the 3' end should have no more than two G and/or C bases.
- ◆ Place the forward and reverse primers as close as possible to the probe without overlapping the probe.

- ◆ Use an annealing temperature of  $T_m - 5\text{ }^{\circ}\text{C}$ .
- ◆ If  $T_m$  is not measured, use an anneal/extension temperature of  $62\text{ }^{\circ}\text{C}$ .

---

**Order Reagents** You will need the following reagents and equipment to create your own applications.

**Table D-2** PCR reagents

Item	Source
TaqMan® DNA Template Reagent Kit	Applied Biosystems (P/N 401970)
TaqMan® PCR Core Reagent Kit	Applied Biosystems (P/N N808-0228)
Custom TaqMan® Quantitation Probes	Applied Biosystems (P/N 450003)
AmpErase® UNG (one 100 $\mu\text{L}$ tube of 1 U/ $\mu\text{L}$ uracil-N-glycosylase)	Applied Biosystems (P/N N808-0096)
Deionized water or TE buffer (10 mM Tris-HCl, 1 mM EDTA, pH 8.0)	Major laboratory suppliers (MLS)
Glycerol, 20%, molecular biology grade	Applied Biosystems (P/N 402929)

**Note** Part numbers can change due to the need of introducing new and improved products. Contact your Applied Biosystems Sales representative for specific ordering information.

**Table D-3** PCR consumables

Item	Source
MicroAmp® Optical 96-Well Reaction Plate	Applied Biosystems (P/N N801-0560)
MicroAmp® Optical 96-Well Reaction Plate and Optical Caps	Applied Biosystems (P/N 403012)
MicroAmp® Optical Tubes	Applied Biosystems (P/N N801-0933)
MicroAmp® Optical Caps	Applied Biosystems (P/N N801-0935)

---

*continued on next page*



## Quantitate Probes and Primers

Use a spectrophotometric method to determine the concentrations of the probes and primers received:

- ◆ Measure the absorbance at 260 nm of a 1:100 dilution of each oligonucleotide in TE buffer.
- ◆ Calculate the oligonucleotide concentration in  $\mu\text{M}$  using the method shown in Table D-4.

**Table D-4** Example of Extinction coefficient calculation for a FAM-labeled probe

Chromophore	Extinction Coefficient	Number	Extinction Coefficient Contribution
A	15,200	1	15,200
C	7,050	6	42,300
G	12,010	5	60,050
T	8,400	6	50,400
FAM	20,958	1	20,958
TAMRA	31,980	1	31,980
TET	16,255	0	—
Total	—	—	220,888

Absorbance (260 nm) = sum of extinction coefficient contributions  $\times$  cuvette pathlength  $\times$  concentration/100

$$0.13 = 220,888 \text{ M}^{-1}\text{cm}^{-1} \times 0.3 \text{ cm} \times C/100$$

$$C = 196 \mu\text{M}$$

## Prepare Master Mix

Use 20% glycerol and the reagents in the TaqMan PCR Core Reagent Kit ((P/N N808-0228) to prepare a TaqMan Master Mix. Remove aliquots of the Master Mix and store them at 2–6 °C. Due to pipetting carry-over, 115 reactions will provide sufficient reagent for 96 wells.

**Table D-5** Master Mix formulation for 115 Reactions

Reagent	Volume ( $\mu\text{L}$ ) for 115 wells of 50 $\mu\text{L}$ each	Final Concentration in each 50 $\mu\text{L}$ reaction
20% Glycerol	1150	8%
10X TaqMan Buffer A	288	1X
25 mM $\text{MgCl}_2$	575	5 mM
dATP	58	200 $\mu\text{M}$
dCTP	58	200 $\mu\text{M}$
dGTP	58	200 $\mu\text{M}$
dUTP	58	400 $\mu\text{M}$
AmpliTaq Gold™ DNA Polymerase (5 U/ $\mu\text{L}$ )	29	0.05 U/ $\mu\text{L}$
AmpErase® UNG (1 U/ $\mu\text{L}$ )	29	0.01 U/ $\mu\text{L}$
Total	2303	—

**Note** More information on preparing and using a Master Mix are provided in Appendix A, “Guidelines to Master Mix Preparation.”

**Run First Test** Run the first iteration of the test using the reagents in Table D-6 and the thermal cycler parameters in Table D-7 on page D-20.

**Table D-6** Reaction mixture

Reaction Component	Volume ( $\mu\text{L}$ )	Final Concentration
TaqMan Master Mix	40	1X
Forward and reverse primers	2.5	200 nM
TaqMan probes	2.5	100 nM
DNA sample	5.0	0.4 ng/ $\mu\text{L}$
Total	50	—

**Table D-7** Thermal cycling conditions

Thermal Cycler	Times and Temperatures			
	Initial Steps		Each of 40 Cycles	
			Melt	Anneal/ Extend
GeneAmp® PCR System 9600	HOLD	HOLD	CYCLE	
	2 min. 50 °C	10 min. 95 °C	15 sec. 95 °C	1 min. 60 °C
ABI PRISM® 7700 Sequence Detector	HOLD	HOLD	CYCLE	
	2 min. 50 °C	10 min. 95 °C	15 sec. 95 °C	1 min. 60 °C

**IMPORTANT** The two-minute, 50 °C step is required for optimal AmpErase® UNG activity. The 10-minute, 95 °C step is required to activate AmpliTaq Gold™ DNA polymerase.

### Optimize Primer Concentrations

The purpose of this procedure is to determine the minimum primer concentrations that give the maximum  $\Delta R_n$ . The ABI PRISM 7700 Sequence Detector can provide additional data for optimization using the minimum threshold cycle ( $C_T$ ). See page C-54 for more information regarding  $C_T$ .

- ◆ Use the thermal cycler conditions in Table D-7.
- ◆ Use one of the allelic discrimination probes at a concentration of 100 nM.
- ◆ Run at least four replicates of each of the nine conditions defined by the  $3 \times 3$  matrix below.

Reverse Primer (nM)	Forward Primer (nM)		
	50	300	900
50	50/50	300/50	900/50
300	50/300	300/300	900/300
900	50/900	300/900	900/900

- ◆ At the end of the runs, tabulate the results for  $\Delta R_n$  and  $C_T$ . Choose the minimum forward and reverse primer concentrations that yield the maximum  $\Delta R_n$  and minimum  $C_T$ .

---

**Optimize Probe Concentrations**

The purpose of this procedure is to determine the minimum probe concentrations that give the maximum  $\Delta R_n$  and minimum  $C_T$  for each probe target.

- ◆ Use the thermal cycler conditions in Table D-7 on page D-20 and the forward and reverse primer concentrations determined above.
- ◆ Run at least four replicates of each of the nine conditions defined by the  $3 \times 3$  matrix below.

Probe 2 (nM)	Probe 1 (nM)		
	100	200	300
100	100/100	200/100	300/100
200	100/200	200/200	300/200
300	100/300	200/300	300/300

- ◆ Tabulate the results for  $\Delta R_n$  and  $C_T$ . Choose the minimum probe concentrations that yield the maximum  $\Delta R_n$  and minimum  $C_T$ .

**Note** Probe optimization is specific for Allelic Discrimination assays.

---

**Run Your Custom Assay**

Run your experiment.

---

## References

The references listed below are those cited by superscript numbers in the text.

### References

1	Lawyer, F.C., Stoffel, S., Saiki R.K., Myambo, K.B., Drummond R., and Gelfand, D.H., 1989. Isolation, characterization, and expression in <i>Escherichia coli</i> of the DNA polymerase gene from the extreme thermophile, <i>Thermus aquaticus</i> . <i>J. Biol. Chem.</i> 264: 6427-6437.
2	Holland, P.M., Abramson, R.D., Watson, R. and Gelfand, D.H. 1991. Detection of specific polymerase chain reaction product by utilizing the 5' to 3' exonuclease activity of <i>Thermus aquaticus</i> DNA polymerase. <i>Proc. Natl. Acad. Sci., USA</i> 88: 7276-7280.
3	Lyamichev, V., Brow, M.A.D., Dahlberg, J.E. 1993. Structure-specific endonucleolytic cleavage of nucleic acids by eubacterial DNA polymerases. <i>Science</i> 260: 778-783.
4	Perkin-Elmer, 1996. AmpliTaq Gold™ Product Insert, Rev. 3.
5	Lee, L.G., Connell, C.R., and Bloch, W. 1993. Allelic discrimination by nick-translation PCR with fluorogenic probes. <i>Nucl. Acids Res.</i> 21: 3761-3766.
6	Gelfand, D.H., Holland, P.M., Saiki, R.K. and Watson, R.M., U.S. Patent 5 210 015, 1993; <i>Chem Abstr.</i> 1992.
7	Förster, V. Th., 1948, Zwischenmolekulare Energie-wanderung und Fluoreszenz. <i>Annals of Physics (Leipzig)</i> 2: 55-75.
8	Lakowicz, Joseph R. 1983. Chapter 10. Energy Transfer. In: <i>Principles of Fluorescent Spectroscopy</i> , Plenum Press, N.Y. pp, 303-339.
9	Higuchi, R., Dollinger, G., Walsh, P.S., and Griffith, R. 1992. Simultaneous amplification and detection of specific DNA sequences. <i>BioTechnology</i> 10:413-417.
10	Higuchi, R., Fockler, C., Dollinger, G. and Watson, R. 1993. Kinetic PCR analysis: Real-time monitoring of DNA amplification reactions. <i>BioTechnology</i> 11:1026-1030.
11	Livak, K., Flood, S., Marmaro, J., Giusti, W., and Deetz, K. Oligonucleotides with fluorescent dyes at opposite ends provide a quenched probe system useful for detecting PCR product and nucleic acid hybridization. <i>PCR Methods and Applications</i> 4: 357-362.
12	Rychlik, W., Spencer, W.J., and Rhoads, R.E. 1990. Optimization of the annealing temperature for DNA amplification <i>in vitro</i> . <i>Nucl. Acids. Res.</i> 18:6409-6412.
13	Livak, K.J., Marmaro, J., and Todd, J.A. 1995. Towards fully automated genome-wide polymorphism screening. <i>Nature Genetics</i> 9:341-342.
14	Bloch, W. 1991. A biochemical perspective of the polymerase chain reaction. <i>Biochemistry</i> 30:2735-2747.
15	Martens, H. and Naes, T., 1989. In: <i>Multivariate Calibration</i> , John Wiley & Sons, Chichester.

# *Limited Warranty Statement*

---



Applied Biosystems ("ABD") warrants to the customer that, for a period ending on the earlier of one year from the completion of installation or fifteen (15) month(s) from the date of shipment to the customer (the "Warranty Period"), the ABI PRISM® 7700 Sequence Detector purchased by the customer (the "Instrument") will be free from defects in material and workmanship, and will perform in accordance with the installation specifications set forth in the system specification sheet which accompanies the Instrument or which is otherwise available from an ABD sales representative (the "Specifications").

During the Warranty Period, if the Instrument's hardware becomes damaged or contaminated or if the Instrument otherwise fails to meet the Specifications, ABD will repair or replace the Instrument so that it meets the Specifications, at ABD's expense. However, if the thermal cycle module becomes damaged or contaminated, or if the chemical performance of the Instrument otherwise deteriorates, due to solvents and/or reagents other than those supplied or expressly recommended by ABD, ABD will return the Instrument to Specification at the customer's request and at the customer's expense. After this service is performed, warranty coverage of the Instrument will be restored thereafter for the remainder of the original Warranty Period.

This Warranty does not extend to any Instrument or part which has been (a) the subject of an accident, misuse, or neglect, (b) modified or repaired by a party other than ABD, or (c) used in a manner not in accordance with the instructions contained in the Instrument User's Manual. This Warranty does not cover the customer-installable accessories or customer-installable consumable parts for the Instrument that are listed in the Instrument User's Manual. Those items are covered by their own warranties.

ABD's obligation under this Warranty is limited to repairs or replacements that ABD deems necessary to correct those failures of the Instrument to meet the Specifications of which ABD is notified prior to expiration of the Warranty Period. All repairs and replacements under this Warranty will be performed by ABD on site at the Customer's location at ABD's expense.

No agent, employee, or representative of ABD has any authority to bind ABD to any affirmation, representation, or warranty concerning the Instrument that is not contained in ABD's printed product literature or this Warranty Statement. Any such affirmation, representation or warranty made by any agent, employee, or representative of ABD will not be binding on ABD.

ABD shall not be liable for any incidental, special, or consequential loss, damage or expense directly or indirectly arising from the purchase or use of the Instrument. ABD makes no warranty whatsoever with regard to products or parts furnished by third parties.

This Warranty is limited to the original location of installation and is not transferable. Attempts to move or reinstall the Instrument may result in the loss of warranty coverage.

THIS WARRANTY IS THE SOLE AND EXCLUSIVE WARRANTY AS TO THE INSTRUMENT AND IS IN LIEU OF ANY OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND IS IN LIEU OF ANY OTHER OBLIGATION ON THE PART OF ABD.

---

# Index

## *Symbols*

- DRn
  - and data analysis 2-4
  - and G+C content of probe D-11
  - display C-48
- ∞
  - see forever hold C-26

## *Numerics*

- 5' nuclease assay
  - allelic discrimination D-13
  - requirements D-11
- 7700 Sequence Detector
  - sample volume 3-20
- 96-well sample map 3-24

## *A*

- A1 position
  - on heating block 3-29
- ABI PRISM 7200
  - importing a setup file C-21
- aborting
  - a run C-40
  - data handling C-11
  - in status display C-12
- Acronym
  - Sample Type Setup C-34
- acronym name, changing C-34
- active pure spectra C-43
- designating C-42
- adding
  - Data Collection icon 3-21, C-32
  - Step, Cycle or Hold C-26
- Allelic Discrimination
  - and multiple probes D-13
  - command, using to view results C-50–C-51
  - plate type C-16
- Allelic Discrimination plate type
  - sample types required C-37
  - viewing results C-50–C-51
- Amplification Plot C-52–C-54
- Analysis menu C-48
  - Allelic Discrimination
    - command C-50–C-51
    - Options command C-49
- Analysis Options dialog box, using to set analysis options C-49
- Analysis view C-10–C-13
  - comments C-7
- assigning samples to wells 3-3

- Auto Increment
  - indicator C-30
  - temperature 3-20, C-30
  - time 3-20, C-30
- autodecrement C-31
- automatic connection to instrument 3-6, C-23

## *B*

- background 6-9
- background component C-41
  - advanced options C-44
  - calibrating 3-7
  - extract C-40
  - in saved plate document C-17
  - viewing C-41
- Background plate type C-16
- best fit
  - in Raw Spectra view C-56
  - viewing C-44
- bin, spectral C-18
- Blackboard 6-9
- Border
  - on graph area C-61

## *C*

- calculated data values, for all wells 5-5
- Calibrate command C-40–C-43
- calibration
  - background component C-40
  - spectra component C-41
- CCD camera 3-26
  - function D-3
- cell cultures
  - DNA purification B-1
- channel C-18
- charge-coupled device, see CCD
- checkbox
  - as toggle C-59
  - connect to instrument 3-6
  - Running C-23
- Clear command
  - deleting Steps C-28
- click 5-6
- Clipped
  - exporting data C-18
- Collecting data C-31
- color
  - in graphs C-60
  - sample type C-34

- color, setting for sample type C-34
- column of wells
  - selecting 3-15, C-9
- Comm light 3-31
- comments
  - on Analysis view 3-22, C-7
  - on Experiment Report 3-22, C-7
  - on Setup view 3-4
  - saving on Plate Document 3-22
- component
  - background C-41, C-44
  - pure dye C-40, C-44
- Component Series
  - in Multicomponent view C-55
- confidence level 5-3
- connecting to instrument 3-6, C-23
- Cov. Temp. C-12
- cover
  - closing heating block 3-30
  - opening heating block 3-32
  - sample 3-30
- creating
  - background component C-41
  - pure spectra component C-41
- CT 2-4, 2-6
- Cut command C-22
- Cycle
  - adding C-26
  - counting repetitions C-13
  - default configuration C-27
  - definition C-25
  - deleting C-27
  - placement of new C-27
- cycle repetitions C-13

## *D*

- data
  - in saved plate document C-17
  - Table of locations 5-4, 5-8
- data analysis
  - and extension time C-28
  - and Run Types 2-4
  - in Plate Read Only 2-6
  - in Real Time run 2-6
- data bin C-18
- data collection
  - and exposure time C-45
  - and Run Type 2-4
  - and size of files C-32
  - eliminating C-32
  - in Thermal Cycler
    - Conditions 3-19

- instrument connection C-23
- setting in Preferences C-23
- Data Collection icon
  - adding 3-21, C-32
  - removing 3-21, C-32
- data exporting
  - all wells C-19
  - selected wells C-19
- decrement indicator C-30
- default
  - PCR volume C-23
  - Step, Cycle and Hold configurations C-27
  - unit of measure C-23
- deleting
  - sample type in well C-62
  - Step, Cycle, or Hold C-27
- Display command C-48
- Sample Type C-49
- displaying
  - Background component C-41
  - Experiment Report 5-5
  - heating block cover temperature 3-5
  - mean squared error C-44
- DNA purification procedure B-1
- DNA purity B-12
- Dual Reporter
  - plate type C-16
- dye layer
  - definition 2-7
  - pop-up menu 2-7, C-42
  - viewing samples 3-16
- Dye Layer pop-up menu
  - displaying active dyes C-34
- dye pop-up C-42
- dye spectra
  - in pop-up menu C-42
- dyes
  - for Sample Types 3-3

## **E**

- Edit menu C-22
- editing
  - a method C-26
  - data C-62
  - Experiment Report C-62
  - Pure Spectra C-41
  - Sample List
    - on Sample Type Palette C-33
- Editing Sample Attributes command C-35
- end-point analysis 2-4
- entry fields
  - Setup view C-6
- Event Log C-63
- Experiment Report C-62
  - and analyzed data C-62
  - Mean C-6

- Name C-23
- printing 5-6
- Replicate values C-6
- Std. Dev. C-6
- Experiment Report, No Amp call 5-9
- Export command C-18
- exporting
  - All Wells C-19
  - Selected Wells C-19
- extension time
  - recommended C-28
- extracting
  - Background Component C-40
  - Background Spectra 3-8
  - Spectra Component 3-11, C-41

## **F**

- FAM D-7
- File menu C-16–C-21
  - Import command C-21
- Firmware 6-6
- Fit, best
  - correlation to Raw Spectra C-56
- floating window C-33
- fluorescence
  - detection system D-3
- Fluorescence Tests 6-8
- fluorogenic probe
  - design D-7
- forever hold 3-32, C-26
  - displaying time C-12

## **G**

- G+C content
  - of fluorogenic probes D-11
- GenePure Basebinder
  - DNA purification B-2
- graph
  - features C-59–C-61
- graphical tools, using on Allelic Discrimination results C-51
- Grid
  - on graph area C-61
- guide, on-line 2-8
- guidelines
  - Master Mix preparation A-1–A-4
  - PCR optimization D-17
  - TaqMan probe design D-7

## **H**

- heating block
  - closing cover 3-30
  - cover temperature 3-5
- help
  - on-line guide 2-8
- HEX D-7
- Hold
  - adding C-26
  - default configuration C-27

- definition C-25
- deleting C-27
- forever 3-32, C-12
- placement of new C-27
- Holding
  - in status display C-12
- hot starts, manual 3-32
- hybridization
  - of probe and primers D-10

## **I**

- Idle
  - in status display C-12
- Importing a setup file C-20
- importing a setup file C-21
- Increment indicator C-31
- increment indicator C-30
- Insert bar
  - determining placement C-26
  - editing a method C-26
- inserting
  - Auto Increment C-30
  - Auto increment C-30
  - Step, Cycle or Hold C-26
- Instrument
  - in Preferences C-22
- Instrument menu C-40–C-43
- interrupting a run C-40
- IPC Dye Layer 5-7
- IPC Dye Layer, results 5-9
- IPC Layer setup, typical 5-7
- IPC+ and IPC- 5-7
- IPCs, how to add 5-7

## **J**

- JOE D-7

## **K**

- keyboard shortcuts C-14

## **L**

- Landscape printing C-22
- LED display
  - Comm 3-31

## **M**

- manual hot starts 3-32
- map of samples 3-24
- Master Mix
  - definition A-1
  - preparation guidelines A-1–A-4
- Mean
  - Experiment Report C-6
- melting temperature
  - of fluorogenic probe, see also T<sub>m</sub> D-10
  - use of estimated D-11
- method



- defining 3-19–3-21, C-24
- editing 3-20–3-21, C-26
- MgCl<sub>2</sub> concentration D-11
- MicroAmp Optical Caps and Tubes 3-26
- MicroAmp® Optical Caps
  - preparing sample wells (illustration) 3-25
- modifying
  - graph axis C-60
  - ramp time C-29
  - spectra in graphs C-59
  - time or temperature C-28
- MSE, viewing C-44
- Multicomponent 6-10
  - axes defined C-54
  - exporting C-18
  - opening view C-55
- multicomponent
  - background C-41
  - editing pure spectra C-42
- multiple contiguous wells
  - selecting 3-15, C-9
- multiple discontinuous wells
  - selecting 3-15, C-9

## N

- Name
  - user C-23
- New Plate command 3-13, C-16
  - See also Plate Type
- Normal File format C-17
  - saving a setup 3-23
- normalized reporter 2-6, D-3
  - see also Rn
- nucleic acid
  - default quantity C-23
- number C-13
  - Stage C-13

## O

- Off-line
  - in status display C-12
- on-line help 2-8
- Open Plate command C-17
- operating Sequence Detector C-40
  - power switch 3-5
- Optical Caps and Tubes 3-26
  - illustration 3-25
  - preparing sample wells 3-25
- Options command, using to set
  - Analysis options C-49

## P

- Page Setup command 3-24, C-22
- PCR
  - optimization guidelines D-17
  - volume, default C-23
- PCR threshold, criteria 5-2

- performance specifications
  - sample volume 3-20, C-23
- plate document
  - features C-3–C-13
  - size of saved file C-32
  - transferring setup to new plate C-20
- Plate Read Only
  - analysis features 2-6
  - data analysis 2-4
  - data collection 2-4
  - Run Type C-16
- Plate Type
  - Allelic Discrimination 2-4, C-16
  - Background C-16
  - Dual Reporter C-16
  - in Preferences C-22
  - new C-16
  - Pure Spectra C-16
  - selecting 3-3, 3-13
  - Single Reporter 2-4, C-16
- Plate Types
  - Table of features 2-4
- Plus/Minus Scoring 5-1, 5-2
- power switch 3-5
- Preferences C-22
  - data collection C-23
  - default unit of measure C-23
  - establishing connection C-23
  - Instrument types C-22
  - Plate Type 3-13, C-22
  - quantity units 3-17
  - Run Type C-23
  - Running checkbox 3-6
  - User Name C-23
- primer hybridization D-10
- printing
  - Experiment Report 5-6
  - options C-22
  - Raw Spectra over time C-56
  - sample map 3-24
  - Standard Curve C-58
- probe, fluorogenic
  - hybridization D-10
  - purity and quenching D-9
  - recommended length D-11
  - structures to avoid D-9
  - T<sub>m</sub> D-10
- probe-primer hybrids D-10
- Pure Spectra
  - Editor C-41
  - exporting C-18
  - plate type C-16
- pure spectra
  - active C-42
  - components 3-10, C-40, C-44
  - discarding C-41
  - in saved plate document C-17
  - viewing raw spectra 3-10
- Pure Spectra plate type

- sample types required C-37
- samples types required C-37

## Q

- quantity
  - default unit C-23
  - entering knowns 3-18
  - scientific notation C-6
  - units 3-17
- Quantity display C-48
- Quantity field C-6
- Quencher dye D-7
  - placement D-10
  - proximity to Reporter D-9
  - setting in Setup View C-35
- quick review of setup 3-1

## R

- radiolabeled samples 3-29
- RAM 6-6
- ramp
  - definition C-25
- ramp time
  - definition 3-20, C-29
  - maximum C-29
  - minimum C-29
  - modifying 3-20, C-29
- Ramping
  - in status display C-12
- Raw Spectra 2-6
  - viewing Fit C-55
  - viewing pure dyes 3-10
- raw spectra
  - viewing Fit C-50
- Reading
  - in Raw Spectra view C-56
- Real Time
  - analysis features 2-6
  - data analysis 2-4
  - data collection 2-4
  - Run Type C-16
- rebuilding the Macintosh desktop 6-2
- Reference dye C-35
- remaining
  - in status display C-12
- removing
  - Data Collection icon 3-21, C-32
  - spectra in graphs C-59
  - Step, Cycle, or Hold C-27
- repetition
  - and data collection C-32
  - counting cycles C-13
- Replicate field C-6
- DRn
  - display C-48
- Reporter dye D-7
  - in Amplification Plot C-53
  - in Sample Type Palette 3-14
  - in Sample Type Setup C-34

- Reporter dye layer 2-7
- reporter dye, how to change C-35
- reviewing data 5-6
- Rn 2-6
  - and data analysis 2-4
  - display C-48
- row of wells
  - selecting 3-15, C-9
- run
  - starting C-40
  - stopping C-40
- Run command C-40
- Run Type
  - in Preferences C-23
  - Plate Read Only 2-4, 2-6
  - Plate Read only C-16
  - Real Time 2-4, 2-6, C-16
  - selecting 3-3
- Running preferences C-23

**S**

- Sampl. Temp. C-12
- Sample (Well) 3-12
- sample attributes 3-17
  - Sample Type Setup C-34
- sample block C-11
  - temperature range C-30
- Sample List
  - deleting information C-38
  - editing C-35
  - Sample Type Setup C-33
- Sample Name
  - Setup view C-6
- sample name
  - changing C-34
- Sample Setup Type dialog box
  - adding sample list
    - information C-38
  - removing sample list
    - information C-38
- sample tray
  - assembly 3-25
  - position on heating block 3-29
- sample tray, assembly
  - illustration 3-25
- sample tubes 3-26
- Sample Type
  - assign to wells 3-3
  - designating dyes 3-3
  - displaying on Analysis view C-49
- Sample Type Palette 3-3
  - modifying Sample List 3-14, C-33
  - Sample List C-33
  - source of entries 3-14
- Sample Type pop-up
  - assigning samples to wells 3-14
  - modifying Sample List 3-14
  - source of entries 3-14
- Sample Type Setup C-33
- Acronym C-34
  - and dye layers 2-7
  - changing color C-34
  - modifying Sample Type
    - Palette 3-14
  - Reporter dye C-34
  - Sample List C-33
- Sample Type Setup dialog box
  - master list of sample types C-36
- sample types
  - displaying master list of all
    - samples C-36
- sample volume
  - and performance
    - specifications 3-20
  - designating default 3-20
- sample wells
  - Optical Caps and Tubes 3-25, 3-26
  - Optical Tubes 3-26
- samples
  - assigning to wells 3-3
  - editing the attributes C-35
  - radiolabeled 3-29
- Save As command C-17
- Save command 3-23, C-17
- saving
  - as Stationery C-17
  - in normal file format C-17
- saving a setup 3-23
- scale
  - modifying graph axis C-60
- scientific notation C-6
- select
  - dyes for Sample Types 3-3
- selecting
  - connection to instrument 3-6
  - Plate Type 3-3
  - Run Type 3-3
- selecting wells
  - an entire row or column 3-15, C-9
  - multiple contiguous 3-15, C-9
  - multiple discontinuous 3-15, C-9
- Sequence Detector
  - connecting C-23
  - starting run C-40
  - status C-12
  - stopping a run C-40
- Setup
  - default unit of measure C-23
- setup file, importing C-21
- Setup menu C-24–C-39
  - adding sample list
    - information C-38
  - displaying master list of sample
    - types C-36
  - editing sample attributes C-35
  - removing sample list
    - information C-38
- Setup Pure Spectra C-42, C-43
- Setup view C-6–C-9
  - comments 3-4, 3-22, C-7
  - features C-3–C-9
  - method 3-3, C-24
  - Replicate field C-6
  - saving 3-23
  - saving as stationery 3-23
  - Thermal Cycler Conditions 3-3
- shortcuts, keyboard C-14
- Show
  - Analysis view C-7
  - Data Collection C-24
  - Setup view C-7
  - Time and Temperature C-24
- Single Reporter plate type C-16
  - sample types required C-37
  - with IPC, sample types
    - required C-37
- software bugs, known 6-6
- software questions 2-8
- spectra component C-40, C-41
  - extract C-41
- spectra, pure
  - active C-42
- spectral bin C-18
- spectrograph
  - function D-3
- Stage
  - definition C-25
  - illustration C-25
  - status field C-12
- Standard
  - entering quantity 3-18, C-6
- Standard Curve 2-6
  - exporting C-18
  - number of knowns 3-16
  - printing C-58
- starting
  - Sequence Detector C-40
- Stationery File format
  - features C-17
  - saving a setup 3-23
- status display C-12
  - Stage status C-12
  - thermal cycler status C-12
- Std. Dev.
  - Experiment Report C-6
- Step
  - adding C-26
  - default configuration C-27
  - definition C-25
  - deleting C-27
  - in status display C-13
  - modifying temperature and
    - time C-28
  - placement of new C-27
- stopping a run C-40
  - data handling C-11
- Success

in status display C-11, C-12  
System requirements 6-6

## **T**

### Table

data locations 5-4, 5-8  
default configurations C-27  
keyboard shortcuts C-14  
placement of Steps, Cycles, and  
Holds C-27

Plate Type features 2-4

TAMRA D-7

TaqMan Allelic® Discrimination  
Demonstration Kit 4-11

TaqMan fluorogenic probe  
design D-7

### temperature

changing C-28  
decrement 3-20  
increment 3-20  
increment or decrement C-31  
melting, of probe D-10  
modifying a method C-28  
plateau C-25  
range of sample block C-28  
rate of change 3-20  
sample, during PCR C-12  
starting a run C-11  
thermal cycler cover C-12

Temperature Verification 6-6

test tray 6-8

TET D-7

Thermal Cycler 6-6, 6-10

### thermal cycler

method 3-19, 3-20, 3-21  
status C-12, C-13

### Thermal Cycler

Conditions 3-19–3-21,  
C-24–C-32  
defining a method 3-3  
Show Data Collection C-24  
Show Time and  
Temperature C-24  
viewing 3-19

threshold cycle 2-4, 2-6, C-57  
on Standard Curve C-57  
See also CT

### time

changing C-28  
decrement 3-20, C-31  
increment 3-20, C-31  
modifying a method C-28  
ramp C-25  
recommended extension C-28  
status of PCR C-12, C-13

### tissue homogenates

DNA purification B-1

### Tm

of fluorogenic probe D-10, D-11  
use of estimated D-11

### toggling

plate document views C-7  
spectra displays C-59  
toolbox, using on Allelic Discrimination  
results C-51  
Troubleshooting 6-1  
turning on instrument 3-5

## **U**

Undo command C-22  
unit of measure, default C-23  
user attention words 1-2  
User Name  
Experiment Report C-23  
Preferences C-23

## **V**

View Background Component C-41  
Virtual Memory 6-6  
Voltage and Frequency  
Configuration 6-6  
volume  
default C-23  
designating default sample 3-20

## **W**

### Waiting

in status display C-11, C-12

### wavelength

measured range C-18

### well features

contents C-23  
quantity 3-18

### wells

assigning samples 3-3

### whole blood

DNA purification B-1

### window

Amplification Plot C-52–C-54  
Analysis view C-10–C-13  
Event Log C-63  
Experiment Report C-62  
Multicomponent C-55  
Raw Spectra C-55  
Setup view C-3–C-9

### words in well

quantity 3-18





---

**Headquarters**

850 Lincoln Centre Drive  
Foster City, CA 94404 USA  
Phone: +1 650.638.5800  
Toll Free: +1 800.345.5224  
Fax: +1 650.638.5884

**Worldwide Sales Offices**

Applied Biosystems vast distribution and service network, composed of highly trained support and applications personnel, reaches into 150 countries on six continents. For international office locations, please call our local office or refer to our web site at [www.appliedbiosystems.com](http://www.appliedbiosystems.com).

---

**[www.appliedbiosystems.com](http://www.appliedbiosystems.com)**

---



Applera Corporation is committed to providing the world's leading technology and information for life scientists. Applera Corporation consists of the Applied Biosystems and Celera Genomics businesses.

Printed in the USA, 01/2001  
Part Number 904989B

an **Applera** business