# **HUAWEI** MediaPad T2 7.0 User Guide



2 Getting started	2
Locking and unlocking the screen	2
Notification and status icons	2
Common keys	3
Home screen operations	3
Text input	5
Editing Text	5
Selecting an input method	5
Network connection	6
Connecting to a Wi-Fi network	
Connecting to a Wi-Fi network using WPS	
Turning on your mobile data connection	6
Network sharing	7
Sharing your data connection using a Wi-Fi hotspot	
Sharing your data connection through USB tethering	
Sharing your data connection through Bluetooth tethering	7
Contacts	9
Creating a contact	9
Synchronizing contacts	9
Importing contacts	
Backing up contacts	
Sharing contacts	10
Calls	11
Making an emergency call	
Making a conference call	
Adding an unknown number to your contacts	
Adding an unknown number to your contacts  Clearing call logs	11
Clearing call logs  Messaging	12
Clearing call logs  Messaging  Searching for a message	12
Clearing call logs  Messaging	12
Clearing call logs  Messaging  Searching for a message  Customizing message settings	12 12
Clearing call logs  Messaging  Searching for a message	12 12 12

10 Multimedia	14
Importing photos	14
Viewing photos or videos	14
Sharing photos or videos	15
11 Customized settings	16
Changing the theme	
Adding a widget to the home screen	
Setting the ringtone	
Setting the font size	17
Adjusting the screen brightness	17
Setting the file safe	17
12 File sharing	18
Sharing files using Wi-Fi Direct	
Sharing files using Bluetooth	
Copying files from a computer	
13 Settings	20
Setting the screen timeout period	
Setting a screen lock	
Adjusting the volume	
Enabling power saving mode	
Checking the memory status	
Setting the date and time	
Formatting a microSD card	21
Restoring factory settings	21
Updating your HUAWEI MediaPad T2 7.0	21
14 Personal Information and Data Security	22
15 Legal Notice	

# 1 About this document

Thank you for choosing the HUAWEI MediaPad T2 7.0.

This document is intended for HUAWEI MediaPad T2 7.0 that runs EMUI 4.0.

Figures in this document are screenshots taken under the **Spectrum(magazine)** theme. Switch to the **Spectrum(magazine)** theme to better understand this guide. For details, see **Changing the theme**.



Certain functions may vary with models and regions.

### 2 Getting started

#### Locking and unlocking the screen

- Locking the screen: If your HUAWEI MediaPad T2 7.0 has been idle for a specified period of time, the screen locks itself automatically. You can also press the power button to lock the screen.
- On the home screen, touch
- Unlocking the screen: Press the power button to turn on the screen. Slide your finger toward any direction to unlock the screen.

#### **Notification and status icons**

The notification and status bars may display the following icons to inform you of your  ${\sf HUAWEI}$  MediaPad T2 7.0's status.

<b>*</b>	Airplane mode	*	Bluetooth on
9	GPS in use	<b>*</b>	Charging
	Battery full	1	Battery extremely low
$\searrow$	New email	((0))	Wi-Fi hotspot on
ū	SIM card not inserted		Preparing the microSD card
	Headset connected	(L)	Alarms enabled
<u>†</u>	Uploading or sending files	<u>+</u>	Downloading or receiving files
	Memory full	A	System exception
43	Synchronizing data	₹ <u>ĵ</u> }	Synchronization failed
•	Connected to a VPN	<b></b>	USB tethering on
(î;	Wi-Fi networks available	(î.	Connected to a Wi-Fi network
	USB debugging on		

#### **Common keys**

$\equiv$	Menu	ک	Share
<b>/</b>	Completed	+	Add
Q	Search	Ш	Delete data
$\mathcal{C}$	Refresh		Save
$\Diamond$	Favorites	C	Call

#### Home screen operations

- To open an application: On the home screen, touch the application.
- To switch between the home screen and its extensions: On the home screen, flick your finger left or right.
- Personalizing the home screen: Touch and hold a blank area on the home screen or pinch two fingers together to set the wallpaper, widgets, and more.



 Opening the notification and shortcut panels: Slide down from the status bar to open the notification panel. Flick left or right to switch between the notifications and shortcuts tabs.



- Touch a notification to view its details and flick left or right across a notification to dismiss it.
- Touch to delete all notifications.
- 3 Drag the slider to adjust the screen brightness.

Touch the shortcut switches on the notification panel to turn on or off the functions. Touch and hold a switch to enter the settings screen of the corresponding function.

Slide down the shortcut switches, you can then touch **Edit** to customize the list.

# 3 Text input

Your HUAWEI MediaPad T2 7.0 comes with multiple input methods. You can quickly enter text using the onscreen keyboard.

- Touch a text input field to bring up the onscreen keyboard.
- When you are done, touch to hide the onscreen keyboard.

#### **Editing Text**

You can copy, cut, and paste text.

- Select text: Touch and hold the text field until
   and appear. Drag and
  - to select the text you want to edit, or touch **Select all** to select all text.
- Copy text: After selecting text, touch Copy.
- Cut text: After selecting text, touch Cut.
- Paste text: Touch where you want to insert the text (to move the insertion point, drag
  - ) and touch **Paste** to paste the text you copied or cut.


### Selecting an input method

The HUAWEI MediaPad T2 7.0 provides multiple ways to text input. You can select the input method you like.

- 1. On the text editing screen, touch a text field to bring up the onscreen keyboard.
- 2. Flick down from the notification bar to display the notification panel.
- 3. On the notification panel, touch Select input method.
- 4. On the displayed option menu, select the desired input method.

# 4 Network connection

#### Connecting to a Wi-Fi network



- 1. On the home screen, touch Settings > Wi-Fi.
- Toggle the switch of Wi-Fi to turn on Wi-Fi. Your HUAWEI MediaPad T2 7.0 then scans for available Wi-Fi networks.
- 3. Select the desired Wi-Fi network and follow the onscreen instructions.
- To connect to a Wi-Fi network that has a hidden SSID, touch **Add network** under the Wi-Fi network list, and then follow the onscreen instructions to enter the required information and connect to that network.

Your HUAWEI MediaPad T2 7.0 consumes more power when Wi-Fi is turned on. To save battery power, turn off Wi-Fi when it is not in use.

### Connecting to a Wi-Fi network using WPS

If the wireless router being used supports the Wi-Fi protected setup (WPS) function, you can quickly connect to a Wi-Fi network using WPS.

- 1. On the home screen, touch Settings > Wi-Fi.
- 2. Toggle the switch of Wi-Fi to turn on Wi-Fi.
- Touch => Advanced settings > WPS connection or WPS PIN connection, and follow the onscreen instructions for operations to perform on the wireless router.

### Turning on your mobile data connection

Using mobile data services may incur data usage charges. For details, contact your service provider.

- 1. On the home screen, touch Settings > More > Mobile network.
- 2. Toggle the **Mobile data** switch to to enable mobile data.

# 5 Network sharing

You can use various methods to share your HUAWEI MediaPad T2 7.0's data connection with other wireless devices.

### Sharing your data connection using a Wi-Fi hotspot

By setting up your HUAWEI MediaPad T2 7.0 as a Wi-Fi hotspot, you can share your mobile network with other devices.

Before sharing your data connection, turn on mobile data on your HUAWEI MediaPad T2 7.0. For details, see Turning on your mobile data connection.

When other devices access the Internet using your HUAWEI MediaPad T2 7.0's data connection, the data usage of your HUAWEI MediaPad T2 7.0 will be consumed.

- 1. On the home screen, touch
- 2. Touch More > Tethering & portable hotspot > Portable Wi-Fi hotspot.
- 3. Toggle the switch to turn on your Wi-Fi hotspot.
- Touch Configure Wi-Fi hotspot and follow the onscreen instructions to set the required information, such as your Wi-Fi network name and password.

Once the Wi-Fi hotspot settings are complete, other Wi-Fi enabled devices can search for and connect to the Wi-Fi hotspot provided by your HUAWEI MediaPad T2 7.0.

### Sharing your data connection through USB tethering

You can share your HUAWEI MediaPad T2 7.0's network with a computer using a single USB cable


- Connect your HUAWEI MediaPad T2 7.0 to a computer using the USB cable provided with the HUAWEI MediaPad T2 7.0.
- 2. On the home screen, touch Settings > More > Tethering & portable hotspot.
- 3. Touch USB tethering to share your mobile data connection.

After the connection is set up, you can access the Internet from the computer.

When using the USB tethering function, you cannot simultaneously use your HUAWEI MediaPad T2 7.0 as a USB storage device.

### Sharing your data connection through Bluetooth tethering

With Bluetooth tethering, you can share your HUAWEI MediaPad T2 7.0's data connection with other Bluetooth devices.




- 2. Touch Bluetooth tethering to turn on Bluetooth tethering.
- 3. Enable Bluetooth on the other device and pair your HUAWEI MediaPad T2 7.0 with it.

### 6 Contacts

#### **Creating a contact**

- On the home screen, touch

  Contacts to display your contacts list.
- 2 Touch +



- Enter the related information, such as the contact's name, phone number, and email address.
- 4. Touch Add another field to add more information.
- **5.** Touch ✓.

### Synchronizing contacts

You can synchronize the contacts stored in your Gmail and Exchange accounts to your HUAWEI MediaPad T2 7.0 and vice versa.

- 1. On the home screen, touch Settings
- 2. Under Accounts, touch the type of account you want to synchronize.
- 3. Touch the account you want to synchronize.
- **4.** Toggle the **Sync contacts** switch to ...

If the account you want to synchronize has not been added to your HUAWEI MediaPad T2 7.0, touch **Add account** and follow the onscreen instructions to add the account. When it is added, your HUAWEI MediaPad T2 7.0 automatically synchronizes with it.

#### Importing contacts

You can import contacts from a micro-SIM or microSD card to your HUAWEI MediaPad T2 7.0, or use Wi-Fi Direct to import the contacts from other devices to your HUAWEI MediaPad T2 7.0.

- 1. On the home screen, touch Contacts to display your contacts list.
- 2. Touch = > Import/Export.
- 3. Select an import method and follow the onscreen instructions.

#### **Backing up contacts**

You can back up your contacts to a microSD card in case your contacts are accidentally deleted or lost.



- 2. Touch  $\equiv$  > Import/Export.
- 3. Touch Export to storage.

#### **Sharing contacts**

You can share contacts in your HUAWEI MediaPad T2 7.0 with your friends using email, Bluetooth, and more.

- 1. On the home screen, touch Contacts.
- 2. From the contacts list, you can:
- ullet Touch the contact you want to share, and then touch  $\equiv$  > Share contact.
- Touch ≡ > Import/Export > Share contacts, select the contacts you want to share, and touch <sup>L</sup>.
- In the displayed dialog box, choose a sharing mode and follow the onscreen instructions to share the contacts.

### 7 Calls

#### Making an emergency call

In the event of an emergency, you can make emergency calls without a SIM card. However, you must still be within the coverage area.

1. On the home screen, touch



2. Enter a local emergency number and touch



Emergency calls are subject to the quality of the cellular network, use environment, service provider policies, and local laws and regulations. Never rely solely on your HUAWEI MediaPad T2 7.0 for critical communications when emergencies occur.

#### Making a conference call

Making conference calls with your friends, family, and co-workers is easy with your HUAWEI MediaPad T2 7.0.



Before you make a conference call, be sure you have subscribed to the conference call service. For details, contact your service provider.

- 1. Call the first participant.
- **2.** When the call is connected, touch + and call the second participant. The call with the first participant is put on hold.
- **3.** When the second call is connected, touch **\(\beta\)** to start a conference call.
- 4. To add more participants, repeat steps 2 and 3.

When the call is complete, touch to end it.



### Adding an unknown number to your contacts

- 1. On the home screen touch
- 2. From the call log, touch in next to the unknown number.
- 3 Touch + or △

### Clearing call logs

To delete a single call log entry: On the Dialer screen, touch and hold the call log entry. On the displayed option menu, touch Delete entry.

To delete all or multiple call log entries: On the **Dialer** screen, touch = > **Delete call log**.

- Select the **Select all** check box and touch to delete all call log entries.
- Ш Select one or more call logs and touch

### 8 Messaging

#### Searching for a message

If you are having trouble finding a specific message in a pile of messages, this function can come to your rescue.

Messaging.



- 1. On the home screen, touch
- 2. Enter a keyword in the search box.
- 3. In the results list, select the desired message to open it.

### **Customizing message settings**

To customize text and multimedia message settings, message notification tones, and more, from the message list, touch  $\equiv$  > **Settings**.

# 9 Managing applications

#### Installing an application



When you install an application, the "Install blocked" message may be displayed. Read the message carefully. If you want to continue with the installation, follow the onscreen instructions.

You can obtain and install an application using any of the following methods:

- Download it from an online app store or by using a browser. After the application is downloaded, follow the onscreen instructions to install it.
- Some third-party applications may not be compatible with your HUAWEI MediaPad T2 7.0. They may not run properly and your HUAWEI MediaPad T2 7.0 may shut down. It is recommended that you download applications from trusted sources only.
- Connect your HUAWEI MediaPad T2 7.0 to a computer. Then use the HiSuite or thirdparty software to download the application. After the application is downloaded, follow the onscreen instructions to install it.
- Use Bluetooth or Wi-Fi Direct to send the application on another device, such as a
  phone or tablet, to your HUAWEI MediaPad T2 7.0. After the transmission is complete,
  touch the application to install it.
- Download the application from a computer. Then copy the application to your HUAWEI

MediaPad T2 7.0. Once copied, touch Files on your HUAWEI MediaPad T2 7.0's home screen. Touch Applications > Apps under Categories, select the application and then follow the onscreen instructions to complete the installation.

### Uninstalling and sharing an application

On the home screen, touch and hold the application you want to uninstall or share.

- Drag it to iii to uninstall the application.
- Drag it to  $\stackrel{2}{\sim}$  to share the application.
- •

Some pre-installed applications cannot be uninstalled.

### 10 Multimedia


#### Importing photos

You can import photos from a camera or other storage device (such as a USB flash drive or phone) to your HUAWEI MediaPad T2 7.0 using only a USB OTG cable.



To purchase a USB OTG cable, please contact an Huawei authorized supplier or your device vendor.

1. Use a USB OTG cable to connect a camera and your HUAWEI MediaPad T2 7.0.



- 2. On your HUAWEI MediaPad T2 7.0's home screen, touch Files > Local > USB.
- Touch and hold the photos or folders you want to import into your HUAWEI MediaPad T2 7.0.
- 4. Touch Copy or Move.
- 5. Choose where you want to save the files and touch Paste.

#### Viewing photos or videos

Gallery enables you to conveniently view photos and videos. It automatically searches and organizes photos and videos stored on your HUAWEI MediaPad T2 7.0's internal storage and the microSD card for your easy reference.

- 1. On the home screen, touch Gallery to open Gallery.
- Touch a photo or video to view it in full screen mode. Flick your finger left or right across the screen to view the previous or next file.
  - You can pinch two fingers apart or together to zoom in or out.

### **Sharing photos or videos**

You can share photos and videos via Bluetooth or email. Take your HUAWEI MediaPad T2 7.0 and start sharing!



- 2. Touch and hold the photo, video you want to share .
- 3. Touch on and choose how you want to share the selected file, for example, using Bluetooth or Wi-Fi Direct. Then follow the onscreen instructions. For details, see File sharing.

# 11 Customized settings

#### Changing the theme

Your HUAWEI MediaPad T2 7.0 comes with multiple themes, easily allowing your device to have a new look as often as you want.

- 1. On the home screen, touch
- Flick left or right to browse different local and online themes. (Applicable to selected models)
- **3.** Select the desired theme. Then, touch  $\square$ .

#### Adding a widget to the home screen

You can add widgets, such as the calendar and bookmarks, to the home screen.

- 1. On the home screen, touch and hold a blank area.
- 2. Touch Widgets.
- 3. Drag a widget to the home screen and release your finger.



### Setting the ringtone

- 1. On the home screen, touch Settings > Sound
- 2. Select the desired ringtone type.

Follow the onscreen instructions to select your favorite music or recording as the ringtone.

#### Setting the font size



- 1. On the home screen, touch
- 2. Touch Font size.
- 3. Select the desired font size.

#### Adjusting the screen brightness

- 1. On the home screen, touch Settings > Display > Brightness.
- In the displayed dialog box, Drag the slider left or right to manually adjust the screen brightness.
  - You can also open the notification panel and quickly adjust the screen brightness using the shortcut switch.

### Setting the file safe

The file safe helps you keep your important files private and protected.

- 1. On the home screen, touch
- 2. Under Categories or Local, touch Safe.
- 3. Touch Enable
- Follow the onscreen instructions to set up your safe password and security question, and then touch Done.
- 5. Touch Add.
- 6. Follow the onscreen instructions and select the files you want to add to the safe.
- 7. Touch ADD to add the files to the safe.
  - Enter the file safe, touch **Settings** > **Destroy safe**, and follow the onscreen instructions to destroy the safe. To remove any files before destroying the safe, select **Remove files**.

### 12 File sharing

#### **Sharing files using Wi-Fi Direct**

Wi-Fi Direct is a function to connect wireless devices using a Wi-Fi network. After wireless devices are connected, they can quickly share files among them.

- 1. On the home screen, touch Settings > Wi-Fi.
- 2. Touch the key next to Wi-Fi or drag the key to To turn on Wi-Fi.
- 3. Touch <sup>1</sup>/<sub>₹</sub>. On the receiving device, turn on Wi-Fi Direct. Your HUAWEI MediaPad T2 7.0 then automatically searches for available devices.
- 4. Select the device to pair it with your HUAWEI MediaPad T2 7.0.
- On your HUAWEI MediaPad T2 7.0, touch and hold the file you want to share. On the displayed option menu, touch Share > Wi-Fi Direct.
- On the displayed option menu, select the desired device, and lastly, touch the key on the device to receive the file.
- If your HUAWEI MediaPad T2 7.0 and the device have connected to the same Wi-Fi network and both have Wi-Fi Direct turned on, you can directly share files between them without pairing them.

#### **Sharing files using Bluetooth**

- 1. On the home screen, touch Settings > Bluetooth.
- 2. Touch the key next to Turn on Bluetooth or drag the key to \_\_\_\_ to turn on Bluetooth.
- 3. Select the device to pair your HUAWEI MediaPad T2 7.0 and the device.
- On your HUAWEI MediaPad T2 7.0, touch and hold the file you want to share. On the displayed option menu, touch Share > Bluetooth.
- On the displayed option menu, select the desired device. On the device, touch the related key to receive the file.

### Copying files from a computer

Use a USB cable to connect your HUAWEI MediaPad T2 7.0 to a computer. Flick down from the status bar to open the notification panel. Follow your HUAWEI MediaPad T2 7.0's onscreen instructions to select a connection method. You can then transfer files between your HUAWEI MediaPad T2 7.0 and the computer.

Connecti on Mode	Function	Operation
Photos	On the computer, view and manage the image files stored on your HUAWEI MediaPad T2 7.0.	Click the newly displayed drive letter on the computer. Then transfer image files between your HUAWEI MediaPad T2 7.0 and the computer.

Connecti on Mode	Function	Operation
Files	On the computer, view and manage the files stored on your HUAWEI MediaPad T2 7.0 and the microSD card.  Using Windows Media Player 11 or a later version in the computer, view and manage the multimedia files stored on your HUAWEI MediaPad T2 7.0 and the microSD card.	Click the newly displayed drive letter on the computer. Then transfer files between your HUAWEI MediaPad T2 7.0 and the computer. Start Windows Media Player on the computer. Follow the onscreen instructions to transfer multimedia files between your HUAWEI MediaPad T2 7.0 and the computer.
USB drive	On the computer, view and manage the files stored on the microSD card.  This method is available only when your HUAWEI MediaPad T2 7.0 has a microSD card inserted.	Click the newly displayed drive letter on the computer. Then transfer files between the microSD card and the computer.

# 13 Settings

#### Setting the screen timeout period

You can set a screen timeout period so your HUAWEI MediaPad T2 7.0 automatically turn offs the screen to save power.

- 1. On the home screen, touch Settings > Display > Sleep.
- 2. Choose a timeout period.

#### Setting a screen lock

- 1. On the home screen, touch Settings > Screen lock & passwords.
- 2. Follow the onscreen instructions to set the screen lock.

With a screen lock set, if your HUAWEI MediaPad T2 7.0 is idle for a specified period of time, it automatically locks its screen. You can also touch the power key to lock the screen.

#### Adjusting the volume

You can set the volume for the ringtone, media, alarms, and notifications.

- 1. On the home screen, touch Settings > Sound > Volume.
- 2. Drag the sliders left or right to adjust the volume.

You can also use the volume keys to adjust the volume of running applications.

#### **Enabling power saving mode**

- On the home screen, touch Power plan.

  Settings > Advanced settings > Battery manager > Power plan.
- Select a power saving mode.

#### Checking the memory status

Before moving a large file to your HUAWEI MediaPad T2 7.0's internal storage or the microSD card, check the available storage space that has left on it.

- 1. On the home screen, touch Settings
- 2. Touch Advanced settings > Memory & storage to view memory information.

#### Setting the date and time

- 1. On the home screen, touch Settings > Advanced settings > Date & time.
- Deselect the Automatic date & time check box.
- 3. Follow the onscreen instructions to set the date and time.



If your HUAWEI MediaPad T2 7.0 is set to automatically update the date and time, it obtains the date and time information from the network and updates them according to your time zone. In this case, you cannot manually change the time zone, date, or time displayed on your HUAWEI MediaPad T2 7.0.

#### Formatting a microSD card



Back up important data before you format a microSD card.





2. Touch Advanced settings > Memory & storage > SD card > Format.

#### **Restoring factory settings**



Restoring your HUAWEI MediaPad T2 7.0 to its factory settings erases all your personal data, including information about your accounts, your system and application settings, and your installed applications. Before restoring factory settings, back up the important data on your HUAWEI MediaPad T2 7.0.

- 1. On the home screen, touch Settings > Advanced settings > Backup & reset.
- Touch Factory data reset and follow the onscreen instructions to back up data or directly restore factory settings.

#### Updating your HUAWEI MediaPad T2 7.0



- Updating your HUAWEI MediaPad T2 7.0 may clear all the data in it. Back up important data before updating your HUAWEI MediaPad T2 7.0.
- Using unauthorized third-party software to update your HUAWEI MediaPad T2 7.0 may render your HUAWEI MediaPad T2 7.0 unusable or put your personal information at risk. Always update through your HUAWEI MediaPad T2 7.0's online update feature or send your HUAWEI MediaPad T2 7.0 to a nearby authorized Huawei service center for assistance.
- **1.** On the home screen, touch Settings > Updater to view the system information.
- Touch Check for updates. If a new version is available, follow the onscreen instructions
  to update online. You can also choose = > Download latest full package to update
  the system using a local update package.
- To update using a local update package, refer to the update guide included in the package.

# 14 Personal Information and Data Security

The use of some functions or third-party applications on your device could result in your personal information and data being lost or becoming accessible to others. Several measures are recommended to help you protect personal and confidential information.

- Place your device in a safe area to prevent it from unauthorized use.
- Set your device screen to lock and create a password or unlock pattern to open it.
- Periodically back up personal information kept on your memory card, or stored in your device memory. If you change to a different device, be sure to move or delete any personal information on your old device.
- If you are worried about viruses when you receive messages or emails from a stranger, you can delete them without opening them.
- If you use your device to browse the Internet, avoid websites that might pose a security risk to avoid theft of your personal information.
- If you use services such as Wi-Fi or Bluetooth, set passwords for these services to prevent unauthorized access. When these services are not in use, turn them off.
- Install or upgrade device security software and regularly scan for viruses.
- Be sure to obtain third-party applications from a legitimate source. Downloaded thirdparty applications should be scanned for viruses.
- Install security software or patches released by Huawei or third-party application providers.
- Some applications require and transmit location information. As a result, a third-party may be able to share your location information.
- Your device may provide detection and diagnostic information to third-party application providers. Third party vendors use this information to improve their products and services.
- If you have concerns about the security of your personal information and data, please contact mobile@huawei.com.

# 15 Legal Notice

#### Copyright © Huawei Technologies Co., Ltd. 2016. All rights reserved.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd. and its affiliates ("Huawei").

The product described in this manual may include copyrighted software of Huawei and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders.

#### **Trademarks and Permissions**



HUAWEI, HUAWEI, and Technologies Co., Ltd.



are trademarks or registered trademarks of Huawei

Android™ is a trademark of Google Inc.

LTE is a trade mark of ETSI.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Huawei Technologies Co., Ltd. is under license.

Other trademarks, product, service and company names mentioned may be the property of their respective owners.

#### **Notice**

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and therefore may not be activated or may be limited by local network operators or network service providers.

Thus, the descriptions herein may not exactly match the product or its accessories which you purchase.

Huawei reserves the right to change or modify any information or specifications contained in this manual without prior notice and without any liability.

#### **Third-Party Software Statement**

Huawei does not own the intellectual property of the third-party software and applications that are delivered with this product. Therefore, Huawei will not provide any warranty of any kind for third party software and applications. Neither will Huawei provide support to customers who use third-party software and applications, nor be responsible or liable for the functions or performance of third-party software and applications.

Third-party software and applications services may be interrupted or terminated at any time, and Huawei does not guarantee the availability of any content or service. Third-party service providers provide content and services through network or transmission tools outside of the control of Huawei. To the greatest extent permitted by applicable law, it is explicitly stated that Huawei shall not compensate or be liable for services provided by third-party service providers, or the interruption or termination of third-party contents or services.

Huawei shall not be responsible for the legality, quality, or any other aspects of any software installed on this product, or for any uploaded or downloaded third-party works in any form, including but not limited to texts, images, videos, or software etc. Customers shall bear the risk for any and all effects, including incompatibility between the software and this product, which result from installing software or uploading or downloading the third-party works.

This product is based on the open-source Android™ platform. Huawei has made necessary changes to the platform. Therefore, this product may not support all the functions that are supported by the standard Android platform or may be incompatible with third-party software. Huawei does not provide any warranty or representation in connect with any such compatibility and expressly excludes all liability in connection with such matters.

#### DISCLAIMER

ALL CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL HUAWEI BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOSS OF PROFITS, BUSINESS, REVENUE, DATA, GOODWILL SAVINGS OR ANTICIPATED SAVINGS REGARDLESS OF WHETHER SUCH LOSSES ARE FORSEEABLE OR NOT.

THE MAXIMUM LIABILITY (THIS LIMITATION SHALL NOT APPLY TO LIABILITY FOR PERSONAL INJURY TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH A LIMITATION) OF HUAWEI ARISING FROM THE USE OF THE PRODUCT DESCRIBED IN THIS MANUAL SHALL BE LIMITED TO THE AMOUNT PAID BY CUSTOMERS FOR THE PURCHASE OF THIS PRODUCT.

#### Import and Export Regulations

Customers shall comply with all applicable export or import laws and regulations and be responsible to obtain all necessary governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.

#### **Privacy Policy**

To better understand how we protect your personal information, please see the privacy policy at http://consumer.huawei.com/privacy-policy.