

# Defunc TRUE GO SLIM - User Manual

Thank you for choosing the Defunc TRUE GO SLIM model. Read this manual to optimize your experience.

## Technical specifications

Bluetooth® version: 5.0

Transmission frequency: 2.4 GHz

Earbud battery: 30 mAh

Charging case: 400 mAh

Earbud recharges in charging case: 5-6 times

Active playtime: ≈ 3.5-4.5h

Standby time: ≈ 37h

Charging time: ≈ 2hrs

Speaker dimension: Dia 13mm  $25\Omega \pm 15\%$

Speaker sensitivity:  $108 \pm 3\text{dB}$ , at 1K 0.179V

Charging means: USB to Type C

Power supply bin voltage: 5V

Transmission frequency: 20hz-20khz

Codex: SBC

Rated Power for Earbuds: 3mW

Rated power for Charging case: 1.75W

**Frequency band in which the product operates==2402~2480MHz**

**Maximum radio-frequency power transmitted within above frequency band==0dBm**

Net weight: ≈ approx 42g

## What's included

Defunc True GO SLIM earbuds

USB-C charging cable

Charging case

User manual x1

Thank you cardx1

Silicon tips, 2pcs L size, 2pcs M size

## Without Hall switch

When open the charging case and take the earbuds out will automatically power on and pair to each other.

## Overview and controls

Power on: Open the cap of the charging case and take the earbuds out for auto-power on. or touch the L & R earbuds for 3 seconds to power on the earbuds.

Power off: Put the earbuds back in the charging case or touch either the right or left earbuds for 5 seconds

Auto-power off: The earbud will turned off after 5 minutes in paired mode without connected device.

Answer/end call: Double-click either the left or right earbud for pick up the phone calls or end the phone calls.

Reject call: Press either the left or right earbuds for 2 seconds to reject the call.

Play/pause: While listening to music, double-click the touch area of any earbud once for play&pause the music.

Next track: While listening to music, press the right earbud for 2 seconds to enter into next song.

Previous track: While listening to music, press the left earbud for 2 seconds to enter into next song.

Voice assistant: Triple-click on the right earbud for active the Voice Assistant, and triple-click on the right earbud again to close it.

Volume increase: once-click on the right earbud

Volume decrease: once-click on the left earbud

**Pairing**

Charge the earbuds fully before pairing it to you device for first time using.

- 1.Remove the earbuds from the charging case, the Earbuds will automatically power on and paired to each other.
2. When blue/red lights in the right earbud flashing alternatively, means earbuds are ready to be paired to your device.
3. Active Bluetooth function on your device and select Defunc TRUE GO SLIM in the Bluetooth list.

**Charging**

Charge earbuds: Put the earbuds back in charging case and close the cap.

Charging: Solid red light on case.

**Charge case**

Connect it to the power supply with USB cable.

Charging: Blue lights flashing

Charging status: Each light equals 25% charged

Charing Case and earbuds can be charged simultaneously.

For support, visit [www.defunc.com/troubleshooting](http://www.defunc.com/troubleshooting)

#### FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.