


AUDIO VIDEO SURROUND RECEIVER

KRF-V5010/V5010E/V5010W/ V6010/V6010E/V6010W/ V7010/V7010E/V7010W/ VR-205/207/255/257

SERVICE MANUAL

KENWOOD

© 1998-4/B51-5425-00 (K/K) 3484



* Refer to parts list on page 33.


KRF-V5010/V6010/V7010/VR-205/206/207/255/257

CONTENTS / ACCESSORIES

Contents

CONTENTS / ACCESSORIES	2	ADJUSTMENT	13
CONTROLS	3	PC BOARD	14
DISASSEMBLY FOR REPAIR	5	SCHEMATIC DIAGRAM	17
WIRING DIAGRAM	6	EXPLODED VIEW	32
BLOCK DIAGRAM	7	PARTS LIST	33
CIRCUIT DESCRIPTION	8	SPECIFICATIONS	47

Accessories



Model name vs remote controller

Remote controller		Model name	Destination	Battery cover
Parts number	Model name			
A70-1194-05	RC-R0607	VR-207	KP1	A09-0366-08
		VR-257	K1P2	
		VR-255	K1P2	
		KRF-V7010	Y1M1	
A70-1195-05	RC-R0507	KRF-V7010	X1E1T1	
		KRF-V7010W	Q1	
		KRF-V7010E	E2	
		KRF-V6010	E	A09-0396-08
A70-1196-05	RC-R0307	KRF-V6010W	Q1	
		KRF-V6010E	E1	
		KRF-V5010	E1T1	
		KRF-V5010W	Q1	
		KRF-V5010E	E2	
A70-1199-05	RC-R0407	VR-206	K2P3	
		KRF-V6010	M1X1	
		VR-205	KP1	
		KRF-V5010	Y1M1X1	

Resetting the Microcomputer

If the microcomputer may malfunction (unit cannot be operated, or shows an erroneous display) if the power cord is unplugged while the power is ON, or due to some other external factor. If this happens, execute the following procedure to reset the microcomputer and return the unit to its normal operating condition.

For U.S.A. and Canada


Unplug the power cord from the wall outlet, then plug it back in while holding down the POWER key.

For other countries

With the power cord plugged in, turn the POWER key OFF. Then, while holding down the ON/STANDBY key, press POWER.

- Please note that resetting the microcomputer will clear the contents of the memory and returns the unit to the state it was in when it left the factory.

CONTROLS



- 1 POWER key**
(For U.S.A. and Canada)
Use to turn the power ON/OFF.
STANDBY indicator
- 1 ON/STANDBY (1/0) key**
(Except for U.S.A. and Canada)
Use to switch the power ON/STANDBY when the POWER is turned ON.
STANDBY indicator
- 2 POWER key**
(Except for U.S.A. and Canada)
- 3 DIMMER key**
Use to adjust the brightness of the display.
- 4 P.CALL keys (Except for VR-257)**
Use to call up previously registered radio stations.
- 5 BAND key**
Use to select the broadcast band.
- 6 AUTO key**
Use to select the auto tuning mode.

- 7 MEMORY key**
Use to store radio stations in the preset memory.
- 8 VOLUME CONTROL knob**
- 9 PHONES jack**
Use for headphone listening.
- 10 SPEAKERS A key**
Use to turn speaker system A on and off.
SPEAKERS key
(VR-205, VR-255, KRF-V5010)
Use to turn the speakers on and off.
- 11 SPEAKERS B key**
Use to turn speaker system B on and off.
MUTE key
(VR-205, VR-255, KRF-V5010)
Use to temporarily mute the sound.
- 12 BASS BOOST key**
Use to select the maximum adjustment setting for the low frequency range.


- 13 VIDEO 2/MONITOR key**
- 14 SOURCE DIRECT key**
- 15 LISTEN MODE key**
Use to select the listening mode.
- 16 SOUND key**
Use to adjust the sound quality and ambience effects.
- 17 SETUP key**
Use to select the surround sound settings.
- 18 MULTI CONTROL knob**
Use to make a variety of settings.
- 19 INPUT SELECTOR knob**
Use to select the input sources.

About the STANDBY indicator

This unit has a STANDBY indicator. When the STANDBY indicator is lit, the unit consumes a small amount of power to preserve the memory. This is called STANDBY mode. This mode also lets you turn the power ON using the remote control.

CONTROLS

Remote control unit (RC-R0407)



1 Numeric keys

If CD or MD is selected as the input source, these keys function as numeric keys. If tuner is selected as the input source, these keys are used to call up station presets.

2 Input selector keys

Use to select the receiver's input source.

3 Component operation keys

Use these keys to operate other components with system control connections to the receiver.

TUNING (◀▶) keys

If tuner is selected as the input source, these keys function as tuning keys.

If CD or MD is selected as the input source, these keys function as search keys.

P.CALL (◀▶) keys

If tuner is selected as the input source, these keys function as P.CALL keys.

If CD or MD is selected as the input source, these keys function as skip keys.

◀ key

If tape is selected as the input source, this key functions as the play key for side B of the cassette (the side facing away from the front of the deck).

BAND (▶/II) key

If tuner is selected as the input source, this key functions as the band selector key.

If CD is selected as the input source, this key functions as the play/pause key.

If MD is selected as the input source, this key functions as the play key.

DISC SKIP, A/B, +100 key

If CD is selected as the input source, this key functions as the multi-CD player disc skip key.

If TAPE is selected as the input source, this key is used to switch between the two decks (A and B) of a double cassette deck.

AUTO key

If tuner is selected as the input source, this key functions as the AUTO key.

If CD or MD is selected as the input source, this key functions as the stop key.

4 LISTEN MODE key

Use to select the listening mode.

5 SOUND key

Use to adjust the sound quality and ambience effects.

6 SETUP key

Use to select the surround sound settings.

7 POWER key

Use to switch the power ON/STANDBY when the POWER is turned ON.

8 BASS BOOST key

Use to select the maximum adjustment setting for the low frequency range.

9 SOURCE DIRECT key

Use to temporarily mute the sound.

10 MUTE key


Use to make a variety of settings.

11 MULTI CONTROL key

Use to make a variety of settings.

12 VOLUME CONTROL key

Remote control unit (RC-R0607, RC-R0507)



There are some cases in which keys (or knobs) that have the same function on the receiver and on the remote control have different names. In the instructions of this manual, if the names of corresponding keys (or knobs) on the receiver and remote control are different, the name of the remote control key is indicated in parentheses.

1 POWER key

Use to turn the receiver on and off.

Use in combination with the input selector (AUDIO, VIDEO, or TV) keys and SHIFT key to turn various components on and off.

2 MACRO key

Use in combination with the AUDIO, VIDEO, or TV keys to execute a series of commands automatically (MACRO PLAY).

3 VIDEO selector key

Selects the video inputs and sets the remote control to operate the component registered at the respective input.

4 Multi control keys

Use to operate the selected component.

5 REC key

Use to operate the selected component.

6 TUNING/SKIP key

Use during the setup procedure to specify various settings. Use to operate the tuner or selected component.

7 SUBWOOFER key

Use in combination with the VOLUME +/- keys to adjust the volume of the subwoofer.

8 FUNCTION SHIFT key

Use in combination with the numeric keys to execute alternate commands.

9 Numeric keys

Provide functions identical to those of the original remote control supplied with the component you are controlling.

To access the functions printed above the keys, press within 3 seconds of pressing the FUNCTION SHIFT key. Function availability varies for each component.

10 SHIFT key

Use in combination with the AUDIO and VIDEO keys to change the remote control mode without changing the input selector or in combination with the POWER key to turn on and off components programmed into the remote control.

11 TV selector key

Sets the remote control to operate a TV or cable box. This key does not change the input selector on the receiver.

12 AUDIO selector key

Selects the audio inputs and sets the remote control to operate the respective KENWOOD audio component.

If you connect audio components from KENWOOD and other makers to the MD/TAPE or CD jacks, you can set the remote control to operate these components by registering the appropriate setup code at the respective input.

13 GUIDE key

Use to activate the OSD menu functions of registered components.

14 VOLUME key

Use to adjust the receiver volume.

15 MUTE key

Use to temporarily mute the sound.

16 SOUND key

Use to adjust the sound quality and ambience effects.

17 LISTEN MODE key


Use to select the listening mode.

18 SETUP key


Use to select the surround sound settings.

KRF-V5010/V6010/V7010/VR-205/206/207/255/257


DISASSEMBLY FOR REPAIR



1. Remove the 9 screws (①,②,③), remove the rear panel.
2. Connect the GND of the rear panel and the chassis, the GND of the mounting hardware and the chassis with 2 alligators clip (④)



BLOCK DIAGRAM



CIRCUIT DESCRIPTION

1. BACK UP DATA AND INITIAL STATE

1-1 BACK UP

(1) AMP

- POWERSTAND BY
- INPUT SELECTORTUNER
- SELECTOR FRESETNONE
- VIDEO OUTPUT.....VIDEO1
- SPEAKER A RELAYON
- SPEAKER B RELAYOFF
- VOLUME LEVEL-78dB
- BASS LEVEL.....0dB
- TREBLE LEVEL0dB
- INPUT LEVEL.....0dB
- BASS BOOSTOFF
- SOURCE DIRECTOFF
- SUB WOOFERYES
- MONITOR.....OFF
- SL16/XS8SL16
- DIMMER LEVEL.....LIGHT

(2) SURROUND

- LISTEN MODESTEREO
- INPUT MODE.....DIGITAL AUTO
- CENTER SPEAKER.....NORMAL
- SURROUND SPEAKER....YES
- DISTANCEFch 3.0m/10ft
Cch 3.0m/10ft
Sch 3.0m/10ft
- LEFT LEVEL.....0dB
- RIGHT LEVEL0dB

- CENTER LEVEL.....0dB
- REAR (LS, RS) LEVEL.....0dB
- SUB WOOFER LEVEL.....0dB
- MID NIGHTOFF

(3) TUNER

- BAND.....FM(EXCEPT VR-257)
TV (VR-257)
- FRESET CHANNEL"- -"
- FREQUENCYMINIMUM FREQUENCY
J1FM : 76.00MHz
AM : 531kHz
K1FM : 87.50MHz
AM : 530kHz
E1/E3.....FM : 87.50MHz
AM : 531kHz
Q1FM : 65.00MHz
AM : 531kHz
VR-257.....TV : 3ch
- SAP MODE.....STEREO (VR-257)
- AUTO/MANUAL.....AUTO
- DISPLAY MODE.....FREQUENCY
- EON THRUST
RECEIVING MODEOFF
- M TYPE SETTING
MODE (K2/E1)E1

1-2 INITIAL SETTING

The initial setting is performed when the AC power cord is plugged into the AC power wall outlet while pressing the power (STANDBY) key.

2. DIFFERENCE POINT OF MODEL (VR-209/207)

Model		VR-205/206 KRF-V5010/6010	VR-207/255/257 KRF-V7010	VR-208/209 KRF-V8010D
Function				
REMOCON		NORMAL REMOTE	PRESET TEMOTE	PRESET REMOTE
		RC-R0407 K, P, M, C, X, Y RC-R0307 E, T, Q	RC-R0607 K, P, M, C, Y RC-R0507 E, T, Q, X	RC-R0607 K, P, M, C, Y
SELECTOR	AUDIO	TUNER CD TAPE/MD PHONO	TUNER CD TAPE/MD PHONO	TUNER CD TAPE/MD PHONO
	VISUAL & AUDIO	VIDEO1 VIDEO2/MONITOR DVD 6ch INPUT	VIDEO1 VIDEO2/MONITOR DVD 6ch INPUT	VIDEO1 VIDEO2 VIDEO3
MONITOR	FUNCTION	VIDEO2/MONITOR	VIDEO2/MONITOR	MONITOR
	ON LEVEL	2 step (0/-6)	2 step (0/-6)	3 step (0/-3/-6)
SPEAKER		SP.A/SP.B (206) SP.1 stage (205/255)	SP.A/SP.B	SP.A/SP.B
DIGITAL AUTO		X	X	O
DOLBY DIGITAL		X	X	O
INPUT MODE (VIDEO2/ VIDEO3)		X	X	DIGITAL AUTO/ DIGITAL MANUAL/ ANALOG
LIVE, HALL		O	O	X
SOUND LEVEL		Sch	Sch	RSch/LSch
TUNER	TV & SAP	X	VR257	X
	RDS	E, T, Q	E, T, Q	X

CIRCUIT DESCRIPTION

FUNCTION DIODE MATRIX (X14-)

Model Function	VR-205/255 KRF-V5010	VR-206/207 KRF-V6010/V7010	VR-257	VR-209 KRF-V8010
DOLBY DIGITAL	X	X	X	D503
SPEAKER A only	D522	X	X	X
TV & SAP	X	X	D506	X

3. DESTINATION LIST OF TUNER

• TUNER

Destination	TUNER type	BAND	Receiving frequency range	Channel space	IF	PLL reference frequency	Diode SW			
							DSW3	DSW2	DSW1	DSW0
							D507	D505	D504	D510
K, P, R	K1 1700	FM	87.5MHz~108.0MHz	100kHz	+10.7MHz	25kHz	0	0	0	0
		AM	530kHz~1700kHz	10kHz	+450kHz	10kHz				
Y, M, I, C, V, E, X, H	E1	FM	87.5MHz~108.0MHz	50kHz	+10.7MHz	25kHz	0	0	1	1
		AM	531kHz~1602kHz	9kHz	+450kHz	9kHz				
T	E2 LW	FM	87.5MHz~108.0MHz	50kHz	+10.7MHz	25kHz	0	1	0	0
		MW	531kHz~1602kHz	9kHz	+450kHz	9kHz				
		LW	153kHz~279kHz	9kHz	+450kHz	9kHz				
E	E3 RDS	FM	87.5MHz~108.0MHz	50kHz	+10.7MHz	25kHz	0	1	0	1
		AM	531kHz~1602kHz	9kHz	+450kHz	9kHz				
Q	Q1 RDS	FM L	65.0MHz~74.0MHz	10kHz	+10.7MHz	5kHz	1	0	1	1
		FM H	87.5MHz~108.0MHz	50kHz	+10.7MHz	5kHz				
		AM	531kHz~1602kHz	9kHz	+450kHz	9kHz				

※ 0 : NONE DIODE, 1: ADD DIODE

3-1 Channel Space Selector in Broadcasting setting

1. Push the BAND key for 2 seconds in the standby mode.
2. Display shows "F100/A10kHz" or "F50/A9kHz" blinkingly for 5 seconds.
3. Turn the VOLUME knob (Encoder) to choose your channel space.
4. Push the BAND key to memorize the channel space to E2P ROM.

Note : Channel space will be set by the data from E2P ROM if reconnect the power cord..

Channel space will be set by the destination data from E2P ROM if backup data damaged.

4. TEST MODE

4-1 SETTING

Turn the power ON while pressing the [BAND] key.

4-2 CANCEL

Unplug the AC power cord from an AC power wall outlet.

4-3 STARTING ACTIVE CONTENTS

- ① The power on state is entered whenever the power is turned on while pressing the [BAND] key.
All functions are then initialized and activated in the all-lighting mode.
- ③ All lighting mode is canceled when any main unit's keys are pressed. The normal display obtained when the selector is set to TUNER then appears.

③ E2P ROM check (E, T, Q, M, V type)

Check the reading data and the writing data of the E2P ROM after setting the test mode.

Display shows blank if the reading and writing data is the same. Display shows "□" if the different.

Data (FM 50kHz, AM 9kHz, De-emphasis 50us) will be written to E2P ROM if the unit for M and V type.

4-4 ACTIVE CONTENTS

- ① The mute control is not activated when the mode is switched.
- ② The test mode will be terminated by plugging it off the power source or by initializing it, when all the settings will be initialized.
- ③ During the test mode, it can be operated in a special manner that is different from an ordinary operation by using the keys on the remote control or the main body, specifically as shown in the following table (5. contents).
- ④ Channel space will be no change if set channel space in the reset mode.

4-5 CONTENTS

TUNER (E, T, Q, RDS ONLY)


OPERATION KEY	FUNCTION	FL DISPLAY	Remarks
PTY	• S LEVEL • RF ATT	(EXP.) (1) (S LEVEL), (RF ATT) OFF (2) (S LEVEL), (RF ATT) ON (3) (NORMAL), (RF) ATT OFF	(1) (2) ← (3) CYCLIC
DISPLAY	P. CALL UP	P. CALL FREQUENCY	
BASS BOOST	P. CALL DOWN		

CIRCUIT DESCRIPTION

EXCEPT TUNER (BELOW ※ : TONE, CH. LEVEL is selected SOUND key.)

OPERATION KEY	INPUT LEVEL	FUNCTION	FL DISPLAY
※ BAND	-6dB	BASS, TREBLE	-10dB
		each CH.	-89dB
※ AUTO	-3dB	BASS, TREBLE	+10dB
		each CH.	0dB
※ MEMORY	0dB	BASS, TREBLE	0dB
		each CH.	-78dB
P. CALL ∨	—	MUTE	ON OFF
P. CALL ∧	—	CH. DELAY TIME	DMAX DMIN

5. Microprocessor periphery diagram



CIRCUIT DESCRIPTION

6. Microprocessor pin description

Pin No.	Pin name	I/O	Description	Active
1, 2	G10~G11	O	FL (11-MT-116GK) GRID 10, 11	
3	—	—	Unused	
4	RDS. CK	I	RDS IC (SAA6579) clock input control	
5	RDS. DT	I	RDS IC (SAA6579) data input control	
6	—	I	Unused	
7	VOL. ENC. A	I	Volume encoder A (CW) signal	
8	REMOCON	I	Remote control	
9	VOL. ENC. B	I	Volume encoder B (CCW) signal	
10, 11	—	O	Unused	
12~14	KR0 - KR2	I	Key return 0~2	
15	PROTECT	I	Protection detect	H : PROTECT
16	S. DATA	I/O	Serial communication data	
17	S. BUSY	I/O	Serial communication busy	
18	E2. DT	I/O	E2PROM data	
19	E2. CLK	O	E2PROM clock	
20	SEL. ENC.A	I	Selector encoder A (CW)	
21	SEL. ENC.B	I	Selector encoder B (CCW)	
22	MULTI. ENC.A	I	Multi control encoder A (CW)	
23	MULTI. ENC.B	I	Multi control encoder B (CCW)	
24	SER.IN	I	Serial communication 8bit/16bit changeover	L : 8bit H : 16bit
25	SAP.M1	O	SAP IC (CXA1124BS) M1 control	
26	SAP.IN	I	SAP IC (CXA1124BS) SAP signal control	L : sap
27	SAP.M2	O	SAP IC (CXA1124BS) M2 control	
28	Vdd	—	Analog power supply (+5V)	
29	S.LEVEL	I	Signal level A/D input	
30	P/L. DT	O	PROLOGIC IC (M62460FP) strobe	L : active
31	P/L. CK	O	PROLOGIC IC (M62460FP) clock	L : active
32	P/L. ST	O	PROLOGIC IC (M62460FP) data	
33	PLL. DO	I	PLL IC DO signal	
34	PLL. ST	I	TUNER STEREO signal detect	L : STEREO
35	PLL. SD	I	TUNER SD signal detect	L : TUNED
36	RCV. CE	I	RECEIVER CHIP ENABLE signal	L : ENABLE
37	AVss	—	Analog GND	
38	RESET	I	u-Com reset	
39	EXTAL	I	Main clock (8MHz)	
40	XTAL	—	Main clock (8MHz)	
41	Vss	—	u-Com GND	
42	TX	—	Unused	
43	TEX	I	GND	
44	Vdd	—	+5V	
45	Vfdp	—	-33V	
46	SEL. ST1	O	TC9162AF/63AF/64AF strobe1	H : LATCH
47	PLL. DT	O	PLL IC DATA signal output	
48	PLL. CK	O	PLL IC CLOCK signal output	
49	PLL. CE	O	PLL IC CE signal output	
50	T. MUTE	O	Tuner mute control	L : MUTE ON
51	A. MUTE	O	Output mute control	L : MUTE ON
52	SW. MUTE	O	SUB WOOFER mute control	L : MUTE ON
53	10dB. ATT	O	VOLUME 10dB ATTENUATOR control	L : ATT ON
54	VOL. DT	O	VOLUME IC (M62446SP) data control	
55	VOL. CK	O	VOLUME IC (M62446SP) clock control	H : active
56	VOL. ST	O	VOLUME IC (M62446SP) strobe control	H : active
57	VCR. MUTE	O	VIDEO IC (NJU2279D) cont2/4 control	L : mute on
58	VCR. A	O	VIDEO IC (NJU2279D) cont1 control	H/L : static
59	VCR. B	O	VIDEO IC (NJU2279D) cont3 control	H/L : static
60	FA. RLY	O	Front SP. A relay control	H : relay ON
61	FB. RLY	O	Front SP. B relay control	H : relay ON
62	C. RLY	O	Center SP. relay control	H : relay ON
63	S. RLY	O	Surround SP. relay control	H : relay ON

CIRCUIT DESCRIPTION

Pin No.	Pin name	I/O	Description	Active
64	POWER. RLY	O	Power relay control	H : relay ON
65	STANDBY. LED	O	STANDBY LED control	H : relay ON L : LED ON
66, 67	—	O	Unused	
68	SAP. LED1	O	SAP LED1	L : LED ON
69	SAP. LED2	O	SAP LED2	L : LED ON
70	SAP. LED3	O	SAP LED3	L : LED ON
71	PACK_CTL	O	VIDEO MUTE (M type)	L : MUTE ON
72	—	O	Unused	
73	EMPHASIS	O	TUNER EMPHASIS (M type)	H : 100 /10k L : 50k/9k
74~81	P1/KS7~P8/KS0	O	FL (11-MT-116GK) SEG 1~8 & KEY SCAN 7~0	
82~88	P9~P15	O	FL (11-MT-116GK) SEG 9~15	
89	Vdd	O	u-Com +5V power supply	
90, 91	P16, P17	O	FL (11-MT-116GK) SEG 16, 17	
92~100	G1~G9	O	FL (11-MT-116GK) GRID 1~9	

7. Control list for the switch and the port

(1) Input selector (BU4066BCF)

X09, IC17			
	IC PORT	⑩, ⑪	③, ④
	Surround	⑧, ⑨	②, ①
No.	Input Selector	MD/TAPE REC	LSch/RSch
1	MD/TAPE	X	X
2	6ch INPUT	O	O
3	OTHERS	O	X

(0 : SW OFF/1 : SW ON)

(2) Electric volume (M62446FP)

X09, IC9					
	IC PORT	⑰	⑱	⑲	⑳
	Surround	out1	out2	out3	out4
No.	Input Selector	LSch/RSch	LSch/RSch	----	----
1	MD/TAPE	X	X	X	X
2	6ch INPUT	O	O	X	X
3	OTHERS	X	X	X	X

(0 : SW OFF/1 : SW ON)

(3) Input selector (TC9164AF)

X09, IC6											
	IC CHANNEL	Lch	Rch	Lch	Rch	Lch	Rch	Lch	Rch	Lch	Rch
	IC PORT	S1	S2	S3	S4	S5	S6	S7	S8		
No.	Input Selector	TUNER	PHONO	CD	MD/TAPE/PLAY	VIDEO1 PLAY	VIDEO1 REC	VIDEO2	MONITOR		
1	PHONO	X	O	X	X	X	O	X	X		
2	CD	X	X	O	X	X	O	X	X		
3	VIDEO2	X	X	X	X	X	X	O	X		
4	MONITOR ON	now condition	now condition	now condition	now condition	now condition	X	O(0dB selector)	O(-6dB selector)		
5	TAPE/MD	X	X	X	O	X	O	X	X		
6	VIDEO1	X	X	X	X	O	O	X	X		
7	TUNER	O	X	X	X	X	O	X	X		
8	6ch INPUT	X	X	X	X	X	O	X	X		

(0 : SW OFF/1 : SW ON)

(4)Surr. Mode selector(TC9162AF)

X09, IC7													
	IC CHANNEL	Lch	Rch	Lch	Rch	Lch	Rch	Lch	Rch	Lch	Rch	Lch	Rch
	IC PORT	② S1 ②7	③ S2 ②6	⑤ S3 ②5	⑥ S4 ②3	⑧ S5 ②1	⑨ S6 ②0	⑪ S7 ①8					
	Surround	prologic	6ch input	prologic	6ch input	prologic	6ch input	6ch input					
No.	Speaker	FLch	FRch	FLch	FRch	SWch	Cch	SWch	Cch	LSch	RSch	LSch	RSch
1	DOLBY PROLOGIC	O		X		O	O	X		O		X	
2	DOLBY 3STEREO	O		X		O	O	X		X		X	
3	DSP LOGIC	O (2ch selector)	O (4ch selector)	O	O	X		O		O (4ch selector)		X	
4	STEREO	X		O		O	X	X		X		X	
5	SOURCE DIRECT	X		X		O	X	X		X		X	
6	6ch INPUT	O		O		X	X	O		X		O	

(0 : SW OFF/1 : SW ON)

8. Contents of the speaker setting


(VR-207 series only)

SUB WOOFER	YES/NO					
CENTER SP.	LARGE		NORMAL		NO	
SURROUND SP.	YES	NO	YES	NO	YES	NO
CENTER MODE (PRO LOGIC)	WIDEBAND	↗	NORMAL	↗	PHANTOM	↗

ADJUSTMENT


No.	ITEM	INPUT SETTINGS	OUTPUT SETTINGS	TUNER SETTINGS	ALIGNMENT POINTS	ALIGN FOR	FIG.
FM SECTION : EXCEPT E,T,Q type SELECTOR : FM							
1	DISTORTION (STEREO)	(C) 98.0MHz 1kHz, ±68.25kHz dev. Selector : L or R Pilot : ±6.75kHz dev. 70dBf (ANT. input)	(B)	98.0MHz	IFT (TUNER UNIT: A1)	Minimum distortion (L or R)	(a)
2	TUNING LEVEL	(A) 98.0MHz MONO 1kHz, ±75kHz dev. 25dBf (ANT. input)	(B)	MONO 98.0MHz	VR1 (TUNER UNIT)	Adjust VR1 and stop at the point where ED51 (TUNED) goes on.	(a)
TV SECTION : VR-257 (X04-) only SELECTOR : TV							
1	SEPARATION	(D) TV 3ch : 65.75MHz or TV 4ch : 71.75MHz STEREO AF : 3kHz, NR ON 70dBf.	(B)	TV 3ch or TV 4ch	VR1 (HTB TV UNIT)	Minimum crosstalk	(a)
FM SECTION : E,T,Q type only SELECTOR : FM ※Adjust NO.1 and NO.2 repeat.							
1	DISCRIMINATOR	(A) 98.0MHz 1kHz, ±40kHz dev. 70dBf (ANT. input)	Connect a DC voltmeter between CN2 ① and CN2 ② (TUNER UNIT)	MONO 98.0MHz	L4 (TUNER UNIT)	0V	(a)
2	DISTORTION (MONO)	(A) 98.0MHz 1kHz, ±40kHz dev. MONO 70dBf (ANT. input)	(B)	MONO 98.0MHz	L5 (TUNER UNIT)	Minimum distortion	(a)
3	DISTORTION (STEREO)	(C) 98.0MHz 1kHz, ±40kHz dev. Selector : L or R Pilot : ±6kHz dev. 70dBf (ANT. input)	(B)	AUTO 98.0MHz	IFT (TUNER UNIT : A1)	Minimum distortion (L or R)	(a)
4	TUNING LEVEL	(A) 98.0MHz MONO 1kHz, ±40kHz dev. 25dBf (ANT. input)	(B)	MONO 98.0MHz	VR1 (TUNER UNIT)	Adjust VR1 and stop at the point where ED51 (TUNED) goes on.	(a)

SYSTEM CONNECTIONS




PC BOARD (Component side view)

TUNER UNIT






POWER SUPPLY UNIT





Refer to the schematic diagram for the values of resistors and capacitors.


1
2
3
4
5
6
7



16







DC VOLTAGE FOR IC3

IC3	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
STK411-230K	⊕ 61.2V	0V	35.7V	36.0V	27.8V	27.7V	⊕ 36.0V	⊕ 61.2V	35.7V	35.7V	35.7V	0V	0V	0V	0V	56.0V	57.2V	0V	56.8V	0V	0V	0V	0V
STK407-090K	⊕ 41.8V	⊕ 41.8V	⊕ 41.9V	0V	0V	0V	37.4V	38.5V	0V	0V	36.1V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V	0V

DC VOLTAGE FOR IC4

	PIN NO IC4																										
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	
STK410-030K	(A) 61.2V	0V	35.7V	(C) 36.0V	27.8V	27.7V	(D) 36.0V	(B) 61.2V	35.7V	35.7V	35.7V	0V	0V	0V	0V	56.1V	56.4V	0V	0V	55.0V	0V	0V	0V	0V	35.9V	0V	
STK407-290K							0V	0V	(B)(D) 41.8V	(B)(D) 41.8V	(A)(C) 41.8V	0V	0V	0V	0V	37.4V	38.5V	0V	0V	36.1V	0V	0V	0V	0V	0V	41.8V	0V

KRF-V7010 (X00-288X-XX)															
DESTINATION	UNIT No.	T1	J1	R1	CN8	W1,2	W3	W4	P1						
COUNTRY	ABS														
PK	Y2	2-91	L07-2128-05	E03-0148-05	E03-0149-05	NO	NO	NO	YES	NO					
GENERAL MARKET	M1	0-21				NO	NO	NO	YES	NO					
AUSTRALIA	X1	0-71				NO	NO	NO	YES	NO					
U.S.A.	T1	0-51				YES	YES	YES	NO	NO					
EUROPE	E1	2-72	L07-2129-05	E03-0310-05	E03-0149-05	YES	YES	YES	NO	NO					

KRF-V5010 (X00-288X-XX)															
DESTINATION	UNIT No.	T1	J1	R1	CN8	W1,2	W3	W4	P1						
COUNTRY	ABS														
PK	Y2	2-91	L07-2128-05	E03-0148-05	E03-0149-05	NO	NO	NO	YES	NO					
GENERAL MARKET	M1	0-21				NO	NO	NO	YES	NO					
AUSTRALIA	X1	0-71				NO	NO	NO	YES	NO					
U.S.A.	T1	0-51				YES	YES	YES	NO	NO					
EUROPE	E1	2-72	L07-2129-05	E03-0310-05	E03-0149-05	YES	YES	YES	NO	NO					

KRF-V6010 (X00-288X-XX)															
DESTINATION	UNIT No.	T1	J1	R1	CN8	W1,2	W3	W4	P1						
COUNTRY	ABS														
PK	Y2	2-91	L07-2128-05	E03-0148-05	E03-0149-05	NO	NO	NO	YES	NO					
GENERAL MARKET	M1	0-21				NO	NO	NO	YES	NO					
AUSTRALIA	X1	0-71				NO	NO	NO	YES	NO					
U.S.A.	T1	0-51				YES	YES	YES	NO	NO					
EUROPE	E1	2-72	L07-2129-05	E03-0310-05	E03-0149-05	YES	YES	YES	NO	NO					

KRF-V5010E/V6010E (X00-2882-71)															
DESTINATION	UNIT No.	T1	J1	R1	CN8	W1,2	W3	W4	P1						
COUNTRY	ABS														
RUSSIA	Q1	2-71	L07-2129-05	E03-0149-05	NO	YES	NO	YES	NO	NO					

KRF-V5010W/V6010W (X00-2882-71)															
DESTINATION	UNIT No.	T1	J1	R1	CN8	W1,2	W3	W4	P1						
COUNTRY	ABS														
RUSSIA	Q1	2-71	L07-2129-05	E03-0149-05	NO	YES	NO	YES	NO	NO					

KRF-V7010E (X00-2882-72)															
DESTINATION	UNIT No.	T1	J1	R1	CN8	W1,2	W3	W4	P1						
COUNTRY	ABS														
EUROPE	E2	2-72	L07-2129-05	E03-0149-05	NO	YES	NO	YES	NO	NO					




KRF-V7010W (X00-2882-72)															
DESTINATION	UNIT No.	T1	J1	R1	CN8	W1,2	W3	W4	P1						
COUNTRY	ABS														
RUSSIA	Q1	2-72	L07-2129-05	E03-0149-05	NO	YES	NO	YES	NO	NO					


VR-205/206/207/255/257 (X00-2880-10)															
DESTINATION	UNIT No.	T1	J1	R1	CN8	W1,2	W3	W4	P1						
COUNTRY	ABS														
U.S.A.	R														
CANADA	P1														
U.S.A.	K1														
CANADA	P2														
U.S.A.	K2														
CANADA	P3														

Q1 : 2SC3940A(R.S)
Q2 : 2SC2003(L.K)

D1-4 : 1SR139-400 or S5688B
D5 : MTJ36.2(B) or RD6.2ES(B2)
D6,7,9 : 1SS133 or HSS104A
D8 : MTJ2.7(B) or RD2.7ES(B2)

USED EXCEPT (K,P) TYPE





VR-205/255 (X09-4900-10)																			
DESTINATION		UNIT NO.	ICS1	ICS2.4	D501 502 504 507 510 524 528	D522	W198 201 209	W501 502	R501 509 517 519 520 526 557 564 569 578 580	R522 535 556	R537	C510 515 516 522 524 527 528 533 534	C538	L501 502	X500	S501	S505	S511	S516
COUNTRY	ABB																		
U.S.A.	K	0-10	CXPR2832-144Q	NO	NO	YES	NO	YES	NO	YES	10K	NO	YES	NO	NO	MUTE	DIMMER	P.CALL ^	P.CALL ^
CANADA	P1																		
U.S.A.	K1																		
CANADA	P2																		

VR-206207 (X09-4900-11)																		
DESTINATION		UNIT NO.	IC51	IC52.54	D501 502 504-507 510.522.524.528	W198.201 209	W501 502	R501 509 517 557.564.569.578.580	R522 535 556	R537	C510 515 516 522-524, 527.528.533.534	C535	L501 502	X502	S501	S505	S511	S516
COUNTRY	ABB																	
U.S.A.	K																	
CANADA	P1																	
U.S.A.	K2	0-11	CPX2832-144Q	NO	NO	NO	YES	NO	YES	10K	NO	YES	NO	NO	SP B	DIMMER	P.CALL ✓	P.CALL ✓
CANADA	P3																	
U.S.A.	K2																	

VR-257 (X09-4900-12)																							
DESTINATION		UNIT NO	IC51	IC52.54	D501.502	D501.502	D504.505.507	W198.201	W209	R501.519	R509.517	519.520.526.532	R537	C510.515.516.522-524.	C535	C501	X502	S501	S505	S611	P.5616		
COUNTRY	ABB				506.526	510.522.524	501.502			520.556	535.567	564.969.578.980		527.526.533.534		NO	YES	NO	SP	BIMMER	SAP	P CALL	
K1	K2																						
CANADA		Q-12	CXPR2832-144Q	NO	YES	NO	NO	YES	NO	YES	NO	YES	NO	47K	NO	NO	YES	NO	NO	SP	BIMMER	SAP	P CALL

KRF-V5100 (X09-409-XX)																											
DESTINATION		UNIT	No	IC51	IC52	IC54	D501.502.506.507.526	D504	D505.524	D510.522	W198.201	W209.501.502	R501.519.520	R509.557.564.569.576.590	R517.526.556	R537.535	R532	C510.515.516.522-524.527.528.533	C534	C535	L501.502	X502	S501	S505	S511	S516	
COUNTRY	ABB	PK																									
GENERAL MARKET	Y1		0-21	CPX2832-144Q	YES	NO	NO	YES	NO	YES	NO	NO	NO	YES	NO	YES	10K	NO	YES	NO	NO	NO	NO	MUTE	DIMMER	P.CALL A	P.CALL A
AUSTRALIA	E1				YES	NO	NO	YES	NO	YES	NO	NO	NO	YES	NO	YES	10K	NO	YES	NO	NO	YES	YES	NO	PTY	(RDS) TA/NEWS	TA/NEWS
EUROPE	T1		2-71	CPX2852-130Q	YES	NO	NO	YES	NO	YES	NO	NO	NO	YES	NO	YES	10K	NO	YES	NO	NO	YES	YES	NO	PTY	(RDS) TA/NEWS	TA/NEWS
U.K	X1				YES	NO	NO	YES	NO	YES	NO	NO	NO	YES	NO	YES	10K	NO	YES	NO	NO	YES	YES	NO	PTY	(RDS) TA/NEWS	TA/NEWS

KRF-V5010E (X90-4903-81)																		
DESTINATION		UNIT																
COUNTRY	ABB	IC51	IC52 IC54	D501.502.505, 506.528	D504.507.510, 522.524	W198.201.209, 501.502	R501.519, 520	R509.523.535.557, 564.569.578.580	R517.526, 556	R537	C510.515.516.522-524, 527.529.533.534	C535	L501.502, 503	X502	S501	S505	S511	S516
EUROPE	E2	E-81	CXP62852-130Q	YES	NO	YES	NO	YES	NO	10K	YES	NO	YES	YES	SP B	PTY	(RDS) DISPLAY	TA NEWS

KRF-V5010W (X90-4903-81)																			
DESTINATION		UNIT NO	IC51	IC52	D501.502.505	D504.507.510	W198.201.209	R501.519.	R509.532.535.557	R517.526.	R537	C510.515.516.522-524	C535	L501.502	X502	S501	S505	S511	S516
COUNTRY	ABE		IC54	IC56	506.528	522.524	501.502	520	564.669.578.580	556		527.529.533.534		502					
RUSSIA	X1	3-81	CPX62852-130Q		YES	NO	YES	NO	YES	NO	10K	YES	NO	YES	YES	SP B	PTY	(RDS) DISPLAY	TA NEWS

RKF-V6010 (X09-490X-XX)																											
DESTINATION COUNTRY		ABE	UNIT NO.	IC51	IC52	IC54	D501 502 506 507 522 528	D504	D505 524	D510	W199	W209 501 502	R501 510 520	R509 557 564 568 579 580	R517 526 556	R532 535	R537	C510 515 516 522 524 527 528 533	C534	C535	L501 502	X502	S501	S505	S511	S516	
EUROPE	E	2-72	CXP2852-130Q	YES	YES		NO	YES				NO	YES	NO	YES			YES	YES	YES	YES		PTY	RDS	T/A		
GENERAL MARKET AUSTRALIA	M1	0-22	CXP2832-144Q	YES	NO		YES	NO	YES			NO	NO	NO	YES		10K	NO	YES	YES	NO	NO	SP B	DIMMER	P CALL	T/A CALL	

KRF-V6010E (X09-4903-82)																			
DESTINATION		UNIT	NO.	CS1	CS2	D501.502.505	D504.507	W198.200	R501.517.519	R509.532.535.557	R537	C510.515.516.522.524.	C536	L501.502	X502	S501	S505	S511	S516
COUNTRY	ABB				CS6	506.522.528	510.524	501	502.526.556	564.569.578.580		527.526.533.534							
EUROPE	E2	3-82	CXK62852-130Q	YES	NO	YES	NO	YES	NO	YES	10K	YES	YES	NO	YES	SP B	PTY	(RDS) DISP	TA/NEWS

KRF-V61010W (X09-4903-82)																			
DESTINATION		UNIT NO	IC51	IC52	D501.502.505	D504.507	W198.209	R501.517.519	R509.532.535.557	R637	C510.515.516.522.524.	C535	L501.502	X502	S501	S505	S511	S516	
COUNTRY	ABR			IC54	IC56	502.528.528	510.524	501.502	502.526.556	564.569.578.580		527.528.533.534							
RUSSIA	RU	3-82	CXK62852-130Q	YES	NO	YES	NO	NO	NO	YES	10K	YES	YES	NO	YES	SP B	PTY	(RDS) DISPLAY	TA/NEWS


[illegible]

KRF-701010E (X09-4903-83)																					
DESTINATION		UNIT NO	IC51	IC52	D501.502.505	D504.507	W198.201.209	R501.517	519	R509.532	535.557	R537	C510.515	516.522.524.	C536	L501	X502	S501	S505	S511	S516
COUNTRY	ABE			IC56	506.522.528	510.524	501.502	520.526.556	560	564.569.578.580			527.528.533.534		502						
EUROPE	E2	3-83	CXP62852-130Q	YES	NO	YES	NO	YES	NO	YES	10K	YES	YES	YES	NO	YES	YES	SP B	PTY	(RDS) DISPLAY	TAI/NEWS

KRF-V7010W (X09-4903-83)																		
DESTINATION COUNTRY		UNIT NO.	IC51	IC52 IC54	D501.502.505 506.522.528	D504.507 510.524	W198.201.209 501.502	R501.517 519 520.526.556	R509.632.535.557 564.569.578.580	R537	C15.510 516.522.524. 527.528.533.534	C536	L501 502	X502	S501	S505	S511	S516
RUSSIA	QAB	3-83	CPX62852-130Q	YES	NO	YES	NO	NO	YES	10K	YES	NO	YES	YES	SP B	PTY	(RDS) DISPLAY	TA/NEWS

CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list). Δ indicates safety critical components. For continued protection against risk of fire, replace only with same type and rating fuse(s). To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.

The DC voltage is an actual reading measured with a high impedance type voltmeter with no signal input. The measurement value may vary depending on the measuring instruments used or on the product.




VR-205/206/207/255/257 (K) (3/3)
KRF-V5010/V5010W/V6010/V6010W/V7010/V7010W (E) (3/3)

Y05-5610-10

KENWOOD

KRF-V5010/V6010/V7010/VR-205/206/207/255/257



* New Parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

①

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
VR-206/207/257/KRF-V7010/V7010E/V7010W						
601	1A	*	A01-3534-01	METALLIC CABINET	KP1Y1	
601	1A	*	A01-3534-01	METALLIC CABINET	M1X1K1	
601	1A	*	A01-3534-01	METALLIC CABINET	P2K2P3	
601	1A	*	A01-3545-01	METALLIC CABINET	E1T1Q1	
601	1A	*	A01-3545-01	METALLIC CABINET	E2	
602	1A		A09-0366-08	BATTERY COVER	KP1Y1	
602	1A		A09-0366-08	BATTERY COVER	M1X1E1	
602	1A		A09-0366-08	BATTERY COVER	P2E2	
602	1A		A09-0366-08	BATTERY COVER	T1Q1K1	
602	1A	*	A09-0396-08	BATTERY COVER	K2P3	
604	2A	*	A22-1804-11	SUB PANEL	E1T1Q1	
604	2A	*	A22-1804-11	SUB PANEL	E2	
606	2A	*	A60-1319-12	PANEL	E1T1Q1	
606	2A	*	A60-1319-12	PANEL	E2	
606	2A	*	A60-1320-11	PANEL	KP1	
606	2A	*	A60-1321-11	PANEL	Y1	
606	2A	*	A60-1368-11	PANEL	K1P2	
606	2A	*	A60-1375-11	PANEL	K2P3	
606	2A	*	A60-1443-01	PANEL	M1X1	
607	1A		A70-1194-05	REMOTE CONTROL ASSY(RC-R0607)	KP1Y1	
607	1A		A70-1194-05	REMOTE CONTROL ASSY(RC-R0607)	M1K1P2	
607	1A	*	A70-1195-05	REMOTE CONTROL ASSY(RC-R0507)	Q1E2	
607	1A	*	A70-1195-05	REMOTE CONTROL ASSY(RC-R0507)	X1E1T1	
607	1A	*	A70-1199-05	REMOTE CONTROL ASSY(RC-R0407)	K2P3	
612	2A	*	B10-2439-02	FRONT GLASS	KP1Y1	
612	2A	*	B10-2439-02	FRONT GLASS	M1X1E1	
612	2A	*	B10-2439-02	FRONT GLASS	P3E2	
612	2A	*	B10-2439-02	FRONT GLASS	T1Q1K2	
612	2A	*	B10-2440-02	FRONT GLASS	K1P2	
613	2A		B11-0361-04	SMOKED FILTER	K1P2	
613	2A	*	B11-0362-04	SMOKED FILTER	K1P2	
614	2A	*	B12-0334-14	INDICATOR		
615	2A		B43-0302-04	KENWOOD BADGE	X1	
-			B46-0096-53	WARRANTY CARD		
-			B46-0197-00	QUESTIONNAIRE CARD	KK1K2	
-			B46-0310-03	WARRANTY CARD	E1T1Q1	
-			B46-0310-03	WARRANTY CARD	E2	
-			B46-0330-03	WARRANTY CARD	KY1K1	
-			B46-0330-03	WARRANTY CARD	K2	
-			B46-0336-03	WARRANTY CARD	P1P2P3	
-			B58-0513-04	CAUTION CARD (PRESET220-240)	Y1	
-			B58-0945-03	CAUTION CARD	T1	
-			B58-0964-13	CAUTION CARD (UL)	KY1K1	
-			B58-0964-13	CAUTION CARD (UL)	K2	
-		*	B58-0965-13	CAUTION CARD (T,XtypePL)	X1T1	
-		*	B58-0966-13	CAUTION CARD (ELMtypePL)	M1E1	
-		*	B58-0967-03	CAUTION CARD (PtypePL)	P1P2P3	
-		*	B58-1607-03	CAUTION CARD	Q1E2	
-			B59-1104-00	SERVICE DIRECTORY	Y1	
-		*	B59-1404-03	CATALOG	KP1K2	
-		*	B59-1404-03	CATALOG	P3	
-		*	B59-1406-00	CATALOG	KP1K2	
-		*	B59-1406-00	CATALOG	P3	

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia

Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)

Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

* New Parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

②

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
-		*	B59-1407-00	CATALOG	P1P3	
-		*	B60-3605-00	INSTRUCTION MANUAL(I/SP)	E1	
-		*	B60-3606-00	INSTRUCTION MANUAL(HG/CZ)	E2	
-		*	B60-3609-00	INSTRUCTION MANUAL(ENGLISH)	T1Q1E2	
-		*	B60-3610-00	INSTRUCTION MANUAL(ENGLISH)	KP1Y1	
-		*	B60-3610-00	INSTRUCTION MANUAL(ENGLISH)	M1X1K1	
-		*	B60-3610-00	INSTRUCTION MANUAL(ENGLISH)	P2K2P3	
-		*	B60-3611-00	INSTRUCTION MANUAL(F/D)	E1	
-		*	B60-3612-00	INSTRUCTION MANUAL(FRENCH)	P1P2P3	
-		*	B60-3613-00	INSTRUCTION MANUAL(GERMAN)	E1	
-		*	B60-3614-00	INSTRUCTION MANUAL(SP/CHINESE)	M1	
-		*	B60-3616-00	INSTRUCTION MANUAL(PH)	E2	
-		*	B60-3617-00	INSTRUCTION MANUAL(ENGLISH)	E2	
-		*	B60-3617-00	INSTRUCTION MANUAL(ENGLISH)	X1T1Q1	
-		*	B60-3618-00	INSTRUCTION MANUAL(ENGLISH)	KP1Y1	
-		*	B60-3618-00	INSTRUCTION MANUAL(ENGLISH)	M1K1P2	
-		*	B60-3619-00	INSTRUCTION MANUAL(F/D/I/SP)	E1	
-		*	B60-3620-00	INSTRUCTION MANUAL(FRENCH)	P1P2	
-		*	B60-3621-00	INSTRUCTION MANUAL(SP/CHINESE)	M1	
-		*	B60-3623-00	INSTRUCTION MANUAL(PH/HG/CZ/R)	Q1E2	
-		*	B60-3625-00	INSTRUCTION MANUAL(E/F)	K1P2	
-		*	B60-3626-00	INSTRUCTION MANUAL(R)	Q1	
Δ 618	1A		E03-0115-05	AC PLUG ADAPTER	M1	
Δ 619	1C		E30-2605-05	AC POWER CORD	Y1	
Δ 619	1C		E30-2717-05	AC POWER CORD	X1	
Δ 619	1C		E30-2721-05	AC POWER CORD	T1	
Δ 619	1C		E30-2842-05	AC POWER CORD	E2	
Δ 619	1C		E30-2842-05	AC POWER CORD	M1E1Q1	
Δ 619	1C		E30-2849-05	AC POWER CORD	KP1K1	
Δ 619	1C		E30-2849-05	AC POWER CORD	P2K2P3	
620	1A,1B		E35-2017-05	FLAT CABLE(13P)		
621	2B,2C	*	E35-2042-05	FLAT CABLE(27P)		
Δ F1			F50-0077-05	FUSE(5X20) 125V 8A	KP1K1	
Δ F1			F50-0077-05	FUSE(5X20) 125V 8A	P2K2P3	
Δ F1			F50-0101-05	FUSE(5X20) 250V T3.15AL	E1T1Q1	
Δ F1			F50-0101-05	FUSE(5X20) 250V T3.15AL	E2	
Δ F1			F50-0101-05	FUSE(5X20) 250V T3.15AL	Y1M1X1	
Δ F3			F50-0100-05	FUSE(5X20) 250V T2.5AL	E1Q1E2	
-			H10-7418-12	POLYSTYRENE FOAMED FIXTURE(L)		
-			H10-7419-02	POLYSTYRENE FOAMED FIXTURE(R)		
-			H25-0232-04	PROTECTION BAG (235X350X0.03)	KP1Y1	
-			H25-0232-04	PROTECTION BAG (235X350X0.03)	K2P3E2	
-			H25-0232-04	PROTECTION BAG (235X350X0.03)	M1X1E1	
-			H25-0232-04	PROTECTION BAG (235X350X0.03)	Q1K1P2	
-			H25-0232-04	PROTECTION BAG (235X350X0.03)	T1	
-			H25-0391-04	PROTECTION BAG	KP1	
-			H25-0651-04	PROTECTION BAG (0232 PRINT)	M1	
-		*	H50-2721-04	ITEM CARTON CASE		
-		*	H50-2722-04	ITEM CARTON CASE		
-		*	H50-2723-04	ITEM CARTON CASE	T1	
-		*	H50-2723-04	ITEM CARTON CASE	Y1X1E1	
-		*	H50-2724-14	ITEM CARTON CASE	Q1	
-		*	H50-2725-04	ITEM CARTON CASE	K1P2	
-		*	H50-2844-04	ITEM CARTON CASE	K2P3	

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia

Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)

Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

KRF-V5010W6010N/7010WVR-205/206/207/255/257

PARTS LIST

* New Parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

③

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
-		*	H50-3085-04	ITEM CARTON CASE	E2	
630	2B,2C		J02-1167-03	FOOT	M1X1E1	
630	2B,2C		J02-1167-03	FOOT	T1Q1E2	
630	2B,2C		J02-1405-03	FOOT (D=46,H=14.5,T)	KP1Y1	
630	2B,2C		J02-1405-03	FOOT (D=46,H=14.5,T)	K1P2K2	
630	2B,2C		J02-1405-03	FOOT (D=46,H=14.5,T)	P3	
631	2B,2C		J19-5787-04	UNIT HOLDER		
635	1C		J42-0083-05	POWER CORD BUSHING		
636	1A		J19-3645-05	ANTENNA STAND		
-			J61-0307-05	WIRE BAND		
639	2A		K27-2185-04	KNOB (POWER)	M1X1E1	
639	2A		K27-2185-04	KNOB (POWER)	T1Q1E2	
639	2A	*	K27-2274-04	KNOB (POWER)	Y1	
640	2A	*	K29-6880-04	KNOB (VOLUME CONTROL)	KP1Y1	
640	2A	*	K29-6880-04	KNOB (VOLUME CONTROL)	K1P2K2	
640	2A		K29-6880-04	KNOB (VOLUME CONTROL)	P3	
640	2A	*	K29-7306-14	KNOB (VOLUME CONTROL)	M1X1E1	
640	2A	*	K29-7306-14	KNOB (VOLUME CONTROL)	T1Q1E2	
641	2A		K29-6881-04	KNOB (MULTI CONTROL)	KP1Y1	
641	2A		K29-6881-04	KNOB (MULTI CONTROL)	K1P2K2	
641	2A		K29-6881-04	KNOB (MULTI CONTROL)	P3	
641	2A	*	K29-7307-14	KNOB (MULTI CONTROL)	M1X1E1	
641	2A	*	K29-7307-14	KNOB (MULTI CONTROL)	T1Q1E2	
642	2A		K29-6898-03	KNOB	KP1Y1	
642	2A		K29-6898-03	KNOB	K2P3	
642	2A	*	K29-6899-13	KNOB	E1T1Q1	
642	2A	*	K29-6899-13	KNOB	E2	
642	2A	*	K29-6907-03	KNOB	K1P2	
642	2A	*	K29-7366-03	KNOB	M1X1	
643	2A	*	K29-6939-12	KNOB	KP1Y1	
643	2A	*	K29-6939-12	KNOB	K1P2K2	
643	2A	*	K29-6939-12	KNOB	P3	
643	2A	*	K29-7365-12	KNOB	M1X1	
646	2A	*	L07-2479-05	POWER TRANSFORMER	KP1K1	
646	2A	*	L07-2479-05	POWER TRANSFORMER	P2K2P3	
646	2A	*	L07-2480-05	POWER TRANSFORMER	E1T1	
646	2A	*	L07-2481-05	POWER TRANSFORMER	Y1M1	
646	2A	*	L07-2482-05	POWER TRANSFORMER	Q1E2	
646	2A	*	L07-2483-05	POWER TRANSFORMER	X1	
650	1A		T90-0833-05	LOOP ANTENNA		
651	1A		T90-0836-05	LEAD WIRE ANTENNA		
VR-205/255/KRF-V5010/V5010E/V5010W						
601	1A		A01-3534-01	METALLIC CABINET		
602	1A		A09-0366-08	BATTERY COVER	K1P2	
602	1A	*	A09-0396-08	BATTERY COVER	KP1Y1	
602	1A	*	A09-0396-08	BATTERY COVER	M1X1E1	
602	1A	*	A09-0396-08	BATTERY COVER	T1Q1E2	
606	2A	*	A60-1323-21	PANEL	KP1	
606	2A	*	A60-1324-21	PANEL	Y1	
606	2A	*	A60-1359-21	PANEL	E1T1Q1	
606	2A	*	A60-1359-21	PANEL	E2	
606	2A	*	A60-1376-21	PANEL	K1P2	

L : Scandinavia

K : USA

P : Canada

R : Mexico

C : China

I : Malaysia

Y : PX(Far East, Hawaii)

T : Europe

E : Europe

G : Germany

V : China (Shanghai)

Y : AAFES(Europe)

X : Australia

Q : Russia

H : Korea

M : Other Areas

Δ indicates safety critical components.

* New Parts

Parts without **Parts No.** are not supplied.Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.Teile ohne **Parts No.** werden nicht geliefert.

④

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
606	2A	*	A60-1444-01	PANEL	M1X1	
607	1A		A70-1194-05	REMOTE CONTROL ASSY(RC-R0607)	K1P2	
607	1A	*	A70-1196-05	REMOTE CONTROL ASSY(RC-R0307)	E1T1Q1	
607	1A	*	A70-1196-05	REMOTE CONTROL ASSY(RC-R0307)	E2	
607	1A	*	A70-1199-05	REMOTE CONTROL ASSY(RC-R0407)	KP1Y1	
607	1A	*	A70-1199-05	REMOTE CONTROL ASSY(RC-R0407)	M1X1	
612	2A	*	B10-2439-02	FRONT GLASS		
614	2A		B12-0334-14	INDICATOR		
615	2A		B43-0302-04	KENWOOD BADGE		
-			B46-0096-53	WARRANTY CARD	X1	
-			B46-0197-00	QUESTIONNAIRE CARD	KK1	
-			B46-0310-03	WARRANTY CARD	E1T1Q1	
-			B46-0310-03	WARRANTY CARD	E2	
-			B46-0330-03	WARRANTY CARD	KY1K1	
-			B46-0336-03	WARRANTY CARD	P1P2	
-			B58-0513-04	CAUTION CARD (PRESET220-240)	Y1	
-			B58-0945-03	CAUTION CARD	T1	
-			B58-0964-13	CAUTION CARD (UL)	KY1K1	
-		*	B58-0965-13	CAUTION CARD (T,XtypePL)	X1T1	
-		*	B58-0966-13	CAUTION CARD (ELMtypePL)	M1E1	
-		*	B58-0967-03	CAUTION CARD (PtypePL)	P1P2	
-		*	B58-1607-03	CAUTION CARD	Q1E2	
-			B59-1104-00	SERVICE DIRECTORY	Y1	
-		*	B59-1404-03	CATALOG	KP1K1	
-		*	B59-1404-03	CATALOG	P2	
-		*	B59-1406-00	CATALOG	KP1K1	
-		*	B59-1406-00	CATALOG	P2	
-		*	B59-1407-00	CATALOG	P1P2	
-		*	B60-3605-00	INSTRUCTION MANUAL(I/SP)	E1	
-		*	B60-3606-00	INSTRUCTION MANUAL(HG/CZ)	E2	
-		*	B60-3609-00	INSTRUCTION MANUAL(ENGLISH)	T1Q1E2	
-		*	B60-3610-00	INSTRUCTION MANUAL(ENGLISH)	KP1Y1	
-		*	B60-3610-00	INSTRUCTION MANUAL(ENGLISH)	M1X1K1	
-		*	B60-3610-00	INSTRUCTION MANUAL(ENGLISH)	P2	
-		*	B60-3611-00	INSTRUCTION MANUAL(F/D)	E1	
-		*	B60-3612-00	INSTRUCTION MANUAL(FRENCH)	P1P2	
-		*	B60-3613-00	INSTRUCTION MANUAL(GERMAN)	E1	
-		*	B60-3614-00	INSTRUCTION MANUAL(SP/CHINESE)	M1	
-		*	B60-3616-00	INSTRUCTION MANUAL(PH)	E2	
-		*	B60-3618-00	INSTRUCTION MANUAL(ENGLISH)	K1P2	
-		*	B60-3620-00	INSTRUCTION MANUAL(FRENCH)	P2	
Δ 618	1A		E03-0115-05	AC PLUG ADAPTER	M1	
Δ 619	1C		E30-2605-05	AC POWER CORD	Y1	
Δ 619	1C		E30-2717-05	AC POWER CORD	X1	
Δ 619	1C		E30-2721-05	AC POWER CORD	T1	
Δ 619	1C		E30-2842-05	AC POWER CORD	E2	
Δ 619	1C		E30-2842-05	AC POWER CORD	M1E1Q1	
Δ 619	1C		E30-2849-05	AC POWER CORD	KP1K1	
Δ 619	1C		E30-2849-05	AC POWER CORD	P2	
620	1A,1B		E35-2017-05	FLAT CABLE		
621	2B,2C	*	E35-2042-05	FLAT CABLE		
Δ F1			F50-0076-05	FUSE(5X20) 125V 6.3A	KP1K1	
Δ F1			F50-0076-05	FUSE(5X20) 125V 6.3A	P2	
Δ F2		*	F50-0099-05	FUSE(5X20) 250V T2AL	E1T1Q1	

L : Scandinavia

K : USA

P : Canada

R : Mexico

C : China

I : Malaysia

Y : PX(Far East, Hawaii)

T : Europe

E : Europe

G : Germany

V : China (Shanghai)

Y : AAFES(Europe)

X : Australia

Q : Russia

H : Korea

M : Other Areas

Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

5

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
Δ F2		*	F50-0099-05	FUSE(5X20) 250V T2AL	E2	
Δ F2		*	F50-0099-05	FUSE(5X20) 250V T2AL	Y1M1X1	
Δ F3			F50-0100-05	FUSE(5X20) 250V T2.5AL	E1Q1E2	
-			H10-7418-12	POLYSTYRENE FOAMED FIXTURE(L)		
-			H10-7419-02	POLYSTYRENE FOAMED FIXTURE(R)		
-			H25-0232-04	PROTECTION BAG (235X350X0.03)	E2	
-			H25-0232-04	PROTECTION BAG (235X350X0.03)	KP1Y1	
-			H25-0232-04	PROTECTION BAG (235X350X0.03)	M1X1E1	
-			H25-0232-04	PROTECTION BAG (235X350X0.03)	Q1K1P2	
-			H25-0232-04	PROTECTION BAG (235X350X0.03)		
-			H25-0391-04	PROTECTION BAG		
-			H25-0651-04	PROTECTION BAG (0232 PRI)	T1	
-		*	H50-2727-04	ITEM CARTON CASE	KP1	
-		*	H50-2728-04	ITEM CARTON CASE	M1	
-		*	H50-2729-04	ITEM CARTON CASE	T1	
-		*	H50-2729-04	ITEM CARTON CASE	Y1X1E1	
-		*	H50-2730-14	ITEM CARTON CASE	Q1	
-		*	H50-2731-04	ITEM CARTON CASE	K1P2	
-		*	H50-3086-04	ITEM CARTON CASE	E2	
630	2B,2C		J02-1167-03	FOOT	M1X1E1	
630	2B,2C		J02-1167-03	FOOT	T1Q1E2	
630	2B,2C		J02-1405-03	FOOT (D=46,H=14.5,T)	KP1Y1	
630	2B,2C		J02-1405-03	FOOT (D=46,H=14.5,T)	K1P2	
631	2B,2C		J19-5787-04	UNIT HOLDER		
Δ 635	1C		J42-0083-05	POWER CORD BUSHING		
636	1A		J19-3645-05	ANTENNA STAND	E1T1Q1	
-			J61-0307-05	WIRE BAND	E2	
-			J61-0307-05	WIRE BAND	Y1M1X1	
-			J61-0307-05	WIRE BAND		
639	2A		K27-2185-04	KNOB (POWER)	M1X1E1	
639	2A		K27-2185-04	KNOB (POWER)	T1Q1E2	
639	2A	*	K27-2274-04	KNOB (POWER)	Y1	
640	2A		K29-6880-04	KNOB (VOLUME CONTROL)	KP1Y1	
640	2A		K29-6880-04	KNOB (VOLUME CONTROL)	K1P2	
640	2A	*	K29-7306-14	KNOB (VOLUME CONTROL)	M1X1E1	
640	2A	*	K29-7306-14	KNOB (VOLUME CONTROL)	T1Q1E2	
641	2A		K29-6881-04	KNOB (MULTI CONTROL)	KP1Y1	
641	2A		K29-6881-04	KNOB (MULTI CONTROL)	K1P2	
641	2A	*	K29-7307-14	KNOB (MULTI CONTROL)	M1X1E1	
641	2A	*	K29-7307-14	KNOB (MULTI CONTROL)	T1Q1E2	
642	2A		K29-6898-03	KNOB	KP1Y1	
642	2A		K29-6898-03	KNOB	K1P2	
642	2A	*	K29-6899-13	KNOB	E1T1Q1	
642	2A		K29-6899-13	KNOB	E2	
642	2A	*	K29-7366-03	KNOB	M1X1	
643	2A	*	K29-6939-12	KNOB	KP1Y1	
643	2A	*	K29-6939-12	KNOB	K1P2	
643	2A	*	K29-7365-12	KNOB	M1X1E1	
643	2A	*	K29-7365-12	KNOB	T1Q1E2	
Δ 646	2A	*	L07-2470-15	POWER TRANSFORMER	KP1K1	
Δ 646	2A	*	L07-2470-15	POWER TRANSFORMER	P2	
Δ 646	2A	*	L07-2471-05	POWER TRANSFORMER	E1T1	
Δ 646	2A	*	L07-2472-05	POWER TRANSFORMER	Y1M1	
Δ 646	2A	*	L07-2473-05	POWER TRANSFORMER	Q1E2	
Δ 646	2A	*	L07-2474-05	POWER TRANSFORMER	X1	

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

6

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
650	1A		T90-0833-05	LOOP ANTENNA		
651	1A		T90-0836-05	LEAD WIRE ANTENNA		
KRF-V6010/V6010E/V6010W						
601	1A	*	A01-3534-01	METALLIC CABINET		
602	1A	*	A09-0396-08	BATTERY COVER		
606	2A	*	A60-1334-11	PANEL	EQ1E1	
606	2A	*	A60-1335-11	PANEL	M1X1	
607	1A	*	A70-1196-05	REMOTE CONTROL ASSY(RC-R0307)	EQ1E1	
607	1A	*	A70-1199-05	REMOTE CONTROL ASSY(RC-R0407)	M1X1	
612	2A	*	B10-2439-02	FRONT GLASS		
614	2A	*	B12-0334-14	INDICATOR		
615	2A	*	B43-0302-04	KENWOOD BADGE		
-			B46-0096-53	WARRANTY CARD	X1	
-			B46-0310-03	WARRANTY CARD	E1Q1E2	
-		*	B58-0965-13	CAUTION CARD (T,XtyoePL)	X1	
-		*	B58-0966-13	CAUTION CARD (ELMtypePL)	E1M1	
-		*	B58-1607-03	CAUTION CARD	Q1E2	
-		*	B60-3605-00	INSTRUCTION MANUAL(I/SP)	E1	
-		*	B60-3606-00	INSTRUCTION MANUAL(HG/CZ)	E2	
-		*	B60-3609-00	INSTRUCTION MANUAL(ENGLISH)	Q1E2	
-		*	B60-3610-00	INSTRUCTION MANUAL(ENGLISH)	M1X1	
-		*	B60-3611-00	INSTRUCTION MANUAL(F/D)	E1	
-		*	B60-3614-00	INSTRUCTION MANUAL(SP/CHINESE)	M1	
-		*	B60-3616-00	INSTRUCTION MANUAL(PH)	E2	
-		*	B60-3626-00	INSTRUCTION MANUAL(R)	Q1	
Δ 618	1A		E03-0115-05	AC PLUG ADAPTER	M1	
Δ 619	1C		E30-2717-05	AC POWER CORD	X1	
Δ 619	1C		E30-2842-05	AC POWER CORD	E1Q1M1	
Δ 619	1C		E30-2842-05	AC POWER CORD	E2	
620	1A,1B	*	E35-2017-05	FLAT CABLE(13P)		
621	2B,2C	*	E35-2042-05	FLAT CABLE(27P)		
Δ F1			F50-0101-05	FUSE(5X20) 250V T3.15AL		
Δ F3			F50-0100-05	FUSE(5X20) 250V T2.5AL	E1Q1E2	
-		*	H10-7418-12	POLYSTYRENE FOAMED FIXTURE		
-			H10-7419-02	POLYSTYRENE FOAMED FIXTURE		
-			H25-0232-04	PROTECTION BAG (235X350X0.03)		
-			H25-0391-04	PROTECTION BAG		
-		*	H50-2750-04	ITEM CARTON CASE	E1X1	
-		*	H50-2751-14	ITEM CARTON CASE	Q1	
-		*	H50-2752-04	ITEM CARTON CASE	M1	
-		*	H50-3087-04	ITEM CARTON CASE	E2	
630	2B,2C		J02-1167-03	FOOT		
631	2B,2C		J19-5787-04	UNIT HOLDER		
635	1C		J42-0083-05	POWER CORD BUSHING		
636	1A		J19-3645-05	ANTENNA STAND		
-			J61-0307-05	WIRE BAND		
639	2A		K27-2185-04	KNOB (POWER)		
640	2A	*	K29-7306-14	KNOB (VOLUME CONTROL)		
641	2A	*	K29-7307-14	KNOB (MULTI CONTROL)		
641	2A	*	K29-7366-03	KNOB	M1X1	
642	2A	*	K29-6899-13	KNOB	E1Q1E2	

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

KRF-V5010/V6010/V7010/MR-205/206/207/255/257
PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

7

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
643	2A	*	K29-7365-12	KNOB		
Δ 646	2A	*	L07-2480-05	POWER TRANSFORMER	E1	
Δ 646	2A	*	L07-2481-05	POWER TRANSFORMER	M1	
Δ 646	2A	*	L07-2482-05	POWER TRANSFORMER	Q1E2	
Δ 646	2A	*	L07-2483-05	POWER TRANSFORMER	X1	
650	1A		T90-0833-05	LOOP ANTENNA		
651	1A		T90-0836-05	LEAD WIRE ANTENNA		
POWER SUPPLY UNIT (X00-288X-XX)						
C5 ,6			CK45FF1H103Z	CERAMIC 0.010UF Z		
C7			CE04EW1E331M	ELECTRO 330UF 25WV		
C8			CK45FB1H102K	CERAMIC 1000PF K		
C9			CQ92FM1H104J	MYLAR 0.10UF J		
C10			CE04LW1C470M	ELECTRO 47UF 16WV		
C11			CE04LW1V4R7M	ELECTRO 4.7UF 35WV		
C13 ,14			CC45FSL1H101J	CERAMIC 100PF J		
C21 ,22			CC45FSL1H221J	CERAMIC 220PF J		
C23 -25			CK45FF1H472Z	CERAMIC 4700PF Z	E1T1Q1	7
C23 -25			CK45FF1H472Z	CERAMIC 4700PF Z	E2	7
Δ CN1			E40-4245-05	PIN ASSY	Y1M1	
Δ CN1 -3			E40-4245-05	PIN ASSY	Q1E2	
Δ CN1 -3			E40-4245-05	PIN ASSY	X1E1T1	
Δ CN1 ,2			E40-4245-05	PIN ASSY	KP1K1	
Δ CN1 ,2			E40-4245-05	PIN ASSY	P2K2P3	
CN3			E40-4245-05	PIN ASSY	Y1M1	
CN4			E40-8197-05	SOCKET FOR PIN ASSY		
CN11			E40-4281-05	PIN ASSY	Y1M1	
CN12,13			E40-3247-05	PIN ASSY		
CN14			E40-4101-05	PIN ASSY	E1T1Q1	
Δ CN14			E40-4101-05	PIN ASSY	E2	
Δ J1			E03-0148-05	AC OUTLET	KP1Y1	
Δ J1			E03-0148-05	AC OUTLET	K1P2K2	
Δ J1			E03-0148-05	AC OUTLET	P3	
Δ J1			E03-0149-05	AC OUTLET	E2	
Δ J1			E03-0149-05	AC OUTLET	M1E1Q1	
Δ J1			E03-0310-05	AC OUTLET	T1	
Δ J1			E03-0325-05	AC OUTLET	X1	
J2			E11-0295-05	PHONE JACK (3P)		
J3			E11-0347-05	MINIATURE PHONE JACK(2P)		
J4			E70-0089-05	SCREW TERMINAL BOARD	E1T1Q1	7
J4			E70-0089-05	SCREW TERMINAL BOARD	E2	7
CN5 ,6			J13-0075-05	FUSE CLIP		
CN7 ,8			J13-0075-05	FUSE CLIP	Y1M1	
CN9 ,10			J13-0075-05	FUSE CLIP	E1Q1E2	
E1			J11-0808-05	WIRE CLAMPER		
Δ T1			L07-2127-05	POWER TRANSFORMER	KP1K1	
Δ T1			L07-2127-05	POWER TRANSFORMER	P2K2P3	
Δ T1			L07-2128-05	POWER TRANSFORMER	Y1M1	
Δ T1			L07-2129-05	POWER TRANSFORMER	Q1E2	
Δ T1			L07-2129-05	POWER TRANSFORMER	X1E1T1	
R1			R92-1844-05	CARBON 3.3M J 1/2W	KP1K1	
Δ R1			R92-1844-05	CARBON 3.3M J 1/2W	P2K2P3	
K1			S76-0070-05	MAGNETIC RELAY		

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)

K : USA
T : Europe
X : Australia

P : Canada
E : Europe
Q : Russia

R : Mexico
G : Germany
H : Korea

C : China
V : China (Shanghai)
M : Other Areas

I : Malaysia

Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

8

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
Δ S1			S68-0088-05		E1T1Q1	
Δ S1			S68-0088-05		E2	
Δ S1			S68-0088-05		Y1M1X1	
Δ S2 ,3			S62-0001-05	SLIDE SWITCH	Y1M1	
Δ S4			S62-0034-05	SLIDE SWITCH		
Δ D1 -4			S5688B	DIODE		
Δ D1 -4			1SR139-400	DIODE		
D5			MTZJ6.2(B)	ZENER DIODE		
D5			RD6.2ES(B2)	ZENER DIODE		
Δ D6 ,7			HSS104A	DIODE		
Δ D6 ,7			1SS133	DIODE		
Δ D8			MTZJ2.7(B)	ZENER DIODE		
Δ D8			RD2.7ES(B2)	ZENER DIODE		
Δ D9			HSS104A	DIODE		
Δ D9			1SS133	DIODE		
Δ Q1			2SC3940A(R,S)	TRANSISTOR		
Δ Q2			2SC2003(L,K)	TRANSISTOR		
MPX (SAP) UNIT (X04-1320-10) VR-257 ONLY						
C1 ,2			CE04LW1H100M	ELECTRO 10UF 50WV		
C3 ,4			CQ92FM1H102J	MYLAR 1000PF J		
C5			CE04LW1C470M	ELECTRO 47UF 16WV		
C6 ,7			CE04LW1H100M	ELECTRO 10UF 50WV		
C8 ,9			CC45FCH1H101J	CERAMIC 100PF J		
C10 ,11			CQ92FM1H102J	MYLAR 1000PF J		
C14 ,15			CQ92FM1H102J	MYLAR 1000PF J		
C16 ,17			CE04LW1C470M	ELECTRO 47UF 16WV		
C41			CK45FB1H102K	CERAMIC 1000PF K		
C42			CC45FCH1H470J	CERAMIC 47PF J		
C43			CK45FB1H102K	CERAMIC 1000PF K		
CN4			E40-4372-05	PIN ASSY		
CN5			E40-3259-05	PIN ASSY		
J1			E04-0026-05	RF COAXIAL CABLE RECEPTACLE		
J2			E13-0194-05	PHONO JACK (1P)		
L41 ,42		*	L40-1091-82	SMALL FIXED INDUCTOR(1.0UH)		
R27			RD14NB2E391J	RD 390 J 1/4W		
R28			RS14KB3A151J	FL-PROOF RS 150 J 1W		
VR1			R32-0036-05	SEMI FIXED VARIABLE RESISTOR		
D1			HSS104A	DIODE		
D1			1SS133	DIODE		
D2			MTZJ3.3(B)	ZENER DIODE		
D2			RD3.3ES(B2)	ZENER DIODE		
D3 ,4			MTZJ8.2(B)	ZENER DIODE		
D3 ,4			RD8.2ES(B2)	ZENER DIODE		
D5			MTZJ5.1(B)	ZENER DIODE		
D5			RD5.1ES(B2)	ZENER DIODE		
D41 -44			HSS104A	DIODE		
D41 -44			1SS133	DIODE		
IC1 ,2			NJM4565D	ANALOGUE IC		
IC3			BU4052BC	MOS-IC		
Q1			DTA124ESA	DIGITAL TRANSISTOR		
Q1			UN4112	DIGITAL TRANSISTOR		
Q2 ,3			DTC124ESA	DIGITAL TRANSISTOR		

L : Scandinavia
Y : PX(Far East, Hawaii)
Y : AAFES(Europe)

K : USA
T : Europe
X : Australia

P : Canada
E : Europe
Q : Russia

R : Mexico
G : Germany
H : Korea

C : China
V : China (Shanghai)
M : Other Areas

I : Malaysia

Δ indicates safety critical components.

PARTS LIST

KRF-V5010N/6010N/7010N/R-205/206/207/255/257

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

9

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
Q2 ,3			UN4212	DIGITAL TRANSISTOR		
Q4 ,5			2SD1450(S,T)	TRANSISTOR		
Q6 ,7			2SA1048(Y,GR)	TRANSISTOR		
Q6 ,7			2SA1309A(Q,R)	TRANSISTOR		
A1			W02-2635-05	ELECTRIC CIRCUIT MODULE		
TUNER UNIT (X05-482X-XX)						
C1			CK73FB1H223K	CHIP C	0.022UF K	E1T1Q1 E2
C2			CK73FB1H103K	CHIP C	0.010UF K	
C2			CK73FB1H103K	CHIP C	0.010UF K	
C3			CK73FB1H103K	CHIP C	0.010UF K	
C5 ,6			CK73FB1H103K	CHIP C	0.010UF K	
C7			CE04LW1C470M	ELECTRO	47UF 16WV	KP1Y1 M1X1K1 P2K2P3
C8			CK73EB1H103K	CHIP C	0.010UF K	
C8			CK73EB1H103K	CHIP C	0.010UF K	
C8			CK73EB1H103K	CHIP C	0.010UF K	
C10			CE04LW1C470M	ELECTRO	47UF 16WV	
C11 -13			CK73FB1H473K	CHIP C	0.047UF K	E1T1Q1 E2
C14			CE04LW1C100M	ELECTRO	10UF 16WV	
C15			CE04LW1H010M	ELECTRO	1.0UF 50WV	
C16			C90-3251-05	ELECTRO	0.47UF 50WV	
C17			C90-3253-05	ELECTRO	1.0UF 50WV	
C18			CC73FCH1H470J	CHIP C	47PF J	E1T1Q1 E2 KP1Y1
C19			C90-3217-05	ELECTRO	10UF 10WV	
C20			CK73FB1H473K	CHIP C	0.047UF K	
C21			C90-3241-05	ELECTRO	3.3UF 35WV	
C22			CK73FB1H473K	CHIP C	0.047UF K	
C23			CE04LW1C100M	ELECTRO	10UF 16WV	E1T1Q1 E2 KP1Y1
C24			CK73FB1H331K	CHIP C	330PF K	
C25			CC73FCH1H181J	CHIP C	180PF J	
C25			CC73FCH1H181J	CHIP C	180PF J	
C25			CC73FCH1H391J	CHIP C	390PF J	
C25			CC73FCH1H391J	CHIP C	390PF J	M1X1K1 P2K2P3 E1T1Q1 E2 KP1Y1
C25			CK73FB1H183K	CHIP C	0.018UF K	
C26			CK73FB1H183K	CHIP C	0.018UF K	
C26			CK73FB1H223K	CHIP C	0.022UF K	
C26			CK73FB1H223K	CHIP C	0.022UF K	
C26			CK73FB1H223K	CHIP C	0.022UF K	M1X1K1 P2K2P3 E1T1Q1
C26			CK73FB1H223K	CHIP C	0.022UF K	
C27			CE04HW1E4R7M	NP-ELEC	4.7UF 25WV	
C28 ,29			C90-3240-05	ELECTRO	2.2UF 35WV	
C30 ,31			CK73FB1H223K	CHIP C	0.022UF K	
C30 ,31			CK73FB1H223K	CHIP C	0.022UF K	E2 Y1M1X1 KP1K1 P2K2P3
C30 ,31			CK73FB1H333K	CHIP C	0.033UF K	
C30 ,31			CK73FB1H333K	CHIP C	0.033UF K	
C30 ,31			CE04LW1C100M	ELECTRO	10UF 16WV	
C32						
C33 ,34			CK73FB1H103K	CHIP C	0.010UF K	Y1M1
C36			CK73FB1H103K	CHIP C	0.010UF K	
C37 ,38			C90-3217-05	ELECTRO	10UF 10WV	
C39			CC73FCH1H060D	CHIP C	6.0PF D	
C40			CC73FCH1H020C	CHIP C	2.0PF C	
C41			CC73FCH1H220J	CHIP C	22PF J	E1T1Q1 E2
C42			CC73FCH1H270J	CHIP C	27PF J	
C43			CC73FCH1H220J	CHIP C	22PF J	

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

10

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
C44			CK73FB1H471K	CHIP C	470PF K	E1T1Q1
C45			CC73FCH1H220J	CHIP C	22PF J	
C46			CE04LW1C100M	ELECTRO	10UF 16WV	
C47			CK73FB1H102K	CHIP C	1000PF K	
C48			CE04LW1C470M	ELECTRO	47UF 16WV	
C49			CE04LW1H2R2M	ELECTRO	2.2UF 50WV	E2
C50			CC73FSL1H101J	CHIP C	100PF J	
C51			CK73FB1H471K	CHIP C	470PF K	
C52			CC73FSL1H101J	CHIP C	100PF J	
C70 ,71			CK73FB1H822K	CHIP C	8200PF K	
C70 ,71			CK73FB1H822K	CHIP C	8200PF K	E1T1Q1 E2
C72			CE04LW1H010M	ELECTRO	1.0UF 50WV	
C73			CE04LW1C470M	ELECTRO	47UF 16WV	
C75			CC73FCH1H040C	CHIP C	4.0PF C	
C76			CC73FCH1H470J	CHIP C	47PF J	
C78			CK73FB1H223K	CHIP C	0.022UF K	E1T1Q1 E2
C79 ,80			CK73FB1H472K	CHIP C	4700PF K	
C79 ,80			CK73FB1H472K	CHIP C	4700PF K	
C81			CK73FF1C105Z	CHIP C	1.0UF Z	
C82			CK73FB1H103K	CHIP C	0.010UF K	
C82			CK73FSL1H101J	CHIP C	0.010UF K	E2
C83			CK73FB1H223K	CHIP C	100PF J	
C84 ,85			CK73FB1H223K	CHIP C	0.022UF K	
C86			CK73FB1H471K	CHIP C	470PF K	
CN1			E40-9831-05	SOCKET FOR PIN ASSY		KP1Y1 M1X1E1 P3E2 T1Q1K2 E1T1Q1
CN1			E40-9831-05	SOCKET FOR PIN ASSY		
CN1			E40-9831-05	SOCKET FOR PIN ASSY		
CN1			E40-9831-05	SOCKET FOR PIN ASSY		
CN2			E40-4871-05	PIN ASSY		
CN2			E70-0080-05	LOCK TERMINAL BOARD		E2
CF1 ,2			L72-0531-05	CERAMIC FILTER		
CF1 ,2			L72-0531-05	CERAMIC FILTER		
CF1 ,2			L72-0536-05	CERAMIC FILTER		
CF1 ,2			L72-0536-05	CERAMIC FILTER		
CF1 ,2			L72-0596-05	CERAMIC FILTER		K1P2 Y1M1X1 E1T1Q1 E2 KP1K1
CF1 ,2			L72-0596-05	CERAMIC FILTER		
CF3			L72-0607-05	CERAMIC FILTER		
CF3			L72-0607-05	CERAMIC FILTER		
CF3			L72-0607-05	CERAMIC FILTER		
L1			L39-1366-05	COMBINATION COIL		P2K2P3 KP1Y1 M1X1K1 P2K2P3
L2			L40-1091-82	SMALL FIXED INDUCTOR(1.0UH)		
L3			L30-0911-05	AM IFT		
L4			L30-0950-05	FM IFT		
L4			L30-0950-05	FM IFT		
L5			L30-0951-05	FM IFT		E2 E1T1Q1 E2
L5			L30-0951-05	FM IFT		
L6 ,7			L79-1239-05	LC FILTER		
L6 ,7			L79-1239-05	LC FILTER		
L9			L40-1001-82	SMALL FIXED INDUCTOR(10UH)		
X1			L77-2187-05	CRYSTAL RESONATOR		E1T1Q1 E2
R1			RK73FB2A101J	CHIP R	100 J 1/10W	
R3			RK73FB2A332J	CHIP R	3.3K J 1/10W	
R3			RK73FB2A332J	CHIP R	3.3K J 1/10W	
R3			RK73FB2A332J	CHIP R	3.3K J 1/10W	

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

KRF-V5010W6010N/7010WVR-205/206/207/255/257
PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

11

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
R4			RK73FB2A681J	CHIP R	680	J 1/10W
R5			RK73FB2A332J	CHIP R	3.3K	J 1/10W
R6			RK73FB2A221J	CHIP R	220	J 1/10W
R7			RK73FB2A821J	CHIP R	820	J 1/10W
R8			RK73FB2A100J	CHIP R	10	J 1/10W
					E1T1Q1	
R8			RK73FB2A100J	CHIP R	10	J 1/10W
R8			RK73FB2A330J	CHIP R	33	J 1/10W
R8			RK73FB2A330J	CHIP R	33	J 1/10W
R8			RK73FB2A330J	CHIP R	33	J 1/10W
R9			RK73FB2A391J	CHIP R	390	J 1/10W
					E2	
R10			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R11			RK73FB2A220J	CHIP R	22	J 1/10W
R11			RK73FB2A220J	CHIP R	22	J 1/10W
R11			RK73FB2A330J	CHIP R	33	J 1/10W
R11			RK73FB2A330J	CHIP R	33	J 1/10W
					KP1Y1	
					M1X1K1	
R11			RK73FB2A330J	CHIP R	33	J 1/10W
R12			RK73FB2A101J	CHIP R	100	J 1/10W
R14			RK73FB2A101J	CHIP R	100	J 1/10W
R14			RK73FB2A101J	CHIP R	100	J 1/10W
R14			RK73FB2A271J	CHIP R	270	J 1/10W
					KP1Y1	
R14			RK73FB2A271J	CHIP R	270	J 1/10W
R14			RK73FB2A271J	CHIP R	270	J 1/10W
R15			RK73FB2A333J	CHIP R	33K	J 1/10W
R15			RK73FB2A333J	CHIP R	33K	J 1/10W
R16			RK73FB2A220J	CHIP R	22	J 1/10W
					E2	
R17			RK73FB2A362J	CHIP R	3.6K	J 1/10W
R18			RK73FB2A302J	CHIP R	3.0K	J 1/10W
R19			RK73FB2A822J	CHIP R	8.2K	J 1/10W
R20			RK73FB2A392J	CHIP R	3.9K	J 1/10W
R23			RK73FB2A153J	CHIP R	15K	J 1/10W
					E1T1Q1	
R23			RK73FB2A153J	CHIP R	15K	J 1/10W
R23			RK73FB2A332J	CHIP R	3.3K	J 1/10W
R23			RK73FB2A332J	CHIP R	3.3K	J 1/10W
R23			RK73FB2A332J	CHIP R	3.3K	J 1/10W
R25			RK73FB2A183J	CHIP R	18K	J 1/10W
					KP1Y1	
R25			RK73FB2A183J	CHIP R	18K	J 1/10W
R25			RK73FB2A273J	CHIP R	27K	J 1/10W
R25			RK73FB2A273J	CHIP R	27K	J 1/10W
Δ R27 ,28			RK73FB2A432J	CHIP R	4.3K	J 1/10W
					E1T1Q1	
Δ R27 ,28			RK73FB2A432J	CHIP R	4.3K	J 1/10W
Δ R27 ,28			RK73FB2A822J	CHIP R	8.2K	J 1/10W
Δ R27 ,28			RK73FB2A822J	CHIP R	8.2K	J 1/10W
Δ R27 ,28			RK73FB2A822J	CHIP R	8.2K	J 1/10W
R30			RK73FB2A561J	CHIP R	560	J 1/10W
					Y1M1	
R31			RK73FB2A473J	CHIP R	47K	J 1/10W
R33 ,34			RK73FB2A101J	CHIP R	100	J 1/10W
R33 ,34			RK73FB2A101J	CHIP R	100	J 1/10W
R33 ,34			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R33 ,34			RK73FB2A102J	CHIP R	1.0K	J 1/10W
					KP1Y1	
					M1X1E1	
R33 ,34			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R33 ,34			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R35			RK73FB2A101J	CHIP R	100	J 1/10W
R35			RK73FB2A101J	CHIP R	100	J 1/10W
R36			RK73FB2A101J	CHIP R	100	J 1/10W
					K1P2	

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

12

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
R36			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R36			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R37			RK73FB2A392J	CHIP R	3.9K	J 1/10W
R37			RK73FB2A392J	CHIP R	3.9K	J 1/10W
R38			RK73FB2A102J	CHIP R	1.0K	J 1/10W
					E1T1Q1	
R38			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R39			RK73FB2A103J	CHIP R	10K	J 1/10W
R39			RK73FB2A103J	CHIP R	10K	J 1/10W
R42			RK73FB2A103J	CHIP R	10K	J 1/10W
R43			RK73FB2A221J	CHIP R	220	J 1/10W
					E2	
Δ R44			RD14NB2E271J	RD	270	J 1/4W
R45			RK73EB2B102J	CHIP R	1.0K	J 1/8W
R46			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R47			RK73EB2B102J	CHIP R	1.0K	J 1/8W
R48			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R49			RK73FB2A103J	CHIP R	10K	J 1/10W
R50			RD14NB2E471J	RD	470	J 1/4W
R51			RK73FB2A562J	CHIP R	5.6K	J 1/10W
R52			RK73FB2A101J	CHIP R	100	J 1/10W
R53			RK73FB2A222J	CHIP R	2.2K	J 1/10W
R54			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R55			RK73FB2A333J	CHIP R	33K	J 1/10W
R56 ,57			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R58			RK73FB2A123J	CHIP R	12K	J 1/10W
R59			RK73FB2A122J	CHIP R	1.2K	J 1/10W
R72 ,73			RK73FB2A153J	CHIP R	15K	J 1/10W
R72 ,73			RK73FB2A153J	CHIP R	15K	J 1/10W
R72 ,73			RK73FB2A392J	CHIP R	3.9K	J 1/10W
R72 ,73			RK73FB2A392J	CHIP R	3.9K	J 1/10W
R72 ,73			RK73FB2A822J	CHIP R	8.2K	J 1/10W
					Y1M1X1	
R74			RK73FB2A473J	CHIP R	47K	J 1/10W
R74			RK73FB2A473J	CHIP R	47K	J 1/10W
R74			RK73FB2A473J	CHIP R	47K	J 1/10W
R74			RK73FB2A473J	CHIP R	47K	J 1/10W
R75			RK73FB2A822J	CHIP R	8.2K	J 1/10W
R75			RK73FB2A822J	CHIP R	8.2K	J 1/10W
R75			RK73FB2A822J	CHIP R	8.2K	J 1/10W
R76			RK73FB2A182J	CHIP R	1.8K	J 1/10W
R76			RK73FB2A182J	CHIP R	1.8K	J 1/10W
R76			RK73FB2A182J	CHIP R	1.8K	J 1/10W
R76			RK73FB2A182J	CHIP R	1.8K	J 1/10W
R76			RK73FB2A182J	CHIP R	1.8K	J 1/10W
R76			RK73FB2A182J	CHIP R	1.8K	J 1/10W
R78			RK73FB2A821J	CHIP R	820	J 1/10W
R78			RK73FB2A821J	CHIP R	820	J 1/10W
R78			RK73FB2A821J	CHIP R	820	J 1/10W
R78			RK73FB2A821J	CHIP R	820	J 1/10W
R78			RK73FB2A821J	CHIP R	820	J 1/10W
R78			RK73FB2A821J	CHIP R	820	J 1/10W
R78			RK73FB2A821J	CHIP R	820	J 1/10W
R80			RK73FB2A223J	CHIP R	22K	J 1/10W
R80			RK73FB2A223J	CHIP R	22K	J 1/10W
R81			RS14KB3A151J	FL-PROOF RS	150	J 1W
R82			RK73FB2A272J	CHIP R	2.7K	J 1/10W
					E1T1Q1	
R82			RK73FB2A272J	CHIP R	2.7K	J 1/10W
R83			RK73FB2A102J	CHIP R	1.0K	J 1/10W
R84			RK73EB2B102J	CHIP R	1.0K	J 1/8W
R85 -87			RK73FB2A105J	CHIP R	1.0M	J 1/10W
R88			RK73FB2A563J	CHIP R	56K	J 1/10W

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

PARTS LIST

KRF-V5010N/6010N/7010N/R-205/206/207/255/257

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

13

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
VR1			R32-0037-05	SEMI FIXED VARIABLE RESISTOR		
W51 ,55			R92-0670-05	CHIP R 0 OHM	K1P2	
W51 ,52			R92-0670-05	CHIP R 0 OHM	KP1Y1	
W51 ,52			R92-0670-05	CHIP R 0 OHM	M1X1E1	
W51 ,52			R92-0670-05	CHIP R 0 OHM	P3E2	
W51 ,52			R92-0670-05	CHIP R 0 OHM	T1Q1K2	
W54 -57			R92-0670-05	CHIP R 0 OHM	Y1M1	
W54 ,55			R92-0670-05	CHIP R 0 OHM	E1T1Q1	
W54 ,55			R92-0670-05	CHIP R 0 OHM	KP1X1	
W54 ,55			R92-0670-05	CHIP R 0 OHM	K2P3E2	
W57			R92-0670-05	CHIP R 0 OHM	E1T1K2	
W57			R92-0670-05	CHIP R 0 OHM	KP1X1	
W57			R92-0670-05	CHIP R 0 OHM	P3	
W57 -60			R92-0670-05	CHIP R 0 OHM	E2	
W57 -60			R92-0670-05	CHIP R 0 OHM	Q1K1P2	
W59 ,60			R92-0670-05	CHIP R 0 OHM	KP1Y1	
W59 ,60			R92-0670-05	CHIP R 0 OHM	M1X1E1	
W59 ,60			R92-0670-05	CHIP R 0 OHM	T1K2P3	
W80			R92-0679-05	CHIP R 0 OHM		
W82 -85			R92-0679-05	CHIP R 0 OHM	KP1Y1	
W82 -85			R92-0679-05	CHIP R 0 OHM	M1X1K2	
W82 -85			R92-0679-05	CHIP R 0 OHM	P3	
W82 -86			R92-0679-05	CHIP R 0 OHM	K1P2	
W84 -86			R92-0679-05	CHIP R 0 OHM	Q1E2	
W84 ,85			R92-0679-05	CHIP R 0 OHM	E1T1	
D1			DA204U	DIODE		
D1			MA143A	DIODE		
D1			1SS302	DIODE		
D3			MTZJ8.2(B)	ZENER DIODE		
D3			RD8.2ES(B2)	ZENER DIODE		
D4			MTZJ5.1(B)	ZENER DIODE		
D4			RD5.1ES(B2)	ZENER DIODE		
D5			MTZJ2.7(B)	ZENER DIODE		
D5			RD2.7ES(B2)	ZENER DIODE		
D8			MA111	DIODE		
D9			MTZJ3.3(B)	ZENER DIODE	KP1Y1	
D9			MTZJ3.3(B)	ZENER DIODE	M1X1E1	
D9			MTZJ3.3(B)	ZENER DIODE	P3E2	
D9			MTZJ3.3(B)	ZENER DIODE	T1Q1K2	
D9			RD3.3ES(B2)	ZENER DIODE	KP1Y1	
D9			RD3.3ES(B2)	ZENER DIODE	M1X1E1	
D9			RD3.3ES(B2)	ZENER DIODE	P3E2	
D9			RD3.3ES(B2)	ZENER DIODE	T1Q1K2	
D11			MA111	DIODE	E1T1Q1	
D11			MA111	DIODE	E2	
D13			MA111	DIODE		
IC1			LA1837	ANALOGUE IC	E1T1Q1	
IC1			LA1837	ANALOGUE IC	E2	
IC1			LA1838	ANALOGUE IC	KP1Y1	
IC1			LA1838	ANALOGUE IC	M1X1K1	
IC1			LA1838	ANALOGUE IC		
IC1			LA1838	ANALOGUE IC		
IC2			LA1838	ANALOGUE IC	P2K2P3	
IC2			LC72131	MOS-IC		
Q1			2SC4081(R,S)	TRANSISTOR		
Q1			2SC4116(Y,GR)	TRANSISTOR		
Q2			2SA1576A(R,S)	TRANSISTOR		

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

14

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
Q2			2SA1586(Y,GR)	TRANSISTOR		
Q3 ,4			2SC4081(R,S)	TRANSISTOR	Y1M1	
Q3 ,4			2SC4116(Y,GR)	TRANSISTOR	Y1M1	
Q6			2SC4081(R,S)	TRANSISTOR	E1T1Q1	
Q6			2SC4081(R,S)	TRANSISTOR	E2	
Q6			2SC4116(Y,GR)	TRANSISTOR	E1T1Q1	
Q6			2SC4116(Y,GR)	TRANSISTOR	E2	
Q7			2SC4081(R,S)	TRANSISTOR	E1T1Q1	
Q7			2SC4081(R,S)	TRANSISTOR	E2K1P2	
Q7			2SC4116(Y,GR)	TRANSISTOR	E1T1Q1	
Q7			2SC4116(Y,GR)	TRANSISTOR		
Q10 ,11			2SC4116(Y,GR)	TRANSISTOR	E2K1P2	
Q10 ,11			2SD1757K	TRANSISTOR	KP1Y1	
Q10 ,11			2SD1757K	TRANSISTOR	M1X1E1	
Q10 ,11			2SD1757K	TRANSISTOR	P3E2	
Q10 ,11			2SD1757K	TRANSISTOR	T1Q1K2	
Q12			2SA1576A(R,S)	TRANSISTOR	KP1Y1	
Q12			2SA1576A(R,S)	TRANSISTOR	M1X1E1	
Q12			2SA1576A(R,S)	TRANSISTOR	P3E2	
Q12			2SA1576A(R,S)	TRANSISTOR	T1Q1K2	
Q12			2SA1586(Y,GR)	TRANSISTOR	KP1Y1	
Q12			2SA1586(Y,GR)	TRANSISTOR	M1X1E1	
Q12			2SA1586(Y,GR)	TRANSISTOR	P3E2	
Q12			2SA1586(Y,GR)	TRANSISTOR	T1Q1K2	
Q14			2SA1576A(R,S)	TRANSISTOR		
Q14			2SA1586(Y,GR)	TRANSISTOR		
A1			W02-2584-05	FM FRONT-END ASSY	E1T1	
A1			W02-2586-05	FM FRONT-END ASSY	E2	
A1			W02-2586-05	FM FRONT-END ASSY	Q1K1P2	
A1			W02-2622-05	FM FRONT-END ASSY	KP1Y1	
A1			W02-2622-05	FM FRONT-END ASSY	M1X1K2	
A1			W02-2622-05	FM FRONT-END ASSY	P3	
AUDIO UNIT(X09-490X-XX)						
D501,502			B30-2513-05	LED(RED)	K1P2	7
D527			B30-2513-05	LED(RED)		
D528			B30-2513-05	LED(RED)	K1P2	7
C1 ,2			CC73FSL1H390J	CHIP C 39PF J		
C3 ,4			CE04LW1C100M	ELECTRO 10UF 16WV		
C5 ,6			CC73FSL1H221J	CHIP C 220PF J		
C7 ,8			CE04LW1A470M	ELECTRO 47UF 10WV		
C11 ,12			CQ93FMG1H123J	MYLAR 0.012UF J		
C13 ,14			CQ93FMG1H332J	MYLAR 3300PF J		
C15 ,16			CE04LW1V4R7M	ELECTRO 4.7UF 35WV		
C17			CC45FSL1H101J	CERAMIC 100PF J		
C18			CK45FF1H103Z	CERAMIC 0.010UF Z		
C19 -36			CC73FSL1H221J	CHIP C 220PF J		
C37 -41			CC73FCH1H470J	CHIP C 47PF J		
C42 ,43			CK45FF1H103Z	CERAMIC 0.010UF Z		
C44			CC73FSL1H471J	CHIP C 470PF J		
C45 ,46			CE04LW1H2R2M	ELECTRO 2.2UF 50WV		
C47 ,48			CC73FSL1H101J	CHIP C 100PF J		
C51			CK45FB1H391K	CERAMIC 390PF K		
C52			CK45FF1H103Z	CERAMIC 0.010UF Z		
C53 ,54			CC73FSL1H101J	CHIP C 100PF J		
C55 ,56			CE04LW1C220M	ELECTRO 22UF 16WV		

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

KRF-V5010W6010N/7010NVR-205/206/207/255/257
PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

15

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
C61 -63 C93,94 C95 C98,99 C100,101			CE04LW1C100M CK45FF1H103Z CC73FSL1H471J CE04LW1A101M CE04LW1C100M	ELECTRO 10UF 16WV CERAMIC 0.010UF Z CHIP C 470PF J ELECTRO 100UF 10WV ELECTRO 10UF 16WV		
C104,105 C106,107 C108,109 C110 C111-118			CK73FB1H153K CE04LW1HR33M CQ93FMG1H822J CC73FSL1H471J CE04LW1V4R7M	CHIP C 0.015UF K ELECTRO 0.33UF 50WV MYLAR 8200PF J CHIP C 470PF J ELECTRO 4.7UF 35WV		
C119,120 C121 C122 C123-126 C127,128			CE04LW1H3R3M CC73FSL1H221J CE04LW1H010M CC73FSL1H101J CE04LW1C100M	ELECTRO 3.3UF 50WV CHIP C 220PF J ELECTRO 1.0UF 50WV CHIP C 100PF J ELECTRO 10UF 16WV		
C129 C130 C131-134 C135 C136			CE04LW1C101M CE04LW1C470M CE04LW1C100M CK73FB1C104K CK73FB1H562K	ELECTRO 100UF 16WV ELECTRO 47UF 16WV ELECTRO 10UF 16WV CHIP C 0.10UF K CHIP C 5600PF K		
C137 C138 C139 C140,141 C142			CE04LW1C100M CE04LW1E221M CE04LW1C470M CK73FF1E104Z CK73FB1H681K	ELECTRO 10UF 16WV ELECTRO 220UF 25WV ELECTRO 47UF 16WV CHIP C 0.10UF Z CHIP C 680PF K		
C143,144 C145 C146 C147,148 C149,150			CK73FF1E104Z CK73FB1H681K CQ93FMG1H104J CQ93FMG1H223J CK73FB1C104K	CHIP C 0.10UF Z CHIP C 680PF K MYLAR 0.10UF J MYLAR 0.022UF J CHIP C 0.10UF K		
C151,152 C153 C154 C155 C156,157			CQ93FMG1H473J CK73FB1C104K CK73FF1C224Z CQ93FMG1H224J CE04LW1V4R7M	MYLAR 0.047UF J CHIP C 0.10UF K CHIP C 0.22UF Z MYLAR 0.22UF J ELECTRO 4.7UF 35WV		
C158 C159 C160 C161 C162			CQ93FMG1H224J CK73FF1C224Z CK73FF1C105Z CK73EB1E473K CK73FB1H562K	MYLAR 0.22UF J CHIP C 0.22UF Z CHIP C 1.0UF Z CHIP C 0.047UF K CHIP C 5600PF K		
C163 C164 C165 C169 C170			CK73FB1H221K CK73FB1H103K CK73FB1C104K CK73FB1H182K CK73FB1H103K	CHIP C 220PF K CHIP C 0.010UF K CHIP C 0.10UF K CHIP C 1800PF K CHIP C 0.010UF K		
C171 C172,173 C174 C175 C176			CQ93FMG1H683J CQ93FMG1H104J CQ93FMG1H683J CQ93FMG1H182J CK73FB1H103K	MYLAR 0.068UF J MYLAR 0.10UF J MYLAR 0.068UF J MYLAR 1800PF J CHIP C 0.010UF K		
C177 C178 C181,182 C183,184 C193,194			CE04LW1H010M CE04LW1C220M CE04LW1V4R7M CC73FSL1H471J CE04LW1V4R7M	ELECTRO 1.0UF 50WV ELECTRO 22UF 16WV ELECTRO 4.7UF 35WV CHIP C 470PF J ELECTRO 4.7UF 35WV		

L : Scandinavia Y : PX(Far East, Hawaii) Y : AAFES(Europe)
K : USA T : Europe X : Australia
P : Canada E : Europe Q : Russia
R : Mexico G : Germany H : Korea
C : China V : China (Shanghai) M : Other Areas
I : Malaysia
Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

16

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
C195,196 C197 C203 C204 C205			CC73FSL1H471J CE04LW1V4R7M CC45FSL1H101J CK45FF1H103Z CE04LW1V4R7M	CHIP C 470PF J ELECTRO 4.7UF 35WV CERAMIC 100PF J CERAMIC 0.010UF Z ELECTRO 4.7UF 35WV		
C206 C206 C206 C207,208 C212			CK45FB1H392K CK45FB2H392K CK45FB2H392K CC73FSL1H471J CC73FSL1H101J	CERAMIC 3900PF K CERAMIC 3900PF K CERAMIC 3900PF K CHIP C 470PF J CHIP C 100PF J		5 7 6
C214 C215 C216,217 C218,219 C220,221			CE04LW1H010M CE04HW1E220M CK73FB1H102K CE04LW1C100M CE04LW1A101M	ELECTRO 1.0UF 50WV NP-ELEC 22UF 25WV CHIP C 1000PF K ELECTRO 10UF 16WV ELECTRO 100UF 10WV		
C222,223 C224,225 C226 C226 C226			CC73FCH1H150J CE04LW2A100M CK45FB1H392K CK45FB2H392K CK45FB2H392K	CHIP C 15PF J ELECTRO 10UF 100WV CERAMIC 3900PF K CERAMIC 3900PF K CERAMIC 3900PF K		5 7 6
C227 C227 C227 C228,229 C228,229			CE04LW1H470M CE04LW2A100M CE04LW2A100M CE04LW1H470M CE04LW1H470M	ELECTRO 47UF 50WV ELECTRO 10UF 100WV ELECTRO 10UF 100WV ELECTRO 47UF 50WV ELECTRO 47UF 50WV		5 7 6 7 6
C230,231 C230,231 C230,231 C232 C232			CK45FB1H392K CK45FB2H392K CK45FB2H392K CE04LW1H470M CE04LW2A100M	CERAMIC 3900PF K CERAMIC 3900PF K CERAMIC 3900PF K ELECTRO 47UF 50WV ELECTRO 10UF 100WV		5 7 6 5
C233-235 C236-238 C239-241 C242-244 C247,248			CK73FB1H102K CE04LW1C100M CE04LW1A101M CC73FCH1H150J CE04LW1H470M	CHIP C 1000PF K ELECTRO 10UF 16WV ELECTRO 100UF 10WV CHIP C 15PF J ELECTRO 47UF 50WV		5
C247,248 C249,250 C253-257 C258-262 C268			CE04LW2A100M CE04LW1H470M CK73FB1H102K CQ93FMG1H104J CE04LW1V4R7M	ELECTRO 10UF 100WV ELECTRO 47UF 50WV CHIP C 1000PF K MYLAR 0.10UF J ELECTRO 4.7UF 35WV		
C269 C270 C271 C272 C272			CE04LW0J221M CK45FF1H472Z CK45FF1H472Z CK45FF1H472Z CK45FF1H472Z	ELECTRO 220UF 6.3WV CERAMIC 4700PF Z CERAMIC 4700PF Z CERAMIC 4700PF Z CERAMIC 4700PF Z	KP1Y1 KP1Y11	5 7
C272 C272 C272 C272 C272			CK45FF1H472Z CK45FF1H472Z CK45FF1H472Z CK45FF1H472Z CK45FF1H472Z	CERAMIC 4700PF Z CERAMIC 4700PF Z CERAMIC 4700PF Z CERAMIC 4700PF Z CERAMIC 4700PF Z	KP1Y11 M1X1K1 M1X1K1 P2K2P3 P2K2P3	6 7 6 7 6
C273,274 C273,274 C275,276 C277-279 C277-279			CK45FF1H472Z CK45FF1H472Z CK45FF1H472Z CK45FB1H102K CK45FB1H102K	CERAMIC 4700PF Z CERAMIC 4700PF Z CERAMIC 4700PF Z CERAMIC 1000PF K CERAMIC 1000PF K	E2	7 6 6 7

L : Scandinavia Y : PX(Far East, Hawaii) Y : AAFES(Europe)
K : USA T : Europe X : Australia
P : Canada E : Europe Q : Russia
R : Mexico G : Germany H : Korea
C : China V : China (Shanghai) M : Other Areas
I : Malaysia
Δ indicates safety critical components.

PARTS LIST

KRF-V5010N/6010N/7010N/R-205/206/207/255/257

17

17

17

18

18

18

PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
J9			E63-1015-05	PHONO JACK		6
J10			E70-0068-05	LOCK TERMINAL BOARD		7
J10			E70-0068-05	LOCK TERMINAL BOARD		6
J10			E70-0094-05	LOCK TERMINAL BOARD		5
J11			E63-1016-05	PHONO JACK		5
-			J19-5879-13	HOLDER		
L1 -5			L39-1373-05	PHASE COMPENSATION COIL		
L501			L40-1091-82	SMALL FIXED INDUCTOR(1.0UH)	E1T1Q1	
L501			L40-1091-82	SMALL FIXED INDUCTOR(1.0UH)	E2	
L502			L40-1001-82	SMALL FIXED INDUCTOR(10UH)	E1T1Q1	
L502			L40-1001-82	SMALL FIXED INDUCTOR(10UH)	E2	
X1		*	L78-0244-05	RESONATOR (4MHZ)		
X501			L78-0290-05	RESONATOR (8MHZ)		
X502			L77-2206-05	CRYSTAL RESONATOR(4.332MHZ)	E1T1Q1	
X502			L77-2206-05	CRYSTAL RESONATOR(4.332MHZ)	E2	
R1 ,2			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R3 ,4			RK73FB2A273J	CHIP R 27K J 1/10W		
R5 ,6			RK73FB2A101J	CHIP R 100 J 1/10W		
R13 ,14			RK73FB2A473J	CHIP R 47K J 1/10W		
R17 ,18			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R19 ,20			RK73FB2A224J	CHIP R 220K J 1/10W		
R21 -24			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R25 ,26			RK73FB2A224J	CHIP R 220K J 1/10W		
R27 ,28			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R29 ,30			RK73FB2A224J	CHIP R 220K J 1/10W		
R31 ,32			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R33 ,34			RK73FB2A224J	CHIP R 220K J 1/10W		
R35 ,36			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R37 ,38			RK73FB2A224J	CHIP R 220K J 1/10W		
R39 ,40			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R41 ,42			RK73FB2A224J	CHIP R 220K J 1/10W		
R43			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R44			RK73FB2A103J	CHIP R 10K J 1/10W		
R45			RK73FB2A224J	CHIP R 220K J 1/10W		
R46			RK73FB2A392J	CHIP R 3.9K J 1/10W		
R47 ,48			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R49 ,50			RK73FB2A224J	CHIP R 220K J 1/10W		
R51 -53			RK73FB2A750J	CHIP R 75 J 1/10W		
R56 ,57			RK73FB2A332J	CHIP R 3.3K J 1/10W		
R59 -62			RK73FB2A224J	CHIP R 220K J 1/10W		
R67 ,68			RK73FB2A224J	CHIP R 220K J 1/10W		
R69 ,70			RK73FB2A4R7J	CHIP R 4.7 J 1/10W		
R71 ,72			RK73FB2A224J	CHIP R 220K J 1/10W		
R93 ,94			RS14KB3A391J	FL-PROOF RS 390 J 1W		
R97			RK73EB2B224J	CHIP R 220K J 1/8W		
R98 -102			RK73FB2A224J	CHIP R 220K J 1/10W		
R109			RS14KB3A221J	FL-PROOF RS 220 J 1W		
R110			RS14KB3A271J	FL-PROOF RS 270 J 1W		
R111-113			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R116,117			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R118			RK73FB2A473J	CHIP R 47K J 1/10W		
R119			RK73FB2A223J	CHIP R 22K J 1/10W		
R122			RK73FB2A473J	CHIP R 47K J 1/10W		
R123			RK73FB2A203J	CHIP R 20K J 1/10W		
R124			RK73FB2A105J	CHIP R 1.0M J 1/10W		

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
R125			RK73FB2A224J	CHIP R 220K J 1/10W		
R126			RK73FB2A104J	CHIP R 100K J 1/10W		
R127			RK73FB2A225J	CHIP R 2.2M J 1/10W		
R128			RK73FB2A752J	CHIP R 7.5K J 1/10W		
R129			RK73FB2A153J	CHIP R 15K J 1/10W		
R130			RK73FB2A473J	CHIP R 47K J 1/10W		
R131			RK73FB2A752J	CHIP R 7.5K J 1/10W		
R132			RK73FB2A153J	CHIP R 15K J 1/10W		
R133			RK73FB2A473J	CHIP R 47K J 1/10W		
R134			RD14NB2E221J	RD 220 J 1/4W		
R135			RS14KB3D680J	FL-PROOF RS 68 J 2W		
R136			RK73FB2A334J	CHIP R 330K J 1/10W		
R137,138			RK73FB2A243J	CHIP R 24K J 1/10W		
R145,146			RK73FB2A122J	CHIP R 1.2K J 1/10W		
R147,148			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R149,150			RK73FB2A104J	CHIP R 100K J 1/10W		
R157,158			RK73FB2A222J	CHIP R 2.2K J 1/10W		
R161,162			RK73FB2A122J	CHIP R 1.2K J 1/10W		
R163,164			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R165,166			RK73FB2A104J	CHIP R 100K J 1/10W		
R173,174			RK73FB2A222J	CHIP R 2.2K J 1/10W		
R177,178			RK73FB2A122J	CHIP R 1.2K J 1/10W		
R179,180			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R181,182			RK73FB2A104J	CHIP R 100K J 1/10W		
R183			RK73FB2A153J	CHIP R 15K J 1/10W		
R184			RK73FB2A391J	CHIP R 390 J 1/10W		
R186			RK73FB2A183J	CHIP R 18K J 1/10W		
R189,190			RK73FB2A222J	CHIP R 2.2K J 1/10W		
R191			RK73FB2A104J	CHIP R 100K J 1/10W		
R192,193			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R194			RK73FB2A223J	CHIP R 22K J 1/10W		
R195			RK73FB2A104J	CHIP R 100K J 1/10W		
R196,197			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R198			RK73FB2A104J	CHIP R 100K J 1/10W		
R199,200			RK73FB2A223J	CHIP R 22K J 1/10W		
R201,202			RK73FB2A104J	CHIP R 100K J 1/10W		
R203,204			RK73FB2A563J	CHIP R 56K J 1/10W		
R207,208			RK73FB2A331J	CHIP R 330 J 1/10W	KP1Y1	6
R207,208			RK73FB2A331J	CHIP R 330 J 1/10W	KP1Y1	7
R207,208			RK73FB2A331J	CHIP R 330 J 1/10W	M1X1K1	7
R207,208			RK73FB2A331J	CHIP R 330 J 1/10W		
R207,208			RK73FB2A331J	CHIP R 330 J 1/10W		
R207,208			RK73FB2A431J	CHIP R 430 J 1/10W		
R207,208			RK73FB2A431J	CHIP R 430 J 1/10W		
R207,208			RK73FB2A431J	CHIP R 430 J 1/10W		
R207,208			RK73FB2A431J	CHIP R 430 J 1/10W		
R207,208			RK73FB2A431J	CHIP R 430 J 1/10W		
R207,208			RK73FB2A471J	CHIP R 470 J 1/10W		
R207,208			RK73FB2A471J	CHIP R 470 J 1/10W		
R207,208			RK73FB2A471J	CHIP R 470 J 1/10W		
R207,208			RK73FB2A621J	CHIP R 620 J 1/10W		
R207,208			RK73FB2A621J	CHIP R 620 J 1/10W		
R209,210			RK73FB2A563J	CHIP R 56K J 1/10W		
R214,215			RD14NB2E103J	RD 10K J 1/4W		
R216			RS14KB3A392J	FL-PROOF RS 3.9K J 1W		

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

PARTS LIST

KRF-V5010N/6010N/7010N/R-205/206/207/255/257

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

21

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
R216			RS14KB3A392J	FL-PROOF RS 3.9K J 1W		7
R217-219			RK73FB2A104J	CHIP R 100K J 1/10W		
R220			RS14KB3A392J	FL-PROOF RS 3.9K J 1W		7
R220			RS14KB3A392J	FL-PROOF RS 3.9K J 1W		6
R221,222			RK73FB2A563J	CHIP R 56K J 1/10W		
R224			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R225,226			RK73FB2A301J	CHIP R 300 J 1/10W	KP1Y1	7
R225,226			RK73FB2A301J	CHIP R 300 J 1/10W	KP1Y1	6
R225,226			RK73FB2A301J	CHIP R 300 J 1/10W	M1X1K1	7
R225,226			RK73FB2A301J	CHIP R 300 J 1/10W	M1X1K1	7
R225,226			RK73FB2A301J	CHIP R 300 J 1/10W	P2K2P3	6
R225,226			RK73FB2A301J	CHIP R 300 J 1/10W	P2K2P3	7
R225,226			RK73FB2A431J	CHIP R 430 J 1/10W	E1T1Q1	7
R225,226			RK73FB2A431J	CHIP R 430 J 1/10W	E1T1Q1	6
R225,226			RK73FB2A431J	CHIP R 430 J 1/10W	E2	7
R225,226			RK73FB2A431J	CHIP R 430 J 1/10W	E2	6
R225,226			RK73FB2A431J	CHIP R 430 J 1/10W	KP1Y1	5
R225,226			RK73FB2A431J	CHIP R 430 J 1/10W	M1X1K1	5
R225,226			RK73FB2A431J	CHIP R 430 J 1/10W	P2	5
R225,226			RK73FB2A561J	CHIP R 560 J 1/10W	E1T1Q1	5
R225,226			RK73FB2A561J	CHIP R 560 J 1/10W	E2	5
R229,230			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R231			RK73FB2A563J	CHIP R 56K J 1/10W		
R233			RK73FB2A301J	CHIP R 300 J 1/10W	KP1Y1	6
R233			RK73FB2A301J	CHIP R 300 J 1/10W	KP1Y1	7
R233			RK73FB2A301J	CHIP R 300 J 1/10W	M1X1K1	7
R233			RK73FB2A301J	CHIP R 300 J 1/10W	M1X1K1	6
R233			RK73FB2A301J	CHIP R 300 J 1/10W	P2K2P3	7
R233			RK73FB2A301J	CHIP R 300 J 1/10W	P2K2P3	6
R233			RK73FB2A431J	CHIP R 430 J 1/10W	E1T1Q1	7
R233			RK73FB2A431J	CHIP R 430 J 1/10W	E2	6
R233			RK73FB2A431J	CHIP R 430 J 1/10W	E2	7
R233			RK73FB2A431J	CHIP R 430 J 1/10W	KP1Y1	5
R233			RK73FB2A431J	CHIP R 430 J 1/10W	M1X1K1	5
R233			RK73FB2A431J	CHIP R 430 J 1/10W	P2	5
R233			RK73FB2A561J	CHIP R 560 J 1/10W	E1T1Q1	5
R233			RK73FB2A561J	CHIP R 560 J 1/10W	E2	5
R239,240			RS14KB3A392J	FL-PROOF RS 3.9K J 1W		7
R239,240			RS14KB3A392J	FL-PROOF RS 3.9K J 1W		6
R241,242			R92-1866-05	METALFILM 0.1 2W		
R243,244			RK73FB2A333J	CHIP R 33K J 1/10W		
R245,246			RK73FB2A243J	CHIP R 24K J 1/10W		7
R245,246			RK73FB2A243J	CHIP R 24K J 1/10W		6
R245,246			RK73FB2A393J	CHIP R 39K J 1/10W		5
R247,248			RK73FB2A471J	CHIP R 470 J 1/10W		
R249			R92-1866-05	METALFILM 0.1 2W		
R251			RK73FB2A333J	CHIP R 33K J 1/10W		
R253			RK73FB2A243J	CHIP R 24K J 1/10W		7
R253			RK73FB2A243J	CHIP R 24K J 1/10W		6
R253			RK73FB2A393J	CHIP R 39K J 1/10W		
R255			RK73FB2A471J	CHIP R 470 J 1/10W		
R257,258			R92-1866-05	METALFILM 0.1 2W		
R259,260			RK73FB2A333J	CHIP R 33K J 1/10W		
R261,262			RK73FB2A243J	CHIP R 24K J 1/10W		7
R261,262			RK73FB2A243J	CHIP R 24K J 1/10W		6

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

22

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
R261,262			RK73FB2A393J	CHIP R 39K J 1/10W		5
R263,264			RK73FB2A471J	CHIP R 470 J 1/10W		
R265-267			RD14NB2E4R7J	RD 4.7 J 1/4W		
R268			RK73FB2A153J	CHIP R 15K J 1/10W		
R269,270			RD14NB2E4R7J	RD 4.7 J 1/4W		
R271-273			RK73FB2A333J	CHIP R 33K J 1/10W		
R275,276			RK73FB2A333J	CHIP R 33K J 1/10W		
R277			RK73FB2A203J	CHIP R 20K J 1/10W	E1T1Q1	7
R277			RK73FB2A203J	CHIP R 20K J 1/10W	E1T1Q1	6
R277			RK73FB2A203J	CHIP R 20K J 1/10W	E2	7
R277			RK73FB2A203J	CHIP R 20K J 1/10W	E26	
R277			RK73FB2A273J	CHIP R 27K J 1/10W	KP1Y1	7
R277			RK73FB2A273J	CHIP R 27K J 1/10W	KP1Y1	6
R277			RK73FB2A273J	CHIP R 27K J 1/10W	M1X1K1	7
R277			RK73FB2A273J	CHIP R 27K J 1/10W	M1X1K1	6
R277			RK73FB2A273J	CHIP R 27K J 1/10W	P2K2P3	7
R277			RK73FB2A273J	CHIP R 27K J 1/10W	P2K2P3	6
R279,280			RK73FB2A203J	CHIP R 20K J 1/10W	E1T1Q1	7
R279,280			RK73FB2A203J	CHIP R 20K J 1/10W	E1T1Q1	6
R279,280			RK73FB2A203J	CHIP R 20K J 1/10W	E2	7
R279,280			RK73FB2A203J	CHIP R 20K J 1/10W	E2	6
R279,280			RK73FB2A203J	CHIP R 20K J 1/10W	KP1Y1	7
R279,280			RK73FB2A273J	CHIP R 27K J 1/10W	KP1Y1	6
R279,280			RK73FB2A273J	CHIP R 27K J 1/10W	M1X1K1	7
R279,280			RK73FB2A273J	CHIP R 27K J 1/10W	M1X1K1	6
R279,280			RK73FB2A273J	CHIP R 27K J 1/10W	P2K2P3	7
R279,280			RK73FB2A273J	CHIP R 27K J 1/10W	P2K2P3	6
R281-283			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R284			RK73FB2A123J	CHIP R 12K J 1/10W		
R285			RK73FB2A682J	CHIP R 6.8K J 1/10W		
R286			RK73FB2A223J	CHIP R 22K J 1/10W		
R287-291			RK73FB2A272J	CHIP R 2.7K J 1/10W		
R292-295			RK73FB2A102J	CHIP R 1.0K J 1/10W		
R300			RD14NB2E1R0J	RD 1 J 1/4W		
R304,305			RK73FB2A273J	CHIP R 27K J 1/10W		5
R304,305			RK73FB2A513J	CHIP R 51K J 1/10W		
R304,305			RK73FB2A513J	CHIP R 51K J 1/10W		7
R306,307			RK73FB2A273J	CHIP R 27K J 1/10W		6
R306,307			RK73FB2A273J	CHIP R 27K J 1/10W		
R308			RD14NB2E4R7J	RD 4.7 J 1/4W		
R309			RD14NB2E103J	RD 10K J 1/4W		7
R309			RD14NB2E103J	RD 10K J 1/4W		6
R309			RD14NB2E472J	RD 4.7K J 1/4W		5
R311			RK73FB2A273J	CHIP R 27K J 1/10W		5
R311			RK73FB2A513J	CHIP R 51K J 1/10W		7
R311			RK73FB2A513J	CHIP R 51K J 1/10W		
R312			RK73FB2A273J	CHIP R 27K J 1/10W		6
R312			RK73FB2A273J	CHIP R 27K J 1/10W		7
R315,316			RK73FB2A472J	CHIP R 4.7K J 1/10W		
R317			RK73FB2A273J	CHIP R 27K J 1/10W		
R318			RS14KB3A681J	FL-PROOF RS 680 J 1W		
R320			RK73FB2A103J	CHIP R 10K J 1/10W		
R321			RK73FB2A473J	CHIP R 47K J 1/10W		
R322			RS14KB3D391J	FL-PROOF RS 390 J 2W		
R323			R92-1878-05	WIRE-WOUND RESISTOR		
R325			RS14KB3D391J	FL-PROOF RS 390 J 2W		

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

KRF-V5010W6010N/7010MR-205/206/207/255/257
PARTS LIST

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

23

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
R326-330 R331 R332 R333 R361,362			RK73FB2A102J RK73FB2A363J RK73FB2A751J RK73FB2A272J RS14KB3D391J	CHIP R 1.0K J 1/10W CHIP R 36K J 1/10W CHIP R 750 J 1/10W CHIP R 2.7K J 1/10W FL-PROOF RS 390 J 2W		
R363 R400 R403-407 R408 R409			RK73FB2A473J RK73FB2A472J RK73EB2B220J RK73FB2A222J RK73FB2A333J	CHIP R 47K J 1/10W CHIP R 4.7K J 1/10W CHIP R 22 J 1/8W CHIP R 2.2K J 1/10W CHIP R 33K J 1/10W		
R410,411 R412,413 R414 R415 R416			RK73EB2B224J RK73FB2A224J RK73FB2A103J RK73FB2A104J RK73FB2A683J	CHIP R 220K J 1/8W CHIP R 220K J 1/10W CHIP R 10K J 1/10W CHIP R 100K J 1/10W CHIP R 68K J 1/10W		
R417 R450,451 R450,451 R452 R452			RK73FB2A473J RK73FB2A272J RK73FB2A272J RK73FB2A361J RK73FB2A361J	CHIP R 47K J 1/10W CHIP R 2.7K J 1/10W CHIP R 2.7K J 1/10W CHIP R 360 J 1/10W CHIP R 360 J 1/10W	7 6 7 6	
R453 R453 R456 R457 R458			RK73FB2A472J RK73FB2A472J RK73FB2A473J RK73FB2A102J RK73FB2A101J	CHIP R 4.7K J 1/10W CHIP R 4.7K J 1/10W CHIP R 47K J 1/10W CHIP R 1.0K J 1/10W CHIP R 100 J 1/10W	7 6	
R460,461 R462 R514 R515 R523			RK73FB2A102J RK73EB2B101J RK73FB2A222J RK73FB2A103J RD14NB2E1R0J	CHIP R 1.0K J 1/10W CHIP R 100 J 1/8W CHIP R 2.2K J 1/10W CHIP R 10K J 1/10W RD 1 J 1/4W		
R524,525 R528 R529,530 R536 R545,546			RK73FB2A101J RK73FB2A101J RK73FB2A473J RK73FB2A102J RK73FB2A103J	CHIP R 100 J 1/10W CHIP R 100 J 1/10W CHIP R 47K J 1/10W CHIP R 1.0K J 1/10W CHIP R 10K J 1/10W		
R552 R556 R556 R556 R565			RK73FB2A102J RK73FB2A103J RK73FB2A103J RK73FB2A103J RK73FB2A103J	CHIP R 1.0K J 1/10W CHIP R 10K J 1/10W CHIP R 10K J 1/10W CHIP R 10K J 1/10W CHIP R 10K J 1/10W	KP1Y1 M1X1K1 P2K2P3	
R568 R570 R577 R580 R580			RK73FB2A103J RK73FB2A103J RK73FB2A103J RK73FB2A222J RK73FB2A222J	CHIP R 10K J 1/10W CHIP R 10K J 1/10W CHIP R 10K J 1/10W CHIP R 2.2K J 1/10W CHIP R 2.2K J 1/10W	E1T1Q1 E2	
R582 W303 W304-306 W309,310 W312			RK73FB2A102J R92-0679-05 R92-0670-05 R92-0679-05 R92-0679-05	CHIP R 1.0K J 1/10W CHIP R 0 OHM CHIP R 0 OHM CHIP R 0 OHM CHIP R 0 OHM		
W314 W315 W316-318 W501,502 W501,502			R92-0679-05 R92-0670-05 R92-0679-05 R92-0670-05 R92-0670-05	CHIP R 0 OHM CHIP R 0 OHM CHIP R 0 OHM CHIP R 0 OHM CHIP R 0 OHM	KP1Y1 M1X1K1	

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas ⚠ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

24

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
W501,502			R92-0670-05	CHIP R 0 OHM	P2K2P3	
K1 K2 K2 K3 ,4 S501-505			S76-0061-05 S76-0061-05 S76-0061-05 S76-0061-05 S70-0031-05	MAGNETIC RELAY MAGNETIC RELAY MAGNETIC RELAY MAGNETIC RELAY TACT SWITCH		7 6
S507 S509-512 S514-516 S520,521			S70-0031-05 S70-0031-05 S70-0031-05 S70-0031-05	TACT SWITCH TACT SWITCH TACT SWITCH TACT SWITCH		
S517 S518,519			T99-0602-05 T99-0605-05	ROTARY ENCODER ROTARY ENCODER		
D3 ,4 D3 ,4 D5 ,6 D5 ,6 D7			MTZJ5.1(B) RD5.1ES(B2) MTZJ6.8(B) RD6.8ES(B2) MTZJ5.1(B)	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE		
D7 D8 D8 D10 D10			RD5.1ES(B2) MTZJ11(B) RD11ES(B2) MTZJ8.2(B) MTZJ8.2(B)	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE	7 6	
D10 D10 D11 D11 D11			RD8.2ES(B2) RD8.2ES(B2) MTZJ7.5(B) MTZJ7.5(B) RD7.5ES(B2)	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE	7 6 7 6 6	
D11 D12 ,13 D12 ,13 D12 ,13 D12 ,13			RD7.5ES(B2) MTZJ8.2(B) MTZJ8.2(B) RD8.2ES(B2) RD8.2ES(B2)	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE	7 6 7 7 6	
D14 ,15 D14 ,15 D14 ,15 D14 ,15 D19			MTZJ10(B) MTZJ10(B) RD10ES(B2) RD10ES(B2) MA111	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE DIODE	6 7 7 6	
D20 D20 D21 -23 D24 D24			MA111 MA111 MA111 MTZJ4.7(B) RD4.7ES(B2)	DIODE DIODE DIODE ZENER DIODE ZENER DIODE	7 6	
D25 D25 D26 D31 ,32 D33 -36			MTZJ3.3(B) RD3.3ES(B2) MA111 D4SBL20UF03 S5688B(TPB5)	ZENER DIODE ZENER DIODE DIODE DIODE DIODE		
D37 ,38 D37 ,38 D39 ,40 D39 ,40 D50 ,51			MTZJ16(B) RD16ES(B2) MTZJ18(B) RD18ES(B2) MA111	ZENER DIODE ZENER DIODE ZENER DIODE ZENER DIODE DIODE		6
D50 ,51 D52			MA111 MA111	DIODE DIODE	Y1M1X1	7

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas ⚠ indicates safety critical components.

PARTS LIST

KRF-V5010N/6010N/7010N/R-205/206/207/255/257

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

25

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
D53			MA111	DIODE		6
D53			MA111	DIODE		7
D54			MA111	DIODE		7
D54			MA111	DIODE		6
D55			MA111	DIODE		7
D55			MA111	DIODE		6
D56			MTZJ7.5(B)	ZENER DIODE		7
D56			RD7.5ES(B2)	ZENER DIODE		7
D504			HSS104A	DIODE	Q1E2	
D504			HSS104A	DIODE	Y1M1X1	
D504			1SS133	DIODE	Q1E2	
D504			1SS133	DIODE	Y1M1X1	
D505			HSS104A	DIODE	E1T1	
D505			1SS133	DIODE	E1T1	
D506			HSS104A	DIODE	K1P2	7
D506			1SS133	DIODE	K1P2	7
D507			HSS104A	DIODE	Q1E2	7
D507			1SS133	DIODE	Q1E2	7
D508,509			HSS104A	DIODE		
D508,509			1SS133	DIODE	KP1K1	
D510			HSS104A	DIODE	E1T1Q1	
D510			HSS104A	DIODE	E2	
D510			HSS104A	DIODE	Y1M1X1	
D510			1SS133	DIODE	E1T1Q1	
D510			1SS133	DIODE	E2	
D510			1SS133	DIODE	Y1M1X1	
D511-521			HSS104A	DIODE		
D511-521			1SS133	DIODE		
D522			HSS104A	DIODE		5
D522			1SS133	DIODE		5
D523			HSS104A	DIODE		
D523			1SS133	DIODE		
D524			HSS104A	DIODE	E1T1Q1	
D524			HSS104A	DIODE	E2	
D524			1SS133	DIODE	E1T1Q1	
D524			1SS133	DIODE	E2	
D526			MTZJ6.2(B)	ZENER DIODE		
D526			RD6.2ES(B2)	ZENER DIODE		
D529			HSS104A	DIODE		
D529			1SS133	DIODE		
ED51			11-MT-116GK	INDICATOR TUBE		
IC1			TA7815SB	ANALOGUE IC		
IC2			TA79015SB	ANALOGUE IC		
IC3		*	STK407-090K	HYBRID IC		5
IC3		*	STK411-230D	HYBRID IC		7
IC3		*	STK411-230D	HYBRID IC		6
IC3		*	STK411-230K	HYBRID IC	KP1Y1	7
IC3		*	STK411-230K	HYBRID IC	M1X1K1	7
IC3		*	STK411-230K	HYBRID IC	P2K2P3	7
IC4		*	STK407-290K	HYBRID IC		5
IC4		*	STK410-030D	HYBRID IC		7
IC4		*	STK410-030D	HYBRID IC		6
IC4		*	STK410-030K	HYBRID IC		7
IC4		*	STK410-030K	HYBRID IC		6
IC5			NJM4580ED	ANALOGUE IC		

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

* New Parts
Parts without **Parts No.** are not supplied.
Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
Teile ohne **Parts No.** werden nicht geliefert.

26

Ref. No	Add-ress	New Parts	Parts No.	Description	Desti-nation	Re-marks
IC6			TC9164AF	MOS-IC		
IC7			TC9162AF	MOS-IC		
IC8			NJM4565MD	IC(OP AMP X2)		
IC9			M62446FP	ANALOGUE IC		
IC12			NJM4565MD	IC(OP AMP X2)		
IC16			M62460AFP	ANALOGUE IC		
IC17			BU4066BCF	IC(ANALOG SWITCH X4)		
IC18			NJM2279M	ANALOGUE IC		
IC19			M5278L05M	ANALOGUE IC		
IC51			CXP82832-144Q	MI-COM IC	KP1Y1	
IC51			CXP82832-144Q	MI-COM IC		
IC51			CXP82832-144Q	MI-COM IC	M1X1K1	
IC51			CXP82852-130Q	MI-COM IC	P2K2P3	
IC51			CXP82852-130Q	MI-COM IC	E1T1Q1	
IC52			X24C02S	MEMORY IC	E2	
IC52			X24C02S	MEMORY IC	E1T1Q1	
IC52			S-80740AL-A4	IC(VOLTAGE DETECTOR)	E2	
IC53			SAA6579T	ANALOGUE IC	Y1M1X1	
IC54			SAA6579T	ANALOGUE IC	E1T1Q1	
IC54			SAA6579T/R	ANALOGUE IC	E2	
IC54			SAA6579T/R	ANALOGUE IC	E1T1Q1	
Q1 -11			2SC2878(B)	TRANSISTOR		
Q12			2SC4213(B)	TRANSISTOR		
Q13 ,14			2SA1586(Y,GR)	TRANSISTOR		
Q13 ,14			2SA1611(M5,M6)	TRANSISTOR		
Q15 -19			2SC1845(F,E)	TRANSISTOR		
Q20			DTC123JUA	DIGITAL TRANSISTOR		
Q21			DTC123JUA	DIGITAL TRANSISTOR		7
Q22 ,23			DTC123JUA	DIGITAL TRANSISTOR		
Q24 ,25			2SC3722K(R,S)	TRANSISTOR		
Q26			2SA1255	TRANSISTOR		
Q29			2SC2631(S,T)	TRANSISTOR		
Q30			2SA1123(S,T)	TRANSISTOR		
Q31			2SA1534A	TRANSISTOR		5
Q31			2SB1640	TRANSISTOR		7
Q31			2SB1640	TRANSISTOR		6
Q32 -34			2SC3722K(R,S)	TRANSISTOR		
Q35			2SA1255	TRANSISTOR		
Q36 ,37			2SC3722K(R,S)	TRANSISTOR		
Q40			2SC4213(B)	TRANSISTOR		7
Q40			2SC4213(B)	TRANSISTOR		6
Q41			DTC113ZUA	DIGITAL TRANSISTOR		7
Q41			DTC113ZUA	DIGITAL TRANSISTOR		6
Q41			UN5219	DIGITAL TRANSISTOR		7
Q41			UN5219	DIGITAL TRANSISTOR		6
Q42			2SC4213(B)	TRANSISTOR	Y1M1X1	7
Q42			2SC4213(B)	TRANSISTOR	Y1M1X1	6
Q501			2SC4116(Y,GR)	TRANSISTOR		
Q501			2SC4177(L5,L6)	TRANSISTOR		
Q503			2SC4116(Y,GR)	TRANSISTOR		
Q503			2SC4177(L5,L6)	TRANSISTOR		
A501			W02-2625-05	OPTIC RECEIVING MODULE		

L : Scandinavia K : USA P : Canada R : Mexico C : China I : Malaysia
Y : PX(Far East, Hawaii) T : Europe E : Europe G : Germany V : China (Shanghai)
Y : AAFES(Europe) X : Australia Q : Russia H : Korea M : Other Areas Δ indicates safety critical components.

KRF-V5010W6010N/7010MR-205/206/207/255/257
PARTS LIST

KRF-V5010/V6010/V7010/VR-205/206/207/255/257

PARTS LIST

HOW TO READ THE PARTS LIST

ABBREVIATION OF MODEL AND MASS PRODUCTION'S DESTINATIONS

MODEL	ABB.	Australia	Canada	China	England	Europe	Germany	Korea	Malaysia
KRF-5010	5	X1	-		T1	E1	-	-	-
KRF-5010E		-	-	-	-	E2	-	-	-
KRF-5010W		-	-	-	-	-	-	-	-
VR-205		-	P1	-	-	-	-	-	-
VR-255		-	P2	-	-	-	-	-	-
KRF-V6010	6	X1	-	-	-	E1	-	-	-
KRF-V6010E		-	-	-	-	E2	-	-	-
KRF-V6010W		-	-	-	-	-	-	-	-
KRF-V7010	7	X1	-		T1	E1	-	-	-
KRF-V7010E		-	-	-	-	E2	-	-	-
KRF-V7010W		-	-	-	-	-	-	-	-
VR-206		-	P3	-	-	-	-	-	-
VR-207		-	P1	-	-	-	-	-	-
VR-257		-	P2	-	-	-	-	-	-
MODEL	ABB.	Mexico	PX/AAFES	Russia	Scandinavia	Shanghai	USA	Other area	
KRF-5010	5	-	Y1	-	-	-	-	M1	-
KRF-5010E		-	-		-	-	-	-	-
KRF-5010W		-	-	Q1	-	-	-	-	-
VR-205		-	-	-	-	-	K	-	-
VR-255		-	-	-	-	-	K1	-	-
KRF-V6010	6	-	-	-	-	-	-	M1	-
KRF-V6010E		-	-	-	-	-	-	-	-
KRF-V6010W		-	-	Q1	-	-	-	-	-
KRF-V7010	7	-	Y1	-	-	-	-	M1	-
KRF-V7010E		-	-	-	-	-	-	-	-
KRF-V7010W		-	-	Q1	-	-	-	-	-
VR-206		-	-	-	-	-	K2	-	-
VR-207		-	-	-	-	-	K	-	-
VR-257		-	-	-	-	-	K1	-	-

SPECIFICATIONS

For U.S.A and Canada

AUDIO section

Rated power output during STEREO operation
VR-207, VR-257, VR-206

100 watts per channel minimum RMS, both channels driven, at 8 Ω from 40 Hz to 20 kHz with no more than 0.7% total harmonic distortion.(FTC)

VR-205, VR-255

50 watts per channel minimum RMS, both channels driven, at 8 Ω from 40 Hz to 20 kHz with no more than 0.7% total harmonic distortion.(FTC)

Effective power output during SURROUND operation

VR-207, VR-257, VR-206
FRONT (1kHz, 0.7% T.H.D. at 8 Ω one channel driven)
..... 100 W + 100 W
CENTER (1kHz, 0.7% T.H.D. at 8 Ω one channel driven)
..... 100 W
SURROUND (1kHz, 0.7% T.H.D. at 8 Ω one channel driven)
..... 100 W + 100 W

VR-205, VR-255
FRONT (1kHz, 0.7% T.H.D. at 8 Ω one channel driven)
..... 50 W + 50 W
CENTER (1kHz, 0.7% T.H.D. at 8 Ω one channel driven)
..... 50 W
SURROUND (1kHz, 0.7% T.H.D. at 8 Ω one channel driven)
..... 50 W + 50 W

Total harmonic distortion
VR-207, VR-257, VR-206 0.03% (1 kHz, 50W, 8 Ω)
VR-205, VR-255 0.03% (1 kHz, 25W, 8 Ω)

Signal to noise ratio (IHF'66)
PHONO (MM) 75 dB
CD 91 dB

Input sensitivity / impedance
PHONO (MM) 2.5 mV / 27 k Ω
CD 200 mV / 47 k Ω
DVD 6CH (SUBWOOFER) 200 mV / 10 k Ω

Output level / impedance
TAPE REC 200 mV / 1 k Ω
PRE OUT (CENTER, SURROUND) 1 V / 1 k Ω
(only VR-207, VR-257, VR-206)
PRE OUT (SUBWOOFER) 1 V / 600 Ω

Tone control
BASS ± 10 dB (at 100 Hz)
TREBLE ± 10 dB (at 10 kHz)

VIDEO section

VIDEO inputs / outputs
VIDEO (composite) 1 Vp-p / 75 Ω

TV tuner section (For VR-257)

Reception frequency 65.75 MHz (3ch)
71.75 MHz (4ch)

FM tuner section

Tuning frequency range 87.5 MHz ~ 108 MHz
Usable sensitivity (MONO)
..... 1.6 μ V (75 Ω) / 15.2 dBf (75 kHz DEV., SINAD 30 dB)
50dB quieting sensitivity
STEREO 31.6 μ V (75 Ω) / 41.2 dBf
Total harmonic distortion (1 kHz)
MONO 0.6% (65 dBf input)
STEREO 0.7% (65 dBf input)
Signal to noise ratio (1 kHz, 75 kHz DEV.)
MONO 75 dB (65 dBf input)
STEREO 68 dB (65 dBf input)
Stereo separation (1 kHz) 38 dB
Selectivity (± 400 kHz) 70 dB
Frequency response 30 Hz ~ 15kHz, +0.5 dB, -3.0 dB

AM tuner section

Tuning frequency range
10 kHz step 530 kHz ~ 1,700 kHz
Usable sensitivity (30% mod., S/N 20 dB)
..... 16 μ V / (600 μ V/m)
Signal to noise ratio (30% mod. 1 mV input) 50 dB

GENERAL

Power consumption 2.2 A
AC outlet
SWITCHED 2 (total 150 W, 1.25 A max.)

Dimensions W : 440 mm (17-5/16")
H : 144 mm (5-11/16")
D : 390 mm (15-3/8")

Weight (Net)
VR-207, VR-257, VR-206 8.6 kg (19.0 lb)
VR-205, VR-255 8.2 kg (18.1 lb)

Notes

1. KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.
2. The full performance may not be exhibited in an extremely cold location (under a water-freezing temperature).

KRF-V5010/V6010/V7010/VR-205/206/207/255/257

SPECIFICATIONS

For Europ

AUDIO section

Rated power output during STEREO operation

KRF-V7010
(DIN) 1 kHz, 0.7% at 4 Ω 100 W + 100 W

KRF-V6010
(DIN) 1 kHz, 0.7% at 4 Ω 90 W + 90 W

KRF-V5010
(DIN) 1 kHz, 0.7% at 4 Ω 50 W + 50 W

Effective power output during SURROUND operation

KRF-V7010
FRONT(1kHz, 0.7% T.H.D. at 4 Ω one channel driven)
..... 100 W + 100 W
CENTER (1kHz, 0.7% T.H.D. at 4 Ω one channel driven)
..... 100 W
SURROUND(1kHz, 0.7% T.H.D. at 4 Ω one channel driven)
..... 100 W + 100 W

KRF-V6010
FRONT(1kHz, 0.7% T.H.D. at 4 Ω one channel driven)
..... 80 W + 80 W
CENTER (1kHz, 0.7% T.H.D. at 4 Ω one channel driven)
..... 80 W
SURROUND(1kHz, 0.7% T.H.D. at 4 Ω one channel driven)
..... 80 W + 80 W

KRF-V5010
FRONT(1kHz, 0.7% T.H.D. at 4 Ω one channel driven)
..... 50 W + 50 W
CENTER (1kHz, 0.7% T.H.D. at 4 Ω one channel driven)
..... 50 W
SURROUND(1kHz, 0.7% T.H.D. at 4 Ω one channel driven)
..... 50 W + 50 W

Total harmonic distortion

KRF-V7010 0.03%(1 kHz, 50W, 4 Ω)
KRF-V6010 0.03%(1 kHz, 40W, 4 Ω)
KRF-V5010 0.03%(1 kHz, 25W, 4 Ω)

Signal to noise ratio

PHONO (MM) 75 dB (IHF'66)
..... 55 dB (DIN 50mW output)
CD 91 dB (IHF'66)
..... 56 dB (DIN 50mW output)

Input sensitivity / impedance

PHONO (MM) 2.5 mV / 27 k Ω
CD 200 mV / 47 k Ω
DVD 6CH (SUBWOOFER) 200 mV / 10 k Ω

Output level / impedance

TAPE REC 200 mV / 1 k Ω
PRE OUT (CENTER, SURROUND) 1 V / 1 k Ω
(only KRF-V7010, KRF-V6010)
PRE OUT (SUBWOOFER) 1 V / 600 Ω

Tone control

BASS ± 10 dB (at 100 Hz)
TREBLE ± 10 dB (at 10 kHz)

VIDEO section

VIDEO inputs / outputs

VIDEO (composite) 1 Vp-p / 75 Ω

FM tuner section

Tuning frequency range

U.K. and Europe 87.5 MHz ~ 108 MHz
Russia 87.5 MHz ~ 108 MHz,
65.0 MHz ~ 74.0 MHz

Usable sensitivity (DIN, 75 Ω)

MONO 1.2 μ V / 13.2 dBf (40 kHz DEV., S/N 26 dB)
STEREO 35 μ V / 42.1 dBf (46 kHz DEV., S/N 46 dB)

Total harmonic distortion (DIN, 1 kHz)

MONO 0.2% (65.2 dBf input)
STEREO 0.8% (65.2 dBf input)

Signal to noise ratio (DIN weighted, 1 kHz)

U.K. and Europe
MONO 65 dB (40 kHz DEV., 65.2 dBf input)
STEREO 60 dB (46 kHz DEV., 65.2 dBf input)
Russia
MONO 63 dB (40 kHz DEV., 65.2 dBf input)
STEREO 58 dB (46 kHz DEV., 65.2 dBf input)

Stereo separation (DIN, 1 kHz) 36 dB

Selectivity (DIN, ± 300 kHz) 64 dB

Frequency response (30 Hz ~ 15kHz) +0.5 dB, -3.0 dB

AM tuner section

Tuning frequency range 531 kHz ~ 1,602 kHz

Usable sensitivity (30% mod., S/N 20 dB)

..... 16 μ V / (600 μ V/m)

Signal to noise ratio (30% mod., 1 mV input) 50 dB

GENERAL

Power consumption

KRF-V7010, KRF-V6010 280 W
KRF-V5010 210 W

AC outlet

SWITCHED 2 (total 150 W max.)

Dimensions

W : 440 mm
H : 144 mm
KRF-V7010 D : 400 mm
KRF-V6010, KRF-V5010 D : 390 mm

Weight (Net)

KRF-V7010, KRF-V6010 8.6 kg
KRF-V5010 8.2 kg

Notes

1. KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.
2. The full performance may not be exhibited in an extremely cold location (under a water-freezing temperature).

KRF-V5010/V6010/V7010/VR-205/206/207/255/257

SPECIFICATIONS

For other countries

AUDIO section

Effective power output during STEREO operation

KRF-V7010	
1kHz,10% T.H.D.,at 8 Ω	140 W + 140 W
KRF-V6010	
1kHz,10% T.H.D.,at 8 Ω	120 W + 120 W
KRF-V5010	
1kHz,10% T.H.D.,at 8 Ω	70 W + 70 W

Rated power output during STEREO operation

KRF-V7010	
DIN (63 Hz ~ 12.5 kHz, 0.7%, 8 Ω)	110 W + 110 W

100 watts per channel minimum RMS, both channels driven, at 8 Ω from 40 Hz to 20 kHz with no more than 0.7% total harmonic distortion.(FTC)

KRF-V6010	
DIN (63 Hz ~ 12.5 kHz, 0.7%, 8 Ω)	80 W + 80 W

80 watts per channel minimum RMS, both channels driven, at 8 Ω from 40 Hz to 20 kHz with no more than 0.7% total harmonic distortion.(FTC)

KRF-V5010	
DIN (63 Hz ~ 12.5 kHz, 0.7%, 8 Ω)	50 W + 50 W

50 watts per channel minimum RMS, both channels driven, at 8 Ω from 40 Hz to 20 kHz with no more than 0.7% total harmonic distortion.(FTC)

Effective power output during SURROUND operation

KRF-V7010	
FRONT (1kHz, 10% T.H.D. at 8 Ω one channel driven)	100 W + 100 W
CENTER (1kHz, 10% T.H.D. at 8 Ω one channel driven)	100 W
SURROUND (1kHz, 10% T.H.D. at 8 Ω one channel driven)	100 W + 100 W

KRF-V6010	
FRONT (1kHz, 10% T.H.D. at 8 Ω one channel driven)	80 W + 80 W
CENTER (1kHz, 10% T.H.D. at 8 Ω one channel driven)	80 W
SURROUND (1kHz, 10% T.H.D. at 8 Ω one channel driven)	80 W + 80 W

KRF-V5010	
FRONT (1kHz, 10% T.H.D. at 8 Ω one channel driven)	50 W + 50 W
CENTER (1kHz, 10% T.H.D. at 8 Ω one channel driven)	50 W
SURROUND (1kHz, 10% T.H.D. at 8 Ω one channel driven)	50 W + 50 W

Total harmonic distortion

KRF-V7010	0.03%(1 kHz, 50W, 8 Ω)
KRF-V6010	0.03%(1 kHz, 40W, 8 Ω)
KRF-V5010	0.03%(1 kHz, 25W, 8 Ω)

Signal to noise ratio (IHF'66)

PHONO (MM)	75 dB
CD	91 dB

Input sensitivity / impedance

PHONO (MM)	2.5 mV / 27 kΩ
CD	200 mV / 47 kΩ
DVD 6CH (SUBWOOFER)	200 mV / 10 kΩ

Output level / impedance

TAPE REC	200 mV / 1 kΩ
PRE OUT (CENTER, SURROUND)	1 V / 1 kΩ
(only KRF-V7010, KRF-V6010)	
PRE OUT (SUBWOOFER)	1 V / 600 Ω

Tone control

BASS	±10 dB (at 100 Hz)
TREBLE	±10 dB (at 10 kHz)

VIDEO section

VIDEO inputs / outputs

VIDEO (composite)	1 Vp-p / 75 Ω
-------------------	---------------

FM tuner section

Tuning frequency range	87.5 MHz ~ 108 MHz
Usable sensitivity (MONO)	1.6 μV (75 Ω) / 15.2 dBf (75 kHz DEV., SINAD 30 dB)
50dB quieting sensitivity	STEREO 31.6 μV (75 Ω) / 41.2 dBf
Total harmonic distortion (1 kHz)	MONO 0.6% (65 dBf input)
	STEREO 0.7% (65 dBf input)
Signal to noise ratio (1 kHz, 75 kHz DEV.)	MONO 75 dB (65 dBf input)
	STEREO 68 dB (65 dBf input)
Stereo separation (1 kHz)	38 dB
Selectivity (±400 kHz)	50 dB
Frequency response	30 Hz ~ 15kHz, +0.5 dB, -3.0 dB

AM tuner section

Tuning frequency range	9 kHz step 531 kHz ~ 1,602 kHz
	10 kHz step 530 kHz ~ 1,610 kHz
Usable sensitivity (30% mod., S/N 20 dB)	16 μV / (600 μV/m)
Signal to noise ratio (30% mod. 1 mV input)	50 dB

GENERAL

Power consumption

KRF-V7010, KRF-V6010	280 W
KRF-V5010	210 W

AC outlet

SWITCHED (for Australia)	1 (total 150 W max.)
SWITCHED (except Australia)	2 (total 150 W max.)

Dimensions

W : 440 mm
H : 144 mm
D : 390 mm

Weight (Net)

KRF-V7010, KRF-V6010	9.4 kg
KRF-V5010	8.2 kg

Notes

1. KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.
2. The full performance may not be exhibited in an extremely cold location (under a water-freezing temperature).

Note:

Component and circuit are subject to modification to insure best operation under differing local conditions. This manual is based on General market(M) standard, and provides information on regional circuit modification through use of alternate schematic diagrams, and information on regional component variations through use of parts list.

KENWOOD CORPORATION

14-6,Dogenzaka 1-chome, Shibuya-ku, Tokyo, 150-8501 Japan

KENWOOD SERVICE CORPORATION

P.O BOX 22745, 2201 East Dominguez St., Long Beach, CA 90801-5745, U.S.A.

KENWOOD ELECTRONICS CANADA INC.

6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

KENWOOD ELECTRONICS LATIN AMERICA S.A.

P.O BOX 55-2791, Piso 6 plaza Chase, Cl. 47 y Aquilino de la Guardia Panama, Republic de Panama

KENWOOD ELECTRONICS BRASIL LTDA.

Av Indianópolis, 628, 04062-001 Planalto Paullista São Paulo-SP-Brasil

KENWOOD ELECTRONICS U.K. LIMITED

KENWOOD House, Dwight Road, Watford, Herts., WD1 8EB., United Kingdom

KENWOOD ELECTRONICS BELGUM N.V.

Meachelsesteenweg 418, B-1930 Zaventem, Belgium

KENWOOD ELECTRONICS DEUTSCHLAND GMBH

Rembrücker Str. 15, 63150 Heusenstamm, Germany

KENWOOD ELECTRONICS FRANCE S.A.

13 Boulevard Ney, 75018 Paris, France

KENWOOD ELECTRONICS ITALIA S.p.A.

Via G. Sirtori, 7/9 20129, Milano, Italy

KENWOOD IBÉRICA S.A.

Bolivia, 239-08020 Barcelona, Spain

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD.

(A.C.N. 001499 074)

P.O Box 504, 8 Figtree Drive, Australia Centre, Homebush, N.S.W. 2140, Australia

KENWOOD & LEE ELECTRONICS, LTD.

Unit 3712-3724, Level 37, Tower 1, Metroplaza, 223 Hing Fong Road, Kwai Fong N.T., Hong Kong

KENWOOD ELECTRONICS GULF FZE

P.O.Box 61318, Jebel Ali, Dubai, U.A.E.

KENWOOD ELECTRONICS SINGAPORE PTE LTD.

No. 1 Genting Lane #02-02, KENWOOD Building, Singapore, 349544

KENWOOD ELECTRONICS (MALAYSIA) SDN BHD.

#4.01 Level 4, Wisma Academy Lot 4A, Jalan 19/1 46300 Petaling Jaya Selangor Darul Ehsan Malaysia

KENWOOD ELECTRONICS (THAILAND) CO., LTD.

573/111 Soi Ramkhamhaeng 39, Ramkhamhaeng Road, Wangthonglang, Bangkok, Bangkok 10301 Thailand