

Gima S.p.A. Via Marconi, 1 - 20060 Gessate (MI) Italy gima@gimaitaly.com - export@gimaitaly.com www.gimaitaly.com

## **3 CHANNEL ECG 300G** MONITOR UP TO 12 CHANNELS

User manual

**ATTENTION:** The operators must carefully read and completely understand the present manual before using the product.




## ECG300G (GIMA 33221)

CONTEC MEDICAL SYSTEMS CO., LTD No. 112 Qinhuang West Street, Economic & Technical Development Zone, Qinhuangdao, Hebei Province, PEOPLE'S REPUBLIC OF CHINA Made in China



Shanghai International Holding Corp. GmbH (Europe) Eiffestrasse 80, 20537 Hamburg - Germany

Imported by: Gima S.p.A. Via Marconi, 1 - 20060 Gessate (MI) Italy gima@gimaitaly.com - export@gimaitaly.com www.gimaitaly.com



#### Preface

Please read the User Manual carefully before using this product. The operating procedures specified in this User Manual should be followed strictly. This manual describes in detail the operation steps which must be noted, the procedures which may result in abnormality, and possible damage to the product or users. Refer to following chapters for details. Failed to follow the User Manual may cause measuring abnormality, device damage or personal injury. The manufacturer is NOT responsible for the safety, reliability and performance issues of such results due to user's negligence of this user manual for using, maintenance or storage. The free service s and repairs do not cover such faults either.

The content in this user manual complies with real product. For software upgrade and some modifications, the content in this user manual is subject to change without prior notice, and we sincerely apologize for that.

#### Attentions

Before using this product, the safety and effectiveness described in the following shall be considered:

- Type of protection against electric shock: class I (AC power supply), internal powered equipment (power supplied by battery)
- > Degree of protection against electric shock: type CF, defibrillation-proof applied part
- Working mode: continuous running equipment
- Enclosure protection class: IPX0
- Measurement results shall be described by professional doctor combined with clinical symptoms.
- The using reliability depends on whether the operation guide and maintenance instructions in this user manual is followed.
- Service life: 5 years
- Date of manufacture: see the label
- Contraindications: none

▲ Warning: To ensure the device safety and effectiveness, please use the company recommended accessories. The maintenance and repair of the device should be done by professional personal specified by the company. It is forbidden to refit the device.

#### Responsibility of the operator

- The device must be operated by a professionally trained medical staff, and kept by a special person.
- The operator should read the User Manual carefully before use, and strictly follow the operating procedure described in the User Manual.
- The safety requirements have been fully considered in product designing, but the operator can not ignore the observation of the patient and device.
- The operator is responsible for providing the information of product use to the company.

#### Responsibility of the company

- > The company supplies qualified products to user in accordance with enterprise standard.
- > The company installs and debugs the equipment and trains the physicians by contract.
- The company performs device repair in warranty period (a year) and maintenance service after warranty period.
- > The company responds timely to the user's request.

The user manual is written by Contec Medical Systems Co., Ltd. All rights reserved.

#### Statement

Our company owns all rights to this unpublished work and intends to maintain it as confidential information. This user manual is used only for reference of operation, maintenance, or repair of our device. No part of this can be disseminated to others. And our company takes no responsibilities for any consequences and liabilities caused by using this user manual for other purposes.

This document contains proprietary information, which is protected by copyright. All rights reserved. Photocopy, reproduction or translation of any part in the manual without our company's written permission is prohibited.

All information contained in this user manual is believed to be correct. Our company shall not be liable for incidental and consequential damages in connection with the furnishing, performance, or use of this material. This user manual may refer to information and protected by copyrights or patents and does not convey any license under the patent rights of our company, nor the rights of others.Our company does not assume any liability for arising out of any infringements of patents or other rights of the third parties.

Our company owns the final explanation right to this user manual, and reserves the right to change the content of this user manual without prior notice, and the rights to change product technology and specification.

Chapter 1 Overview 1
1.1 Overview
1.2 Intended use
1.3 Main technical specifications1
1.4 Main Characteristics
1.5 Software overview
Chapter 2 Safety Precautions
Chapter 3 Warranty
Chapter 4 Working Principle and Structural Characteristics
4.1 Working principle and its block diagram8
4.2 Name of each part and its function9
Chapter 5 Operation Precautions
5.1 Precautions before use12
5.2 Precautions during operating12
5.3 Precautions after use12
Chapter 6 Preparations before Operation13
6.1 Installation of recording paper13
6.2 Power supply connection13
6.3 Lead cable connection14
6.4 Electrode installation14
Chapter 7 Operation Instructions and Parameter Setting17
7.1 Main Interface17
7.2 Sample interface17
7.3 Case information input interface20
7.4 Case management20
7.5 Query
7.6 Review
7.7 Date and time setup23
7.8 System setup23
7.9 Sample setup

## Contents

7.10 Analysis Setup	25
7.11 Print setup	25
7.12 Lead placement	27
7.13 About	27
Chapter 8 Troubleshooting	28
8.1 Auto shutdown	28
8.2 AC interference	28
8.3 EMG interference	28
8.4 Baseline drift	29
8.5 Troubleshooting list	29
Chapter 9 Maintenance	31
9.1 Battery	31
9.2 Recording paper	32
9.3 Maintenance after use	32
9.4 Lead cables and electrodes	33
9.5 Silicone rubber roller	33
9.6 Cleaning of thermal print head	33
9.7 Disposal of product scrap	33
9.8 Others	33
Chapter 10 Packing List and Accessories	35
10.1 Accompanying accessories	35
10.2 Notes	35
Appendix I ECG Automated Measurement&Interpretation Guide	36
1. Preface	36
2. Automated measurement parameters and Automated interpretation items	36
3. Algorithm description	38
4. Data sources and data preprocessing	48
5. Process and Result of Verification	52
Appendix II EMC Guidance and Manufacturer6 Declaration	62

## **Chapter 1 Overview**

#### 1.1 Overview

This product is a kind of electrocardiograph, which is able to sample 12 leads ECG signals simultaneously and print out the ECG waveform with thermal printing system. Its functions are as follows: recording and displaying ECG waveform in auto/manual mode; measuring ECG waveform parameters automatically, and automatic analysis; pacing ECG detection; prompt for electrode-off and out of paper; optional interface languages(Chinese/English, etc.); built-in lithium battery, powered either by AC or DC; arbitrarily select the rhythm lead to conveniently observe abnormal heart rhythm; case database management, etc.

#### 1.2 Intended use

This product is suitable for hospital, scientific research, wards, ambulances and carrying out medical consultations. It can be used by medical institutions to record human ECG signals, collect and extract the ECG waveform.

#### 1.3 Main technical specifications

1.3.1 Environment conditions

Operation:

- a). Environment temperature: 5°C~40°C
- b). Relative humidity: 25%~95%(no condensation)
- c). Atmospheric pressure: 700 hPa~1060 hPa
- d). Power supply:

Voltage: 100-240 V $\sim$ Frequency: 50 Hz, 60 Hz

Input power: ≤150 VA

Battery: 7.4 V, 3500 mAh rechargeable lithium battery

Transportation and Storage:

- a). Environment temperature: -20 °C~+55 °C
- b). Relative humidity: ≤95%
- c). Atmospheric pressure: 500 hPa $\sim$ 1060 hPa
- 1.3.2 Input way: Floating and defibrillation protection
- 1.3.3 Lead: Standard 12 leads
- 1.3.4 Patient leakage current: <10µA
- 1.3.5 Input impedance: ≥2.5 MΩ

#### 1.3.6 Frequency response:

Rated input	Input frequency and waveform	Relative output response
amplitude		
1.0	0.67Hz~40Hz, Sine wave	±10%ª
0.5	40Hz~100Hz, Sine wave	+10 %, -30 %ª
0.25	100Hz~150Hz, Sine wave	+10 %, -30 %ª

0.5	150 Hz ~ 500 Hz, Sine wave	+10 %, -100 %ª
1.5	≤1Hz,200ms, Triangle wave	+0 %, -10 % <sup>b</sup>
	<sup>a</sup> relative to 10Hz <sup>b</sup> relative to 200	) ms

1.3.7 Time constant: ≥3.2s

1.3.8 CMRR: >105 dB

1.3.9 Filter: power frequency(AC50/60 Hz), myoelectricity(25 Hz/35 Hz (-3 dB)), baseline drift filter

1.3.10 Recording way: Thermal printing system

1.3.11 Specification of recording paper: 80 mm(W)×20 m(L) high-speed thermal paper

1.3.12 Time base selection(paper speed):

12.5 mm/s, 25 mm/s, 50 mm/s, error: ±5%

1.3.13 Gain control(sensitivity): 5,10, 20mm/mV, accuracy is  $\pm 2\%$ ; Standard sensitivity: 10 mm/mV $\pm 0.2$  mm/mV

1.3.14 Auto record: record setup according to auto record format and mode, automatically change leads, automatically measure and analyze.

1.3.15 Rhythm record: record setup according to rhythm record format and mode, automatically measure and analyze.

1.3.16 Manual record: record according to manual record format.

1.3.17 Measurement parameters: HR, PR Interval, P Duration, QRS Duration, T Duration, QT/

QTc Interval, P/QRS/T Axis, R(V5) amplitude, S(V1) amplitude, R(V5)+S(V1) amplitude

1.3.18 Product safety type: Class I type CF defibrillation-proof applied part

1.3.19 Polarization resistance voltage: ±610 mV

1.3.20 Noise level: ≤12 µVp-p

1.3.21 ECG signal input sampling frequency: 32 kHz

1.3.22 Waveform data processing sampling frequency: 1 kHz

1.3.23 Sampling precision: 24-bit

1.3.24 The minimum detection signal: 10 Hz, 20  $\mu V(\text{peak-peak value})$  deflected sinusoidal signal can be detected

1.3.25 Pacing detection channel: standard II

1.3.26 Accuracy of input signal: ±5%.

1.3.27 Amplitude quantization: ≤5µV/LSB

1.3.28 Dimension: 315 mm(L)×215 mm(W)×77 mm(H)

1.3.29 Net Weight: 1.6 kg

1.3.30 Interchannel time deviation: <100 µs

#### **1.4 Main Characteristics**

1.4.1 High resolution thermal-array output system(8 dots/mm), no adjustment required. Frequency Response is up to 150Hz.

1.4.2 Record clear and exact three channels ECG waveform and remarks in real-time and continuously. The remark includes: lead sign, sensitivity, paper speed, filter state, etc.

1.4.3 In auto mode, recording can be completed with one-button operation, which improves

work efficiency.

1.4.4 Under the best DC condition, the device can stand by for 10 hours, or print for at least 3 hours, or print 260 pieces ECG.

1.4.5 At least 1,000 pieces of medical records can be stored in the device, which facilitates doctors to review and information statistics.

1.4.6 Beautiful and smooth appearance.

1.4.7 Degree of protection against ingress of liquid: IPX0

1.4.8 Use digital signal processing technology to conduct AC filter, baseline filter and EMG filter on ECG signals, in order to get high-quality ECGs.

1.4.9 With auto-measurement, auto-analysis functions of regular ECG parameters, which reduces doctor's workload and improves working efficiency.

1.4.10 With pacing ECG detection function.

#### 1.5 Software overview

The ECG analysis program shows the results after analyzing the form of the electrocardiogram, providing auxiliary reference for doctors to make diagnosis. The analysis result cannot be used as the only standard for diagnosis. A comprehensive evaluation should be made by professional electrocardiogram technicians and physicians according to clinical experience and other test results.

The device is intended for use on all patient populations, which is decided by the clinical doctor. The analysis program only provides ECG analysis for patients above 3 years old (including 3 years).

Name of software: embedded software

Software specification: none

Software version: V1.9.11

Version naming rules: V<major version number>.<minor version number>.<revision version number>

The version of the software can be obtained in "About".

Involved algorithm:

Name: ECG algorithm

Type: mature algorithm

Use: to convert ECG signals of human body into intuitive waveform images and then analyzing.

Clinical function: Electrocardiogram is an important method for clinical diagnosis of cardiovascular disease. How to use computer to quickly, automatically and accurately analyze ECG has been a hot topic for scholars at home and abroad. The ECG algorithm is the key to the analysis and diagnosis of ECG signals, and its accuracy and reliability determine the effectiveness of diagnosis and treatment of patients with heart disease.

## **Chapter 2 Safety Precautions**

2.1 Ensure that the device is placed on a flat level worktable. Avoid strong vibration or impact when moving it.

2.2 When working with AC power, the power cord must be 3-core, the frequency and voltage value of the AC power source must match the identification on the manual and have sufficient capacity. When the provided three-core power cord cannot be used, please use the built-in DC power supply or replace the three-core power cord that meets the standard requirements.
2.3 A perfect power supply system and grounding are necessary in the room.

# Warning: To avoid the risk of electric shock, the device must be connected a power supply with protective grounding.

2.4 If there are any questions for the integrality of protective grounding cable or the reliability of protective grounding cable connection can not be guaranteed, the device must be run with built-in DC power supply.

2.5 The safety requirements have been fully considered in product designing, but the operator can not ignore the observation of the patient and device. Cut off the power or take off the electrode when necessary to ensure patient's safety.

2.6 Please turn off the device and unplug the power cord before replacing the fuse or cleaning and disinfection. Don't rub the screen with sharp materials.

2.7 Keep the device from water, don't use or store it in places with high air pressure, humidity or temperature over the standard, bad ventilation, or too much dust.

2.8 Do not use the device in the place with flammable anesthetic gases or other flammable chemicals, otherwise there is a danger of explosion or fire.

2.9 Do not use the device in medical hyperbaric oxygen chamber, otherwise there is a danger of explosion or fire.

2.10 This device is not intended to act directly on the human heart. If this device is used with cardiac defibrillator or other electric stimulating devices at the same time, single-use electrodes and ECG lead cables with defibrillation-proof function should be selected. It is better not to use this device with other electric stimulating devices at the same time. If it is necessary, there must be professional technician guiding on the scene, and the selected accessories should be designated by our company.

## Warning: Do not operate the instrument on parts of human body with wounds, and do not perform measurements on parts with wounds on the surface.

2.11 When the electrocardiograph is used together with a high-frequency electrosurgical knife, the ECG electrode should be kept away from the contact of the electrosurgical knife to prevent burns and burning of the electrode wires caused by high-frequency sparks.

2.12 When the electrocardiograph is used together with a defibrillator, the operator should avoid contact with the patient or the sickbed. The defibrillation electrode should not directly

touch the ECG electrode to prevent sparks from burning the device and the patient.

2.13 Please do not use the electrocardiograph in the environment that is interfered by high-power device such as high-voltage cables, X-rays, ultrasonic machines and electrizer, keep the device away from emission sources such as mobile phones.

2.14 If other equipment is connected with this ECG device, it must be a Class I device that complies with IEC60601-1. Because the total leakage current may hurt patient, the monitoring of leakage current is carried out and taken charge by the connected equipment.

2.15 Notes related to EMC

The device complies with the safety standards for medical electrical equipment or system electromagnetic compatibility in IEC60601-1-2. Electromagnetic environments exceeding the IEC60601-1-2 standard may cause harmful interference to the device or prevent the device from performing its intended function or degrade its performance. Therefore, if there is a phenomenon that does not match its function during use, be sure to confirm and eliminate adverse effects before continuing to use it. Corresponding precautions for this situation are given in this manual.

- The device or system should not be used near or stacked with other devices. If it must be used near or stacked with other devices, it should be observed and verified that the device is working normally under the configuration it is using.
- The use of ACCESSORIES other than those specified by the MANUFACTURER of the device or system, may result in increased EMISSIONS or decreased IMMUNITY of the ME EQUIPMENT or ME SYSTEM.
- Effect from radiated electromagnetic waves:

The use of a mobile phone may affect the operation of the device. When installing medical electrical equipment, be sure to remind people around the device to turn off mobile phones and small radios.

Effect from shock and conduction electromagnetic waves:

High frequency noise from other equipment can enter the device through the AC socket. Please identify the source of noise, if possible, stop using the equipment. If the equipment can not be deactivated, use noise cancellation equipment or take other measures to reduce the impact.

Effect from static electricity:

Static electricity in a dry environment(indoor) may affect the operation of the device, especially in winter. Before using the device, humidify the indoor air or discharge the static electricity from the cable and operator.

Effect from thunder and lightning:

If there is thunder and lightning nearby, it may cause a voltage surge in the device. If you are concerned about danger, disconnect the AC power and use the internal power supply.

2.16 Notes concerning ECG waveform measurement and analysis

2.16.1 The identification of P wave and Q wave is not always reliable with intensive EMG or AC interference. Neither are the ST segment and T wave with baseline drift.

2.16.2 Winding and unclear end position of S wave and T wave may cause error in measurement.

2.16.3 When R wave is uninspected caused by some leads off or QRS wave low voltage, the heart rate measurement may deviate greatly from the correct.

2.16.4 In case of QRS low voltage, ECG axis calculation and border-point identify of QRS wave are not always reliable.

2.16.5 Occasionally, frequent ventricular premature complexes may be identified as dominant beat.

2.16.6 Merging of versatile arrhythmia may result in unreliable measurement because of the difficulty in distinguishing P wave in such situation.

2.16.7 The device has an automatic analysis function that automatically analyzes the obtained ECG waveform without reflecting all the patient's status. The results of the analysis may sometimes not comply with the doctor's diagnosis. Therefore, the final conclusion needs to be comprehensively analyzed by doctors in combination with analysis results, patient clinical characterization and other test results.

## **Chapter 3 Warranty**

3.1 In normal use, under strict observance of user manual and operation notes, in case of failure, please contact with our customer service department. Our company has the sales record and customer archives for each device. The customer has one year free warranty service from the date of shipping according to the following conditions. To supply all-around and quick maintenance service for you, please mail the maintenance card to us in time.

3.2 Our company may adopt such ways as guidance, express to company or door-to-door service, etc. to carry out warranty promise.

3.3 Even in warranty period, the following repairs are charged.

3.3.1 Faults or injuries caused by misuse that not according to user manual and operation notes.

3.3.2 Faults or injuries caused by dropping accidentally after purchase.

3.3.3 Faults or injuries caused by repair, reconstruction, decomposition, etc. not by our company.

3.3.4 Faults or injuries caused by improper storage or force majeure after purchase.

3.3.5 Faults or injuries caused by using improper thermal recording paper.

3.4 The warranty period for accessories and fray parts is half a year. Power cable, recording paper, operation manual and packing material are excluded.

3.5 Our company is not responsible for the faults of other connected devices caused by the faults of this device directly or indirectly.

3.6 The warranty will be canceled if we find the protection label has been destroyed.

3.7 For charged maintenance beyond warranty period, our company advises to continue using "Maintenance contract regulation". Please refer to our customer service department for details.

#### **Chapter 4 Working Principle and Structural Characteristics**

#### 4.1 Working principle and its block diagram

#### 4.1.1 The power supply unit

Principle of power supply

After the AC power supply enters the switching power supply, it is converted to DC voltage and supplied to the DC-DC power unit, it also provides constant voltage current limiting charging for the rechargeable lithium battery in the device through the DC-DC circuit, and generates +5V and +8.5V voltage through the power conversion to supply power to the corresponding modules. At the same time, the lithium battery in the device can independently satisfy working requirements of each module in the device through the buck-boost circuit.

ANote: The principle block diagram and component list are only available to service stations or maintenance personnel designated by our company.

#### 4.1.2 Signal acquisition unit

The signal acquisition unit uses a floating setting, which is a signal acquisition and processing system, including analog circuit part and A/D conversion (with sampling accuracy of 24 bits) and data processing part. The analog circuit consists of signal following, amplification, anti-aliasing low-pass filtering, lead-off detection and overload detection. CPU system is responsible for coordinating the work of each circuit such as the A/D converter, the lead-off detection circuit and the overload detection circuit, in order to achieve signal acquisition, processing, and lead-off detection. Control information and A/D conversion and data acquisition between the floating circuit and the solid circuit are transmitted through the optoelectronic coupler.

#### 4.1.3 Control unit

#### (1) Principle of control unit

The control system consists of printing system, button system, liquid crystal display system, and signal acquisition system. The ECG signal sent from the signal acquisition system through the high-speed optoelectronic coupler is received by the CPU system, after digital filtering, gain adjustment and motor drive, it is sent to the printing system to print the ECG waveform. After the printing is completed, the CPU system processes waveform measurement and analysis. The CPU system also receives an interrupt signal and button code from the button system to complete the interrupt processing. In addition, the lead-off signal, paper out detection, battery voltage management, and automatic power-off are also managed by the CPU system. The liquid crystal controller receives data and commands from the CPU system to complete the display of the control state of the device.

(2) Principle block diagram is shown in Figure 4-1.




Figure 4-1 Block diagram of control unit

4.2 Name of each part and its function

#### 4.2.1 Front view



Figure 4-2 Front view

1. Paper compartment cover

Keep the paper compartment closed, hold the printing paper

2. Display screen

Display patient's ECG and related information

3. Button area

Control the operations of the device, and enter information.

4. Cover switch

To open or close the paper compartment cover.

### Note

- Do not put heavy objects on the screen or hit against it, otherwise the screen will be damaged.
- > If the device is not in use, cover it to prevent liquid spills on the screen.
- > Do not use sharp stuff to operate the buttons, otherwise it may case permanent

#### damage to the buttons.

4.2.2 Side view




Figure 4-3 Side view

5. Lead cable interface

Connect with lead cables.

6. USB interface

Communicate with the computer. The ECG data and analysis result can be transmitted to a computer, by using the computer, many functions can be achieved, such as archiving, managing, and analyzing ECG data, which facilitates clinical research, organization teaching and training, as well as program upgrade, case export and connection with external printer.

#### <u>∕</u>Note

- Lead cables must be disconnected from patient before connecting with a computer via the USB interface.
- > Operator must not touch the USB interface and patient at the same time.

#### 4.2.3 Rear view



Figure 4-4 Rear view

#### 7. Equipotential terminal

Connect with the potential equalization conductor.

8. Input socket

Connect with AC power cord.

4.2.4 Buttons




Figure 4-5 Schematic diagram of buttons

1. Startup indicator It lights in green after turning on the device. 2. Power status indicator Green indicates that the AC power supply is used. At this time, there is no battery in the device or the battery is full. Red and green two colors indicate that the battery is being charged. 3. MENU Menu button 4. MODE When the device in sampling interface, use MODE button to select the print mode. 5. 1mV Calibration button 6. PRINT Print the sampled ECG waveform or end the printing. 7. Direction button Up button 8. Direction button **Right button** 9. SET System menu and confirm. 10. Direction button Down button 11. Direction button Left button 12. FILTER Set the filter mode. 13. SPEED Change the ECG recording speed 14. SEN Adjust the sensitivity manually. 15. ON/OFF When the device is turned on, short press this button, it will prompt whether to shut down the device, long press this button to turn off the device.

## **Chapter 5 Operation Precautions**

#### 5.1 Precautions before use

5.1.1 For safe and effective use, please read the user manual carefully before operation.

5.1.2 Check to ensure that the device is in good condition.

5.1.3 The device shall be placed on a flat surface, and moves gently to avoid strong vibration or shock.

5.1.4 Check to ensure that the lead cables are correctly connected, and the device grounding is correct.

5.1.5 The AC frequency and voltage should comply with the requirements, and enough current capacity should be guaranteed.

5.1.6 When using the battery for power supply, check to ensure that the battery voltage and battery status are in good condition, and the battery has enough power.

5.1.7 When the device is used together with other equipment, all devices and equipment should be equipotential grounded in order to protect the user and operator.

5.1.8 Install the device where easily grounded in the room. Do not allow the patient and patient-connected lead cables and electrodes to come into contact with other conductor parts, including the earth or a hospital bed.

5.1.9 Clean the lead cable with neutral solvent. Do not use alcohol-based cleaners or gemicides.

5.1.10 Ensure that the device is running within the normal ambient temperature range of  $5^{\circ}$ C to 40°C. If the device is stored at a higher or lower temperature, leave it in the operating environment for approximately 10 minutes before use in order to ensure the normal work.

#### 5.2 Precautions during operating

5.2.1 The printing can be started after the ECG waveform is stable.

5.2.2 During using, the doctor should observe the patient carefully and cannot leave the operating site. If necessary, turn off the power or remove the electrode to ensure patient safety.

5.2.3 The patient and the device can only be connected via lead cables through the electrodes, in order to avoid patient touches other parts of device or conductors.

5.2.4 Patient can not move during operating.

5.2.5 Maintenance or repair to the device or accessory is not allowed during using.

#### 5.3 Precautions after use

5.3.1 Set the states of all functions to initial states.

5.3.2 Cut off the power, gently remove the electrodes and limb clips, then remove the lead cables, do not pull with force.

5.3.3 Clean the device and all accessories, and store them for the next use.

## **Chapter 6 Preparations before Operation**

#### 6.1 Installation of recording paper

6.1.1 The device adopts high-speed recording paper, its specification is 80 mm(W)×20 m(L).

6.1.2 The installation method of recording paper is described as below:

1. As shown in Figure 6-1, open the paper cabinet cover, take out the paper axis, insert it into the roll paper as shown in the figure. The paper side with grids should be faced downwards, and then install it to proper position in the paper cabinet.




Figure 6-1 Installation of recording paper

2. Close the paper cabinet cover, it would be better to leave 2cm paper outside the exit of paper cabinet.

#### ANote: The recording paper should be aligned with the slot of the paper cabinet cover. It is

#### recommended to leave 2cm paper outside.

6.1.3 If the recording paper runs out during recording, the device will stop printing automatically, and the screen will display a prompt of lack of paper.

#### 6.2 Power supply connection

#### 6.2.1 AC

Insert one end of the provided three-core power cord into the device's input socket, and insert the other end into a three-core power socket that meets the requirements. Ensure that the connection is secure and reliable, and the device is automatically grounded.

When the device is used in conjunction with other medical equipment, use the supplied potential equalization wire to connect the equipotential terminal of the device to the equipotential terminal of the connected equipment to prevent leakage current and protect the device.

#### 6.2.2 Battery

The device has a built-in rechargeable lithium battery, which does not need to be re-installed by user. Check the battery's power and status before use.

ANote: Connect one end of the potential equalization wire to the equipotential terminal of

the device, and connect the other end to the ground to enhance the reliability of the grounding. Do not use other pipes as ground wire, otherwise, the patient may be in danger of electric shock.

#### 6.3 Lead cable connection

Connect the lead cable to the lead cable interface on the device, and fasten it to the device with the fixing knobs at both sides of the lead cable in order to prevent bad connection and affecting the detection.

#### ANote: The lead cable interface can not be used for other purposes except as the input

#### interface of ECG signals.

#### 6.4 Electrode installation

Proper installation of the electrodes is an important part of accurately recording the electrocardiogram. Make sure the electrodes are in good contact. Old and new electrodes or reusable electrodes and disposable electrodes cannot be used at the same time. If different types of electrodes are used together, it will seriously affect the ECG recording. The electrode or lead plug must not touch other object surfaces or conductors, such as metal beds. Please replace them all when updating the electrodes.

#### Marning: Do not test on part with wounds.

#### 6.4.1 Chest electrodes

As shown in Figure 6-2:




Figure 6-2 Installation of chest electrode

The chest electrodes should be installed to the following parts:

- C1 (VI) : the fourth intercostal space at the right sternal margin
- C2  $\,$  (V2)  $\,$  : the fourth intercostal space at the left sternal margin
- C3  $\,$  (V3)  $\,$  : between C2 and C4  $\,$
- C4 (V4) : the intersection between midclavicular line and the fifth intercostal space
- C5 (V5) : left anterior axillary line on the same plane as C4
- C6  $\,$  (V6)  $\,$  : left midaxillary line on the same plane as C4  $\,$

Clean the chest skin where the electrodes to be installed with alcohol, and apply some conductive pastes to these skin (about 25 mm-diameter range) and the edge of the chest electrode suction cup. Squeeze the suction ball to install the chest electrode at the positions of Cl-C6.

#### ANote: The conductive paste coating should be separated from each other, and the chest

#### electrodes should not touch each other to avoid short circuit.

#### 6.4.2 Limb electrodes

The limb electrodes should be placed on the soft skin of both hands and feet. Before connecting, clean the skin of the electrode installation area with alcohol, and then apply a small amount of conductive paste on the cleaned skin. The electrode connection of the limbs is shown in Figure 6-3.




Figure 6-3 Installation of limb electrodes

#### 6.4.3 Colors of lead cables

**Note:** In practical use, if the electrode mark is inconsistent with the mark described in the user manual, please follow the European/American standard in below table to use.

The correspondence of electrodes in each standard is shown in Table 6-1:

Electronic contribution	European standard		American s	standard
Electrode position	Mark	Color	Mark	Color
Right arm	R	Red	RA	White
Left arm	L	Yellow	LA	Black
Left leg	F	Green	LL	Red
Right leg	N/RF	Black	RL	Green
Chest 1	Cl	Red	VI	Red
Chest 2	C2	Yellow	V2	Yellow
Chest 3	C3	Green	V3	Green
Chest 4	C4	Brown	V4	Blue
Chest 5	C5	Black	V5	Orange
Chest 6	C6	Purple	V6	Purple

Table 6-1 Colors of lead cables

## Note

- > It is recommended to install the lead cables after turning off the device.
- Apply appropriate amount of conductive paste on the electrode when installing the electrode.
- If the ECG waveform does not appear for a long time, check if the electrode is in good contact with the skin.

#### 6.4.4 Lead method and system

As shown in Figure 6-4:




Figure 6-4 Lead system

#### 6.4.5 Lead-off and overload indication

The device can check the connection status of the lead at any time. If lead-off or overload is detected, the screen will display corresponding lead code on the top left corner.


## **A**Note

- In the lead-off prompt area, red font represents lead-off, yellow font represent overload.
- When the connection between lead cable and patient/the device is not reliable, and the ECG signal can not correctly transmitted, the device displays lead-off.
- ➢ In the printed report, lead-off is marked with "\*", and lead overload is marked with "+".

## **Chapter 7 Operation Instructions and Parameter Setting**

#### 7.1 Main Interface

As shown in below figure:



#### Status bar

- Storage space usage: display the usage condition of current storage space
- Current case amount: display the total number of current case
- Battery power (refer to 9.1): display current power status of the device
- Time (on bottom right corner of the screen): display current time of the system

#### Function buttons

- New: to enter the sampling interface, finish waveform acquisition, display and report
  printing, generally, the device will automatically enter this interface after powering on
- Archive: to enter the case management interface, in this interface, user can query, modify or delete case information
- Figure: to view the placement of leads
- Date And Time: to set time and date
- System Setup: to perform system setting
- Sample Setup: to perform sampling setting
- Analysis Setup: to set the parameters used in automatic analysis
- Print Setup: to set the print mode, print style and print content, etc.
- About: to display software version No., creation time and firmware information, etc.

#### 7.2 Sample interface

Click "New" on the main interface or press the button to enter the sampling interface.

Note: If "Info Input" is set to "Before" in Sample Setup, the case information needs to be entered before acquisition (refer to 7.3).

Instant Heart rate Lead-off Information Status Instant Waveform Lead Gain Filter Print Mode Print Return Sneed End sampling: After the device starts sampling, use the button to end the sampling, and back to the main interface. Switch lead: When the device does not simultaneously display 12 leads, use the  ${igsian}$ buttons to switch displayed waveform. **Switch lead display style:** use the **S** and **D** buttons to switch the display style between 3-lead, 6-lead and 12-lead. Lead-off information: In demo mode, it displays "DEMO ECG". In sampling mode, it displays the detected lead status. Print mode: use the button to switch the print mode between Manual, Auto 4×3, Auto 3×4+1, Auto 3×4, Auto 2×6+1, Auto 2×6, Auto 3-2+1, Auto 3-2, Auto 1×12+1, Auto 1×12, Rhythm 4, Rhythm 3 and Rhythm 2. Gain (sensitivity): use the button to switch the gain between 5 mm/mV. 10 mm/mV and 20 mm/mV. The overall gain (sensitivity) can be checked by calibration function. Speed: use the mm/s button to switch the speed between 12.5 mm/s, 25 mm/s and 50 mm/s. Filter: use the button to switch the filter between no filter. AC. EMG. DFT. AC+EMG, AC+DFT, EMG+DFT and AC+EMG+DFT. In which, AC AC filter EMG filter EMG DFT **Baseline filter** 

The sampling interface provides several lead display modes, including 3-lead, 6-lead and 12-lead. The following figure uses 12-lead as an example:

## **Display calibration signal:** after pressing **LILL** button.1 mV signal will occur on the

screen once.

Note: The calibration is an automatic process, user does not need to press any button.

Print/End print: use the

button to start or end the printing operation.

Auto mode: After starting to print, the system automatically prints and stores the real-time 12-lead ECG waveform. The length is determined by the relevant settings in the print setup. Based on the settings, the automatic analysis data and conclusions are printed, and the system automatically ends printing.

Manual mode: After starting to print, user need to switch the lead to print the waveform of different leads, that is, the ECG printed in the manual mode is asynchronous, and the data is not saved. User need to press the PRINT button again when the print needs to be terminated.

If lead-off appears during acquisition, the waveform printed will be marked with "\*".

If lead overload appears during acquisition, the waveform printed will be marked with "+". During printing, the display content of print status are including:

Display content	Explanation	
Process	It is printing.	
Waiting	It is finishing printing.	
No Paper.	Lack of paper, user should restart printing after loading paper.	
Print Timeout.	Communication failure between this system and printing sub-system.	
ECG Timeout	Communication failure between this system and sampling sub-system.	
Low Power	Low power, it cannot start printing.	
Drint Failed	When it was set to use a USB printer, no such printer was connected,	
Print Failed	please print again after connecting a USB printer.	

Note: You can not print until ECG waveforms are displayed on the screen.

In current interface, press **SET** to enter quick setup interface.


The optional content of each setting item and its description are shown in the following table:

ltem	Options	Description
AC filter	[ON]/[OFF]	Turn on or off the AC filter.
EMG filter	[ON]/[OFF]	Turn on or off the EMG filter.
DFT Filter	[ON]/[OFF]	Turn on or off the Baseline filter.
Rhythm Lead	Any lead among the 12 leads	Set the rhythm lead that used for printing under rhythm mode
Show Style	[3 Leads]/[6Leads]/[12Leads]	Set the display method of ECG.
Show Gain	[5mm/mV]/[10mm/mV]/[20mm/m V]	Set the gain of displayed ECG.
Show Speed	[12.5mm/s]/[25mm/s]/[50mm/s]	Set the speed of displayed ECG.

Click "OK" to apply new setup and return to sampling interface; while click"Cancel" not to apply and directly return to sampling interface.

#### 7.3 Case information input interface

Due to the difference of Info Input (refer to 7.9), user could choose to input case information (including ID, name, pacing, etc.) before or after the sampling, or not input the case information, the dialogue box is shown as below:



After selecting a edit box, pressing SET button could pop up a soft keyboard .

Clicking "Caps" can switch between numbers, lowercase letters, capital letters and symbols.

"Space" is the space key, press it to enter a space; "Backspace" is the backspace key, press it to

delete the last character entered. Click "OK" to confirm the entry and exit the interface.

The keyboard may have input restrictions according to the limitation of content. The restricted keys will be grayed out and unavailable.

#### 7.4 Case management

In the main interface, click "Archive" to enter the case management interface, as shown below:

	Total: 1	Current: 1/1	d <b>a se</b>
Date And Time	ID	Name	Sex TimeLen
Sampling Time	001	Patient Name	Sex TimeLen
		Case list	
Adv-opr   <	~ >>	>   Review Delete	Return

The above interface shows all medical records stored in the device. User can search necessary cases by the query function in the interface (refer to 7.5), modify any case information and review the case waveform stored by "Review" (refer to 7.6), and delete the case by "Delete".

The Adv-opr includes the following contents:

- List All: list all cases
- Query: refer to 7.5
- Delete All: delete all cases (caution, it is unrecoverable).
- Export: connect the U disk through the USB port, to export the cases in the device into the specified folder in the U disk.
- Return: return to the case management interface.

Click Lo jump to the first page of case list.


Click to jump to the last page of case list.

Click do jump to the previous page.

Click by to jump to the next page.

#### 7.5 Query

Select "Adv-opr" in the case management interface to enter its sub-menu, then select "Query" to enter its setting interface. Input query conditions and click "Select" to obtain expected results. After clicking "Clear", the system will clear all query conditions that entered.




"Cond.And" and "Cond.Or" indicate the matching mode of the query conditions. You can choose one of the two. If you select "Cond.And", the displayed query results will satisfy all the input conditions at the same time; if you select "Cond.Or", the displayed query results only need to meet any of the conditions entered.

Suggestion: When there are many cases, it would be better to input accurate query conditions and choose "Cond.And" to quickly find the case.

#### 7.6 Review

In the case management interface, select a case to be reviewed, click "Review" to enter

the following dialog box, which displays the case information. User is allowed to modify patient information, after clicking "Save", the information will be changed. Please note that the modification is irreversible.



Make sure the input information is correct, click "Review" to enter the review interface, which is similar with the sampling interface.

Sampling Time	Review time / Sampling time length	Status	4
	Review Waveform	1	
Gain Speed	< >> Prin	t Mode Diagnose	Print Return

In current interface, user could adjust the time period of displayed waveform by  ${}^{\bigvee}$  and

buttons, each pressing could move the waveform to corresponding direction for 1s, and

the speed and gain can be changed (refer to 7.2).

In this interface, if lead-off appears during acquisition, the waveform reviewed will be marked with "\*".

In this interface, if lead overload appears during acquisition, the waveform reviewed will be marked with "+".

In this interface, user can use

button to change the print mode.

In this interface, user can use button to print.



If lead-off appears during acquisition, the waveform printed will be marked with "\*".

If lead overload appears during acquisition, the waveform printed will be marked with "+".



In current interface, press **SET** to enter quick setup interface. The optional content

of each setting item and its description are shown in the following table:

ltem	Options	Description
	[Auto 4×3]/[Auto 3×4]/[Auto 2×6], and	The system takes the
Print Mode	other print modes that applicable for	selected option as print
	current case	mode.
		Set the rhythm lead that
Rhythm Lead	Any lead among the 12 leads	used for printing under
		rhythm mode
Show Style	[2   opds]/[6   opds]/[12   opds]	Set the display method of
	[3 Leads]/[6Leads]/[12Leads]	ECG.
Show Gain		Set the gain of displayed
	[5mm/mV]/[10mm/mV]/[20mm/mV]	ECG.
Show Speed		Set the speed of displayed
	[12.5mm/s]/[25mm/s]/[50mm/s]	ECG.

Click "OK" to apply new setup and return to review interface; while click"Cancel" not to apply and directly return to review interface.

#### 7.7 Date and time setup

In the main interface, click "Date And Time" to set date and time.

In current interface, user can switch the items via O and O buttons, and adjust the

content of the item by **O** and **D** buttons.

#### 7.8 System setup

Select "System Setup" in main menu to enter its setting interface, the options and their descriptions are as followings:

Item	Options	Description
ScreenSaver	[None]/[30Seconds]/[1 Minute]/[2 Minutes] /[5 Minutes]/[10 Minutes], etc.	If there is no operation after reaching the set time, screen saver will be active. If it is set to "None", this function will not be used

Back-light	[30Seconds]/[1 Minute]/[2 Minutes] /[5 Minutes]/[10 Minutes]/[Always On], etc.	If there is no operation after reaching the set time, screen backlight will turn off. If it is set to "Always On", the backlight will always keep on.
Auto Off	[None]/[1 Minute]/[3 Minutes]/[5 Minutes]/[10 Minutes]/[15 Minutes]/[30 Minutes]/[60 Minutes], etc.	If there is no operation after reaching the set time, the system will automatically turn off. If it is set to "None", the system will always keep on.
Low Power	[None]/[Only once]/[Always]	It determines the alarm method that the device uses in low power.
Filter Freq	[50Hz/35Hz]/[50Hz/25Hz]/ [60Hz/25Hz]/[60Hz/35Hz]	To set the parameters of AC filter and EMG filter.
Language	[English]/[Chinese], etc.	To set the default language of system.
K-B Sound	[ON]/[OFF]	If it is selected, the button makes sound while pressing, otherwise, there will be no sound.
Demo Mode	[ON]/[OFF]	If it is selected, the system will run in Demo mode; otherwise, the system will run in sampling mode.
Default		Select "Default", the system settings will restore to the default options.

## 7.9 Sample setup

Select "Sample Setup" in main menu to enter its setting interface, the options and their descriptions are as followings:

	Item	Options	Description
AC Filter		[OFF]/[ON]	Turn on or off the AC filter.
EMG Filter		[OFF]/[ON]	Turn on or off the EMG filter.
DFT Filter		[OFF]/[ON]	Turn on or off the Baseline filter.
Info Input		[Before]/[After]/[None]	Set to input the case information before or after sampling, or not input
Show Style		[3 Leads]/[6 Leads]/[12 Leads]	Set the display method of ECG.
Show Gain		[5mm/mV]/[10mm/mV]/[2 0mm/mV]	Set the gain of displayed ECG.
Show Speed		[12.5mm/s]/[25mm/s]/[50 mm/s]	Set the speed of displayed ECG.
Adv -opr	Sort Lead	[Routine Lead] / [Cabrera Lead]	Set the arrangement mode of the lead

	Backgrou nd Grid	[Show]/[Not Show]	Be used to set whether with background grid.
	Low-pass Filter	[OFF]/[75Hz]/[100Hz]]/ [150Hz]], etc.	Set the parameters of the low-pass filter.
	DFT Freq	[0.05Hz]/[0.15Hz]/[0.25Hz]/ [0.32Hz]/[0.50Hz]/[0.67Hz]/ [1Hz], etc.	Set the parameters of the DFT filter.
	Hospital		Fill in the hospital name in the report.
Default			Select "Default", the system settings will restore to the default options.

#### 7.10 Analysis Setup

Select "Analysis Setup" in main menu to enter its setting interface, the options and their descriptions are as followings:

The setup here will affect real-time analysis during sampling, case review and diagnosis prompt of print report.

Item	Options	Description
Rhythm Lead	[I]/[II]/[III]/[aVR]/[aVL]/[a VF]/[V1]/[V2]/[V3]/[V4]/[ V5]/[V6]	Set the rhythm lead, be used to print under rhythm mode.
Heartbeat Sound	[OFF]/[ON]	Be used to set whether it has heartbeat sound.
Premature (%)		The system will take the input value as the criterion of premature beat.
Pause Time (ms)		The system will take the input value as the criterion of asystole.
Tachycardia (bpm)		The system will take the input value as the criterion of tachycardia.
Bradycardia (bpm)		The system will take the input value as the criterion of bradycardia.
Default		Select "Default", the system settings will restore to the default options.

#### 7.11 Print setup

Select "Print Setup" in main menu to enter its setting interface, the options and their descriptions are as followings:

Item	Options	Description
Print Mode	[Manual]/[Auto	The system takes the selected

	4×3]/[Auto 3×4+1]/[Auto	option as the default print mode.
	3×4]/[Auto 2×6+1]/[Auto	option as the delidate print mode.
	2×6]/[Auto 3-2+1]/[Auto	
	3-2]/[Auto 1×12+1]/[Auto	
	1×12]/[Rhythm	
	4]/[Rhythm 3][/Rhythm 2],	
	etc.	
Lead Gain	[Smart]/[Current]	The system will take the selected item as the gain mode of printing. "Smart" means the system will adjust gain automatically to fit paper height. "Current" indicates that the system will use the gain of waveform on the screen as the print gain.
Auto Strip	[3 sec]/[4 sec]/[5 sec]/[6 sec]/[8 sec]/[10 sec]/[15 sec]/[20 sec]/[25 sec], etc.	The system takes the selected time as the time for printing each strip.
Rhythm Strip	[10 sec]/[15 sec]/[20 sec]/[25 sec]/[30 sec], etc.	When "Print Mode" is set to "Rhythm", the system will take the selected time as the time length for printing each waveform.
Average QRS	[4×3+Mark]/[4×3]/ [3×4+Mark]/[3×4]/ [2×6+Mark]/[2×6]/ [Not print], etc.	When "Print Mode" is set to "Auto" or "Rhythm", the system will print the average QRS waveform in selected format.
Auto-Diagnosis	[All]/[Only Data]/ [Only Conclusion]/ [Not print]	The diagnosis contains data and conclusion, which can be chosen by user as demand.
Period	[Off]/[per 1 min]/[per 2 min]/[per 3 min]/[per 5 min]/[per 10 min]/[per 20 min]/[per 30 min]/[per 60 min], etc.	During the ECG acquisition process, the system will automatically activate the printing operation according to the selected time interval. When the print mode is set to "Manual", it will output 3-lead, otherwise, it will output according to the current setting mode.

Adv-opr	Print-Sav e	[Print and Save]/[Save no Print]/[Print no Save]	When sampling the case, the user can select whether print / save the case after pressing "PRINT".
	Print Device	[Inside]/[Outside A4]	The user can select to use the internal thermal paper or outside USB printer to print.
	Print ST Vector	[Not Print]/[Print]	Be used to set whether to print ST vector.
	Print Depth	[1]/[2]/[3]/[4]	The user can select the depth of the waveform as required.
Default			Select "Default", the system settings will restore to the default options.

Note 1: The settings of auto strip, rhythm strip, average QRS, auto diagnosis and periodic print are only optional in auto mode and rhythm mode.

Note 2: If printing time is less than 8s, no analysis, the sampling and printing time are the same; if the printing time is equal to or greater than 8s, the sampling and analysis time keeps the same with print time.

#### 7.12 Lead placement

Select "Figure" in main menu to check the sketch map of lead placement (also refer to 6.4).

Press any button to exit this interface.

#### 7.13 About

Select "About" in main menu to view the information about the device, it contains the following contents:


- Version: version No. of current program
- Build: creation time of current program.
- FirmInfo: select it to check the firmware information of the device.

## **Chapter 8 Troubleshooting**

#### 8.1 Auto shutdown

- > The battery is almost running out, which causes overdischarge protection circuit action.
- The voltage of AC power supply is too high, which causes overvoltage protection circuit action.

#### 8.2 AC interference




- Whether the device is grounded reliably?
- Whether the electrode or lead cable is connected correctly?
- Whether the electrodes and skin are daubed with enough conductive paste?.
- > Whether the metal bed is grounded reliably?
- Whether the patient is touching the wall or metal parts of the bed?
- Whether the patient touches other people?
- Whether there is high power electric equipment working nearby? Such as X-ray machine or ultrasonic device, etc.

#### ANote: If the interference can not be removed after taking above measures, please use a AC

filter.

#### 8.3 EMG interference




- > Whether the room is comfortable?
- Whether the patient is nervous?
- Whether the bed space is narrow?
- Whether patient speaks during recording?
- Whether the limb electrode is too tight?

### ANote: If the interference can not be removed after taking above measures, please use a

EMG filter. The ECG waveform recorded at this time will be slightly attenuated.

#### 8.4 Baseline drift



- > Whether the electrode installation is stable?
- Whether the connection of lead cables or electrodes is reliable?
- Whether the electrodes and patient skin are cleaned and are daubed with enough conductive paste?
- Whether it is caused by patient's movement or breathing?
- > Whether the electrodes or leads are in bad connection?

## ANote: If the interference can not be removed after taking above measures, please use a

#### baseline filter.

#### 8.5 Troubleshooting list

Phenomenon	Cause of failure	Solutions
Too large interference, disorderly waveform	<ol> <li>Grounding cable is not connected reliably.</li> <li>Lead cables are not connected reliably.</li> <li>There is AC interference.</li> <li>Patient is nervous and can not keep quiet.</li> </ol>	<ol> <li>Check the power cord and lead cables.</li> <li>Let the patient prepare for the measurement.</li> </ol>
Baseline burr	<ol> <li>AC interference is large.</li> <li>Patient nervous, and EMG interference is large.</li> </ol>	<ol> <li>Improve the environment.</li> <li>If the bed is made of steel, replace it.</li> <li>The power cable and lead cables are not parallel or too close to each other.</li> </ol>
Not regular waveform, large up-and-down, beeline figure	<ol> <li>Bad electrode conductivity.</li> <li>Low battery.</li> <li>Bad connection between electrodes and patient skin.</li> <li>Loose connection between lead cables and the device's plug.</li> <li>Bad connection between electrodes and lead cables.</li> </ol>	<ol> <li>Use alcohol of high quality.</li> <li>Clean electrode slice and the skin under the electrode with alcohol.</li> <li>Charge the battery.</li> </ol>

Baseline draft	1. Low power. 2. Patient movement.	<ol> <li>Charge the battery.</li> <li>Keep patient still.</li> </ol>
Unclear waveform	<ol> <li>Low battery.</li> <li>The printer head surface is dirty.</li> <li>The thermal paper problem.</li> </ol>	<ol> <li>Charge the battery.</li> <li>Cut off the power, clean the printer head with alcohol, air dry.</li> <li>Replace the thermal print paper with specified one.</li> </ol>

# **Chapter 9 Maintenance**

### 9.1 Battery

9.1.1 The device is designed with built-in full-sealed and maintenance-free rechargeable lithium battery, also equipped with perfect auto-charging-discharging monitor system. When the device is connected to AC power supply, the battery will be charged automatically. Battery status will be displayed on right edge of LCD screen in powering on state, as shown in Table 9-1. After absolutely discharged, the battery needs 5 hours to charge to 90%, and 5.5 hours to charge to full capacity.

No.	lcon	Description
а	•••	The battery status is unknown, generally it appears within 1 min after turning on.
b	⇒~	Using AC power supply, and the battery is full or no battery in the device
с	İ	Using battery, and battery is full
d	•	Using battery, and battery level is 3/4 of battery full
е	•	Using battery, and battery level is 1/2 of battery full
f	Using battery, and battery level is 1/4 of battery full	
g	•	Using battery, and the battery is low. It is recommended to charge the battery before use or adopt AC power supply.

Note: When charging the battery, the displayed status of battery level switches between icon f to icon c.

9.1.2 The device can print for 3 hours or work for more than 10 hours in standby mode when battery is completely charged. When the device is powered by battery, a battery icon will be displayed on the LCD screen, showing the battery capacity in 5 modes. When the battery capacity is too low for the device to operate, the device will turn off automatically to avoid permanent damage to the battery.

**Note:** The above data is obtained by printing demo waveform under the test environment of temperature 25°C, speed 25mm/s and gain 10mm/mV. In actual use, the operation time may be shorten due to operation condition and environment.

9.1.3 The battery should be recharged in time after discharged completely. If not used for long period, the battery should be recharged every 3 months, which can extend the life of the battery.

9.1.4 When the battery can not be recharged or works no more than 10 minutes after fully charged, please replace the battery.

### <u>∕</u>Note

Do not try to dismantle the sealed battery without permission. The replacement of battery shall be carried out by professional maintenance personal authorized by our company, and the same model of rechargeable battery provided by our company should be used.

- ≻ Do not touch the positive and negative terminals of the battery directly with wire, otherwise there is a danger of fire.
- Do not use the battery near fire sources or in environments where the temperature  $\triangleright$ exceeds 60°C. Do not heat the battery or throw it into fire, water and avoid splashed by water.
- $\triangleright$ Do not puncture, hammer or strike the battery or destroy it by other ways, otherwise it will cause battery overheat, smoke, deform or burn dangers.
- $\triangleright$ Keep away from the battery when it appears leakage or emitting unpleasant smell. If the battery electrolyte leaks onto the skin or clothes, clean with water immediately. If the electrolyte accidentally enters your eyes, do not rub your eyes, immediately clean with water and see a doctor.
- ≻ If the battery reaches its service life, or battery smell, deform, discolor or distorted appears, please stop using the battery and dispose it in accordance with local regulations.

### 9.2 Recording paper

In order to ensure the quality of the ECG waveform, please use the high-speed thermal recording paper supplied or specified by the company. If you use unspecified recording paper, the recorded ECG waveform may be blurred, faded, and the paper feeding may not be smooth. This may even increase the wear of the device and shorten the service life of important parts such as the thermal print head. For information on how to purchase such recording paper, please contact your dealer or the company. Please be careful!

9.2.1 When using recording paper, it is absolutely not allowed to use recording paper with wax on the surface or in grayish/black color. Otherwise, the wax will stick to the heating part of the print head, resulting in abnormal work or damage of the print head.

9.2.2 High temperature, humidity and sunlight may cause the recording paper to change color. Please keep the recording paper in a dry and cool place.

9.2.3 Please do not place the recording paper under fluorescent light for a long time, otherwise it will affect the recording effect.

9.2.4 Please do not to put the recording paper together with the PVC plastic, otherwise the color of recording paper will change.

9.2.5 Please use the recording paper with specified dimension. Recording paper that does not meet the requirements may damage the thermal print head or silicone rubber roller.

### 9.3 Maintenance after use

9.3.1 Press button to shutdown the device.

9.3.2 Unplug the power cord and lead cables. Hold the header of plug to disconnect, and do not pull the cable with force directly.

9.3.3Clean the device and accessories, cover them up to against dust.

9.3.4 Store the device in a cool and dry place, avoid strong vibration when moving.

9.3.5 When cleaning the device, do not immerse it in the cleaner. Power supply must be cut off before cleaning. Use neutral detergents for cleaning. Do not use any detergent or disinfectant containing alcohol.

### 9.4 Lead cables and electrodes

9.4.1 The connectivity of the lead cable can be detected by the multimeter. Check whether each wire of the lead cable is in good contact according to the following table. The resistance of each wire from the electrode plug to the corresponding pin in the lead cable plug should be less than 10 $\Omega$ . The integrity of the lead cable must be checked regularly. Any lead wire damage will cause a false waveform of the corresponding lead or all leads on the ECG. The lead cable can be cleaned with neutral solvent. Do not use the detergent or germicide containing alcohol (Please do not immerse the lead cables in liquid for cleaning).

Note: The resistance of lead cable with defibrillation-proof protection function is about 10KΩ. Table 9-2 Lead cable mark and pin position table

Mark	L	R	C1	C2	C3	C4	C5	C6	F	Ν
Pin position	10	9	12	1	2	3	4	5	11	14

9.4.2 Bending or knotting will shorten the service life of the lead cable. When using it, please straighten the lead cable first.

9.4.3 The electrode should be well stored. After long time use, the surface of the electrode may oxidize and discolor due to corrosion and other factors, which may affect the signal acquisition. In this case, the electrode must be replaced.

### 9.5 Silicone rubber roller

The silicone rubber roller should be smooth and free of stains, otherwise it will affect the ECG recording effect. In order to remove the stains on the roller, please use a clean soft cloth damped with a small amount of alcohol to wipe it along the longitudinal direction, and scroll the roller in the paper conveying direction while wiping until it is clean.

#### 9.6 Cleaning of thermal print head

Dirt and dust on the surface of the TPH can affect the clarity of the waveform. To clean the print head surface, open the paper compartment cover after turning off the device, use a clean and soft cloth dampened with alcohol to wipe the surface gently. For the residual stains on print head, moist it with a little alcohol first, then wipe with a soft cloth. Never use hard objects to scratch the surface, otherwise the print head will be damaged. Wait until the alcohol has evaporated, then close the paper compartment cover. The print head should be cleaned at least once a month during normal use.

#### 9.7 Disposal of product scrap

The disposal of packaging materials, waste battery and end-of-life device should obey the local laws and regulations, and user should treat the scrapped products and materials properly according to the laws and regulations, and try to support the classification and recycling work.

### 9.8 Others

9.8.1 Do not open the device enclosure to avoid electric shock danger.

9.8.2 The device associated circuit schematics and critical parts list are only available to authorized service station or maintenance personnel, who is responsible for maintenance of the device.

9.8.3 The device belongs to measuring instrument. User should send the device to national designated inspection institution for inspection according to the requirements of the national metrological verification procedure. The device shall be inspected at least once per year, and all the accessories should be inspected and maintained regularly (at least once every six months).

# **Chapter 10 Packing List and Accessories**

### 10.1 Accompanying accessories

When the device is shipped from the factory, the intact packaging should contain the following contents, as shown in Table 10-1:

Name	Quantity
Electrocardiograph	1 pc
Chest electrodes (suction cup/electrode	1 set (6 pcs)
slice)	
Limb electrodes (limb clip)	1 set (4 pcs)
ECG lead cable	1 pc
Potential equalization wire	1 pc
Power cord	1pc
User manual	1 pc
Recording paper	1 pc

Table 10-1 Packing list	and accessories
-------------------------	-----------------

#### 10.2 Notes

10.2.1 Please follow the instructions on the package when opening the package.

10.2.2 After unpacking, please check the accessories and accompanying documents in accordance with the packing list, then start inspecting the device.

10.2.3 If the packaging content does not meet the requirement or the device does not work properly, please contact our company immediately.

10.2.4 Please use the accessories provided by our company, otherwise the performance and safety of the device may be affected. If accessories provided by other company need to be used, please first consult the after-sales service of our company, or we will not responsible for any caused damages.

10.2.5 The package shall be kept properly for future use in regular maintenance or device repair.

# Appendix I ECG Automated Measurement&Interpretation Guide

### 1. Preface

The appendix describes the functions of ECG automated measurement and automated interpretation. It explains the specific implementation method, algorithm and formulas related to these two functions, as well as the content output by the automated measurement and automated interpretation.

According to the requirement of *IEC60601-2-51:2003 Medical electrical equipment - Part* 2-51: Particular requirements for safety, including essential performance, of recording and analysing single channel and multichannel electrocardiographs, Clause 50 Accuracy of operating data, the appendix gives a description of verification process and results of the performance for automated measurement and automated interpretation.

### 2. Automated measurement parameters and Automated interpretation items

The output measurement parameter, interpretation item and others that require explanation are as follows:

#### 2.1 Measurement parameters

No.	Parameter	Unit
1	HR	bpm
2	PR-interval	ms
3	P-duration	ms
4	QRS-duration	ms
5	T-duration	ms
6	QT/QTc	ms
7	P/QRS/T electric axis	deg
8	R(V5)/S(V1)	mV
9	R(V5)+S(V1)	mV

### 2.2 Interpretation items

No.	Item
1	No abnormal
2	Sinus mode Bradycardia
3	Sinus mode Tachycardia
4	Left atrium Hypertrophy
5	Right atrium Hypertrophy
6	Dual atrium Hypertrophy
7	QRS low voltage
8	Cardiac electric axis normal
9	Left axis deviation

10	Right axis deviation
10	Completeness Right Bundle branch block
11	
	Completeness Left Bundle branch block
13	No Completeness Right Bundle branch block
14	No Completeness Left Bundle branch block
15	V1 shows RSR' type
16	Left anterior fascicular block
17	Left posterior fascicular block
18	Left ventricular hypertrophy
19	Right ventricular hypertrophy
20	l atrioventricular block
21	Early anteroseptal MI
22	Possible acute forepart anteroseptal MI
23	Old anteroseptal MI
24	Early anterior MI
25	Possible acute anterior MI
26	Old anterior MI
27	Early extensive anterior MI
28	Possible acute extensive anterior MI
29	Old extensive anterior MI
30	Early apical MI
31	Acute apical MI
32	Old apical MI
33	Early anterolateral MI
34	Possible acute anterolateral MI
35	Old anterolateral MI
36	Early high lateral MI
37	Possible acute high lateral MI
38	Old high lateral MI
39	Early inferior MI
40	Possible acute inferior MI
41	Old inferior MI
42	Early inferolateral MI
43	Possible acute inferolateral MI
44	Old inferolateral MI
44	

45	ST depression, mild anteroseptal myocardial ischemia		
46	ST depression, mild anterior myocardial ischemia		
47	ST depression, mild extensive anterior myocardial ischemia		
48	ST depression, mild apical myocardial ischemia		
49	ST depression, mild anterolateral myocardial ischemia		
50	ST depression, mild high lateral myocardial ischemia		
51	ST depression, mild inferior myocardial ischemia		
52	ST depression, mild inferolateral myocardial ischemia		
53	ST depression, anteroseptal myocardial ischemia		
54	ST depression, anterior myocardial ischemia		
55	ST depression, extensive anterior myocardial ischemia		
56	ST depression, apical myocardial ischemia		
57	ST depression, anterolateral myocardial ischemia		
58	ST depression, high lateral myocardial ischemia		
59	ST depression, inferior myocardial ischemia		
60	ST depression, inferolateral myocardial ischemia		

#### 2.3 Intended use

The intended use of the Automated Measurement&Interpretation function is shown as below:

Application	To detect the abnormal of heart of human body, examination items refer		
and diagnosis	to above description		
Population	Teenagers and adults, age range: 12-87		
Application site	hospitals		
Accuracy Accuracy of this function is reflected by the balance perform sensitivity and specificity.			
Others This function does not generate any alarm when using, so it shoul operated by professional or trained personal.			


### 3. Algorithm description

This section describes the algorithm, formulas and judgment conditions for interpretation items related to functions of ECG automated measurement and automated interpretation.

The 12-lead sync ECG waveform passes through the filter (AC, EMG, DFT (if has, and open)) into the module of automated measurement and automated interpretation.

The module of automated measurement and automated interpretation mainly includes process of find the cardiac impulse location, find the beginning/end for each wave, amplitude calculation, parameters calculation, and interpretations judgment based on known parameters.

The workflow is shown as below:



#### 3.1 Find the cardiac impulse location

1) Data preprocessing, obtain the absolute value trend of slope for each lead; then superimpose each absolute value, obtain the superimposed graph of absolute value of slope.

2) Smoothing filter the superimposed graph on average of width 80ms, obtain the analytical data source DDD.

3) Find the cardiac impulse location, give an initial threshold for searching, orderly scan the data in the analytical data source DDD, then compare it with the threshold value:

When the value is greater than the threshold, it may be the beginning of qrs-complex. If the distance from the previous qrs-complex to the current location is less than 150ms, then give up the location.

Otherwise, take the 1/4 of threshold value as a reference, find the beginning of qrs-complex within 100ms before the current location.

When the value is less than the threshold value, it may be the end of qrs-complex. Take the 1/4 of threshold value as a reference, find the end of qrs-complex.

If the found qrs-complex is wide, this qrs-complex shall be excluded. Otherwise, save the found qrs-complex.

4) Locate: after found the qrs-complex, search the max value point between the beginning point and end point in the ecg original data, mark the point as cardiac impulse location.

5) Dynamically threshold adjustment: after found the cardiac impulse location, use the

value at the cardiac impulse location for the dynamically adaptive adjustment of the threshold value. Define the threshold value as 1/3 of the average of the nearest three cardiac impulses.

6) After found the cardiac impulse location, compute the RR-interval and accumulate it with the previous RR-intervals, then count the number of accumulated RR-intervals.

7) Continue searching until the end of data, and calculate the global average value for RR-intervals at the same time.

#### 3.2 Find the beginning/end for each wave

The beginning/end of qrs-complex has been approached in above cardiac impulse locating process, but it is mainly in order to assist to find the cardiac impulse location; in addition, the location is searched based on the slope threshold value, which is imprecise. Here, according to the found cardiac impulse location, the beginning/end of qrs-complex will be sought accurately. Name the cardiac impulse location as the peak of R-wave.

1. Read data

1) Read one data of qrs-complex: take the peak of R-wave as reference, locate directly to the original ecg file, read a piece of data containing the qrs-complex.

2) Preprocessing: superimpose the absolute value of slope for 12-lead signals.

 Use the preprocessed data to carry on the searching of QRS-complex, P-wave and T-wave as the followings.

4) Read the next data of qrs-complex, repeat step 2 and step 3 until the analyzing of all qrs-complex are finished.

2. Find QRS-complex

1) Calculate the threshold value of S-wave: search the minimal value within 200ms after the peak of R-wave, take the value that equals to minimal value plus 0.4, as the threshold value for finding the end of S-wave.

2) Find the beginning of Q-wave: take 0.5 as the threshold vale, search forwardly starting from R-wave, a point that less than the threshold value, within Oms-200ms before the peak of R-wave, which is the beginning of Q-wave.

3) Find the end of S-wave: search backwardly starting from R-wave, a point that less than the threshold value of the end of S-wave, within Oms-200ms after the peak of R-wave, which is the end of S-wave.

3. Find P-wave

1) Peak of P-wave: search the max value within 30ms-100ms before the beginning of Q-wave, temporarily mark the point as the peak of P-wave.

2) Find the end of P-wave: search the minimal value between the peak of P-wave and the beginning of Q-wave, the minimal value plus 0.05 is the threshold value, use the threshold value to find the end of P-wave.

3) Find the beginning of P-wave: search the minimal value within 150ms before the peak of P-wave, the minimal value plus 0.06 is the threshold value, use the threshold value to find the beginning of P-wave.

4) If the found P-wave is narrow, research the P-wave according to the following steps.

5) Change the searching range of 30ms-100ms to 100ms-350ms in step 1, repeat step 1-4.

6) If the found P-wave is still narrow, it means that P-wave doesn't exist.

4. Find T-wave

1) Peak of T-wave: search the max value within 30ms-300ms after the end of QRS-complex, save it as the peak of T-wave.

2) Threshold value of the beginning of T-wave: search the minimal value within 0ms-100ms after the end of QRS-complex, the minimal value plus 1/10 of the peak value of T-wave is the threshold for finding the beginning of T-wave.

3) Threshold value of the end of T-wave: search the minimal value within 200ms after the peak of T-wave, the minimal value plus 1/10 of the peak value of T-wave is the threshold for finding the end of T-wave.

4) Find the beginning of T-wave: in the range between the minimal value in step2 and the peak of T-wave, find a point that less than the .threshold value of the beginning of T-wave, the point is the beginning of T-wave.

5) Find the end of T-wave: in the range between the minimal value in step3 and the peak of T-wave, find a point that less than the threshold value of the end of T-wave, the point is the end of T-wave.

5. Explanation of equipotential segment

In searching the QRS-complex, this algorithm adopts the analysis method of superposition of the slopes for all leads, therefore, the equipotential segments before and after the QRS-complex are partly included in the start and end points of the QRS-complex. It is depends on the number of leads containing equipotential segments. If there are more leads containing equipotential segments, the slope value will be smaller after superposition, so it is difficult to meet the threshold condition, and only a small part of the equipotential segments is counted to the start and end points of the QRS-complex. On the contrary, if there are less leads containing equipotential segments, a large part of the equipotential segments will be counted to the start and end points of the QRS-complex. Anyway, the equipotential segments before and after the QRS-complex are partly included in the QRS-complex duration.

#### 3.3 Amplitude measurement

After finding the position of each wave, i.e. the start and end points of P wave, QRS complex and T wave, use the following method to measure P, Q, R, S, ST and T waves of each lead.

### 1. P-wave

Calculate the average value of the data 20ms before the start point of P wave, and use this average value as the baseline of P wave. Find the max value between the start point and end point of P wave, the difference between the max value and the baseline would be the amplitude of P wave.

### 2. Q/R/S wave

Calculate the average value of the data 10-30ms before the start point of QRS complex, and use this average value as the baseline of QRS complex. Search boundary points that exceeding the baseline from the start point of Q wave to the end point of S wave. Each adjacent two boundary points forms a sub-wave. Determine whether each sub-wave is a recognizable minimum wave

(see the definition below). If it is a recognizable minimum wave, first identify its direction. If it is above the QRS baseline, it is R wave, if it is below the baseline, it is Q wave or S wave. Find the extreme value of this wave, and the difference between the extreme value and the baseline is the amplitude of Q/R/S wave.

Note: If there is only one downward wave, its amplitude should be respectively recorded in the amplitude of Q wave and S wave.

### 3. ST segment

Take above baseline of QRS complex as the ST baseline. Calculate the differences between the ST baseline and the points at 40ms and 60ms after the end point of QRS complex, and calculate the average value of these two differences, the average value is the amplitude of ST segment.

### 4. T-wave

Calculate the average value of the data 20-50ms after the end point of T wave, and average this value with the QRS baseline in 2, then use the result as the baseline of T wave. Find the max value between the start point and end point of T wave, the difference between the max value and the baseline would be the amplitude of T wave.

5. Recognition of minimum wave

The minimum wave can be recognized by the algorithm according to the requirement of IEC60601-2-51:2003 Medical electrical equipment - Part 2-51: Particular requirements for safety, including essential performance, of recording and analysing single channel and multichannel electrocardiographs, Annex GG, Clause GG.5 Definition of waveforms, measurement of minimum waves. The wave that meet the following conditions is the minimum wave that can be recognized by the algorithm.

1) The signal part under consideration shows clearly two opposite slopes with at least one turning point in between;

2) The signal part under consideration deviates at least  $30\mu V$  from the reference level for a duration of at least 6ms;

3) The minimum observable duration of wave under consideration is 12ms and amplitude  ${\geq}30\mu V.$ 

#### 3.4 Calculation after intervals determination

The following parameters are determined according to the requirement of *IEC60601-2-51:2003 Medical electrical equipment - Part 2-51: Particular requirements for safety, including essential performance, of recording and analysing single channel and multichannel electrocardiographs, Annex GG Definitions and rules for the measurement of ELECTROCARDIOGRAMS.* 

No.	Parameter	Calculation
1	HR	$60 / \mathrm{RR}^{\oplus}$
2	PR-interval	Qs <sup>∅</sup> - Ps <sup>③</sup>
3	P-duration	Pe <sup>(4)</sup> - Ps <sup>(3)</sup>
4	QRS-duration	Se <sup>(5)</sup> - Qs <sup>@</sup>

5	T-duration	Te <sup>⑦</sup> - Ts <sup>⑥</sup>
6	QT	${\sf Te}^{ar{\mathcal{O}}}  ext{-} {\sf Qs}^{arnothing}$
7	QTc	$\frac{QT}{\sqrt{RR}}^{\circ}$
8	P/QRS/T electric axis	Electric axis formula: $\frac{\arctan(2.0 \times (S_{III} + S_{I}), S_{I} \times \sqrt{3}) \times 180}{PI}$ (8) P electric axis: S <sub>III</sub> : voltage sum from the beginning point to the end point of P-wave on lead III S <sub>1</sub> : voltage sum from the beginning point to the end point of P-wave on lead I QRS electric axis: S <sub>III</sub> : voltage sum from the beginning point to the end point of QRS-complex on lead III S <sub>1</sub> : voltage sum from the beginning point to the end point of QRS-complex on lead I T electric axis: S <sub>III</sub> : voltage sum from the beginning point to the end point of T-wave on lead I S <sub>1</sub> : voltage sum from the beginning point to the end point of T-wave on lead III S <sub>1</sub> : voltage sum from the beginning point to the end point of T-wave on lead III S <sub>1</sub> : voltage sum from the beginning point to the end point of T-wave on lead III
9	R(V5)	Height (voltage value) of R-wave on lead V5
10	S(V1)	Height (voltage value) of S-wave on lead V1

Note:

1 RR: RR-interval

(2) Qs: beginning of the Q-wave

③ Ps: beginning of the P-wave

④ Pe: end of the P-wave

- (5) Se: end of the S-wave
- 6 Ts: beginning of the T-wave
- ⑦ Te: end of the T-wave
- (8) PI: 3.1415926

# 3.5 Interpretations judgment based on parameters

No.	Item	Rule of interpretation				
1	No abnormal	No any abnormal are detected				
2		Sinus P-wave, PR-interval between				
2	Sinus mode Bradycardia	110ms-210ms, HR≤*/min, general *=50				
2		Sinus P-wave, PR-interval between				
3	Sinus mode Tachycardia	110ms-210ms, HR≥ */min, general *=100				
		P-wave of leads I, II, aVL shall meet the				
4		conditions: width increase of P-wave≥110ms,				
4	Left atrium Hypertrophy	or P-wave displays in double-peak type,				
		value of peak to peak ≥40ms				
L		For leads I, II, aVF, amplitude of P-wave				
5	Right atrium Hypertrophy	≥0.25mV, or P-wave is sharp				
6		For leads I, II, aVF, amplitude of P-wave				
0	Dual atrium Hypertrophy	≥0.25mV and P-wave duration >110ms				
7		Voltage of I-aVF limb leads $<$ 0.5mV,				
/	QRS low voltage	and voltage of V1-V6 chest leads $<$ 0.8mV				
8	Cardiac electric axis normal	QRS-axis between 30 to 90 degree				
9	Left axis deviation	QRS-axis between -90 to-30 degree				
10	Right axis deviation	QRS-axis between 120 to 180 degree				
11	Completeness Right Bundle	QRS-duration>120ms, R-wave of lead				
11	branch block	V1 or aVR is wide (width of R-wave>80ms)				
12	Completeness Left Bundle branch	QRS-duration>120ms, R-wave of lead				
12	block	V5 or V6 is wide				
13	No Completeness Right Bundle	QRS-duration<120ms, R-wave of lead				
15	branch block	V1 or aVR is wide (width of R-wave>80ms)				
14	No Completeness Left Bundle	QRS-duration<120ms, R-wave of lead V15 or				
14	branch block	V6 is wide (width of R-wave>80ms)				
15	V1 shows RSR' type	QRS-complex of lead V1 is RSR' type				
		QRS-duration<110ms, QRS-axis <-30				
16	Laft autorian faction lands to st	degree, lead I and lead aVL are qR type, and				
10	Left anterior fascicular block	Q-wave duration<20ms, lead II, III and aVF				
		are rS type.				
17	Left posterior fascicular block	QRS-duration<110ms, QRS-axis >90				

		degree, lead I and lead aVL are rS type, lead
		II, III and aVF are gR type, and Q-wave of
		lead II and III <20ms.
		R amplitude of lead I >1.5mV, R
		amplitude of lead V5 >2.5mV, R amplitude of
18	Left ventricular hypertrophy	lead aVL >1.2mV, R amplitude of lead
		aVF >2mV, R amplitude of lead V5 minus S
		amplitude of lead V1 >4mV (male) or 3.5mV
		(female).
		R amplitude of lead aVR >0.5mV, R
		amplitude of lead V1 >1mV, R amplitude of
19	Right ventricular hypertrophy	lead V1 minus S amplitude of lead
_	inght ventricalar hypertrophy	V5 >1.2mV, R amplitude of lead V1 is larger
		than S amplitude, R amplitude of lead V5 is
		smaller than S amplitude.
20	l atrioventricular block	PQ interval >210ms
21		Early myocardial infarction change of leads
21	Early anteroseptal MI	V1, V2, V3, no change of leads V4, V5.
22	Possible acute forepart	Acute myocardial infarction change of
22	anteroseptal MI	leads V1, V2, V3, no change of leads V4, V5.
22		Old myocardial infarction change of
23	Old anteroseptal MI	leads V1, V2, V3, no change of leads V4, V5.
		Early myocardial infarction change of leads
24	Early anterior MI	V3, V4, V5, no change of leads V1, V2, V6.
		Acute myocardial infarction change of leads
25	Possible acute anterior MI	V3, V4, V5, no change of leads V1, V2, V6.
		Old myocardial infarction change of leads V3,
26	Old anterior MI	V4, V5, no change of leads V1, V2, V6.
		Early myocardial infarction change of leads
27	Early extensive anterior MI	V1, V2, V3, V4, V5.
	Possible acute extensive anterior	Acute myocardial infarction change of leads
28	MI	V1, V2, V3, V4, V5.
	ivii	Old myocardial infarction change of leads V1,
29	Old extensive anterior MI	V2, V3, V4, V5.
		Early myocardial infarction change of leads
30	Early apical MI	V4, V5, no change of leads V1, V2, V3.
		Acute myocardial infarction change of leads
31	Acute apical MI	
		V4, V5, no change of leads V1, V2, V3.

32	Old anical MI	Old myocardial infarction change of leads V4,				
52	Old apical MI	V5, no change of leads V1, V2, V3.				
33	Forth optorolatoral N4	Early myocardial infarction change of leads I,				
55	Early anterolateral MI	aVL, V4, V5, V6				
34	Dessible coute enterelatoral MI	Acute myocardial infarction change of leads				
54	Possible acute anterolateral MI	I, aVL, V4, V5, V6.				
35	Old anterolateral MI	Old myocardial infarction change of leads I,				
35		aVL, V4, V5, V6				
36	Easte bish lateral MA	Early myocardial infarction change of leads I,				
30	Early high lateral MI	aVL, no change of leads II, III, aVF, V4, V5, V6.				
		Acute myocardial infarction change of leads				
37	Possible acute high lateral MI	I, aVL, no change of leads II, III, aVF, V4, V5,				
		V6.				
38	Old high lateral MI	Old myocardial infarction change of leads I,				
50	Old high lateral MI	aVL, no change of leads II, III, aVF, V4, V5, V6.				
39	Forby informer N4L	Early myocardial infarction change of leads II,				
35	Early inferior MI	III, aVF, no change of leads I, aVL.				
40	Possible acute inferior MI	Acute myocardial infarction change of leads				
40		II, III, aVF, no change of leads I, aVL.				
41	Old inferior MI	Old myocardial infarction change of leads II,				
41		III, aVF, no change of leads I, aVL.				
42		Early myocardial infarction change of leads I,				
72	Early inferolateral MI	II, III, aVL, aVF.				
43	Possible acute inferolateral MI	Acute myocardial infarction change of leads				
43		I, II, III, aVL, aVF.				
44	Old inferolateral MI	Old myocardial infarction change of leads I,				
44		II, III, aVL, aVF.				
45	ST depression, mild anteroseptal	Mild ST-segment depression of leads V1, V2,				
45	myocardial ischemia	V3, and no change of leads V4, V5.				
46	ST depression, mild anterior	Mild ST-segment depression of leads V3, V4,				
40	myocardial ischemia	V5, and no change of leads V1, V2, V6.				
47	ST depression, mild extensive	Mild ST-segment depression of leads V1, V2,				
- 7/	anterior myocardial ischemia	V3, V4, V5.				
48	ST depression, mild apical	Mild ST-segment depression of leads V4, V5,				
-0	myocardial ischemia	and no change of leads V1, V2, V3.				
49	ST depression, mild anterolateral	Mild ST-segment depression of leads I, aVL,				
45	myocardial ischemia	V4, V5, V6.				

CT 1	Mild ST-segment depression of leads I, aVL,				
	<b>U</b>				
myocardial ischemia	and no change of leads II, III, aVF, V4, V5, V6.				
ST depression, mild inferior	Mild ST-segment depression of leads II, III,				
myocardial ischemia	aVF, and no change of leads I, aVL.				
ST depression, mild inferolateral	Mild ST-segment depression of leads I, II, III,				
myocardial ischemia	aVL, aVF.				
ST depression, anteroseptal	Severe ST-segment depression of leads V1,				
myocardial ischemia	V2, V3, and no change of leads V4, V5.				
ST depression, anterior myocardial	Severe ST-segment depression of leads V3,				
ischemia	V4, V5, and no change of leads V1, V2, V6.				
ST depression, extensive anterior	Severe ST-segment depression of leads V1,				
myocardial ischemia	V2, V3, V4, V5.				
ST depression, apical myocardial	Severe ST-segment depression of leads V4,				
ischemia	V5, and no change of leads V1, V2, V3.				
ST depression, anterolateral	Severe ST-segment depression of leads I,				
myocardial ischemia	aVL, V4, V5, V6.				
	Severe ST-segment depression of leads I,				
1 , 5	aVL, and no change of leads II, III, aVF, V4,				
myocardial ischemia	V5 <i>,</i> V6.				
ST depression, inferior myocardial	Severe ST-segment depression of leads II, III,				
ischemia	aVF, and no change of leads I, aVL.				
ST depression, inferolateral	Severe ST-segment depression of leads I, II,				
myocardial ischemia	III, aVL, aVF.				
	ST depression, mild inferior myocardial ischemia ST depression, mild inferolateral myocardial ischemia ST depression, anteroseptal myocardial ischemia ST depression, anterior myocardial ischemia ST depression, extensive anterior myocardial ischemia ST depression, apical myocardial ischemia ST depression, anterolateral myocardial ischemia ST depression, high lateral myocardial ischemia ST depression, inferior myocardial ischemia ST depression, inferior myocardial ischemia ST depression, inferolateral				

#### Note:

Early myocardial infarction: normal Q-wave, ST elevation or ST slope elevation Acute myocardial infarction: abnormal Q-wave, ST elevation or ST slope elevation Old myocardial infarction: abnormal Q-wave, no ST elevation. Abnormal Q-wave:

For leads I, II, III, avR, avL, avF, V3, V4, V5, V6, voltage of Q-wave <-0.3mV, or 4 times of negative wave of Q-wave> voltage of R-wave and R'-wave, and/or Q-duration>40ms.

For leads V1, V2, voltage of Q-wave <-0.08mV and Q-duration>10ms.

ST elevation:

For leads I, II, III, avR, avL, avF, V4, V5, V6, the voltage of ST segment at 60ms point >0.1mV, and for leads V1, V2, V3, the voltage at 60ms point >0.3mV.

ST slope elevation:

Voltage of ST segment at 20ms point>=voltage of J point, voltage at 40ms point >= the one at 20ms, voltage at 60ms point >= the one at 40ms, with change of ST elevation.

#### 4. Data sources and data preprocessing

#### 4.1 Data sources

According to the requirement of *IEC60601-2-51:2003 Medical electrical equipment - Part 2-51: Particular requirements for safety, including essential performance, of recording and analysing single channel and multichannel electrocardiograph, the CSE measurement database, CSE diagnostic database, CTS calibration database and customized data shall be used to evaluate the function of automated measurements and automated interpretations.* 

Verification	Database	Database items
Automated measuremen	CTS database	CAL05000 CAL10000 CAL15000 CAL20000 CAL20002 CAL20100 CAL20110 CAL20160 CAL20200 CAL20210 CAL20260 CAL20500 CAL30000 ANE20000 ANE20001 ANE20002
t	CSE measurement database	MA_0001~MA0125
Automated	CSE diagnostic database	D_0001~D_1220
interpretatio n	Customized data	000001~000549

#### 4.2 CTS introduction

The CTS computerized ECG conformance testing project was launched in 1989 by the European Union. This project laid the foundation for computerized ECG conformance testing service. Currently, about 20 types of waveform have been designed derived from the test signals having an infinite length, these signals are part of the CTS-ECG test database, and have proven their effectiveness in a series of official tests. According to the requirement of *IEC60601-2-51:2003 Medical electrical equipment - Part 2-51: Particular requirements for safety, including essential performance, of recording and analysing single channel and multichannel electrocardiograph Clause 50.101.1, 13 data (CAL05000, CAL10000, CAL20000, CAL20100, CAL20100, CAL20100, CAL20100, CAL20500, CAL30000) are used in the automated parameters verification for this test.* 

### 4.3 CSE introduction

The EU CSE (Common Standards for Quantitative Electrocardiography) ECG database contains 3-lead measurement database of collection1 and collection2, 12-lead measurement database of collection3 and collection4, and a diagnostic database of collection5. In which, the 12-lead measurement database contains 250 groups of interference data; Diagnostic database contains 1220 cases of short-term ECG recording. The primary development purpose of using 12-lead or 15-lead is to evaluate the performance of the automatic ECG analyzer. In addition to the normal data, the database also includes clinically confirmed ECGs of variety cases, such as left ventricular hypertrophy, right ventricular hypertrophy, every part of myocardial infarction and ventricular hypertrophy accompanying myocardial infarction. The database has made a

great contribution to the study of electrocardiology, which is, the CSE group published a report on the recommended standard for general ECG measurements based on the investigation and study of the database, which has been widely recognized by the world.

CSE database diagnostic items:

Item	Number
Normal	382
Left ventricular hypertrophy	183
Right ventricular hypertrophy	55
Biventricular hypertrophy	53
Anterior myocardial infarction	170
Inferior myocardial infarction	273
Complex myocardial infraction	104
Synthetical accuracy	1220

### 4.4 Customized data

### 4.4.1 Data description

Customized	Description
data	
Total recording	549
number	
Race	Yellow race
Coverage of	Aged from 17 to 87, average age 57.23, standard deviation 21.32;
age, gender	326 male, average age 55.54, standard deviation 19.81;
	223 female, average age 59.70, standard deviation 22.63.
Sampling data	12-lead ECG data (I, II, III, AVR, AVL, AVF, V1, V2, V3, V4, V5, V6),
	sampling frequency of each channel: 1kHz, amplitude quantization:
	2.4μV/LSB.
Remark	The interpretation conclusion of customized data is determined by the
	physician diagnostic results of cardiac catheterization and ultrasonic
	examination, and the ECG judgment result in physical examination, the
	details as blow:
	1) Normal ECG
	Determined by the diagnostic result that judged as normal in cardiac
	catheterization and ultrasonic examination, and the result that judged as
	normal in physical examination.
	2) Atrium hypertrophy
	Determined by the diagnostic results of ultrasonic examination.

3) Myocardial infarction and myocardial ischemia
Determined by the physician diagnostic results of cardiac catheterization.
4) Tachycardia, bradycardia, low voltage, axis
Determined by the diagnostic results of ultrasonic examination.
5)Conduction block
Determined by the physician diagnostic results of cardiac catheterization.
The standard of normal population in the customized database: physical
examination is normal, no heart disease or other diseases that may affect
cardiac functions or shape.

# 4.5 Data coverage of verification for automated interpretation

Analyzing the content of CSE diagnostic database and customized data, the overall condition and coverage of statistical samples are shown as below:

	Total Male Femal							Female										
	Youngest Oldest		Average	SD	Total	You	ngest	Oldest	Average	SD	Total	You	ngest	Oldest	Average	SD	Total	
Т	otal	12	87	54.87	15.34	1769	1	4	87	54.33	14.33	1157		12	80	55.89	15.48	612
SD: sta	ndard dev:	iation											_					
																	Unit: ye	ars
						Total					Male					Female		
No.		Items		Young	Oldest	Avera	SD		Young	Oldest	Avera	SD		Young		Avera	SD	
				est	Oldest	ge	SD	Total	est	Oldest	ge	SD	Total	est	Oldest	ge	50	Total
1		No abnorma	1	12	87	47.39	18.21	585	14	79	46.37	17.51	234	12	87	48.07	18.32	351
2	Sin	us mode Brady	/cardia	14	85	51.62	17.93	191	14	85	53.74	18.12	114	15	83	48.48	16.99	77
3	Sin	us mode Tachy	zcardia	19	79	50.26	16.97	78	23	76	53.33	18.76	25	19	79	48.81	17.65	53
4	Lef	tatrium Hyper	trophy	17	81	49.52	12.37	51	17	73	45.78	13.45	31	21	81	55.32	13.02	20
5	Righ	at atrium Hype	rtrophy	18	76	48.71	15.34	43	19	71	47.21	14.36	27	18	76	51.24	15.29	16
6	Dus	al atrium Hype:	rtrophy	26	77	51.32	16.49	22	26	75	49.91	16.13	15	29	77	54.34	15.47	7
7		QRS low volt	age	33	67	52.44	15.83	5	52	52	52	0	1	33	67	52.55	15.99	4
8	Cardi	iac electric axi	s normal	12	87	48.97	19.06	733	12	85	46.52	18.98	304	14	87	50.71	19.26	429
9	1	Left axis devia	tion	27	73	49.48	15.71	168	28	73	48.73	14.27	86	27	71	49.66	15.09	83
10	R	light axis devie	tion	36	77	52.76	14.68	107	36	72	51.85	15.11	56	37	77	53.76	14.79	51
11	Complet	eness Right Bu	indle branch	46	78	56.97	11.53	28	46	75	55.86	10.97	15	50	78	58.25	11.20	13
		block		40	70	50.97	11.55	20	40	15	55.80	10.57	15		/0	22.00	11.20	15
12	Comple	teness Left Bu	ndle branch	44	79	56.99	10.93	32	44	73	55.72	10.21	18	52	79	58.62	9.74	14
		block				50.99	10.95	35		15	55.75	10.21	10	75		20.02	9.74	14
13	No Co	mpleteness Rig	ht Bundle	41	73	55.83	11.14	41	41	71	55.11	10.75	24	47	73	56.85	11.06	17
		branch block	8			00100						10110						
14	No Co	mpleteness Le	ft Bundle	43	71	55.76	10.38	47	43	69	54.36	10.27	31	48	71	58.47	10.67	16
		branch block	s.	45	71	55.76	10.56	4)	45	09	34.50	10.27	51	40	1 11	58.41	10.67	10
15	V	1 shows RSR	type	37	75	56.81	15.77	13	37	74	56.16	15.46	10	40	75	58 <i>.</i> 98	17.69	3
16	Left a	nterior fascicu	lar block	38	81	57.66	17.49	26	38	81	55.82	17.92	15	40	81	60.17	18.06	11
17	Left p	osterior fascicu	ılar block	41	78	56.78	16.88	18	43	78	55.16	17.93	12	41	77	60.02	15.69	6
18	Left	/entricular hyp	ertrophy	29	85	58.70	19.23	236	29	83	57.98	19.67	184	32	85	61.25	18.76	52
19	Right	ventricular hy	pertrophy	27	84	59.31	19.54	108	27	79	58.09	20.04	71	31	84	61.65	19.33	37
20	Ιa	trioventricular	block	19	76	57.62	18.73	13	19	74	57.04	18.92	9	20	76	58.93	18.77	4
21	Ea	arly anterosept	al MI	48	83	63.48	10.34	10	48	80	61.39	10.29	7	59	83	68.36	12.84	3
22	Possible	acute forepart	anteroseptal	53	73	60.48	9.71	27	53	70	59.99	9.64	19	62	73	61.64	8.12	8
		MI		55	15	00.40	2.24			70	57.77	2.04	1.2	0.2	10	01.04	0.12	
23	C	)ld anterosepta	I MI	55	82	65.37	9.17	26	55	80	64.78	10.08	20	58	82	67.34	9.68	6
24		Early anterior	MI	47	76	61.26	10.41	77	47	71	60.32	9.62	53	55	76	63.34	9.77	24
25	Pos	sible acute ante		51	77	63.81	9.16	10	51	69	62.14	9.45	8	64	77	70.49	9.21	2
26		Old anterior I		53	83	66.48	9.86	13	53	81	65.94	9.76	9	62	83	67.70	9.27	4
27	Early	y extensive ant	erior MI	52	75	60.35	11.74	24	52	72	59.88	11.52	17	58	75	61.49	12.36	7
28		acute extensive		55	79	63.81	12.34	16	55	75	61.58	10.63	10	58	79	67.53	11.21	6
29	Old	extensive ante	rior MI	60	86	65.37	10.08	30	60	80	64.37	10.66	21	63	86	67.70	10.74	9
30		Early apical I		39	71	60.36	12.47	15	39	69	60.18	12.76	10	47	71	60.72	11.28	5
31		Acute apical l	MI	43	77	62.58	11.57	21	43	74	62.69	12.03	16	50	77	62.23	12.46	5
32		Old apical Iv	п	52	82	63.74	10.84	19	52	78	62.35	11.59	15	57	82	68.95	11.94	4
33		uly anterolater		47	83	60.37	11.62	36	47	80	60.21	12.41	28	55	83	60.93	12.68	8
34		le acute antero		55	80	63.77	10.66	9	55	75	62.18	11.62	7	58	80	69.34	15.08	2
35	С	old anterolatera	1 MI	56	82	64.82	10.73	14	56	76	64.05	11.62	10	60	82	66.75	10.47	4
36	E	arly high laters	I MI	48	73	61.38	10.79	16	48	70	60.46	10.88	12	56	73	64.14	8.29.	4

37	Possible acute high lateral MI	54	72	63.34	9.89	8	54	70	62.67	8.06	7	68	68	68.00	0	- 1
38	Old high lateral MI	55	77	65.17	11.44	23	55	74	64.09	10.12	17	58	11	68.23	9.94	6
39	Early inferior MI	46	74	61.31	12.55	31	46	70	61.02	11.81	22	50	74	62.02	11.73	9
40	Possible acute inferior MI	53	76	62.48	10.99	11	53	74	62.13	11.04	8	56	76	63.41	10.96	3
41	Old inferior MI	56	81	65.37	9.79	101	56	76	65.01	10.61	72	60	81	66.26	9.96	29
42	Early inferolateral MI	44	72	60.18	12.71	73	44	70	59.89	13.53	52	50	72	60.90	13.33	21
43	Possible acute inferolateral MI	50	78	63.47	10.77	29	50	75	62.49	11.62	20	55	78	65.65	11.78	9
44	Old inferolateral MI	56	83	66.56	9.83	28	56	80	65.41	9.96	19	60	83	68.99	8.24	9
45	ST depression, mild anteroseptal myocardial ischemia	43	74	62.34	12.77	7	43	70	62.47	11.99	5	50	74	62.02	16.94	2
46	ST depression, mild anterior myocardial ischemia	44	72	61.59	12.69	5	44	72	61.15	12.76	4	63	63	63.00	0	1
47	ST depression, mild extensive anterior myocardial ischemia	46	73	62.77	11.98	13	46	69	62.18	12.26	9	54	73	64.10	10.65	4
48	ST depression, mild apical myocardial ischemia	45	75	61.62	11.87	17	45	71	61.33	11.64	10	51	75	62.03	11.29	7
49	ST depression, mild anterolateral myocardial ischemia	44	74	60.97	12.65	25	44	72	60.07	12.39	15	50	74	62.32	12.04	10
50	ST depression, mild high lateral myocardial ischemia	46	81	64.36	12.31	21	46	79	63.94	11.82	16	53	81	65.70	12.74	5
51	ST depression, mild inferior myocardial ischemia	43	76	63.41	12.46	12	43	74	62.89	12.13	10	56	76	66.01	14.13	2
52	ST depression, mild inferolateral myocardial ischemia	39	72	62.76	12.38	20	39	69	62.11	12.12	13	44	72	63.97	13.37	7
53	ST depression, anteroseptal myocardial ischemia	49	78	65.61	11.62	4	49	78	65.24	14.81	3	67	67	67.00	0	1
54	ST depression, anterior myocardial ischemia	51	79	66.73	11.53	12	51	74	65.89	11.54	8	60	79	68.41	10.49	4
55	ST depression, extensive anterior myocardial ischemia	50	79	67.26	11.69	7	50	76	66.87	11.07	5	57	79	68.24	15.22	2
56	ST depression, apical myocardial ischemia	48	85	65.39	11.39	18	49	83	65.09	11.79	11	56	85	65.86	12.04	7
57	ST depression, anterolateral myocardial ischemia	52	83	66.93	10.97	13	53	83	66.42	12.32	7	52	81	67.53	11.69	6
58	ST depression, high lateral myocardial ischemia	53	84	65.74	10.88	16	54	84	65.16	12.36	9	53	82	66.49	11.47	7
59	ST depression, inferior myocardial ischemia	49	81	65.82	11.03	12	49	11	65.28	12.27	9	55	81	67.44	13.04	3
60	ST depression, inferolateral myocardial ischemia	49	82	66.04	11.14	6	49	79	65.49	16.98	4	52	82	67.14	21.02	2

L

not contained in above sheet won't be regarded as the judgment object for the verification of automated interpretation accuracy.

### 4.6 Data preprocessing

### 4.6.1 CTS preprocessing

The 16 cases (CAL05000, CAL10000, CAL15000, CAL20000, CAL20002, CAL20100, CAL20110, CAL20160, CAL20200, CAL20210, CAL20260, CAL20500, CAL30000, ANE20000, ANE20001, ANE20002) from CTS-ECG shall be processed for voltage conversion and frequency conversion for resampling as the applicable format in the system. Then cases will be imported to the device. After that, the verification of automated measurement parameters will be carried on.

### 4.6.2 CSE preprocessing

The cases (MA\_0001~MA0125, D\_0001~D\_1220) from the CSE shall be processed for voltage conversion and frequency conversion for resampling as the applicable format in the system. Then cases will be imported to the device. After that, the case of MA\_0001~MA0125 shall be used for the following verification of automated measurement parameters, and the case of D\_0001~D\_1220 shall be used for the following verification of automated interpretation.

### 4.6.3 Customized data preprocessing


The customized initial case files shall be processed for voltage conversion and frequency conversion for resampling as the applicable format in the system. Then cases will be imported to the device. After that, the verification of automated interpretation will be carried on.

### 5. Process and Result of Verification

### 5.1 Verification of measurement function

### 5.1.1 Verification and Process for CTS measurement database

The cases (CAL05000, CAL10000, CAL15000, CAL20000, CAL20002, CAL20100, CAL20110, CAL20160, CAL20200, CAL20210, CAL20260, CAL20500, CAL30000, ANE20000, ANE20001, ANE20002) imported to the device shall be used to verify the automated measurement parameters.



#### 5.1.2 Verification and Process for CSE measurement database


Import the converted case files into the device, add appropriate database records, then

waveform for all case files can be reviewed in the device, therefore the automated measurement parameters can be obtained.

Eliminate the cases existing obvious error for the diagnostic parameters (P-wave location is wrong) from the CSE database.

Make a comparison between the ECG analytical parameters (the beginning/end of P-wave, QRS-complex and T-wave) and the diagnostic parameters (the beginning/end of P-wave, QRS-complex and T-wave) provided by CSE database. Draw the two groups of waveform and mark the location of the beginning/end of P-wave, QRS-complex and T-wave corresponding to each case. The picture provides a visualized comparison, so the mean and standard deviation of the differences can be calculated. According to the requirement of IEC60601-2-51:2003 Medical electrical equipment - Part 2-51: Particular requirements for safety, including essential performance, of recording and analysing single channel and multichannel electrocardiograph, the four largest deviations from the mean shall be eliminated before recalculation of mean and standard deviation of the differences.

Flow diagram of CSE measurement database verification process



### 5.1.3 Verification results

### 5.1.3.1 Accuracy of amplitude measurements

Calibration and analytical ECGs shall be used to measure the amplitude value, the summary as follows:

Amplitude	Mean difference (uV)	Standard deviation (uV)				
P-wave	-1.70	5.72				
Q-wave	7.51	18.07				
R-wave	-18.05	21.70				
S-wave	7.77	18.58				
ST-segment	0.15	4.24				
T-wave	-5.81	8.03				

Note: In amplitude measurement, for large-amplitude ECG, such as CAL30000, it is necessary to adjust to 0.5 times the gain before testing.

### 5.1.3.2 Accuracy of absolute interval and wave duration measurements

Calibration and analytical ECGs shall be used to measure the global interval and wave duration (including Q-wave ,R-wave ,S-wave), the summary as follows:

Interval&Duration	Mean difference (ms)	Standard deviation (ms)				
P-duration	-5.70	1.88				
PQ-interval	-2.58	1.94				
QRS-duration	-0.23	3.26				
QT-interval	-6.70	4.37				

### 5.1.3.3 Accuracy of interval measurements on biological ECGs

CSE database shall be used to evaluate the accuracy of interval measurements on biological ECGs, the summary as follows:

Interval&Duration	Mean difference (ms)	Standard deviation (ms)
P-duration	0.99	13.46
PR-interval	3.65	9.68
QRS-duration	-1.69	6.11
QT-interval	-2.32	20.69

### 5.1.3.4 Stability of measurements against NOISE

The test is carrying on according to MA-series data (008, 011, 013, 014, 015, 021, 026, 027, 042, 061) in CSE database.

Global	The state of the state of	Disclosed differences		
measurement parameters	Type of added NOISE	Mean (ms)	Standard deviation (ms)	
P-duration	High frequency	-5.65	12.33	

P-duration	Line frequency	-0.25.	12.71
P-duration	Base-line	-4.90	33.15
QRS-duration	High frequency	-0.95	5.13
QRS-duration	QRS-duration Line frequency		4.71
QRS-duration	Base-line	-1.55	7.68
QT-interval	High frequency	-14.55	6.51
QT-interval	Line frequency	-8.55	20.73
QT-interval	Base-line	36.20	64.47

The biological ECGs are fed into the device in form of digital signals, then the measurement value can be obtained by calculation.

Test condition:

a) without NOISE

b)with 25uV high frequency

c) with 50uV peak to valley 50Hz/60Hz sinusoidal line frequency NOISE


d) with 1mV peak to valley 0.3Hz sinusoidal base-line NOISE

For each NOISE level above, the differences of measurements between the NOISE-free ECGs and the ECGs with NOISE shall be determined. The two largest deviations from the mean shall be estimated before calculation of mean and standard deviation of differences.


### 5.2 Verification of interpretation function

### 5.2.1 Verification process

### 5.2.1.1 CSE diagnostic database



### 5.2.1.2 Customized database



### 5.2.2 Verification results

No.	ltem	ECGs numbe r	Sensitivit y %	Specifici ty %	Positive predictive value %
1	No abnormal	585	92.01	79.16	97.38
2	Sinus mode Bradycardia	191	96.68	99.73	98.64
3	Sinus mode Tachycardia	78	97.44	96.49	96.90
4	Left atrium Hypertrophy	51	51.09	99.89	81.82
5	Right atrium Hypertrophy	43	42.64	99.66	50.00
6	Dual atrium <u>Hypertrophy</u>	22	93.58	99.14	60.19
7	QRS low voltage	5	96.37	99.36	63.25
8	Cardiac electric axis normal	733	98.36	89.13	98.79
9	Left axis deviation	168	98.65	89.40	98.18
10	Right axis deviation	107	98.23	88.99	94.90
11	Completeness Right Bundle branch block	28	97.00	89.50	95.45
12	Completeness Left Bundle branch block	32	97.73	89.65	91.43
13	No Completeness Right Bundle branch block	41	96.86	89.83	82.35
14	No Completeness Left Bundle branch block	47	94.68	89.83	89.66
15	V1 shows RSR' type	13	90.32	91.14	65.12
16	Left anterior fascicular block	26	91.43	93.25	71.11
17	Left posterior fascicular block	18	89.29	97.37	52.63
18	Left ventricular hypertrophy	236	41.37	92.65	70.36
19	Right ventricular hypertrophy	108	39.75	93.47	65.39
20	I atrioventricular block	13	94.58	91.67	80.64
21	Early anteroseptal MI	10	83.33	99.94	90.91
22	Possible acute forepart anteroseptal MI	27	16.67	98.73	91.89
23	Old anteroseptal MI	26	92.00	98.90	86.47
24	Early anterior MI	77	93.90	88.22	71.96
25	Possible acute anterior MI	10	80.00	99.72	44.44
26	Old anterior MI	13	24.00	99.66	50.00
27	Early extensive anterior MI	24	79.67	99.43	41.18
28	Possible acute extensive anterior	16	81.82	99.66	75.00

	MI				
29	Old extensive anterior MI	30	90.91	88.05	37.04
30	Early apical MI	15	88.32	87.21	88.54
31	Acute apical MI	21	78.12	78.66	53.85
32	Old apical MI	19	79.63	89.94	80.00
33	Early anterolateral MI	36	77.51	79.94	83.33
34	Possible acute anterolateral MI	9	28.57	99.77	33.33
35	Old anterolateral MI	14	70.00	93.60	50.00
36	Early high lateral MI	16	79.65	95.78	80.42
37	Possible acute high lateral MI	8	81.60	99.94	85.71
38	Old high lateral MI	23	81.82	99.66	60.00
39	Early inferior MI	31	88.89	95.00	40.00
40	Possible acute inferior MI	11	76.00	99.60	61.11
41	Old inferior MI	101	96.07	99.24	93.44
42	Early inferolateral MI	73	98.77	96.82	75.94
43	Possible acute inferolateral MI	29	11.11	99.94	50.00
44	Old inferolateral MI	28	84.62	99.83	78.57
45	ST depression, mild anteroseptal myocardial ischemia	7	75.36	99.55	46.67
46	ST depression, mild anterior myocardial ischemia	5	81.24	99.94	33.33
47	ST depression, mild extensive anterior myocardial ischemia	13	79.83	99.13	53.59
48	ST depression, mild apical myocardial ischemia	17	76.97	99.14	43.13
49	ST depression, mild anterolateral myocardial ischemia	25	77.54	99.08	37.64
50	ST depression, mild high lateral myocardial ischemia	21	80.64	99.14	47.39
51	ST depression, mild inferior myocardial ischemia	12	79.73	99.60	55.16
52	ST depression, mild inferolateral myocardial ischemia	20	80.59	99.26	50.61
53	ST depression, anteroseptal myocardial ischemia	4	85.41	99.72	44.44
54	ST depression, anterior myocardial ischemia	12	87.66	98.58	34.85

55	ST depression, extensive anterior myocardial ischemia	7	84.78	98.04	67.75
56	ST depression, apical myocardial ischemia	18	79.95	99.14	55.12
57	ST depression, anterolateral myocardial ischemia	13	87.42	98.97	59.09
58	ST depression, high lateral myocardial ischemia	16	90.06	99.31	57.14
59	ST depression, inferior myocardial ischemia	12	89.88	99.13	40.08
60	ST depression, inferolateral myocardial ischemia	6	91.39	99.16	50.47

Sensitivity: probability that a "True sample" would be determined as certain "Item" by automated interpretation function;

Specificity: probability that a "True unfit sample" would be determined as certain "Unfit item" by automated interpretation function;

Positive predictive value: probability that a determined "Unfit item" is a "True unfit item".

# Appendix II EMC Guidance and Manufacturer6 Declaration

### Table 1:

Guidance and manufacturer's declaration –electromagnetic emission			
The device is intended for use in the	The device is intended for use in the electromagnetic environment specified below. The		
purchaser or the user of the device shou	ld assure that it is used in such environment.		
Emission test Compliance			
RF emissions CISPR 11 Group 1			
RF emissions CISPR 11 Class A			
Harmonic emissions	Class A		
IEC 61000-3-2			
Voltage fluctuations/flicker emissions	ions Not applicable		
IEC 61000-3-3			

### Table 2:

Guidance and manufa	cturer's declaration-electrom	agnetic immunity			
The device is tended for use in	The device is tended for use in the electromagnetic environment specified below. The				
purchaser or the user of the device	should assure that it is used	in such an environment.			
Immunity test	IEC60601 test level	Compliance level			
Electrostatic discharge (ESD)	±8kV contact	±8kV contact			
IEC 61000-4-2	± 15 kV air	±15kV air			
Electrical fast transient/burst IEC 61000-4-4	±2kV for power supply lines ±1kV for input/output line	±2kV for power supply lines Not Applicable			
Surge	±1 kV lines to lines	±1 kV lines to lines			
IEC 61000-4-5	±2 kV lines to earth	±2 kV lines to earth			
	<5%UT(>95%dip in UT) for 0.5 cycle	<5%UT(>95%dip in UT) for 0.5 cycle			
Voltage dips, short interruptions	40% UT(60%dip in UT) for 5	40% UT(60%dip in UT) for 5			
and voltage vatiations on power	cycle	cycle			
supply input lines	70%UT(30%dip in UT) for	70%UT(30%dip in UT) for 25			
IEC 61000-4-11	25 cycle	cycle			
	<5%UT(>95%dip in UT) for	<5%UT(>95%dip in UT) for 5			
	5 sec	sec			
Power frequency (50 / 60Hz) magnetic field	30 A/m	30A/m			
IEC 61000-4-8					

### Table 3:

Guidance and manufacturer's declaration – electromagnetic immunity					
The device is ten	The device is tended for use in the electromagnetic environment specified below. The				
purchaser or the us	er of the device should assure that	it is used in such an environment.			
Immunity test IEC 60601 test level Compliance level					
3V 3V					
Conducted RF 0,15 MHz – 80 MHz 0,15 MHz – 80 MHz					
IEC61000-4-6 6 V in ISM bands between 6 V in ISM bands between					
0,15 MHz and 80 MHz 0,15 MHz and 80 MHz					
Radiated RF					
IEC61000-4-3         3 V/m 80 MHz- 2.7 GHz         3 V/m80 MHz- 2.7 GHz					
NOTE 1 At 80	NOTE 1 At 80 MHz and 800 MHz, the higher frequency range applies.				

NOTE 1 At 80 MHz and 800 MHz, the higher frequency range applies.

NOTE 2 These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

Field strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephones and land mobile radios, amateur radio, AM and FM radio broadcast and TV broadcast cannot be predicted theoretically with accuracy. To assess the electromagnetic environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the device or system is used exceeds the applicable RF compliance level above, the device should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as adjusting the direction or location of the device.

### Table 4:

	Guidance and manufacturer's declaration - electromagnetic Immunity						
The [Code S	61] is intended	d for use in	the electror	nagnetic enviror	nment specified	l below. The	customer or the
user of the	[Code SI] sho	uld assure	that it is use	d in such an env	ironment		
Radiated RF IEC61000-	Test Frequency (MHz)	Band a) (MHz)	Service a)	Modulation b)	Modulation b) (W)	Distance (m)	IMMUNITY TEST LEVEL (V/m)
4-3 (Test specificati	385	380 390	TETRA 400	Pulse modulation b) 18 Hz	1,8	0,3	27
ons for ENCLOSU RE PORT IMMUNIT	450	380 390	GMRS 460, FRS 460	FM c) ± 5 kHz deviation 1 kHz sine	2	0,3	28
Y to RF wireless	710 745 780	704 – 787	LTE Band 13, 17	Pulse modulation b) 217 Hz	0,2	0,3	9

communic ations equipmen t)	810 870 930	800 – 960	GSM 800/900, TETRA 800, iDEN 820, CDMA 850, LTE Band 5	Pulse modulation b) 18 Hz	2	0,3	28
	1720		GSM				
	1845		1800; CDMA				
	1970	1 700 – 1 990	1900; GSM 1900; DECT; LTE Band 1, 3, 4, 25; UMTS	Pulse modulation b) 217 Hz	2	0,3	28
	2450	2 400 – 2 570	Bluetooth, WLAN, 802.11 b/g/n, RFID 2450, LTE Band 7	Pulse modulation b) 217 Hz	2	0,3	28
	5240		WLAN	Pulse			
	5500	5 100 – 5 800	802.11	modulation b)	0,2	0,3	9
	5785		a/n	217 Hz			

NOTE If necessary to achieve the IMMUNITY TEST LEVEL, the distance between the transmitting antenna and the

ME EQUIPMENT or ME SYSTEM may be reduced to 1 m. The 1 m test distance is permitted by IEC 61000-4-3.

a) For some services, only the uplink frequencies are included.

b) The carrier shall be modulated using a 50 % duty cycle square wave signal.

c) As an alternative to FM modulation, 50 % pulse modulation at 18 Hz may be used because while it does not represent actual modulation, it would be worst case.

The MANUFACTURER should consider reducing the minimum separation distance, based on

RISK MANAGEMENT, and using higher IMMUNITY TEST LEVELS that are appropriate for the reduced minimum separation distance. Minimum separation distances for higher IMMUNITY TEST LEVELS shall be calculated using the following equation:

$$E = \frac{6}{d}\sqrt{P}$$

Where P is the maximum power in W, d is the minimum separation distance in m, and E is the IMMUNITY TEST LEVEL in V/m.

### Warning

- Don't near active HF SURGICAL EQUIPMENT and the RF shielded room of an ME SYSTEM for magnetic resonance imaging, where the intensity of EM DISTURBANCES is high.
- Use of this equipment adjacent to or stacked with other equipment should be avoided because it could result in improper operation. If such use is necessary, this equipment and the other equipment should be observed to verify that they are operating normally.
- Use of accessories, transducers and cables other than those specified or provided by the manufacturer of this equipment could result in increased electromagnetic emissions or decreased electromagnetic immunity of this equipment and result in improper operation."
- Portable RF communications equipment (including peripherals such as antenna cables and external antennas) should be used no closer than 30 cm (12 inches) to any part of the device including cables specified by the manufacturer. Otherwise, degradation of the performance of this equipment could result.
- > Active medical devices are subject to special EMC precautions and they must be installed and used in accordance with these guidelines.

Note:

- The EMISSIONS characteristics of this equipment make it suitable for use in industrial areas and hospitals (CISPR 11 class A). If it is used in a residential environment (for which CISPR 11 class B is normally required) this equipment might not offer adequate protection to radio-frequency communication services. The user might need to take mitigation measures, such as relocating or re-orienting the equipment.
- When the device is disturbed, the data measured may fluctuate, please measure repeatedly or in another environment to ensure its accuracy.

# 4.2.5 Symbols

~CA	Alternating current
\ ↓	Equipotentiality
$\triangle$	Caution: read instructions (warnings) carefully.
-l 🍽 F	Defibrillation-proof type CF applied part
• <del>/</del> *	USB interface
	Lead cable socket
SN	Serial number
	Manufacturer
	Date of manufacture
LOT	Lot number
<b>N</b>	Latex free
<u></u>	Atmospheric pressure limit
X	Temperature limit
<u></u>	Humidity limit
	This way up
	Fragile, handle with care
	Keep in a cool, dry place

8	Stacking limit by number
	General warning label NOTE: Background col our:yellow Triangular band:Black
CE	This item is compliant with Directive 93/42/EEC
	Refer to instruction manual/booklet
REF	Product code
EC REP	Authorized representative in the European Community
Ŕ	WEEE disposal. This symbol indicates that electrical and electronic equipment waste cannot be disposed of as unsorted municipal waste and must be recycled separately.