



Stream Music & Video
In Any Room. Wirelessly.


VOCO PRODUCT

USER GUIDE

www.myvoco.com


Select a "Zone"

Next to the name of your VOCO device, in the ZONES screen of the VOCO Controller App, there is a round button. Tap on that button and it will highlight in green.....you have now selected a "Zone"



Select a Music Source

In the ZONES screen hold down the MY MUSIC tab and pull it out. Available music sources will be listed. Simply tap the music source you want to stream music from.



Install VOCO VMS Software

In order to play music content from your computer, you must install VOCO software onto your MAC or PC computer. To do this, go to myvoco.com/support to download and install.




Now when you pull out the MY MUSIC tab you will have the option to select your computer as a music source.

**Note: Your computer must be on the same network for you to select it as a music source.*

Perform a Voice Search

Press and hold the VOCO “Press and Speak” icon and say the name of the ARTIST, ALBUM, OR SONG you are searching for, then release the icon. VOCO will search your music library and return any matching results.



VOCO)) “Press and Speak”

- It is important that you speak normally and not hold the phone mic too close to your mouth or speak at high volume. This is a sophisticated system, and it will capture what you are saying.

When your results appear, you have several options to listen to music.

Option 1- If your ARTIST, ALBUM OR SONG is available on your selected source, the system will list the number of

ARTISTS, ALBUMS OR SONGS on your current zone and source. Tap on your selection and listen to you music!

“Search Results” Page

1 Artist with "adele"	MORE RESULTS
0 Albums with "adele"	MORE RESULTS
0 Songs with "adele"	MORE RESULTS

Option 2- If you want to search TuneIn Radio (80,000 global stations) for radio that is playing your ARTIST, ALBUM OR SONG, tap the “TUNEIN” icon to the right of your search results even when the system shows “0” results. The next screen will show a list of all stations playing your ARTIST, ALBUM OR SONG, then list stations that play similar music.

Option 3- Press and hold on the returned results, select the service you want, i.e. Pandora, YouTube, etc. to search that service and enjoy the music.

Browse Internet Radio Stations

There are 2 easy ways to use the VOCO Controller App to easily access thousands of internet radio stations and stream them to your VOCO device:

- 1.) Press the ONLINE SERVICES icon at the top of the screen and select the service you would like to use.



- 2a.) Select the service you would like to use, e.g. TuneIn, Pandora, YouTube, Murfie, SkyFM or JazzRadio. Then click through genres and stations until you find a station you would like to hear. Tap the station and, after a couple of seconds, you will hear your music through your device.

NOTE: To see the name of the artist and song you are listening to, tap the "Now Playing" gallery button at the top of the application.

— OR —

- 2b.) Perform a voice search and follow the instructions for option 2 or 3 under the voice search instructions.

NOTE: To stream YouTube® videos, please ensure your VOCO device (V-Zone+ and above) is connected via HDMI to your TV if you would like to watch the video.

VOCO Controller "ZONES" Screen



VOCO DEVICE LED's

What Do They Mean?



During your initial setup of your VOCO device you will see the LED lights on the front go through the following sequence and what each means:

- 1.) Slow Blinking Red - New Firmware is being uploaded
- 2.) Fast Blinking Red and Blue - Firmware packages being updated
- 3.) Solid Green - All firmware has been updated and it is reconnected

After initial setup of your VOCO device, the following is a guide to what the LED's mean on your VOCO device.



Red:

1. When red light is solid, it means the device is beginning to boot up or has recycled power; your player will not be functional at this stage.
2. When red light is blinking alone, it means one of two things: (1) this device is doing a media scan (your player may be functional at this stage) or (2) your VOCO app is in the "Config Wizard" configuring a zone (your device may be functional at this stage).
3. When red light is blinking rapidly along with the blue light, it means that it is downloading new or updated software. Your device will not be functional at this point, and you must let the download happen. Timing on this will depend on your WiFi or internet connection speed.



Orange:

1. When orange light is solid, that means the device is currently connected to Ethernet.
2. When the orange light is blinking, the device is recognizing Ethernet.
3. When the orange light is flickering (devices with touch panels), that means the device's touch panel is being manually touched.



Green:

1. When green light is blinking that means the device is currently not on the (a) network. This happens most often if the device is configuring or if the device has not yet been configured.
2. When green light is solid, the device is successfully on the (a) network. This is a prerequisite for the device working properly.



Blue:

1. When blue light is blinking (blink, blink, blink...pause) repeatedly, that means the device is not connected to the server. This could be while it is warming up for a boot up or if a server that the unit was previously connected has become unavailable on the network.
2. When blue light is solid, this means that media (music or video) is currently streaming.
3. When blue light is blinking rapidly with the red light: Please refer to #3 under red.



Stream Music & Video In Any Room. Wirelessly.

For troubleshooting, latest Quick Start Guide, Full Manuals
and additional assistance go to the SUPPORT section of
www.myvoco.com

Or contact us at:

Phone: 888-879-VOCO (8626)

Email: support@myvoco.com