




Equipment Guide

E61 - Wega - Expobar

1. Cup tray (machine heat keeps them warm)
2. Hot water knob
3. Sight glass (boiler water level)
4. Hot water spout/Tamper
5. Drip tray
6. Group handle
7. Group extraction lever
8. Pressure release valve
9. On/off switch
10. Group head
11. Steam wand
12. Pump pressure gauge (through group head)
13. Boiler pressure gauge
14. Steam knob






Equipment Guide

La Marzocco Linea

1. Cup tray (machine heat keeps them warm)
2. Pressure Gauge (boiler & group)
3. Touchpad
4. Steam knob
5. On/Off switch
6. Steam wand
7. Drip tray
8. Group handle
9. Group head
10. Hot water switch
11. Sight glass (boiler water level)
12. Hot water spout
13. Manual coffee brewing switch
14. Manual fill switch (water in boiler)
15. Machine heating light






Equipment Guide

La Marzocco FB 80 - GB5

1. Cup tray (machine heat keeps them warm)
2. Pressure Gauge (coffee boiler)
3. Pressure Gauge (steam boiler)
4. Touchpad
5. Steam knob
6. On/off switch
7. Drip tray
8. Group handle
9. Group head
10. Hot water spout
11. Steam wand
12. Anti-burn rubber
13. Hot water button 2
14. Digital display
15. Hot water button 1






Equipment Guide

Slayer Steam

1. Group Paddle
2. Menu dial
3. Digital Display (for every group)
4. Hot water spout
5. Drip tray (adjustable height)
6. Drain hose
7. Group handle
8. Group head
9. On/Off switch (under machine)
10. Steam wand
11. Steam lever





Equipment Guide

Kees Van Der Westen spirit

1. Cup warmer tray
2. Pressure Gauge (left coffee group)
3. Group brewing lever
4. Steam lever
5. Anti-burn rubber
6. Group indicator light
7. Program button
8. Volume switch
9. Group head
10. Hot water spout
11. Drip tray
12. Pressure Gauge (right coffee group)
13. Hot water button 2
14. Coffee boiler heating on/off switch
15. Group handle
16. Steam wand
17. Main on/off switch
18. Hot water lever
19. Steam boiler temperature controller
20. Steam boiler heating on/off switch
21. Shot timers

