



A20002 Bases & Drive Nuts
Sizes 0, 1, 2



A20001 Gearcase



A20006 Terminal Bung



A20002 Drive Nuts
Sizes 3, 4, 5, 6, 7, 8



A20003 Handwheel




A20007 Comprehensive
Spares Kit




A20008 Electronics Cover



A20004 Motor



A20005 Electronics




A20009 Terminal Cover

Workshop and spare parts manual
IQ MKII Range Actuators - Main PCB
Part Number: A2000506

rotork®

**NOTE: ALL PARTS SHOWN IN
BLACK ARE SUPPLIED, PARTS
SHOWN IN RED ARE NOT
SUPPLIED.**






Workshop and spare parts manual
IQ MKII Range Actuators - Electronic Chassis
Assembly
Part Number: A2000502


rotork[®]

**NOTE: ALL PARTS SHOWN IN
BLACK ARE SUPPLIED, PARTS
SHOWN IN RED ARE NOT
SUPPLIED.**



Workshop and spare parts manual
IQ MKII Range Actuators - Electronic Chassis
Assembly
Part Number: A2000502

rotork®



Workshop and spare parts manual
IQ MKII Range Actuators - Local Control PCB
Part Number: A2000802

rotork®

**NOTE: ALL PARTS SHOWN IN
BLACK ARE SUPPLIED, PARTS
SHOWN IN RED ARE NOT
SUPPLIED.**

