


☐

I'm not robot


reCAPTCHA

I'm not robot!

Nellie's wow mop manual

Nellie's wow mop instructions. Reviews nellie's wow mop.

Who would've thought that you would ever look forward to mopping your floors? Nellie's WOW Mop makes cleaning your floors - dare we say it - enjoyable. Truth is, you might never want to stop! Cordless, lightweight, and rechargeable, the WOW Mop is incredibly easy to use. Even your teenager can do it! With high-frequency pads that oscillate 1000x per minute, the mop removes dirt and grime effortlessly. The WOW Mop comes with a pair of Nellie's WOW Wet Floor cleaning pads, which are reusable and machine washable. Or better yet, Bundle and Save 20% with Nellie's WOW Mop Bundle! For Warranty and Replacement information, please visit our Mop Replacement Page.

Home » Nellie's » nellie's Wow Mop Cordless Light Weight and Rechargeable User Manual Operating Press the power button on the handle to make the cleaning pads oscillate, and press it again to stop. While the pads are oscillating, hold down the spray button to spray cleaning solution. Release button to stop. Notes: Do not operate while the mop is charging. The longest time of spraying is 5 seconds with one press. The machine will automatically turn into "sleep mode" after 2 minutes of no use and the full battery light will twinkle. Adding Cleaning Solution Open the cap of the reservoir and fill using the measuring cup to add liquid. Do not overfill. Close the cap. Best used with Nellie's Floor Care on hardwood, ceramic and tile. Note: The maximum capacity of the reservoir is 230mL. Taking Care of Your Reservoir Nellie recommends to use Nellie's Floor Care or distilled/purified water in the reservoir.



This will maintain good performance and extend the life of your mop. Empty the reservoir when not in use. Battery Lights Three battery lights will show the status of the battery. 100%, 65% and 30%. 3 lights will flash when the machine is low in battery indicating to charge immediately. Notes: 3 lights on 100% 2 lights on 65% 1 light on 30% 3 lights flashing low battery First Time Charging Pull out the rubber cork and turn it until the whole charging port is revealed.



Plug the charger into the charging port. Note: Use the original equipment manufactured adapter. Overcharging the battery may cause damage. Please avoid charging for more than 3 hours. Pad Changing Unplug/turn off the machine. Ensure that the tank is empty. Hold the mop upside down and remove the pads from the bottom. Alternatively, you can also hold the mop up and change the pads. OPERATION TIP Turning Off Put the handle in an upright position to turn it off. Cleaning Pads Machine wash pads with fragrance-free detergent. Do not use fabric softener. FYI Nellie's Laundry Soda works great! Who would've thought that you would ever look forward to mopping your floors? Nellie's WOW Mop makes cleaning your floors - dare we say it - enjoyable. Truth is, you might never want to stop! Cordless, lightweight, and rechargeable, the WOW Mop is incredibly easy to use. Even your teenager can do it! With high-frequency pads that oscillate 1000x per minute, the mop removes dirt and grime effortlessly. The WOW Mop comes with a pair of Nellie's WOW Wet Floor cleaning pads, which are reusable and machine washable. Or better yet, Bundle and Save 20% with Nellie's WOW Mop Bundle! For Warranty and Replacement information, please visit our Mop Replacement Page.

© 1996-2014, Amazon.com, Inc. or its affiliates