bluMe Pro

Quick Start Guide

theauris.com

WELCOME!

Congratulations on your purchase of the auris bluMe Pro Premium Hi-Fi Bluetooth Music Receiver!

The following pages explain the features and operations of bluMe Pro. Please take a few moments to read this user guide.

Also read all safety instructions before proceeding. The answers to most set up and performance questions can be found in this guide. If you have any further questions about the operation or use of this product, please contact our customer care team for assistance on support@theauris.com

In the Box
auris bluMe Pro
2RCA to 2RCA stereo audio cable
3.5mm to 2RCA splitter cable
Power adapter with detachable USB to USB-C cable
Self adhesive feet bumpers x 4
Quick Start Guide

Overview
bluMe Pro is the HiFi Bluetooth Music Receiver reinvented for hi-res wireless audio streaming, combining audiophile-grade componentry and highest quality Bluetooth audio capabilities, to create a modern addition to any existing HiFi stereo systems or your favorite set of powered speakers.

KEYS AND PARTS

1. Antenna
2. OLED Display
3. Power On/Off button
4. Stereo RCA outputs
5. Digital Optical output
6. Digital Coaxial output
7. DC power input / USB In

Front Panel   Right Side Panel

Rear Panel

QUICK SETUP

Setup and pairing is really easy. The following instructions will help you connect bluMe Pro to your music system and pair with your tablet, computer or smartphone.

Step 1: Connect audio cables from bluMe Pro rear panel to your music system audio input.

Step 2: Connect a power adapter to bluMe Pro with the included power supply cable and plug the power adapter into an AC outlet.

Step 3: bluMe Pro will automatically 'Power ON' with a sound and go into discoverable / pairing mode. The OLED display will show "Pairing" indicating that the unit is now ready to be paired.

Step 4: Turn ON Bluetooth on your device and go to Bluetooth preferences.

Step 5: Scan listed Bluetooth devices and select "bluMe Pro" to pair and connect. The OLED display will indicate "Connected" with a sound.

Step 6: Make sure your Hi-Fi audio system is turned on and the proper input source is selected.

Step 7: The music on your smart device will now play through your Hi-Fi audio system while bluMe Pro will display the Bluetooth status, format / sampling rate and the song name!

bluMe Pro can connect to one smart device at a time, but is capable of remembering up to 8 devices. Automatically connects to the last paired device.

CONNECT TO A COMPUTER

bluMe Pro can be used as a USB DAC when connected to a computer (PC/Mac) with the included USB-microUSB cable. It allows you to bypass your computer's soundcard and send audio through USB, processing digital audio at any bit depth up to 24 bits and any sample rate to 192kHz.

Step 1: Connect the RCA's / Optical / Coaxial output on the rear of bluMe Pro to your music system audio input.

Step 2: Connect bluMe Pro to your computer's USB port with the included USB to USB-C cable.

Step 3: bluMe Pro will automatically 'Power ON' with a sound. The OLED display will indicate that the unit has now entered the USB DAC mode.

Step 4: On your computer select bluMe Pro as the default audio output device to play music - If you're using a Mac, you will need to go to System Preferences / Sound, and select "bluMe Pro" and if you're using a PC, no setting changes are needed as the computer will automatically find the USB driver.

Step 5: Make sure your Hi-Fi audio system is turned on and the proper input source is selected.

Step 6: The music from your favorite media player on your computer will now play through your Hi-Fi audio system!

NOTE:

1. bluMe Pro connects to your computer without any software / app / driver installation.

2. When connected to the computer, bluMe Pro is powered via the computer's USB power and therefore no external power supply is needed.

TROUBLESHOOTING TIPS

My device does not pair with bluMe Pro.
Ensure that Bluetooth is turned ON on your device. Make sure that the OLED display indicates "Pairing" and your device is within bluMe Pro's wireless range of 30 meters (100 feet).
Check whether no other devices are connected. If so, either disconnect or turn off Bluetooth on the other devices, then try connecting.
Try unpairing and repairing your device to bluMe Pro.
Power cycle bluMe Pro by disconnecting and reconnecting the power cable.

The OLED display shows my device is connected but there is no audio output.
Ensure that the bluMe Pro output is correctly connected to your audio system.
Check whether the audio source is correctly selected on your music system (analog audio or digital optical input).
Verify the 2RCm levels on your computer OS and player app.
Try unpairing and repairing your device to bluMe Pro.
Power cycle bluMe Pro by disconnecting and reconnecting the power cable.

The volume output level from bluMe Pro is Low.
Verify the volume levels on your computer OS and player app.
Also check the volume levels on your powered speakers or stereo system.

The sound quality is poor and / or the audio is cutting out.
Move your device or bluMe away from cordless phones, routers, microwave ovens or other Bluetooth devices.
Try moving your device closer to bluMe Pro.
Try another location.
Turn off your device's Wi-Fi.

TECHNICAL SPECIFICATIONS

Try unpairing and repairing your device to bluMe Pro.
Power cycle bluMe Pro by disconnecting and reconnecting the power cable.
Check that your device's OS is updated to the latest version.

When powered ON bluMe Pro automatically connects to the last paired device. How to pair to a different smartphone / smart device.
Double Click the Power On/Off button when the device is ON to force bluMe Pro to enter pairing mode.

Power OFF bluMe Pro.
Either Press & Hold the Power On/Off button for 2secs or simply disconnect the power supply from the AC outlet.

How to factory reset bluMe Pro.
Perform a factory reset on bluMe Pro if you experience malfunction or freeze.
Power OFF bluMe Pro (keeping the device connected to the power supply)
Press & Hold the Power On/Off button for 10 secs until "Pairing" shows on the display with a sound.
Note: This will also clear the pairing record/list from the device.

If you have any further queries please contact us on **support@theauris.com**

Bluetooth® Version	Bluetooth v5.0
Supported Codecs	LDAC, Qualcomm™ aptX™ HD, aptX™ LL, aptX™, AAC and SBC
Bluetooth® Range	30 meters, 100 feet
Bluetooth Chipset	Qualcomm CSR8675
D/A Converter	ESS SABRE ES9028Q2M
Digital Conversion Chip	Cirrus Logic CS8406
Dynamic Range (DNR)	129dB
Total Harmonic Distortion	-120dB
PCM Support	384kHz / 32bit
Outputs	Stereo Analog RCA Digital Optical Digital Coaxial
Power In	DC 5V/1A
USB Port	Type C
Screen	1.3 inch OLED, 128 x 64 pixels
Enclosure	Aluminum
Included Accessories	2RCA to 2RCA stereo audio cable 3.5mm to 2RCA splitter cable Power adapter with detachable USB to USB-C cable Self adhesive feet bumpers x 4 Quick Start Guide

Dimensions	Height	1.34 inches (34 mm)
	Width	2.95 inches (75 mm)
	Depth	4.37 inches (111 mm)
	Weight	8.47 ounces (240 grams)

4.37 inches (111 mm)
1.34 inch (34 mm)
2.5 inches (75 mm)
Weight: 8.47 oz (240 grams)

PRODUCT SAFETY

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. Improper use of this product can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use. Keep these instructions handy for future reference.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION: To reduce the risk of electric shock do not remove cover (or back).
No user-serviceable parts inside.
Refer servicing to qualified service personnel.

Users of this product are cautioned not to make modifications or changes that are not approved by Auris, Inc. Doing so may void the compliance of this product and may result in the loss of the user's authority to operate the equipment.

SAFETY INSTRUCTIONS

• Keep product dry to avoid affecting the interior circuitry of the product.

• Don't put the product in direct sunlight or place in hot areas.

• High temperature will shorten the life of electronic device.

• Don't expose to extreme temperatures, it may damage the internal circuit board.

• Don't take the product apart or the warranty will be voided.

• Don't drop the product.

• Don't use chemical or detergent to clean the product.

• Due to isolating characteristic of the product, do not use the product at excessive volume while driving or in any other activity where failure to hear surrounding sounds could be dangerous.

• Using the product at excessive volumes may cause permanent hearing damage. You can get the most out of your equipment and enjoy great audio performance even at safe levels.

WARRANTY

Don't worry. Your auris bluMe Pro is covered under our warranty.
For warranty information please visit:

https://theauris.com/pages/warranty

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including the interference that can cause undesired operation.
Any changes or modifications to the device will void the user's authority to operate the device.

This device complies with FCC radiation exposure limits set for an uncontrolled environment. This device should be installed and operated with minimum distance of 20cm between the radiator and the body.

FCC ID: 2ABCJAU07

www.theauris.com
support@theauris.com

LDAC | Qualcomm aptX HD | Qualcomm aptX Low Latency | Qualcomm aptX

FC CE RoHS