


ENC Wireless Earphone

THE INSTRUCTIONS



Please carefully read this Manual before using this product for the very first time and well keep it for the further reference.

1


Precautions

Thank you for purchasing the Environmental Noise Cancelling True Wireless Bluetooth Headphones produced by our company.
For listening experience, please wear and use the headset correctly, and do not disassemble the hardware by yourself.
Please read this manual carefully before use, thank you again for your support and love.

II .Specification

Bluetooth	V5.2
Communication Scope	≤10m(no obstacle)
Waterproof Level	IPX4
Frequency Response	20Hz-20KHz
Sensitivity	110.6dB±3dB
Impedance	32Ω
Support	HFP/HSP/A2DP/AVRCP
Battery Capacity	350mAh/30mAh
Horn	10mm Dynamic unit
Chip	Bluetrum 5626A
Audio Coding	SBC/AAC
Play Time	4.5H
Charging Case Charging Port	Type-c Port
Product Size(charging box)	58.8*51.3*28.3mm
Product Weight	About 39g
Packing List	Headphone set, Silicone earbuds, Charging cable, instruction manual

II .Schematic Diagram




- 1 Touch sensing area
- 2 Charging interface
- 3 Charging case indicator

2

III. Function Overview

Steps:

- Power on: Open the charging case, take out the earbuds and turn it on.
- Bluetooth Pairing: Turn on the "Bluetooth" of the device and take out the earbuds from the charging case, search for "Amita P5" click "connect" .
When using the headset again, open the charging case, take out the earbuds, and the earbuds will automatically connect to the device.



Warm tips:
If the pairing fails, put the earbuds into the charging case, and then try the steps above again, the earbuds will automatically shut down when there is no devices to connect in 5 minutes.

3

IV.Charging Operation

- Charging Case Charging: Connect the charging cable into the charging pot on the charging case.
- Earbuds Charging: Put the earbuds into the charging case, the earbuds will automatically shut down and charge.

FUNCTION	OPERATION
Pause/Start	Tap the left or right earbud once
Previous Song	Tap the left earbud three times
Next Song	Tap the right earbud three times
Answer A Call	Long Press the left or right earbud for 2s
Reject A Call	Tap the left or right earbud twice
End A Call	Tap the left or right earbud twice
Game/Music Mode	Tap the left earbud four times
Wake up voice assistant	Long Press the left or right earbud
EQ Mode	Tap the right earbud four times
Volume +	Tap the right earbud twice
Volume -	Tap the left earbud twice
Power ON	Long Press the left and right earbud for 5S
Power OFF	Long Press the left or right earbud for 5S

Product Status	Electricity Status	Indicator Light
Charging case (Charging)	Fully Charged	The light is always on
	Charging	Light flashes
Discharging The Charging case	Normal Discharge State	The light turns off after 4s
	Low Light	The light flashes for 4s and then turns off
Put The Earbuds Back into the Charging case	/	The light flashes once

4

SAFTY MATTERS:

- Do not throw the product into the fire to avoid explosion.
- The product should avoid rain, dampness or other liquids.
- While using the product for the first time, fully charges before using it.
- Using the earbuds for the first time, please adjust the volume to reasonably, then gently switch to the appropriate volume, if the volume is too high, might cause tinnitus or damage to the ear and the product itself.
- Please use the original battery, and original charger.

FCC Requirement


Any changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

5

ENC通话降噪真无线蓝牙耳机

使用说明书



使用前请仔细阅读本说明书，并妥善保管。

1


注意事项

感谢您购买我司生产的ENC通话降噪真无线蓝牙耳机，为获得更好的听觉体验，请正确佩戴使用耳机，请勿自行拆解硬件。使用前请仔细阅读本说明书，再次感谢您的支持与厚爱。

1.规格参数

蓝牙	V5.2
通讯范围	≤10m（无障碍物）
防水等级	IPX4
频率响应	20Hz-20KHz
灵敏度	110.6dB±3dB
阻抗	32Ω
支持协议	HFP/HSP/A2DP/AVRCP
电池容量	350mAh/30mAh
喇叭	10mm动圈单元
芯片	中科蓝讯 5626A
音频编码	SBC/AAC
听歌时长	4.5H
充电仓充电接口	Type-C接口
产品尺寸（充电仓）	58.8*51.3*28.3mm
产品重量	约39g
包装清单	耳机套袋、硅胶耳塞、充电线、说明书

2.产品示意图



- 1 触摸感应区
- 2 充电接口
- 3 充电盒指示灯

2

3.功能概述

操作步骤:

开机：打开充电仓，耳机取出开机。

配对：打开设备“蓝牙”并从充电仓取出耳机，点击 Amita P5 进行连接。
再次使用耳机时，开盖取出，耳机将自动与设备连接。



*如果配对失败，请将耳机放入充电仓，然后再按照以上步骤尝试一次。

3

4.充电操作

充电仓充电：
将附带的充电线连接充电仓与充电设备USB端口进行充电。
按键定义：

功能	操作方式
暂停/播放	单击左耳(L)或右耳(R)
上一首	三击左耳(L)
下一首	三击右耳(R)
接听电话	来电时，长按左耳(L)或右耳(R)2s
拒接电话	来电时，双击左耳(L)或右耳(R)
挂断电话	通话时，双击左耳(L)或右耳(R)
游戏/音乐模式	四击左耳(L)
唤醒语音助手	长按左耳(L)或右耳(R)
EQ模式	四击右耳(R)
音量+/-	双击右耳(R) / 双击左耳(L)
开机	长按左耳和右耳
关机	长按左耳或右耳

充电与指示灯显示：	指示灯显示	
产品状态	电量	常亮
充电仓充电	充满状态	闪烁
	充电状态	亮4s后灭掉
充电仓放电	正常放电状态	闪烁4s后灭掉
	低电状态	闪烁一次
耳机放回充电仓	/	

4

注意事项

- 首次使用该产品时，先充满电再使用。
- 产品应避免雨淋、潮湿或接触其他液体。
- 请勿将该产品扔入火中，以免导致爆炸。
- 第一次使用该耳机时，请将音量控制到最小，然后逐渐调至合适的音量，以免音量过高造成耳鸣或损伤耳朵。
- 请使用原配充电器。

保修卡

用户姓名 _____
用户电话 _____
用户地址 _____
购机日期 _____
发票编号 _____
销售单位名称 _____
销售单位地址 _____
销售单位电话 _____

- *我司产品严格执行国家三包政策且自购买日起支持一年免费保修。
有以下情况之一不享受免费保修。
1.人为损坏。
2.超过保质期。
3.不能提供有效购买凭证。
4.未按说明书操作使用，维护而造成的损坏。
5.擅自拆卸、维修产品或使产品浸湿。
6.其它不可抗力因素造成的损坏。

5