


# ONKYO

W800BT

USER  
MANUAL





# Contents

<b>1</b>	<b>Important safety instructions</b>	<b>2</b>
	Hearing Safety	2
	General information	2
<b>2</b>	<b>Onkyo Bluetooth wireless headset</b>	<b>3</b>
	Box content	3
	Other devices	3
	Overview of your Bluetooth wireless headset	3
<b>3</b>	<b>Charge and pair your headset</b>	<b>4</b>
	Charge the battery	4
	Pair your headset	5
<b>4</b>	<b>Use your headset</b>	<b>6</b>
	Connect the headset to a Bluetooth device	6
	Operate your headset	6
	Wear your headset	7
<b>5</b>	<b>Technical data</b>	<b>8</b>
<b>6</b>	<b>Notice</b>	<b>9</b>
	Declaration of conformity	9
	Disposal of your old product and battery	9
	Compliance with EMF	10
	Trademarks	10
<b>7</b>	<b>Frequently asked questions</b>	<b>11</b>

# 1 Important safety instructions

## Hearing Safety



### Danger

- To avoid hearing damage, limit the time you use headphones at high volume and set the volume to a safe level. The louder the volume, the shorter the safe listening time is.

### Be sure to observe the following guidelines when using your headset.

- Listen at reasonable volumes for reasonable periods of time.
- Be careful not to adjust the volume continuously upwards as your hearing adapts.
- Do not turn up the volume so high that you can't hear what's around you.
- You should use caution or temporarily discontinue use in potentially hazardous situations.
- Excessive sound pressure from earphones and headphones can cause hearing loss.
- Using headphones with both ears covered while driving is not recommended and may be illegal in some areas while driving.
- For your safety, avoid distractions from music or phone calls while in traffic or other potentially dangerous environments.

## General information

To avoid damage or malfunction:



### Caution


- Do not expose the headset to excessive heat.
- Do not drop your headset.
- Headset shall not be exposed to dripping or splashing.
- Do not allow your headset to be submerged in water.
- Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives.
- If cleaning is required use a soft cloth, if necessary dampened with a minimum amount of water or diluted mild soap, to clean the product.
- The integrated battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- Risk of explosion if battery is replaced by an incorrect type. Replace only with the same or equivalent type.

### About operating and storage temperatures and humidity

- Operate or store in a place where temperature is between -15°C (5°F) and 55°C (131°F) (up to 90% relative humidity).
- Battery life may be shorter in high or low temperature conditions.

## 2 Onkyo Bluetooth wireless headset


### Box content




Onkyo Bluetooth wireless headset W800BT



Replaceable rubber ear caps x 2 pairs



Charging case




Quick start guide

### Other devices

A mobile phone or electronic device (e.g. notebook, PDA, Bluetooth adapters, MP3 players etc) which supports Bluetooth and is compatible to the headset (see 'Technical data' on page 6).

### Overview of your Bluetooth wireless headset



- ① On/off, call control button
- ② LED indicator
- ③ Microphone
- ④ USB cable (for charging)
- ⑤ Headset charging socket
- ⑥ Battery indicator
- ⑦ Battery indicator button
- ⑧ LED indicator
- ⑨ On/off button

# 3 Charge and pair your headset

## Charge the battery


### Note

- Before you use your headset/charging case for the first time, charge the battery for 5 hours for optimum battery capacity and lifetime.
- Use only the original USB charging cable to avoid any damage.
- Finish your call before charging the headset, as connecting the headset for charging will power the headset off.

## Charging case

Plug the USB cable into the power source.

↳ The charging case starts charging.



### Tip


- Normally, a full charge takes 2 hours.
- When the charging case is charging, the battery indicator keeps flashing until charging is complete. There are 5 indicator lights. The leftmost LED light indicates the charging status. The other 4 LED lights indicate the battery level. Each LED light indicated 25% battery. When all 4 LED lights are turned on and stable, the charging case is fully charged.
- Press the battery indicator button to show the battery level status.

## Headset

Place the headset on the charging case.

↳ The headset starts charging.

- When the headset is charging, a white LED light will be displayed.
- When the headset is fully charged, the white light goes off.



### Tip

- Normally, a full charge takes 70 minutes.

## Pair your headset


- 1 Make sure that the headset is fully charged.
- 2 Press and hold the power on/off button.  
↳ The white LED light on the right side of the headset flashes rapidly.
- 3 Turn on the Bluetooth function of your mobile phone.  
↳ The headset is in pairing mode for 2 minutes.
- 4 Pair the headset with the mobile phone. For detailed information, refer to the user manual of your mobile phone.

### Tip

- The headset stores the last 4 devices in the memory. If you try to pair more than 4 devices, the earliest paired device is replaced by the new one.

The following example shows you how to pair the headset with your mobile phone.

- 1 Activate the Bluetooth feature of your mobile phone, select Onkyo W800BT.
- 2 Enter the headset password "0000" (4 zeros) if prompted. For those mobile phones featuring Bluetooth 3.0 or higher, no need to enter a password.



# 4 Use your headset

## Connect the headset to a Bluetooth device

- 1 Turn on your mobile phone/Bluetooth device.
- 2 Press and hold the power on/off button for 2 seconds to turn the headset on.
  - ↳ The white LED light flashes.
  - ↳ The headset is reconnected to the last connected mobile phone/Bluetooth device automatically.

### Tip

- If you turn on the mobile phone/Bluetooth device or activate the Bluetooth feature after turning on the headset, you have to reconnect the headset and mobile phone/Bluetooth device manually.
- If your mobile phone/Bluetooth device cannot reconnect automatically, try to reconnect manually by clicking the headset's name again under the Bluetooth setting menu on your mobile phone/Bluetooth device.

### Note

- If the headset fails to connect to any Bluetooth device within range in 5 minutes, it will switch off automatically to save the battery life.

## Operate your headset

### On/off

Task	Button	Operation
Turn the headset on.	On/off, call control	Press and hold for 2 seconds. ↳ You hear a power on signal tone.
Turn the headset off.	on/off, call control	Press and hold for 4 seconds. ↳ The white LED is on for 2 seconds and then the headset is off. ↳ You hear a power off signal tone.

### Call control

Task	Button (right headset)	Operation
Pick up/hang up a call.	On/off, call control	Press once.
Reject an incoming call.	On/off, call control	Press and hold for 2 seconds.

### Other headset indicator status


Headset status	Indicator (right headset)	Signal
The battery level is low.	The white LED light of the headset flashes for every 10 seconds.	Low battery signal tone will ring for every minute.



The headset is ready for pairing.	The white LED light of the headset flashes rapidly.	N/A
The headset is paired and ready to use.	The white LED light flashes every 2 seconds.	One short beep.
The headset are on but not connected to a Bluetooth device.	The white LED light the headset flashes rapidly.	N/A

## Wear your headset

- 1 Push your headset inward and rotate it forward to ensure the winglet is nested inside the cavity above the ear canal.
- 2 Rotate your headset forward and backward accordingly for the best personal fit.



# 5 Technical data

## Headset

- Play time: up to 3 hrs (up to 15 hrs with charging case)
- Standby time: 40 hrs (up to 200 hrs with charging case)
- Charging Time: 70 mins
- Rechargeable Li-ion battery: 55mAh
- Bluetooth 4.1, Bluetooth mono support (Headset profile - HSP, Hands-Free Profile - HFP), Bluetooth stereo supported (Advanced Audio Distribution Profile - A2DP)
- Operating range : Up to 10 meters (33 feet)
- Digital noise and echo reduction
- Auto power off

## Charging case

- Charging time: 2hrs
- Rechargeable Li-ion battery : 900mAh
- Number of recharges supported: 5



### Note

- Specifications are subject to change without notice.

# 6 Notice

## Declaration of conformity

Hereby, Gibson Innovations declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. You can find the Declaration of Conformity on [www.onkyo-headphones.com](http://www.onkyo-headphones.com)

## Disposal of your old product and battery



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



This symbol on a product means that the product is covered by European Directive 2012/19/EU.



This symbol means that the product contains a built-in rechargeable battery covered by European Directive 2013/56/EU which cannot be disposed of with normal household waste. We strongly advise you to take your product to an official collection point to have a professional remove the rechargeable battery.


Inform yourself about the local separate collection system for electrical and electronic products and rechargeable batteries. Follow local rules and never dispose of the product and rechargeable

batteries with normal household waste. Correct disposal of old products and rechargeable batteries helps prevent negative consequences for the environment and human health.


## Remove the integrated battery for disposal

If there is no collection/recycling system for electronic products in your country, you can protect the environment by removing and recycling the battery before disposing the headset.

- Make sure the headset is disconnected from the charging case before removing the battery.



- Make sure the charging case is disconnected from the USB charging cable before removing the battery.



---

## Compliance with EMF

This product complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

### Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

---

## Trademarks

---

### Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Gibson Innovations Limited is under license. Onkyo® is a registered trade mark of Gibson Brands Inc. Other trademarks and trade names are those of their respective owners.

# 7 Frequently asked questions

## **My Bluetooth headset does not switch on.**

The battery level is low. Charge the headset.

## **I cannot pair my Bluetooth headset with a mobile phone.**

The Bluetooth is disabled. Enable the Bluetooth feature on your mobile phone and turn on the mobile phone before you turn on the headset.

## **Pairing does not work.**

Make sure the headset is in pairing mode.

- Follow the steps described in this user manual (see 'Charge and pair your headset' on page 4).
- Make sure that the LED light flashes rapidly on the right side of the headset.

## **The mobile phone cannot find the headset.**

- The headset may be connected to a previously paired device. Turn off the connected device or move it out of range.
- Pairing may have been reset or the headset has been previously paired with another device. Pair the headset with the mobile phone again as described in the user manual (see 'Charge and pair your headset' on page 4).

My Bluetooth headset is connected to a Bluetooth stereo enabled mobile phone, but music only plays on the mobile phone speaker.

Refer to the user manual of your mobile phone. Select to listen to music through the headset.

## **The audio quality is poor and crackling noise can be heard.**

The Bluetooth device is out of range. Reduce the distance between your headset and Bluetooth device, or remove obstacles between them.

## **The audio quality is poor when streaming from the mobile phone is very slow, or audio streaming does not work at all.**

Make sure your mobile phone not only supports (mono) HSP/HFP but also supports A2DP (see 'Technical data' on page 8).

For further support, visit [www.onkyo-headphones.com](http://www.onkyo-headphones.com)

2016 © Gibson Innovations Limited. All rights reserved.  
This product has been manufactured by, and is sold under the  
responsibility of Gibson Innovations Ltd., and Gibson Innovations  
Ltd. is the warrantor in relation to this product.  
Onkyo® is a registered trade mark of Onkyo Corporation. Other  
trademarks and trade names are those of their respective owners.



**ONKYO**

[www.onkyo-headphones.com](http://www.onkyo-headphones.com)