

IBM Proventia Network Intrusion Prevention System

GX3002 Appliance

Getting Started Guide

IBM Internet Security Systems

© Copyright IBM Corporation 2003, 2007.
IBM Global Services
Route 100
Somers, NY 10589
U.S.A.

Produced in the United States of America.

All Rights Reserved.

IBM and the IBM logo are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. ADDME, Ahead of the threat, BlackICE, Internet Scanner, Proventia, RealSecure, SecurePartner, SecurityFusion, SiteProtector, System Scanner, Virtual Patch, X-Force and X-Press Update are trademarks or registered trademarks of Internet Security Systems, Inc. in the United States, other countries, or both. Internet Security Systems, Inc. is a wholly-owned subsidiary of International Business Machines Corporation.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

Other company, product and service names may be trademarks or service marks of others.

References in this publication to IBM products or services do not imply that IBM intends to make them available in all countries in which IBM operates.

Disclaimer: The information contained in this document may change without notice, and may have been altered or changed if you have received it from a source other than IBM Internet Security Systems (IBM ISS). Use of this information constitutes acceptance for use in an "AS IS" condition, without warranties of any kind, and any use of this information is at the user's own risk. IBM Internet Security Systems disclaims all warranties, either expressed or implied, including the warranties of merchantability and fitness for a particular purpose. In no event shall IBM ISS be liable for any damages whatsoever, including direct, indirect, incidental, consequential or special damages, arising from the use or dissemination hereof, even if IBM Internet Security Systems has been advised of the possibility of such damages. Some states do not allow the exclusion or limitation of liability for consequential or incidental damages, so the foregoing limitation may not apply.

Reference herein to any specific commercial products, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by IBM Internet Security Systems. The views and opinions of authors expressed herein do not necessarily state or reflect those of IBM Internet Security Systems, and shall not be used for advertising or product endorsement purposes.

Links and addresses to Internet resources are inspected thoroughly prior to release, but the ever-changing nature of the Internet prevents IBM Internet Security Systems, Inc. from guaranteeing the content or existence of the resource. When possible, the reference contains alternate sites or keywords that could be used to acquire the information by other methods. If you find a broken or inappropriate link, please send an email with the topic name, link, and its behavior to support@iss.net.

Document part number: DOC-GSG-PNIPSGX3-001-C

November 19, 2007

Contents

Preface	5
Overview	5
About Proventia Appliance Documentation	6
Getting Technical Support	7
 Chapter 1: Introducing the Proventia Network IPS GX3002 Appliance	
Overview	9
Intrusion Prevention	10
Appliance Package Contents	12
About the GX3002 Appliance	13
Network Cabling Guidelines	16
 Chapter 2: Getting Started	
Overview	19
Getting Started	20
Connecting the Cables and Starting the Appliance	21
Required information checklist	22
Connecting to the Appliance	23
Completing the Initial Configuration	24
Accessing Proventia Manager	27
Working with Proventia Manager	28
Installing the License File	31
Applying Initial Updates	33
 Chapter 3: Reinstalling the Appliance	
Overview	35
Requirements	36
Checklist	38
Reinstalling the Appliance	41
 Index	43

Preface

Overview

Introduction	This guide is designed to help you connect and configure your IBM Proventia Network Intrusion Prevention System (IPS) GX3002 appliance.
Scope	This guide includes basic information and required procedures for connecting the appliance and configuring basic settings.
Audience	This guide is intended for network security system administrators responsible for installing and configuring Proventia Network IPS Appliances. A fundamental knowledge of network security policies and IP network configuration is helpful.

About Proventia Appliance Documentation

Introduction This guide explains how to connect and configure the Proventia Network IPS GX3002 appliance. It also explains how to access the Proventia Manager to install appliance license files and apply initial updates.

Locating additional documentation Additional documentation described in this topic is available on the IBM ISS Web site at <http://www.iss.net/support/documentation/>.

Related publications See the following for more information about the appliance:

Document	Contents
<i>IBM Proventia Network Intrusion Prevention System G and GX Appliance User Guide</i>	Provides overviews and procedures for creating and managing policies and responses, as well as maintaining appliance settings.
<i>Proventia Intrusion Products Help</i>	Procedures for creating and managing policies in Proventia Manager and the Proventia Network IPS Policy Editor in SiteProtector.
<i>Proventia Network IPS Data Sheet</i>	General information about previous Proventia Network IPS appliance features.
<i>Proventia Network IPS Frequently Asked Questions</i>	Frequently asked questions about the appliance and its functions.
Readme File	The most current information about product issues and updates, and how to contact Technical Support located at http://www.iss.net/download/ .

Table 1: Reference documentation

Getting Technical Support

Introduction

IBM ISS provides technical support through its Web site and by email or telephone.

The IBM ISS Web site

The IBM Internet Security Systems (IBM ISS) Resource Center Web site (<http://www.iss.net/support/>) provides direct access to online user documentation, current versions listings, detailed product literature, white papers, and the Technical Support Knowledgebase.

Support levels

IBM ISS offers three levels of support:

- Standard
- Select
- Premium

Each level provides you with 24x7 telephone and electronic support. Select and Premium services provide more features and benefits than the Standard service. Contact Client Services at clientservices@iss.net if you do not know the level of support your organization has selected.

Hours of support

The following table provides hours for Technical Support at the Americas and other locations:

Location	Hours
Americas	24 hours a day
All other locations	Monday through Friday, 9:00 A.M. to 6:00 P.M. during their local time, excluding IBM ISS published holidays Note: If your local support office is located outside the Americas, you may call or send an email to the Americas office for help during off-hours.

Table 2: *Hours for technical support*

Contact information The following table provides electronic support information and telephone numbers for technical support requests:

Regional Office	Electronic Support	Telephone Number
North America	Connect to the MYISS section of our Web site: www.iss.net	Standard: (1) (888) 447-4861 (toll free) (1) (404) 236-2700 Select and Premium: Refer to your Welcome Kit or call your Primary Designated Contact for this information.
Latin America	support@iss.net	(1) (888) 447-4861 (toll free) (1) (404) 236-2700
Europe, Middle East, and Africa	support@iss.net	(44) (1753) 845105
Asia-Pacific, Australia, and the Philippines	support@iss.net	(1) (888) 447-4861 (toll free) (1) (404) 236-2700
Japan	support@isskk.co.jp	Domestic: (81) (3) 5740-4065

Table 3: *Contact information for technical support*

Chapter 1

Introducing the Proventia Network IPS GX3002 Appliance

Overview

Introduction This chapter contains introductory information about deploying your Proventia Network IPS GX3002 appliance.

In this chapter This chapter contains the following topics:

Topic	Page
Intrusion Prevention	10
Appliance Package Contents	12
About the GX3002 Appliance	13
Network Cabling Guidelines	16

Intrusion Prevention

Introduction

The Proventia Network Intrusion Prevention System (IPS) automatically blocks malicious attacks while preserving network bandwidth and availability. The Proventia Network IPS appliances are purpose-built, Layer 2 network security appliances that you can deploy either at the gateway or the network to block intrusion attempts, denial of service (DoS) attacks, malicious code, backdoors, spyware, peer-to-peer applications, and a growing list of threats without requiring extensive network reconfiguration.




Figure 1: *Intrusion prevention overview*

Figure 1 displays how the Proventia Network IPS protects your network. With flexible deployment options and out-of-the-box functionality, these appliances ensure accurate, high-performance protection at both the network perimeter and across internal networks and internal network segments.

About IPS monitoring modes

How you connect the appliance to the network depends on the mode in which you want to run the appliance. The inline appliances include the following adaptor modes:

Mode	Responses	Benefits
Inline protection	Block, Quarantine, Firewall	- Monitors network and actively blocks malicious traffic - Allows you to realize the full benefit of the IPS
Inline simulation	Block, Quarantine (Simulated)	- Monitors network without affecting traffic patterns - Helps you baseline and test your security policy
Passive monitoring	Block	- Replicates traditional IDS technology - Monitors traffic without sitting inline

Table 4: *Monitoring modes*

Appliance Package Contents

Introduction

Before you begin, you should verify that you have all of the package contents necessary to install the appliance.

Verifying the contents

Verify the appliance package includes the following:

✓	Item
☐	Proventia Network IPS GX3002 appliance
☐	Proventia serial console cable
☐	Ethernet crossover cable
☐	For each inline segment: • a pair of Ethernet cables, straight-through or crossover, depending on your network • a crossover adapter • additional Ethernet cables as needed Note: IBM ISS provides one crossover adapter and two one-foot Ethernet cables per segment.
☐	Power cord
☐	Recovery CD pack
☐	Warranty statement
☐	Getting Started Guide

Table 5: *Materials for connecting appliance*

About the GX3002 Appliance

Introduction

Before you connect the appliance to the network, familiarize yourself with the appliance’s hardware features.

GX3002 front panel

Figure 2 displays the GX3002 front panel:




Figure 2: GX3002 appliance front panel

The front panel of the GX3002 appliance includes the following:

Label	Description
A	Power indicator.
B	The lights labeled 0 represent RSKill responses passing through the TCP Reset (RSKill) port. If you have configured the appliance for TCP Reset and the lights flash on, the appliance is in active TCP Reset mode. Note: Once you connect the appliance to the network through the TCP Reset port, you must configure the appliance to run TCPReset. See “Configuring TCPReset” in the <i>IBM Proventia Network Intrusion Prevention System G and GX Appliance User Guide</i>.
C	Lights labeled 1A and 1B represent traffic passing across the protected ports. A green light indicates traffic passing at 100Mbps; no light indicates traffic passing at 10Mbps.
D	Lights labeled 2 represent the Management port, which the appliance uses to communicate with Proventia Manager and the Proventia SiteProtector central management system.

Table 6: GX3002 front panel label descriptions

Label	Description
E	When the Bypass light is on, the appliance is passing traffic successfully. If the light turns off, the appliance has gone into bypass mode, which means it has failed open and is no longer monitoring network traffic.

Table 6: GX3002 front panel label descriptions (Continued)

GX3002 back panel Figure 3 displays the GX3002 back panel:




Figure 3: GX3002 appliance back panel

The back panel of the GX3002 appliance includes the following:

Label	Description
A	Power button.
B	The appliance uses the Management port to communicate with Proventia Manager and/or the Proventia SiteProtector central management system.
C	The Protected Ports work in either inline intrusion prevention (IPS mode) or passive intrusion detection (IDS mode). Inline intrusion prevention uses both ports in the pair; passive detection uses only the 1A port.

Table 7: GX3002 back panel label descriptions

Label	Description
D	The TCP Reset port sends RSKill responses, after you configure the appliance for TCPReset. For information about configuring TCPReset, see “Configuring TCPReset” in the <i>IBM Proventia Network Intrusion Prevention System G and GX Appliance User Guide</i> .
E	The Console port enables terminal-based setup and recovery for the appliance.
F	The appliance reset button.
G	The USB ports are reserved for future use.

Table 7: *GX3002 back panel label descriptions (Continued)*

Internal bypass

The GX3002 has built-in copper bypass hardware, which by default fails “open,” allowing traffic to continue passing through the appliance without being monitored if the appliance fails or loses power.

Network Cabling Guidelines

Introduction

Before you connect the appliance to the network, consider the following guidelines to determine what cabling to use to connect the appliance to the network. Wherever you need a crossover connection, you may use your own Ethernet cable. IBM ISS provides one crossover adapter and two one-foot Ethernet cables per segment. When the appliance is not running, its monitoring ports function as a crossover. The following scenarios work independently of the monitoring port you use.

General cabling guidelines

The following table lists some general cabling guidelines:


Use this Ethernet cable...	In these situations....
Crossover	Between the appliance and a workstation Between the appliance and a router
Straight-through	Between the appliance and a switch or hub

Table 8: General cabling guidelines

Switch or hub 1 to switch or hub 2

To deploy the appliance between two switches or hubs:


- use a straight-through Ethernet cable from Switch or Hub 1 to the appliance
- use a straight-through Ethernet cable from the appliance to Switch or Hub 2



Workstation or server to router

To deploy the appliance between a workstation and a router:


- use an Ethernet crossover cable from the workstation to the appliance
- use an Ethernet crossover cable from the appliance to the router



Workstation or server to switch or hub

To deploy the appliance between a workstation and a switch:


- use an Ethernet crossover cable from the workstation to the appliance
- use a straight-through Ethernet cable from the appliance to the switch



Router to switch or hub

To deploy the appliance between a router and a switch/hub:


- use an Ethernet crossover cable from the router to the appliance
- use a straight-through Ethernet cable from the appliance to the switch or hub



Router to router

To deploy the appliance between two routers:

- use an Ethernet crossover cable from Router 1 to the appliance
- use an Ethernet crossover cable from the appliance to Router 2



Chapter 2

Getting Started

Overview

Introduction This chapter contains connection and configuration procedures for the GX3002 appliance. It also includes checklists to help you gather information to complete these tasks.

In this chapter This chapter contains the following topics:

Topic	Page
Getting Started	20
Connecting the Cables and Starting the Appliance	21
Required information checklist	22
Connecting to the Appliance	23
Completing the Initial Configuration	24
Accessing Proventia Manager	27
Working with Proventia Manager	28
Installing the License File	31
Applying Initial Updates	33

Getting Started

Setup process overview

Connecting and configuring the GX3002 appliance is an 8-step process:

Step	Description	Where to find the procedure
1	Connect the appliance cables to a computer and turn on the appliance.	“Connecting the Cables and Starting the Appliance” on page 21
2	Connect to the appliance through a serial console or remote connection.	“Connecting to the Appliance” on page 23
3	Gather required information.	“Required information checklist” on page 22
4	Log in to Proventia Setup and configure initial network settings.	“Completing the Initial Configuration” on page 24
5	Verify you have the following: - Internet Explorer version 6.0 or later - Java Runtime Environment (JRE) version 1.5. The application prompts you with an installation link if you do not have it installed.	
6	Open Internet Explorer and log in to Proventia Manager as username admin and the password you configured during Proventia Setup.	“Accessing Proventia Manager” on page 27
7	Collect license information and install license.	“Installing the License File” on page 31
8	Apply security and firmware updates.	“Applying Initial Updates” on page 33

Table 9: *Setup process*

Connecting the Cables and Starting the Appliance

Introduction

After you have determined where you plan to place the appliance in your network, you are ready to connect the appliance. You should install the correct network cabling and verify that traffic flows *before* you turn on the appliance.

Important: Keep your management and monitoring communication separate so that network traffic can pass uninterrupted through the appliance's network interface card (NIC).

Connecting the appliance to the network

To connect the appliance to the network:

1. Connect the power cord to the appliance.
2. Connect the **Management** port on the back panel to the network you will use to manage the appliance.
3. Connect the network cables to the **Protected** ports that correspond with the adapter mode (inline or passive) you plan to use for the appliance.

Note: If you plan to run the appliance in passive mode, you should only connect Protected port 1A to the network.

4. If you want the appliance to send kill responses through the **TCP Reset** port while in inline protection or inline monitoring mode, connect the TCP Reset port to the network.

Important: The appliance does not send kill responses for TCP events until you have configured the appliance for TCPReset. See "Configuring TCPReset" in the *IBM Proventia Network Intrusion Prevention System G and GX Appliance User Guide*.

5. (Optional) Connect the serial **Console** cable to the appliance if you want to connect a computer directly to the appliance to complete the initial network configuration.
6. Verify that traffic is passing through the appliance.
7. Flip the power switch to the On position.

Required information checklist

Use the checklist in Table 10 to obtain the information you need to configure the IPS appliance.

✓	Setting	Description
☐	Appliance hostname	The unique computer name for your appliance Example: <i>myappliance</i>
	Your setting:	
☐	Appliance domain name	The domain suffix for the network Example: <i>mydomain.com</i>
	Your setting:	
☐	Appliance domain name server	This is the IP address of the server you are using to perform domain name lookups (DNS search path). (optional). Example: <i>10.0.0.1</i>
	Your setting:	
☐	Management Port IP Address	An IP address for the management network adapter.
	Your setting:	
☐	Management port subnet mask	The subnet mask value for the network that will connect to your management port.
	Your setting:	
☐	Management port default gateway (IP address)	This is the IP address for the management gateway.
	Your setting:	
☐	Adapter mode	The adapter (operation) mode to use for the appliance. The adapter mode you plan to use should correspond to the way you connected the network cables.
	Your setting:	

Table 10: Checklist and worksheet for configuration information

Connecting to the Appliance

Introduction

If you connected the appliance directly to a computer using the serial Console cable, you are ready to log on the appliance and begin configuring. See “Completing the Initial Configuration” on page 24.

If you want to configure the appliance from a remote computer, follow the procedure below, which explains how to connect to the appliance using Hyperterminal. You may use another terminal emulation program, such as PuTTY, to connect to the appliance, but those procedures are not outlined here. Follow the instructions listed in the documentation for the program you choose.

Procedure

To connect to the appliance remotely using Hyperterminal:

1. On your computer, select **Start→Programs→Accessories→Communications**.
2. Select **Hyperterminal**.
3. Create a new connection using the following settings:

Setting	Value
Communications Port	Typically COM1 (depending on computer setup)
Emulation	VT100
Bits per second	9600
Data bits	8
Parity	None
Stop bits	1
Flow control	None

4. Press ENTER to establish a connection.

When the connection is established, the Proventia Setup Configuration Menu appears.

Tip: If you are unable to establish a connection, ensure the appliance has power and that you have started the appliance.

Completing the Initial Configuration

Introduction Proventia Setup is the program you use to configure initial appliance network settings.

Procedure To complete the initial configuration for the appliance:

1. At the unconfigured login prompt, type the user name **admin**, and then press ENTER.
2. Type the default password **admin**.
3. Select **Start**, and then press ENTER.
4. Read the Software License Agreement, and then select **Accept** to continue.
5. Follow the on-screen instructions.

The following table describes the required information. You can use the information you provided in the check list to complete many of these settings.

Information	Description
Change Password	• Admin Password—When you access the appliance, you must provide this password. This password can be the same as the root password. • Root Password—When you access the appliance from a command line, you must provide this password. • Proventia Manager Password—When you access Proventia Manager, you must provide this password. This password can be the same as the root password.
Network Configuration Information	• IP Address—The IP address of the management network adapter. • Subnet Mask—The subnet mask value for the network that connects to the management interface. • Default Gateway—The IP address for the management gateway.

Information	Description
Host Configuration	The appliance uses domain names and DNS information to send email and SNMP responses. If you do not configure this information during setup, you must specify the IP address of the appliance's mail server each time you define an email or SNMP response. • Hostname—The computer name for the appliance. Example: myappliance. • Domain Name—The domain suffix (DNS search path) for the network. Example: mycompany.com. • Primary Name Server—The IP address for the DNS used to perform domain name lookups. Example: 10.0.0.1 • Secondary Name Server—The IP address for the secondary DNS used to perform domain name lookups.
Time Zone Configuration	These settings determine the time zone for the appliance.
Date/Time Configuration	You must set the date and time for the appliance as it appears in the management interface, so you can accurately track events as they occur on the network.
Agent Name Configuration	The Agent Name is the appliance name as it appears in the management interface. This name should correspond to a meaningful classification in the network scheme, such as the appliance's geographic location, business unit, or building address.

Information	Description
Port Link Configuration	Port link settings determine the appliance's performance mode, or how the appliance handles its connection to the network. You can select the speed (the rate at which traffic passes between the appliance and the network) and the duplex mode (which direction the information flows). Select link speeds and settings compatible with your particular network and in relation to the other devices that bracket the Proventia Network IPS appliance. If you are not sure about your network settings, select Auto to enable the appliance to negotiate the speed and duplex mode with the network automatically. Note: After the initial appliance configuration, you can only change port link speed and duplex settings for the inline monitoring and kill ports through Proventia Manager. For more information, see "Managing Network Adapter Cards" in the <i>IBM Proventia Network Intrusion Prevention System G and GX Appliance User Guide</i>.
Adapter Mode Configuration	The Adapter Mode determines how the appliance behaves within the network in order to protect it. Review "About IPS monitoring modes" on page 11 if you are not sure which mode to select. You can select different adapter modes for each port pair, but you must confirm that you have selected the correct adapter mode for the appliance's physical network connections. You may experience significant network implications if you have configured this setting incorrectly.

6. When you have entered all the information, the appliance applies the settings.

When prompted, press ENTER to log off the appliance.

Accessing Proventia Manager

Introduction

Proventia Manager is the Web-based management interface for the appliance. Use Proventia Manager to perform the following tasks:

- monitor the status of the appliance
- configure and manage settings
- view quarantine table and apply changes
- review and manage appliance activities

Logging on to Proventia Manager

To log on to the Proventia Manager interface:

1. Start Internet Explorer 6.
2. Type [https:// <appliance IP address>](https://<appliance IP address>).
3. Log in using the user name `admin` and the Proventia Manager password.
4. If a message informs you that you do not have Java Runtime Environment (JRE) installed, install it, and then return to this procedure.
5. Select **Yes** to use the Getting Started procedures.

Note: You can use the Getting Started procedures to help you customize the appliance settings. If this window does not appear, you can access the Getting Started procedures from the Help.

6. Click **Launch Proventia Manager**.

Working with Proventia Manager

Introduction

When you open the Proventia Manager, the Home page provides an immediate snapshot of the current status of the appliance. This page includes the following navigation, information and reporting options:

- device name (the appliance domain name you configured during setup)
- protection status
- system status
- alerts for each module
- important messages

Viewing protection status

The protection status area describes the current status of the intrusion prevention component. Selecting a component name links you to the component status page.

The following status icons show you the current status of a component:

This icon...	Indicates...
	The component is active.
	The component is stopped.
	The component is in an unknown state. This status may require immediate attention.

Table 11: Protection status icons

Viewing system status

On the Home page, the system status group box describes the current status of the system. The following table describes the data available in the System Status area:

Statistic	Description
Model Number	The model number of the appliance.
Base Version Number	The base version of the appliance software. Note: The base version is the software version shipped with the appliance, or the software version of the most recent firmware update.
Uptime	How long the appliance has been online, in the following format: x days, x hours, x minutes
Last Restart	The last time the appliance was restarted, in the following format: yyyy-mm-dd hh:mm:ss Example: 2004-05-04 16:24:37
Last Firmware Update	The last time appliance firmware was updated, in the following format: yyyy-mm-dd hh:mm:ss - version: x.x Example: 2004-05-04 16:25:56 - version: 1.7
Last Intrusion Prevention Update	The last time appliance security content was updated, in the following format: yyyy-mm-dd hh:mm:ss - version: x.x Example: 2004-01-25 12:34:36 - version: 1.7
Last System Backup	The last time a system backup was created, in the following format: yyyy-mm-dd hh:mm:ss Example: 2004-05-04 15:49:01
Backup Description	The backup type on the appliance: - Factory Default - Full System Backup

Table 12: *System Status statistics*

Viewing important messages

The Home page displays important messages about licensing and updates. If you have not configured the appliance to download updates automatically, these messages may appear with a link to the appropriate Proventia Manager page.

Installing the License File

Introduction

Proventia Network IPS appliances require a properly configured license file. If you have not installed the appropriate license file, you cannot manage the appliance.

To purchase a license, contact your local sales representative.

Use the procedure below to install the license file, which is necessary to make your appliance run at full capability. You must save the license file to the appropriate location so that the Proventia Manager software can locate and acknowledge it.

Prerequisites

Before you install the license file, complete the following:

- register your customer license
- download the license from the IBM ISS Registration Center

About the Licensing page

The Licensing page displays important information about the current status of the license file, including expiration dates. Additionally, this page allows you to access the License Information page, which includes information about how to acquire a current license.

Collecting license information

To collect your license information:

1. Contact your Sales Representative for your license registration number.
2. Register your customer license at the IBM ISS License Registration center (<https://www1.iss.net/cgi-bin/lrc>).
3. Download the license key file from the IBM ISS Registration Center to your computer.

Note: Upload the license key file to a designated directory so that the appliance can download and install the latest updates automatically.

Installing the license file

To install the license file:

1. In Proventia Manager, select **System→Licensing**.
2. Click **Browse**.
3. Locate the license file that you downloaded.
4. Click **OK**.
5. Click **Upload**.

Applying Initial Updates

Introduction

Before you begin to create policies to manage your network security, you must ensure you have applied the latest updates to the appliance. The appliance retrieves updates from the IBM ISS Download Center, accessible over the Internet.

For information about maintaining appliance updates, see “Updating the Appliance” in the *IBM Proventia Network Intrusion Prevention System G and GX Appliance User Guide*.

Types of updates

You can install the following updates:

- **Firmware updates.** These updates include new program files, fixes or patches, enhancements, or online Help updates.
- **Intrusion prevention updates.** These updates contain the most recent security content provided by IBM ISS’s X-Force.

You can find updates on the Updates to Download page, and you can schedule automatic update downloads and installations from the Update Settings page.

Note: Some firmware updates require you to reboot the appliance. For more information about product issues and updates, see your appliance Readme.

Downloading updates

To download initial updates:

1. select **Updates**→**Available Downloads**.
2. If your appliance model requires it, the Export Administration window appears.
Review the agreement, select **Yes**, and then click **Submit**.
3. The Updates to Download window appears and displays the following message if updates are available: “There are updates available. Click here to see details.”
Click the link in the message.
4. On the Updates to Download page, click **Download All Available Updates**.

Installing updates

To install updates:

1. In Proventia Manager, select **Updates**→**Available Installs**.
2. If your appliance model requires it, the Export Administration Regulation window appears.
Review the agreement, select **Yes**, and then click **Submit**.
3. On the Available Installs page, select the updates you want to install, and then click **Install Updates**.

Note: Some firmware updates require you to reboot the appliance. For detailed information about each firmware update, review the appliance Readme.

4. View the installation status in the Update History table on the Update Status page.

Chapter 3

Reinstalling the Appliance

Overview

Introduction

This chapter describes the process and procedures for reinstalling the GX3002 appliance.

Caution: Reinstalling the appliance firmware clears the appliance's current configuration settings and all data stored on the appliance.

In this chapter

This chapter contains the following topics:

Topic	Page
Requirements	36
Checklist	38
Reinstalling the Appliance	41

Requirements

Introduction

The Recovery CD included in the appliance packaging contains the software that was installed on the appliance at the factory. You can reinstall the software from this CD on the appliance.

Important: Reinstalling the appliance means erasing all data from the system and returning it to its factory state. Only perform this procedure under the guidance of IBM ISS technical support.

Results

This process does the following:

- Overwrites software configuration changes you have made since you first installed the appliance.
- Restores the original, default login credentials:
 - username = admin
 - password = admin

Supported network cards

The computer you use to reinstall appliance firmware must have one of the following network cards installed for you to complete the reinstallation successfully:

Important: IBM ISS supports only the network cards listed.

Card	Brand Manufacturer
e1000	Intel PRO/1000
e100	Intel PRO/100
3c59x	3Com 3c590, 3c595, 3c905, 3c575
bcm5700	Broadcom 57xx Gigabit
sk98lin	SysKonnect and Marvell Gigabit
tulip	Digital/Intel 21x4x "Tulip"
eeepro100	Intel PRO/100
8139too	RealTek 8139

Table 13: *Supported network cards*

Card	Brand Manufacturer
ne2k-pci	NE2000-compatible PCI cards
pcnet32	AMD PCnet32, VMWare
sis900	SiS 900, 7016
via-rhine	Via Rhine VT86C100A, 6102, 6105
8139cp	RealTek 8139C+
epic100	SMC83c170, SMC83c175
xircom_cb	Xircom CardBus
3c574_cs	3Com 3c574
axnet_cs	Asix AX88190
nmclan_cs	AMD Am79C940
smc91c92_cs	SMC 91c92
xirc2ps_cs	Xircom CE2, CE IIps, RE-10, CEM28, CEM33, CEM56, CE3-100, CE3B, RE-100, REM10BT, REM56G-100
3c589_cs	3Com 3c589
fmvj18x_cs	FMV J181, FMV J182, TDK LAK-CD021, ConTec C-NET (PC) C, Ungermann Access/CARD
pcnet_cs/NE2000 compatible cards	D-Link DE-650, Linksys PCMCIA, Accton EN2212, RPTI EP400, PreMax PE-200, IBM Credit Card Adapter, Novell NE4100, Kingston KNE-PCM/x, Allied Telesis LA-PCM, ASANTE FriendlyNet

Table 13: *Supported network cards (Continued)*

Checklist

Introduction

Before you reinstall the appliance firmware, ensure you complete the tasks listed in the following checklist.

Before you begin

Before you begin, ensure you have gathered the proper materials and connected the appliance as specified in the following table:

✓	Description
☐	Choose a computer to access the appliance and reinstall the software. This computer is referred to as the <i>Pre-boot eXecution (PXE) server</i>. Requirements: • The BIOS settings on the computer must allow it to restart from a CD. For more information, see the computer's documentation. • Pentium II or compatible CPU • 64M RAM • IDE CD-ROM drive • COM1 serial port
☐	Locate the following items included with the appliance package: • <i>IBM Proventia Network Intrusion Prevention System Recovery CD</i> • an Ethernet cross-over cable • a serial (null modem) cable Important: IBM ISS does not support the use of other cables for this procedure.
☐	Create a backup of the current system in Proventia Manager. You can restore the system settings from this backup after you reinstall the appliance firmware. See “Appliance Management” in the <i>IBM Proventia Network Intrusion Prevention System G and GX Appliance User Guide</i> for more information.
☐	Record the following appliance settings for the management interface: • IP address, subnet mask, and default gateway • hostname, domain name, and DNS name server


Table 14: Reinstallation checklist

✓	Description
☐	Turn off the appliance, and then connect the computer (PXE server) directly to the appliance with the provided cables. See diagram below. Connect the null modem cable to the devices as follows: • On the computer (PXE server), use the port labeled COM1. • On the appliance, use the port labeled Console. Connect the Ethernet cable to the devices as follows: • On the computer (PXE server), use the Ethernet port. • On the appliance, use the left Management port labeled 1. Note: Connecting to the computer (PXE server) to the appliance disables the appliance-Internet connection. When you finish the reinstall process, you must re-establish the Internet connection to retrieve appliance updates. Important: If you are running multiple PXE servers on the network, then you need to disconnect them prior to running the Proventia Network IPS reinstallation. You can verify that you are accessing the correct PXE server by the message displayed in Step 3 in the “Reinstalling the Appliance” procedure.

Table 14: *Reinstallation checklist (Continued)*

Diagram

The following diagram illustrates the proper computer-appliance connections for the reinstall process:



Reinstalling the Appliance

Introduction

Use the following procedure to reinstall the Proventia Network IPS firmware on your appliance.

Procedure

To reinstall the appliance:

1. Insert the *IBM Proventia Network Intrusion Prevention System Recovery CD* into the CD-ROM drive of the PXE boot server, and then restart the PXE boot server.

The PXE boot server displays the following messages:

```
***You may now boot your Proventia GXxxxx via the
network***
```

```
***Starting Terminal Emulator***
```

```
***Press Control-G to Exit and Reboot***
```

Note: The PXE boot server now acts as a terminal emulator for the appliance and displays the console output of the appliance.

2. Turn on the appliance.

The PXE boot server displays boot process messages, and then displays the following prompt:

```
Press L to boot from LAN, or press any other key to boot
normally.
```

Important: The installation process allows only five (5) seconds for you press L to boot from LAN. If you do not press L within this time period, the appliance boots as usual, and you must begin the reinstallation again.

3. Press the L key.

The following message appears:

```
Internet Security Systems
Proventia GXxxxx Recovery Boot
```

The PXE boot server displays status messages from the appliance, and then boots the installer over the network.

4. At the prompt, type **reinstall**, and then press ENTER.

The installer reloads the operating system.

Note: When the reinstallation is complete, the appliance automatically reboots. Let the appliance complete the boot process without interruption.

5. When the appliance has rebooted, the `unconfigured.appliance` login prompt appears.

You can log in with the default user and password of `admin/admin` and configure the appliance using the Configuration Menu.

Index

C

cabling guidelines 16

F

firmware updates 33

front panel 13

I

IBM Internet Security Systems

technical support 7

Web site 7

intrusion prevention updates 33

L

Licensing page 31

N

null modem cable 38

O

operation modes

definitions 11

P

protection status 28

PXE boot server 38

R

Readme document 6

reinstall the appliance software 41

related publications 6

S

settings snapshot, creating 38

T

technical support, IBM Internet Security
Systems 7

U

Update Settings page 33

Updates to Download page 33

W

Web site, IBM Internet Security Systems 7

Internet Security Systems, Inc., an IBM Company Software License Agreement

BY INSTALLING, ACTIVATING, COPYING OR OTHERWISE USING THIS SOFTWARE PRODUCT, YOU AGREE TO ALL OF THE PROVISIONS OF THIS ISS SOFTWARE LICENSE AGREEMENT ("LICENSE"). EXCEPT AS MAY BE MODIFIED BY AN APPLICABLE LICENSE NOTIFICATION THAT ACCOMPANIES, PRECEDES, OR FOLLOWS THIS LICENSE, AND AS MAY FURTHER BE DEFINED IN THE USER DOCUMENTATION ACCOMPANYING THE SOFTWARE PRODUCT, YOUR RIGHTS AND OBLIGATIONS WITH RESPECT TO THE USE OF THIS SOFTWARE PRODUCT ARE AS SET FORTH BELOW. IF YOU ARE NOT WILLING TO BE BOUND BY THIS LICENSE, RETURN ALL COPIES OF THE SOFTWARE PRODUCT, INCLUDING ANY LICENSE KEYS, TO ISS WITHIN FIFTEEN (15) DAYS OF RECEIPT FOR A FULL REFUND OF ANY PAID LICENSE FEE. IF THE SOFTWARE PRODUCT WAS OBTAINED BY DOWNLOAD, YOU MAY CERTIFY DESTRUCTION OF ALL COPIES AND ANY LICENSE KEYS IN LIEU OF RETURN.

"ISS" is Internet Security Systems, Inc., an IBM Company.

"Software" is the following, including the original and all whole or partial copies: 1) machine-readable instructions and data, 2) components, 3) audio-visual content (such as images, text, recordings, or pictures), 4) related license materials, and 5) license use documents or keys, and documentation.

1. **License** - The Software is provided in object code and is licensed, not sold. Upon your payment of the applicable fees and ISS' delivery to you of the applicable license notification, Internet Security Systems, Inc., an IBM Company ("ISS") grants to you as the only end user ("Licensee") a nonexclusive and nontransferable, limited license for the accompanying Software, for use only on the specific network configuration, for the number and type of devices, and for the time period ("Term") that are specified in ISS' quotation and Licensee's purchase order, as accepted by ISS. If no Term is specified in the applicable ISS quotation or Licensee purchase order, the license shall be deemed perpetual. ISS limits use of Software based upon the number of nodes, users and/or the number and type of devices upon which it may be installed, used, gather data from, or report on, depending upon the specific Software licensed. A device includes any network addressable device connected to Licensee's network, including remotely, including but not limited to personal computers, workstations, servers, routers, hubs and printers. A device may also include ISS hardware (each an "Appliance") delivered with pre-installed Software and the license associated with such shall be a non-exclusive, nontransferable, perpetual (unless otherwise specified in the applicable ISS quotation or Licensee purchase order), limited license to use such pre-installed Software only in conjunction with the ISS hardware with which it is originally supplied. Except as provided in the immediately preceding sentence, Licensee may reproduce, install and use the Software on multiple devices, provided that the total number and type are authorized by ISS. Licensee may make a reasonable number of backup copies of the Software solely for archival and disaster recovery purposes. In connection with certain Software products, ISS licenses security content on a subscription basis for a Term. Content subscriptions are licensed pursuant to this License based upon the number of protected nodes or number of users. Security content is regularly updated and includes, but is not limited to, Internet content (URLs) and spam signatures that ISS classifies, security algorithms, checks, decodes, and ISS' related analysis of such information, all of which is owned and copyrighted by ISS and considered ISS confidential information and intellectual property. Security content may only be used in conjunction with the applicable Software in accordance with this License. The use or re-use of such content for commercial purposes is prohibited.

Licensee's access to the security content is through an Internet update using the Software. In addition, unknown URLs may be automatically forwarded to ISS through the Software, analyzed, classified, entered into ISS' URL database and provided to Licensee as security content updates at regular intervals. ISS' URL database is located at an ISS facility or as a mirrored version on Licensee's premises. Any access by Licensee to the URL database that is not in conformance with this License is prohibited. Upon expiration of the security content subscription Term, unless Licensee renews such content subscription, Licensee shall implement appropriate system configuration modifications to terminate its use of the content subscription. Except for a perpetual license, upon expiration of the license Term, Licensee shall cease using the Software and certify return or destruction of it upon request.

2. **Migration Utilities** - For Software ISS markets or sells as a Migration Utility, the following shall apply. Provided Licensee holds a valid license to the Software to which the Migration Utility relates (the "Original Software"), ISS grants to Licensee as the only end user a nonexclusive and nontransferable, limited license to the Migration Utility and the related documentation ("Migration Utility") for use only in connection with Licensee's migration of the Original Software to the replacement software, as recommended by ISS in the related documentation. The Term of this License is for as long as Licensee holds a valid license to the applicable Original Software. Licensee may reproduce, install and use the Migration Utility on multiple devices in connection with its migration from the Original Software to the replacement software. Licensee shall implement appropriate safeguards and controls to prevent unlicensed use of the Migration Utility. Licensee may make a reasonable number of backup copies of the Migration Utility solely for archival and disaster recovery purposes.

3. **Third-Party Products** - Use of third party product(s) supplied hereunder, if any, will be subject solely to the manufacturer's terms and conditions that will be provided to Licensee upon delivery. ISS will pass any third party product warranties through to Licensee to the extent ISS is authorized to do so. If ISS supplies Licensee with Crystal Decisions Runtime Software, then the following additional terms apply:

Licensee agrees not to alter, disassemble, decompile, translate, adapt or reverse-engineer the Runtime Software or the report file (.RPT) format, or to use, distribute or integrate the Runtime Software with any general-purpose report writing, data analysis or report delivery product or any other product that performs the same or similar functions as Crystal Decisions' product offerings;

Licensee agrees not to use the Runtime Software to create for distribution a product that converts the report file (.RPT) format to an alternative report file format used by any general-purpose report writing, data analysis or report delivery product that is not the property of Crystal Decisions;

Licensee agrees not to use the Runtime Software on a rental or timesharing basis or to operate a service bureau facility for the benefit of third-parties unless Licensee first acquires an Application Service Provider License from Crystal Decisions;

CRYSTAL DECISIONS AND ITS SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESS, OR IMPLIED, INCLUDING WITHOUT LIMITATION THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. CRYSTAL DECISIONS AND ITS SUPPLIERS SHALL HAVE NO LIABILITY WHATSOEVER UNDER THIS AGREEMENT OR IN CONNECTION WITH THE RUNTIME SOFTWARE.

In this Section 3 "Runtime Software" means the Crystal Reports software and associated documentation supplied by ISS and any updates, additional modules, or additional software provided by Crystal Decisions in connection therewith; it includes Crystal Decisions' Design Tools, Report Application Server and Runtime Software, but does not include any promotional software or other software products provided in the same package, which shall be governed by the online software license agreements included with such promotional software or software product.

4. **Beta License** - If ISS is providing Licensee with the Software, security content and related documentation, and/or an Appliance as a part of an alpha or beta test, the following terms of this Section 4 additionally apply and supersede any conflicting provisions herein or any other license agreement accompanying, contained or embedded in the subject prototype product or any associated documentation. ISS grants to Licensee a nonexclusive, nontransferable, limited license to use the ISS alpha/beta software program, security content, if any, Appliance and any related documentation furnished by ISS ("Beta Products") for Licensee's evaluation and comment (the "Beta License") during the Test Period. ISS' standard test cycle, which may be extended at ISS' discretion, extends for sixty (60) days, commencing on the date of delivery of the Beta Products (the "Test Period"). Upon expiration of the Test Period or termination of the Beta License,

Licensee shall, within thirty (30) days, return to ISS or destroy all copies of the beta Software, and shall furnish ISS written confirmation of such return or destruction upon request. If ISS provides Licensee a beta Appliance, Licensee agrees to discontinue use of and return such Appliance to ISS upon ISS' request and direction. If Licensee does not promptly comply with this request, ISS may, in its sole discretion, invoice Licensee in accordance with ISS' current policies.

Licensee will provide ISS information reasonably requested by ISS regarding Licensee's experiences with the installation and operation of the Beta Products. Licensee agrees that ISS shall have the right to use, in any manner and for any purpose, any information gained as a result of Licensee's use and evaluation of the Beta Products. Such information shall include but not be limited to changes, modifications and corrections to the Beta Products. Licensee grants to ISS a perpetual, royalty-free, non-exclusive, transferable, sublicensable right and license to use, copy, display, perform, make derivative works of and distribute any report, test result, suggestion or other item resulting from Licensee's evaluation of its installation and operation of the Beta Products.

LICENSEE AGREES NOT TO EXPORT BETA PRODUCTS DESIGNATED BY ISS IN ITS BETA PRODUCT DOCUMENTATION AS NOT YET CLASSIFIED FOR EXPORT TO ANY DESTINATION OTHER THAN THE U.S. AND THOSE COUNTRIES ELIGIBLE FOR EXPORT UNDER THE PROVISIONS OF 15 CFR § 740.17(A) (SUPPLEMENT 3), CURRENTLY CANADA, THE EUROPEAN UNION, AUSTRALIA, JAPAN, NEW ZEALAND, NORWAY, AND SWITZERLAND.

If Licensee is ever held or deemed to be the owner of any copyright rights in the Beta Products or any changes, modifications or corrections to the Beta Products, then Licensee hereby irrevocably assigns to ISS all such rights, title and interest and agrees to execute all documents necessary to implement and confirm the letter and intent of this Section. Licensee acknowledges and agrees that the Beta Products (including its existence, nature and specific features) constitute Confidential Information as defined in Section 18. Licensee further agrees to treat as Confidential Information all feedback, reports, test results, suggestions, and other items resulting from Licensee's evaluation and testing of the Beta Products as contemplated in this License. With regard to the Beta Products, ISS has no obligation to provide support, maintenance, upgrades, modifications, or new releases. However, ISS agrees to use commercially reasonable efforts to correct errors in the Beta Products and related documentation within a reasonable time, and will provide Licensee with any corrections it makes available to other evaluation participants. The documentation relating to the Beta Products may be in draft form and will, in many cases, be incomplete. Owing to the experimental nature of the Beta Products, Licensee is advised not to rely exclusively on the Beta Products for any reason. LICENSEE AGREES THAT THE BETA PRODUCTS AND RELATED DOCUMENTATION ARE BEING DELIVERED "AS IS" FOR TEST AND EVALUATION PURPOSES ONLY WITHOUT WARRANTIES OR INDEMNITIES OF ANY KIND, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. LICENSEE ACKNOWLEDGES AND AGREES THAT THE BETA PRODUCT MAY CONTAIN DEFECTS, PRODUCE ERRONEOUS AND UNINTENDED RESULTS AND MAY AFFECT DATA NETWORK SERVICES AND OTHER MATERIALS OF LICENSEE. LICENSEE'S USE OF THE BETA PRODUCT IS AT THE SOLE RISK OF LICENSEE. IN NO EVENT WILL ISS BE LIABLE TO LICENSEE OR ANY OTHER PERSON FOR DAMAGES, DIRECT OR INDIRECT, OF ANY NATURE, OR EXPENSES INCURRED BY LICENSEE. LICENSEE'S SOLE AND EXCLUSIVE REMEDY SHALL BE TO TERMINATE THE BETA PRODUCT LICENSE BY WRITTEN NOTICE TO ISS.

5. **Evaluation License** - If ISS is providing Licensee with the Software, security content and related documentation on an evaluation trial basis at no cost, such license Term is 30 days from installation, unless a longer period is agreed to in writing by ISS. ISS recommends using Software and security content for evaluation in a non-production, test environment. The following terms of this Section 5 additionally apply and supersede any conflicting provisions herein. Licensee agrees to remove or disable the Software and security content from the authorized platform and return the Software, security content and documentation to ISS upon expiration of the evaluation Term unless otherwise agreed by the parties in writing. ISS has no obligation to provide support, maintenance, upgrades, modifications, or new releases to the Software or security content under evaluation. LICENSEE AGREES THAT THE SOFTWARE, SECURITY CONTENT AND RELATED DOCUMENTATION ARE BEING DELIVERED "AS IS" FOR TEST AND EVALUATION PURPOSES ONLY WITHOUT WARRANTIES OR INDEMNITIES OF ANY KIND, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL ISS BE LIABLE TO LICENSEE OR ANY OTHER PERSON FOR DAMAGES, DIRECT OR INDIRECT, OF ANY NATURE, OR EXPENSES INCURRED BY LICENSEE. LICENSEE'S SOLE AND EXCLUSIVE REMEDY SHALL BE TO TERMINATE THE EVALUATION LICENSE BY WRITTEN NOTICE TO ISS.
6. **Covenants** - ISS reserves all intellectual property rights in the Software, security content and Beta Products. Licensee agrees: (i) the Software, security content and/or Beta Products is owned by ISS and/or its licensors, and is protected by copyright laws and international treaty provisions; (ii) to take all reasonable precautions to protect the Software, security content or Beta Product from unauthorized access, disclosure, copying or use; (iii) not to modify, adapt, translate, reverse engineer, decompile, disassemble, or otherwise attempt to discover the source code of the Software, security content or Beta Product; (iv) not to use ISS trade names or trademarks; (v) to reproduce all of ISS' and its licensors' copyright notices on any copies of the Software, security content or Beta Product; and (vi) not to transfer, lease, assign, sublicense, or distribute the Software, security content or Beta Product or make it available for timesharing, service bureau, managed services offering, or on-line use.
7. **Support and Maintenance** - Depending upon what maintenance programs Licensee has purchased, ISS will provide maintenance, during the period for which Licensee has paid the applicable maintenance fees, in accordance with its prevailing Maintenance and Support Policy that is available at http://documents.iss.net/maintenance_policy.pdf. Any supplemental Software code or related materials that ISS provides to Licensee as part of any support and maintenance service are to be considered part of the Software and are subject to the terms and conditions of this License, unless otherwise specified.
8. **Limited Warranty** - The commencement date of this limited warranty is the date on which ISS provides Licensee with access to the Software. For a period of ninety (90) days after the commencement date or for the Term (whichever is less), ISS warrants that the Software or security content will conform to material operational specifications described in its then current documentation. However, this limited warranty shall not apply unless (i) the Software or security content is installed, implemented, and operated in accordance with all written instructions and documentation supplied by ISS, (ii) Licensee notifies ISS in writing of any nonconformity within the warranty period, and (iii) Licensee has promptly and properly installed all corrections, new versions, and updates made available by ISS to Licensee. Furthermore, this limited warranty shall not apply to nonconformities arising from any of the following: (i) misuse of the Software or security content, (ii) modification of the Software or security content, (iii) failure by Licensee to utilize compatible computer and networking hardware and software, or (iv) interaction with software or firmware not provided by ISS. If Licensee timely notifies ISS in writing of any such nonconformity, then ISS shall repair or replace the Software or security content or, if ISS determines that repair or replacement is impractical, ISS may terminate the applicable licenses and refund the applicable license fees, as the sole and exclusive remedies of Licensee for such nonconformity. THIS WARRANTY GIVES LICENSEE SPECIFIC LEGAL RIGHTS, AND LICENSEE MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM JURISDICTION TO JURISDICTION. ISS DOES NOT WARRANT THAT THE SOFTWARE OR SECURITY CONTENT WILL MEET LICENSEE'S REQUIREMENTS, THAT THE OPERATION OF THE SOFTWARE OR SECURITY CONTENT WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT ALL SOFTWARE OR SECURITY CONTENT ERRORS WILL BE CORRECTED. LICENSEE UNDERSTANDS AND AGREES THAT THE SOFTWARE AND THE SECURITY CONTENT ARE NO GUARANTEE AGAINST UNSOLICITED E-MAILS, UNDESIRABLE INTERNET CONTENT, INTRUSIONS, VIRUSES, TROJAN HORSES, WORMS, TIME BOMBS, CANCELBOOTS OR OTHER SIMILAR HARMFUL OR DELETERIOUS PROGRAMMING ROUTINES AFFECTING LICENSEE'S NETWORK, OR THAT ALL SECURITY THREATS AND VULNERABILITIES, UNSOLICITED E-MAILS OR UNDESIRABLE INTERNET CONTENT WILL BE DETECTED OR THAT THE PERFORMANCE OF THE SOFTWARE AND SECURITY CONTENT WILL RENDER LICENSEE'S SYSTEMS INVULNERABLE TO

SECURITY BREACHES. THE REMEDIES SET OUT IN THIS SECTION 8 ARE THE SOLE AND EXCLUSIVE REMEDIES FOR BREACH OF THIS LIMITED WARRANTY.

9. **Warranty Disclaimer** - EXCEPT FOR THE LIMITED WARRANTY PROVIDED ABOVE, THE SOFTWARE AND SECURITY CONTENT ARE EACH PROVIDED "AS IS" AND ISS HEREBY DISCLAIMS ALL WARRANTIES AND INDEMNITIES, BOTH EXPRESS AND IMPLIED, INCLUDING IMPLIED WARRANTIES RESPECTING MERCHANTABILITY, TITLE, NONINFRINGEMENT, AND FITNESS FOR A PARTICULAR PURPOSE. LICENSEE EXPRESSLY ACKNOWLEDGES THAT NO REPRESENTATIONS OTHER THAN THOSE CONTAINED IN THIS LICENSE HAVE BEEN MADE REGARDING THE GOODS OR SERVICES TO BE PROVIDED HEREUNDER, AND THAT LICENSEE HAS NOT RELIED ON ANY REPRESENTATION NOT EXPRESSLY SET OUT IN THIS LICENSE.
10. **Limitation of Liability** - Circumstances may arise where, because of a default on ISS' part or other liability, Licensee is entitled to recover damages from ISS. In each such instance, regardless of the basis on which Licensee may be entitled to claim damages from ISS, (including fundamental breach, negligence, misrepresentation, or other contract or tort claim), ISS is liable for no more than 1) damages for bodily injury (including death) and damage to real property and tangible personal property and 2) the amount of any other actual direct damages up to the charges for the Software or security content that is the subject of the claim.
This limitation of liability also applies to ISS' licensors and suppliers. It is the maximum for which they and ISS are collectively responsible. UNDER NO CIRCUMSTANCES IS ISS, ITS LICENSORS OR SUPPLIERS LIABLE FOR ANY OF THE FOLLOWING, EVEN IF INFORMED OF THEIR POSSIBILITY: LOSS OF, OR DAMAGE TO, DATA; SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES, OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES; OR LOST PROFITS, BUSINESS, REVENUE, GOODWILL, OR ANTICIPATED SAVINGS. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO LICENSEE.
11. **Termination** - Licensee may terminate this License at any time by notifying ISS in writing. All rights granted under this License will terminate immediately, without prior written notice from ISS, at the end of the Term of the License, if not perpetual. If Licensee fails to comply with any provisions of this License, ISS may immediately terminate this License if such default has not been cured within ten (10) days following written notice of default to Licensee. Upon termination or expiration of a license for Software, Licensee shall cease all use of such Software, including Software pre-installed on ISS hardware, and destroy all copies of the Software and associated documentation. Termination of this License shall not relieve Licensee of its obligation to pay all fees incurred prior to such termination and shall not limit either party from pursuing any other remedies available to it.
12. **General Provisions** - This License, together with the identification of the Software and/or security content, pricing and payment terms stated in the applicable ISS quotation and Licensee purchase order (if applicable) as accepted by ISS, constitute the entire agreement between the parties respecting its subject matter. Standard and other additional terms or conditions contained in any purchase order or similar document are hereby expressly rejected and shall have no force or effect. If Licensee has not already downloaded the Software, security content and documentation, then it is available for download at <http://www.iss.net/download/>. All ISS hardware with pre-installed Software and any other products not delivered by download are delivered f.o.b. origin. Both Licensee and ISS consent to the application of the laws of the State of New York to govern, interpret, and enforce all of Licensee's and ISS' rights, duties, and obligations arising from, or relating in any manner to, the subject matter of this License, without regard to conflict of law principles. The United Nations Convention on Contracts for the International Sale of Goods does not apply. Both Licensee and ISS irrevocably waive any right to a jury trial. If any part of this License is found void or unenforceable, it will not affect the validity of the balance of the License, which shall remain valid and enforceable according to its terms. This License may only be modified in writing signed by an authorized officer of ISS.
13. **Notice to United States Government End Users** - Licensee acknowledges that any Software and security content furnished under this License is commercial computer software and any documentation is commercial technical data developed at private expense and is provided with RESTRICTED RIGHTS. Any use, modification, reproduction, display, release, duplication or disclosure of this commercial computer software by the United States Government or its agencies is subject to the terms, conditions and restrictions of this License in accordance with the United States Federal Acquisition Regulations at 48 C.F.R. Section 12.212 and DFAR Subsection 227.7202-3 and Clause 252.227-7015 or applicable subsequent regulations. Contractor/manufacturer is Internet Security Systems, Inc., 6303 Barfield Road, Atlanta, GA 30328, USA.
14. **Export and Import Compliance** - Each party will comply with applicable import and export control laws and regulations, including those of the United States that prohibit or limit export for certain uses or to certain end users. Many ISS Software products include encryption and export outside of the United States or Canada is strictly controlled by U.S. laws and regulations. ISS makes its current export classification information available at <http://www.iss.net/export>. Please contact ISS' Sourcing and Fulfillment for export questions relating to the Software or security content (fulfillment@iss.net). Licensee understands that the foregoing obligations are U.S. legal requirements and agrees that they shall survive any term or termination of this License.
15. **Authority** - Because the Software is designed to test or monitor the security of computer network systems and may disclose or create problems in the operation of the systems tested, Licensee and the persons acting for Licensee represent and warrant that: (a) they are fully authorized by the Licensee and the owners of the computer network for which the Software is licensed to enter into this License and to obtain and operate the Software in order to test and monitor that computer network; (b) the Licensee and the owners of that computer network understand and accept the risks involved; and (c) the Licensee shall procure and use the Software in accordance with all applicable laws, regulations and rules.
16. **Disclaimers** - Licensee acknowledges that some of the Software and security content is designed to test the security of computer networks and may disclose or create problems in the operation of the systems tested. Licensee further acknowledges that neither the Software nor security content is fault tolerant or designed or intended for use in hazardous environments requiring fail-safe operation, including, but not limited to, aircraft navigation, air traffic control systems, weapon systems, life-support systems, nuclear facilities, or any other applications in which the failure of the Software and security content could lead to death or personal injury, or severe physical or property damage. ISS disclaims any implied warranty of fitness for High Risk Use. Licensee accepts the risk associated with the foregoing disclaimers and hereby waives all rights, remedies, and causes of action against ISS and releases ISS from all liabilities arising therefrom.
17. **Confidentiality** - "Confidential Information" means all information proprietary to a party or its suppliers that is marked as confidential. Each party acknowledges that during the term of this Agreement, it will be exposed to Confidential Information of the other party. The obligations of the party ("Receiving Party") which receives Confidential Information of the other party ("Disclosing Party") with respect to any particular portion of the Disclosing Party's Confidential Information shall not attach or shall terminate when any of the following occurs: (i) it was in the public domain or generally available to the public at the time of disclosure to the Receiving Party, (ii) it entered the public domain or became generally available to the public through no fault of the Receiving Party subsequent to the time of disclosure to the Receiving Party, (iii) it was or is furnished to the Receiving Party by a third party having the right to furnish it with no obligation of confidentiality to the Disclosing Party, or (iv) it was independently developed by the Receiving Party by individuals not having access to the Confidential Information of the Disclosing Party. The Receiving Party agrees not to disclose or use any Confidential Information of the Disclosing Party in violation of this License and to use Confidential Information of the Disclosing Party solely for the purposes of this License. Upon demand by the Disclosing Party and, in any event, upon expiration or termination of this License, the Receiving Party shall return to the Disclosing Party all copies of the Disclosing Party's Confidential Information in the Receiving Party's possession or control and destroy all derivatives and other vestiges of the Disclosing Party's Confidential Information obtained or created by the Disclosing Party. All Confidential Information of the Disclosing Party shall remain the exclusive property of the Disclosing Party, provided however that the Receiving Party may use in its business activities the ideas, concepts and know-how contained in the Disclosing Party's

Confidential Information which are retained in the memories of the Receiving Party's employees who have had access to the Confidential Information under this License.

- 18. Compliance** - From time to time, ISS may request Licensee to provide a certification that the Software and security content is being used in accordance with the terms of this License. If so requested, Licensee shall verify its compliance and deliver its certification within forty-five (45) days of the request. The certification shall state Licensee's compliance or non-compliance, including the extent of any non-compliance. ISS may also, at any time, upon thirty (30) days prior written notice, at its own expense appoint a nationally recognized software use auditor, to whom Licensee has no reasonable objection, to audit and examine use and records at Licensee offices during normal business hours, solely for the purpose of confirming that Licensee's use of the Software and security content is in compliance with the terms of this License. ISS will use commercially reasonable efforts to have such audit conducted in a manner such that it will not unreasonably interfere with the normal business operations of Licensee. If such audit should reveal that use of the Software or security content has been expanded beyond the scope of use and/or the number of authorized devices or Licensee certifies such non-compliance, ISS shall have the right to charge Licensee the applicable current list prices required to bring Licensee in compliance with its obligations hereunder with respect to its current use of the Software and security content. In addition to the foregoing, ISS may pursue any other rights and remedies it may have at law, in equity or under this License.
- 19. Data Protection** - Licensee confirms that it is solely responsible for ensuring that any processing and security obligations comply with applicable data protection laws. Licensee contact information shall not be considered personal information processed on Licensee's behalf.
- 20. Miscellaneous** - Except for any payment obligations, neither Licensee nor ISS is responsible for failure to fulfill any obligations due to causes beyond its control. This License will not create any right or cause of action for any third party, nor will ISS be responsible for any third party claims against Licensee except, as permitted by the Limitation of Liability section above, for bodily injury (including death) or damage to real or tangible personal property for which ISS is legally liable. Nothing in this License affects any statutory rights of consumers that cannot be waived or limited by contract. Licensee agrees to allow ISS to store and use Licensee's contact information, including names, phone numbers, and e-mail addresses, anywhere they do business. Such information will be processed and used in connection with our business relationship, and may be provided to contractors, Business Partners, and assignees of ISS for uses consistent with their collective business activities, including communicating with Licensee (for example, for processing orders, for promotions, and for market research). Neither Licensee nor ISS will bring a legal action under this License more than two years after the cause of action arose unless otherwise provided by local law without the possibility of contractual waiver or limitation.

Revised: February 14, 2007