



HP x360 Chromebook Help Guide

This help guide is designed to provide you with some resources to get familiar with the HP Chromebook with Touchscreen display.

Quick look:



How to Activate & Log-in to your Account




Step 1 - Turn on the Chromebook by pressing the Power Button in the upper right corner of the keyboard (see left image). You should see a screen inviting you to Sign in to your Chromebook. Select "Next".

Step 2 - Enter your district username

Step 3 - Enter your district password

Step 4 - Click "Sign In"




*Additional Note - If you get a wireless connection error, please be sure to choose your home network.

Connect your Chromebook to Wi-Fi (if needed)


To connect to the Internet, use a compatible Wi-Fi network.

Step 1: Click on the Quick Settings Panel at the bottom right of your screen.




Step 2: Click on “no network” and turn on Wi-Fi.

*Note: If you see your Wi-Fi network name signal strength, your Chromebook is already connected to Wi-Fi



Step 3: Select your Wi-Fi network. Then enter password and click “Connect”.



Chromebook Resources:

How to Chromebook (Provides tutorials on everything from editing office documents to keyboard shortcuts)	https://www.google.com/chromebook/howto/
How to use Chrome OS	https://www.youtube.com/watch?v=yTGS-CekbhY Here are some timestamps for the video: Tip 1: 1:25 - Power up Tip 2: 1:59 - Google Account Tip 3: 3:42 - Ports Tip 4: 4:28 - Settings Tip 5: 5:16 - How to extend displays Tip 6: 6:33 - Keyboard shortcuts Tip 7: 7:41 - Trackpad Tip 8: 9:20 - Tablet UI Tip 9: 10:28 - Android & Linux Apps Tip 10: 11:33 - Powerwash

Specifications:

CPU	Intel Celeron N4100		
GPU	Intel UHD Graphics 600		
Display	11.6", HD (1366 x 768), IPS		
HDD/SSD	64GB eMMC		
RAM	8GB LPDDR4		
OS	Chrome OS		
Battery	47.36Wh, 2-cell		
Dimensions	295 x 205.3 x 20.9 mm (11.61" x 8.08" x 0.82")		
Weight	1.45 kg (3.2 lbs)		
Ports and connectivity		Features	
 2x USB Type-A	3.0 (3.1 Gen 1)	 Web camera	HD
 2x USB Type-C	3.0 (3.1 Gen 1), Power Delivery (PD), DisplayPort	 Speakers	2 Speakers
 Card reader	mSD, mSDHC, mSDXC	 Optical drive	✗
 Wi-Fi	802.11ac	 Security Lock slot	✓
 Bluetooth	5.0		
 Audio jack	3.5 mm combo		