


Kingston 6 pc Set Dining Chair-Swivel Instruction Manual

Item#: L-DN1414SST-C

SKU #: 810213846





CAUTION: Chair is for setting purpose only. Standing on or misuse of bench may result in damage or injury. Not intended for commercial use. WEIGHT LIMIT 300 LBS (133 KG).

WARNING:


- _ Keep all children and pets away from assembly area. Children and pets should be supervised when they are in the area of the Chair construction.
- _ Keep assembly area at least 6 feet from any obstruction such as a fence, garage, house, overhanging branches, laundry line or electrical wires.
- _ Some parts may contain sharp edges. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the product. Please read all instructions before assembly and use.
- _ Check all bolts for tightness before use. IMPORTANT - check and tighten bolts often to keep them secure!

Parts List


Part#	Description	Qty
A	Back	1
B	Left armrest	1
C	Right armrest	1
D	Seat	1
E	Base	1
F	Back cushion	1
G	Seat cushion	1
AA	Bolt M6×20	10
BB	M6 Spring washer	10
CC	M6 Flat washer	10
DD	Screw M8*40	4
EE	Screw M8*35 (pre-assembled)	4
FF	M8 Nut(pre-assembled 4)	8
GG	M8 Spring washer (pre-assembled 4)	8
HH	M8 Flat washer (pre-assembled 4)	8
II	Big washer (pre-assembled 2)	6
JJ	Spring steel plate (pre-assembled)	2
KK	Cap	8
LL	Wrench M8	2
MM	Hex key M6	1
NN	Foot pad (pre-assembled on F)	6




Step 1: Attach seat (D) to back (A) by bolt (AA), spring washer (BB), flat washer (CC) and hex key (MM). Do not lock tightly. Put on cap (KK) after locking all bolts tightly.




Step 2: Put bolt (AA) through spring washer (BB), flat washer (CC), attach armrest (B,C) to back (A) by hex key (MM). Do not lock tightly.



Step 3: Attach armrest (B,C) to seat (D) by bolt (AA), spring washer (BB), flat washer (CC) and hex key (MM). Put on cap (KK) after locking all bolts tightly.



Step 4: Put hole of base (E) and hole of assembled frame A(BCD) on the same line, put screw (DD) through big washer (II), spring steel plate (JJ), big washer (II), flat washer (HH), spring washer (GG), attached nut (FF) by wrench (LL). Lock all bolts tightly by wrench (LL).



Step 5: Put seat cushion (G) onto seat, stick velcro, put back cushion (F) on back.

Assembly finished.

Care & Maintenance

Before using, clean the Chair completely with a soft dry towel. When not in use, wipe free of any dirt or loose objects, wash with a mild solution of soap and water; rinse thoroughly and dry completely. Do not use strong detergent or abrasive cleaners. Over time nuts and bolts can loosen. Occasionally, check nuts and bolts, re-tighten if necessary.

Exclusions:

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

CUSTOMER SERVICE

Sunjoy Industries warrants to the original purchaser that this item is free from defects in workmanship and materials of your item provided the item was factory-sealed at the time of purchase and is maintained with care and used only for personal, residential purposes. The item is warranted to be free from defects in material or workmanship for a period of **1 year**. Should any manufacturing defect arise within this warranty period, Sunjoy Industries will repair or replace (at our option) any defective merchandise upon proof of purchase; however, transportation and delivery costs, as well as labor and material charges to remove or replace parts, remain the responsibility of the purchaser. A purchaser of an "open box," previously-returned, or "clearance" item, as well as original purchasers outside of the warranty period, may obtain replacement parts from Sunjoy Industries for products in current production, at nominal cost.

If you are within the return policy that most stores have, you do have the option of returning this item back to the store which you bought it from for an exchange of the same item, or a refund of the purchase.

If you are within or beyond the return policy that most stores have, and need tech. assistance or replacement parts, please call Sunjoy Industries at 1(866) 578-6569 from 8:30 am to 4:30 pm eastern standard time or e-mail to Biglots@sunjoygroup.com or fax your parts replacement order form together with the purchase receipt to 1 (740) 283-3549 for assistance.