

☐

I'm not robot


reCAPTCHA

Continue

Ubiquiti unifi ap ac manual

Unifi ap ac pro how many users. Reset unifi ap ac lite. Ubiquiti unifi ap ac lr manual.



Ubiquiti unifi ap ac mesh pro manual. Ubiquiti unifi ap ac lite manual. Unifi ap ac reset. Ubiquiti unifi ap ac pro manual.

© 1996-2014, Amazon.com, Inc. or its affiliates UniFi Video will no longer be actively supported on December 31st, 2020. For more information, please refer to the official community notice. EN FR DE ES IT HR SV SR SL NL We and our partners use cookies to Store and/or access information on a device. We and our partners use data for Personalised ads and content, ad and content measurement, audience insights and product development. An example of data being processed may be a unique identifier stored in a cookie. Some of our partners may process your data as a part of their legitimate business interest without asking for consent. To view the purposes they believe they have legitimate interest for, or to object to this data processing use the vendor list link below. The consent submitted will only be used for data processing originating from this website. If you would like to change your settings or withdraw consent at any time, the link to do so is in our privacy policy accessible from our home page. Continue with Recommended Cookies User Manual for Ubiquiti models including: UniFi, AP AC Lite, UAP-AC-LITE, 802.11ac, Dual Radio, Access PointUniFi AP-AC Lite Quick Start Guidereport this adPorts Ethernet Port Reset Button Locking Notch Cable Feed Plug Locking Notch The Locking Notch will be used with the Mounting Bracket to help secure the UniFi AP. (This is described further in the Mounting Bracket section.) Ethernet This Gigabit Ethernet port is used to connect the power and should be connected to the LAN and DHCP server.Go NowMedia.s-bol.com View list download › Url: Your Device? Search For Manuals / Datasheets:File Info : application/pdf, 28 Pages, 3.11MBDocumentDocumentoriginal802.11ac Dual Radio Access Point Model: UAP-AC-LITE Introduction Thank you for purchasing the Ubiquiti Networks® UniFi® AP. This Quick Start Guide is designed to guide you through installation and includes warranty terms. IMPORTANT: The UAP-AC-LITE requires the UniFi Controller v5.4 or newer, available at: downloads.ubnt.com/unifi Package Contents UniFi AP AC Lite Mounting Bracket Ceiling Backing Plate Flat Head Screws (Qty. 4) Keps Nuts (Qty. 4) Screws (Qty. 4) 802.11ac Dual Radio Access Point Model: UAP-AC-LITE Gigabit PoE (24V, 0.5A) with Mounting Bracket Power Cord* Installation Requirements Quick Start Guide · Phillips screwdriver · Drill and drill bit (6 mm for wall-mounting or 3 mm for ceiling-mounting) · Optional: Drywall or keyhole saw (to cut 18 mm hole for Ethernet cable feed) · Cat5/6 UTP cable for indoor installations TERMS OF USE: Ubiquiti radio devices must be professionally installed. Shielded Ethernet cable and earth grounding must be used as conditions of product warranty. TOUGH Cable™ is designed for outdoor installations. It is the professional installer's responsibility to follow local country regulations, including operation within legal frequency channels, output power, and Dynamic Frequency Selection (DFS) requirements. System Requirements · Linux, Mac OS X, or Microsoft Windows 7/8/10 · Java Runtime Environment 1.8 (or above) · Web Browser: Google Chrome (Other browsers may have limited functionality). · UniFi Controller software v5.4 or newer (available at: www.ubnt.com/download/unifi) Network Topology Requirements · A DHCP-enabled network (for the AP to obtain an IP address as well as for the wireless clients after deployment) · A UniFi Cloud Key or management station running the UniFi Controller software, located either on-site and connected to the same Layer-2 network, or off-site in the cloud or a NOC UniFi Cloud Key (UniFi Controller) UAP-AC-Lite UAP-AC-HD US-16-150W USG-PRO-4 (DHCP Server) LAN WAN Internet UAP-AC-M-PRO Remote Access too UniFi Controllerr Sample Network Diagram All UniFi devices support off-site management controllers. For setup details, see the User Guide on the website: www.ubnt.com/download/unifi Hardware Overview LED LED Color White Status Factory default, waiting to be integrated. Flashing White Initializing. Alternating White/Blue Device is busy; do not touch or unplug it. This usually indicates that a process such as a firmware upgrade is taking place. Indicates the device has been successfully Blue integrated into a network and is working properly. This is used to locate an AP. Quickly Flashing Blue When you click Locate in the UniFi Controller software, the LED on the AP will flash. It will also display the location of the AP on the map. Steady Blue Indicates the device is in an isolated state with occasional (all WLANs are brought down until an flashing uplink is found). Ports Locking Notch Reset Button Ethernet Cable Port Feed Plug Locking Notch The Locking Notch will be used with the Mounting Bracket to help secure the UniFi AP. (This is described further in the Mounting Bracket section.) Ethernet This Gigabit Ethernet port is used to connect the power and should be connected to the LAN and DHCP server. Power can be provided by a Ubiquiti Networks UniFi Switch with PoE or Gigabit PoE adapter (included with single-pack only). Reset The Reset button serves two functions for the UniFi AP: · Restart Press and release the Reset button quickly. · Restore to Factory Default Settings Press and hold the Reset button for more than five seconds. Alternatively, the UniFi AP may be reset remotely via a Reset button located on the bottom of the Gigabit PoE adapter. Cable Feed Plug If your Ethernet cable feeds along the mounting surface, remove the Cable Feed Plug. Mounting Bracket Locking Tab Mounting Bracket Locking Tab During installation, the Locking Tab on the Mounting Bracket moves from the Initial Position to the Final Position, where the Locking Tab fits securely into the Locking Notch on the UniFi AP to help prevent theft. Initial Position Final Position Slot Note: If you need to remove the UniFi AP from the Mounting Bracket, insert a paper clip in the Slot to release the Locking Tab and turn the UniFi AP counterclockwise. Hardware Installation The UniFi AP can be mounted on the wall or ceiling. Perform the steps for the appropriate installation: Wall Mount 1. Position the Mounting Bracket at the desired location on the wall with the arrow pointing up. 2. Use a pencil to mark the four mounting holes.



Use a 6 mm drill bit to drill the mounting holes. Arrow 3. If your Ethernet cable feeds through the wall, then cut or drill a circle approximately 18 mm in diameter. Then feed the CAT5/6 cable through the hole. 25 mm Note: 25 mm is the distance from the center of the bottom mounting hole to the center of the cable hole. 4. Insert the Screw Anchors into the 6 mm holes. Secure the Mounting Bracket to the wall by inserting the Screws into the anchors. 5. If the Ethernet cable runs along the mounting surface, remove the Cable Feed Plug. 6. Connect the Ethernet cable to the Ethernet port. 7. Align the arrow on the UniFi AP with the arrow on the Locking Tab of the Mounting Bracket. Locking Tab Arrow 3. Ensure that the UniFi AP is firmly seated on the Mounting Bracket. Turn the UniFi AP clockwise until it locks into place and the Locking Tab fits securely into the Locking Notch. 9. Set the ceiling tile back into place. Powering the UniFi AP Use a UniFi Switch with PoE or a Gigabit PoE adapter for power. Connecting to a UniFi Switch with PoE Connect the Ethernet cable from the UniFi AP directly to a PoE port on the UniFi Switch with PoE. SPF1 22 21 19 SPF2 17 15 24 13 22 11 9 20 18 7 16 5 14 3 12 1 10 8 6 4 2 *640-00180-08* 640-00180-08 Connecting Power over Ethernet The single-pack of the UAP-AC-LITE includes one Gigabit PoE adapter. For multi-pack units, we recommend using a UniFi Switch with PoE. 1. Connect the Ethernet cable from the device to the adapter's POE port. 2. Connect an Ethernet cable from your LAN to the adapter's LAN port. 3. Connect the Power Cord to the adapter's power port. Connect the other end of the Power Cord to a power outlet. Mounting the PoE Adapter (Optional) 1. Remove the PoE Mounting Bracket from the adapter, place the bracket at the desired location, and mark the two holes. 2. Pre-drill the holes if necessary, and secure the bracket using two fasteners (not included). 3. Align the adapter's slots with the tabs of the PoE Mounting Bracket, and then slide the adapter down. Software Installation Download and install the latest version of the UniFi Controller software. Launch it and follow the on-screen instructions. The software and step-by-step instructions in the User Guide are available at: www.ubnt.com/download/unifi After you have installed the software and run the UniFi Installation Wizard, a login screen will appear for the UniFi Controller management interface. Enter the Admin Name and Password that you created and click Log In. You can manage your wireless network and view network statistics using the UniFi Controller management interface. For information on configuring and using the UniFi Controller software, refer to the User Guide. Mobile App Installation Ubiquiti Networks also offers the UniFi mobile app, which is available from the App Store (iOS) or Google Play™ Store (Android). You can use it to provision a UniFi AP for basic functionality without configuring a UniFi Controller. It also allows seamless provisioning of APs for remote controllers (controllers not on the same Layer 2 network) and easy access to local controllers and those monitored on unifi.ubnt.com Specifications UniFi AP AC Lite Dimensions 160 x 160 x 31.45 mm (6.3 x 6.3 x 1.24") Weight With Mounting Kits 170 g (6.0 oz) 185 g (6.5 oz) Networking Interface (1) 10/100/1000 Ethernet Port Buttons (1) Reset to Defaults Power Method Passive PoE (Pairs 4, 5+; 7, 8 Return) Power Supply 24V, 0.5A Gigabit PoE Adapter* Max. Power Consumption 6.5W Max. TX Power 2.4 GHz 5 GHz 20 dBm 20 dBm Antennas (2) Dual-Band Antennas, 3 dBi Each Wi-Fi Standards 802.11 a/b/g/n/ac Wireless Security WEP, WPA-PSK, WPA-Enterprise (WPA/WPA2, TKIP/AES) BSSID Up to Four per Radio Mounting Wall/Ceiling (Kits Included) Operating Temperature -10 to 70° C (14 to 158° F) Operating Humidity 5 to 95% Noncondensing Certifications CE, FCC, IC * Only the single-pack of the UAP-AC-LITE includes a PoE adapter. Safety Notices 1. Read, follow, and keep these instructions. 2. Heed all warnings. 3. Only use attachments/accessories specified by the manufacturer. WARNING: Do not use this product in location that can be submerged by water. WARNING: Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning. Electrical Safety Information 1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed. 2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician. 3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet. a. Do not substitute the power cord with one that is not the provided approved type. Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire. b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death. c. Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment. d.



Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection. e. Protective bonding must be installed in accordance with local national wiring rules and regulations. Limited Warranty UBIQUITI NETWORKS, Inc ("UBIQUITI NETWORKS") warrants that the product(s) furnished hereunder (the "Product(s)") shall be free from defects in material and workmanship for a period of one (1) year from the date of shipment by UBIQUITI NETWORKS under normal use and operation. UBIQUITI NETWORKS' sole and exclusive obligation and liability under the foregoing warranty shall be for UBIQUITI NETWORKS, at its discretion, to repair or replace any Product that fails to conform to the above warranty during the above warranty period. The expense of removal and reinstallation of any Product is not included in this warranty. The warranty period of any repaired or replaced Product shall not extend beyond its original term. Warranty Conditions The above warranty does not apply if the Product: (I) has been modified and/or altered, or an addition made thereto, except by Ubiquiti Networks, or Ubiquiti Networks' authorized representatives, or as approved by Ubiquiti Networks in writing; (II) has been painted, rebranded or physically modified in any way; (III) has been damaged due to errors or defects in cabling; (IV) has been subjected to misuse, abuse, negligence, abnormal physical, electromagnetic or electrical stress, including lightning strikes, or accident; (V) has been damaged or impaired as a result of using third party firmware; (VI) has no original Ubiquiti MAC label, or is missing any other original Ubiquiti label(s); or (VII) has not been received by Ubiquiti

within 30 days of issuance of the RMA. In addition, the above RMA process may apply only if: the product has been properly installed and used at all times in accordance with the applicable Product documentation; all Ethernet cabling runs use CAT5 (or above), and for outdoor installations, shielded Ethernet cabling is used, and for indoor installations, indoor cabling requirements are followed. Returns No Products will be accepted for replacement or repair without obtaining a Return Materials Authorization (RMA) number from UBIQUITI NETWORKS during the warranty period, and the Products being received at UBIQUITI NETWORKS' facility freight prepaid in accordance with the RMA process of UBIQUITI NETWORKS. Products returned without an RMA number will not be processed and will be returned freight collect or subject to disposal. Information on the RMA process and obtaining an RMA number can be found at: www.ubnt.com/support/warranty Disclaimer EXCEPT FOR ANY EXPRESS WARRANTIES PROVIDED HEREIN, UBIQUITI NETWORKS, ITS AFFILIATES, AND ITS AND THEIR THIRD PARTY DATA, SERVICE, SOFTWARE AND HARDWARE PROVIDERS HEREBY DISCLAIM AND MAKE NO OTHER REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, REPRESENTATIONS, GUARANTEES, OR WARRANTIES OF MERCHANTABILITY, ACCURACY, QUALITY OF SERVICE OR RESULTS, AVAILABILITY, SATISFACTORY QUALITY, LACK OF VIRUSES, QUIET ENJOYMENT, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT AND ANY WARRANTIES ARISING FROM ANY COURSE OF DEALING, USAGE OR TRADE PRACTICE IN CONNECTION WITH SUCH PRODUCTS AND SERVICES. BUYER ACKNOWLEDGES THAT NEITHER UBIQUITI NETWORKS NOR ITS THIRD PARTY PROVIDERS CONTROL BUYER'S EQUIPMENT OR THE TRANSFER OF DATA OVER COMMUNICATIONS FACILITIES, INCLUDING THE INTERNET, AND THAT THE PRODUCTS AND SERVICES MAY BE SUBJECT TO LIMITATIONS, INTERRUPTIONS, DELAYS, CANCELLATIONS AND OTHER PROBLEMS INHERENT IN THE USE OF COMMUNICATIONS FACILITIES.



UBIQUITI NETWORKS, ITS AFFILIATES AND ITS AND THEIR THIRD PARTY PROVIDERS ARE NOT RESPONSIBLE FOR ANY INTERRUPTIONS, DELAYS, CANCELLATIONS, DELIVERY FAILURES, DATA LOSS, CONTENT CORRUPTION, PACKET LOSS, OR OTHER DAMAGE RESULTING FROM ANY OF THE FOREGOING. In addition, UBIQUITI NETWORKS does not warrant that the operation of the Products will be error-free or that operation will be uninterrupted. In no event shall UBIQUITI NETWORKS be responsible for damages or claims of any nature or description relating to system performance, including coverage, buyer's selection of products (including the Products) for buyer's application and/or failure of products (including the Products) to meet government or regulatory requirements. Limitation of Liability EXCEPT TO THE EXTENT PROHIBITED BY LOCAL LAW, IN NO EVENT WILL UBIQUITI OR ITS SUBSIDIARIES, AFFILIATES OR SUPPLIERS BE LIABLE FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL OR OTHER DAMAGES (INCLUDING LOST PROFIT, LOST DATA, OR DOWNTIME COSTS), ARISING OUT OF THE USE, INABILITY TO USE, OR THE RESULTS OF USE OF THE PRODUCT, WHETHER BASED IN WARRANTY, CONTRACT, TORT OR OTHER LEGAL THEORY, AND WHETHER OR NOT ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Note Some countries, states and provinces do not allow exclusions of implied warranties or conditions, so the above exclusion may not apply to you. You may have other rights that vary from country to country, state to state, or province to province. Some countries, states and provinces do not allow the exclusion or limitation of liability for incidental or consequential damages, so the above limitation may not apply to you. EXCEPT TO THE EXTENT ALLOWED BY LOCAL LAW, THESE WARRANTY TERMS DO NOT EXCLUDE, RESTRICT OR MODIFY, AND ARE IN ADDITION TO, THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE LICENSE OF ANY SOFTWARE (EMBEDDED IN THE PRODUCT) TO YOU. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to any transactions regarding the sale of the Products. Compliance FCC Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions. 1.



This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This radio transmitter (FCC: SWX-UAPACL) has been approved by FCC. ISED Canada CAN ICES-3(A)/NMB-3(A) This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: 1. This device may not cause interference, and 2. This device must accept any interference, including interference that may cause undesired operation of the device. This radio transmitter (IC: 6545A-UAPACL) has been approved by ISED Canada.

CAN ICES-3(A)/NMB-3(A) Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : 1. L'appareil ne doit pas produire de brouillage; 2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. Le présent émetteur radio (IC: 6545A-UAPACL) a été approuvé par ISDE Canada. RF Exposure Warning The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be located or operating in conjunction with any other antenna or transmitter. Les antennes utilisées pour ce transmetteur doivent être installées en considérant une distance de séparation de toutes personnes d'au moins 20 cm et ne doivent pas être localisées ou utilisées en conflit avec tout autre antenne ou transmetteur. Australia and New Zealand Warning: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. Brazil Nota: Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.

CE Marking CE marking on this product represents the product is in compliance with all directives that are applicable to it. Country List AT BE BG CY CZ DE DK EE EL ES FI FR HR HU IE IT LV LT LU MT NL PL PT RO SE SI SK UK BFWA (Broadband Fixed Wireless Access) members noted in blue Note: This device meets Max. TX power limit per ETSI regulations. The following apply to products that operate in the 5 GHz frequency range: Note: This device is restricted to indoor use only when operating in the 5150 - 5350 MHz frequency range within all member states. Note: All countries listed may operate at 30 dBm. BFWA member states may operate at 36 dBm. Note: Operation in the 5.8 GHz frequency band is prohibited in BFWA member states. Other countries listed may use the 5.8 GHz frequency band. RoHS/WEEE Compliance Statement English European Directive 2012/19/EU requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product. Deutsch Die Europäische Richtlinie 2012/19/EU verlangt, dass technische Ausrüstung, die direkt am Gerät und/oder an der Verpackung mit diesem Symbol versehen ist, nicht zusammen mit unsortiertem Gemeindeabfall entsorgt werden darf. Das Symbol weist darauf hin, dass das Produkt von regulärem Haushaltsmüll getrennt entsorgt werden sollte. Es liegt in Ihrer Verantwortung, dieses Gerät und andere elektrische und elektronische Geräte über die dafür zuständigen und von der Regierung oder örtlichen Behörden dazu bestimmten Sammelstellen zu entsorgen. Ordnungsgemäßes Entsorgen und Recyceln trägt dazu bei, potentielle negative Folgen für Umwelt und die menschliche Gesundheit zu vermeiden. Wenn Sie weitere Informationen zur Entsorgung Ihrer Altgeräte benötigen, wenden Sie sich bitte an die örtlichen Behörden oder städtischen Entsorgungsdienste oder an den Händler, bei dem Sie das Produkt erworben haben. Español La Directiva 2012/19/UE exige que los equipos que lleven este símbolo en el propio aparato y/o en su embalaje no deben eliminarse junto con otros residuos urbanos no seleccionados. El símbolo indica que el producto en cuestión debe separarse de los residuos domésticos convencionales con vistas a su eliminación. Es responsabilidad suya desecher este y cualesquiera otros aparatos eléctricos y electrónicos a través de los puntos de recogida que ponen a su disposición el gobierno y las autoridades locales. Al desechar y reciclar correctamente estos aparatos estará contribuyendo a evitar posibles consecuencias negativas para el medio ambiente y la salud de las personas. Si desea obtener información más detallada sobre la eliminación segura de su aparato usado, consulte a las autoridades locales, al servicio de recogida y eliminación de residuos de su zona o pregunte en la tienda donde adquirió el producto.

Français La directive européenne 2012/19/UE exige que l'équipement sur lequel est apposé ce symbole sur le produit et/ou son emballage ne soit pas jeté avec les autres ordures ménagères. Ce symbole indique que le produit doit être éliminé dans un circuit distinct de celui pour les déchets des ménages. Il est de votre responsabilité de jeter ce matériel ainsi que tout autre matériel électrique ou électronique par les moyens de collecte indiqués par le gouvernement et les pouvoirs publics des collectivités territoriales. L'élimination et le recyclage en bonne et due forme ont pour but de lutter contre l'impact néfaste potentiel de ce type de produits sur l'environnement et la santé publique. Pour plus d'informations sur le mode d'élimination de votre ancien équipement, veuillez prendre contact avec les pouvoirs publics locaux, le service de traitement des déchets, ou l'endroit où vous avez acheté le produit.

Italiano La direttiva europea 2012/19/UE richiede che le apparecchiature contrassegnate con questo simbolo sul prodotto e/o sull'imballaggio non siano smaltite insieme ai rifiuti urbani non differenziati. Il simbolo indica che questo prodotto non deve essere smaltito insieme ai normali rifiuti domestici. È responsabilità del proprietario smaltire sia questi prodotti sia le altre apparecchiature elettriche ed elettroniche mediante le specifiche strutture di raccolta indicate dal governo o dagli enti pubblici locali. Il corretto smaltimento ed il riciclaggio aiuteranno a prevenire conseguenze potenzialmente negative per l'ambiente e per la salute dell'essere umano. Per ricevere informazioni più dettagliate circa lo smaltimento delle vecchie apparecchiature in Vostro possesso, Vi invitiamo a contattare gli enti pubblici di competenza, il servizio di smaltimento rifiuti o il negozio nel quale avete acquistato il prodotto. Declaration of Conformity [Bulgarian] UBIQUITI NETWORKS , UAP-AC-LITE 2014/53/ : www.ubnt.com/compliance Hrvatski [Croatian] UBIQUITI NETWORKS ovime izjavljuje da je radijska oprema tipa UAP-ACLITE u skladu s Direktivom 2014/53/EU. Čjeloviti tekst EU izjave o sukladnosti dostupan je na sljedeoj internetskoj adresi: www.ubnt.com/compliance Cestina [Czech] Tímto UBIQUITI NETWORKS prohlašuje, že typ rádiového zařízení UAP-AC-LITE je v souladu se smrnici 2014/53/EU. Úplné zní EU prohlášení o shodě je k dispozici na této internetové adrese: www.ubnt.com/compliance Dansk [Danish] Hermed erklærer UBIQUITI NETWORKS, at radioudstyrstypen UAP-AC-LITE er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: www.ubnt.com/compliance Nederlands [Dutch] Hierbij verklaar ik, UBIQUITI NETWORKS, dat het type radioapparatuur UAPAC-LITE conform is met Richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: www.ubnt.com/compliance English Hereby, UBIQUITI NETWORKS declares that the radio equipment type UAP-AC-LITE is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.ubnt.com/compliance Eesti keel [Estonian] Käesolevaga deklareerib UBIQUITI NETWORKKS, et käesolev raadioseadme tüüp UAP-AC-LITE vastab direktiivi 2014/53/EL nõuetele. ELi vastavusdeklaratsiooni täielik tekst on kätesaadav järgmisel internetiaadressil: www.ubnt.com/compliance Suomi [Finnish] UBIQUITI NETWORKS vakuuttaa, että radiolaitetyypin UAP-AC-LITE on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksti on saatavilla seuraavassa internetosoitteessa: www.ubnt.com/compliance Français [French] Le soussigné, UBIQUITI NETWORKS, déclare que l'équipement radioélectrique du type UAP-AC-LITE est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: www.ubnt.com/compliance Deutsch [German] Hiermit erkläre UBIQUITI NETWORKS, dass der Funkanlagentyp UAP-AC-LITE der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: www.ubnt.com/compliance [Greek] / UBIQUITI NETWORKS, UAP-AC-LITE 2014/53/ : www.ubnt.com/compliance Magyar [Hungarian] UBIQUITI NETWORKS igazolja, hogy a UAP-AC-LITE típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelési nyilatkozat teljes szövege elérhető a következő internetes címen: www.ubnt.com/compliance Íslenska [Icelandic] Hér með lýsir UBIQUITI NETWORKS yfir því að UAP-AC-LITE er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 2014/53/EU.

Fullur texti ESB samræmisfyrirlysing er að finna á eftirfarandi netfangi: www.ubnt.com/compliance Italiano [Italian] Il fabbricante, UBIQUITI NETWORKS, dichiara che il tipo di apparecchiatura radio UAP-AC-LITE è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: www.ubnt.com/compliance Latviesu valoda [Latvian] Ar šo UBIQUITI NETWORKS deklar, ka radioiekrtā UAP-AC-LITE atbilst Direktīvai 2014/53/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šd interneta vietn: www.ubnt.com/compliance Lietuvi kalba [Lithuanian] As, UBIQUITI NETWORKS, patvirtinu, kad radijo rengini tipas UAP-AC-LITE atitinka Direktyv 2014/53/ES. Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: www.ubnt.com/compliance Malti [Maltese] B'dan, UBIQUITI NETWORKS, niddikjara li dan it-tip ta' tagmir tar-radju UAP-ACLITE huwa konformi mad-Direttiva 2014/53/UE. Id-dikjarazzjoni tal-konformità tista' ti' kkonsultata minn www.ubnt.com/compliance Norsk [Norwegian] UBIQUITI NETWORKS erklærer herved at utstyret UAP-AC-LITE er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 2014/53/EU. Den fulle teksten til EU-samsvarserklæringen er tilgjengelig på følgende internetadresse: www.ubnt.com/compliance Polski [Polish] UBIQUITI NETWORKS niniejszym oświadcz, e typ urzdzzenia radiowego UAPAC-LITE jest zgodny z dyrektyw 2014/53/UE.

Pelny tekst deklaracji zgodności UE jest dostpny pod nastpujcm adresem internetowym: www.ubnt.com/compliance Português [Portuguese] O(a) abaixo assinado(a) UBIQUITI NETWORKS declara que o presente tipo de equipamento de rádio UAP-AC-LITE está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: www.ubnt.com/compliance Român [Romanian] Prin prezenta, UBIQUITI NETWORKS declar c tipul de echipamente radio UAP-AC-LITE este în conformitate cu Directiva 2014/53/UE. Textul integral al declaraiei UE de conformitate este disponibil la urmtoarea adres internet: www.ubnt.com/compliance Slovenska [Slovak] UBIQUITI NETWORKS týmto vyhlasuje, že rádiové zariadenie typu UAP-ACLITE je v súlade so smernicou 2014/53/EU. Úplné EU vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: www.ubnt.com/compliance Slovenscina [Slovenian] UBIQUITI NETWORKS potrjuje, da je tip radijske opreme UAP-AC-LITE skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: www.ubnt.com/compliance Español [Spanish] Por la presente, UBIQUITI NETWORKS declara que el tipo de equipo radioeléctrico UAP-AC-LITE es conforme con la Directiva 2014/53/UE.

El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: www.ubnt.com/compliance Svenska [Swedish] Härmed försäkrar UBIQUITI NETWORKS att denna typ av radioutrustning UAP-AC-LITE överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: www.ubnt.com/compliance Online Resources Support help.ubnt.com Downloads downloads.ubnt.com Ubiquiti Networks, Inc. 685 Third Avenue, 27th Floor New York, NY 10017 USA www.ubnt.com ©2016-2018 Ubiquiti Networks, Inc. All rights reserved. Ubiquiti, Ubiquiti Networks, the Ubiquiti U logo, the Ubiquiti beam logo, TOUGH Cable, and UniFi are trademarks or registered trademarks of Ubiquiti Networks, Inc. in the United States and in other countries. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.

App Store is a service mark of Apple Inc. Android, Google, Google Play, the Google Play logo and other marks are trademarks of Google Inc. All other trademarks are the property of their respective owners. AJA1103018 ReferencesGPL Ghostscript 9.26