

STARTING THE CAR:

1. Make sure the gear stick is in P-position.
2. Press down the break pedal and push the




button.

In case the car won't start and the following message appears on the console, simply take out the car's remote key and push the "open doors" button. After that the car will start normally.
(The message is due to a power saving feature of the wireless key reader.)

Avainta ei tunnistettu. Pidä avainta merkityllä pinnalla! Ohjekirja!

AUTOMATIC GEARBOX:

Volkswagen Passat GTE has a highly sophisticated automatic DSG-gearbox with the following positions.



In **B**-mode (Regenerative **B**reaking) the car slows down using regenerative breaking when releasing the gas pedal.

You can check the currently active mode from the console display.

Tiptronic manual mode + / -

Upshift or downshift by tilting gear lever, or by using paddles behind the steering wheel.

PARKING:

Set gear stick to P-position, turn on the electronic parking brake using the lift switch, and turn off power by pushing the START/STOP button.



ATTENTION!

The car has an electric trunk door. You can open the trunk using the switch on the driver's door or from the VW logo on the trunk door.

Always make sure there's enough room behind the car for the door to open before opening the trunk!

FILLING UP THE TANK:

Open the fuel door using the lift switch on the driver's door.
Only use 95 E10 petrol for this car.



In case you have further questions, you can reach our customer service at 0440 24 24 24.