



AUDIBAX Signature S1E Bookshelf HiFi Speakers User Manual

[Home](#) » [AUDIBAX](#) » AUDIBAX Signature S1E Bookshelf HiFi Speakers User Manual 

Contents

- [1 AUDIBAX Signature S1E Bookshelf HiFi Speakers](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Troubleshooting](#)
- [5 Important Safety Instruction](#)
- [6 Passive Speaker](#)
- [7 Specifications](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)



AUDIBAX Signature S1E Bookshelf HiFi Speakers



Product Information

The Signature S1E is a powered speaker product designed to enhance your home entertainment, personal computer, and mini home theater with great sound performance. It is a Class II or double-insulated electrical appliance, meaning it does not require a safety connection to the electrical earth. The product comes with a passive speaker that includes a tweeter, woofer, speaker output, and reflex port.

Product Usage Instructions

To unpack the box, follow these steps:

1. Remove the packaging materials.
2. Take out the passive speaker.
3. Check if the following items are included: speaker wire and user manual.

To connect the speakers, follow these steps:

1. Using qualified cables, connect the speakers.
2. Peel the insulator layer on the cable for about 10mm.
3. Twist the exposed wires of the speaker cables together to prevent short circuits.
4. Loosen the cable terminal on the passive speaker.
5. Insert the cable into the terminal and tighten it.

Connecting Audio Input Signals:

To connect audio input signals, follow these steps:

1. Use an RCA cable plug for connection.
2. Connect the RCA cable with the white (L) and red (R) jacks properly.

Please refer to the user manual for further instructions and safety information.

Troubleshooting

Please check if power is connected, and if the wall outlet is switched on.

- Please switch the system off then on and reconnect to the audio source.
- Please check if the master volume is turned to a minimum.
- Please check if the audio input cable is connected correctly.
- Please check if there is a signal from the audio source.

NOTICE:

- For the need for technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.
- Products will be customized for different applications.
- Pictures and illustrations shown in this manual may be slightly different from the actual product.
- If any difference is found, the actual product prevails.

Important Safety Instruction

WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. Thank you for purchasing our product. We try to provide powered speaker products to satisfy the needs of our end customers. This product can add to your home entertainment, personal computer, and mini home theater great sound performance. Please read this manual carefully before operation.


- The lightning flash with arrowhead inside the triangle, is intended to alert the user to the presence of un-insulated dangerous voltage within the product's enclosure that may be of a sufficient magnitude to constitute a risk of electric shock to persons.
- To prevent the risk of electric shock, do not remove cover (or back). No user -serviceable parts inside. Refer servicing to qualified service personnel only.
- The exclamation point inside the triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

1. Read this instruction:
2. Keep these instructions.
3. Heed all warnings
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves. or other apparatus (including

amplifiers) that produce heat.

9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.


Passive Speaker



Conn


ecting speakers

1. Using qualified cables connect the speakers, peel the insulator layer on the cable for about 10min, twist the exposed wires of the speaker cables together to prevent short circuits
2. Loosen the cable terminal, insert the cable and tighten it.



Connecting audio input signals

1. Please use the RCA cable plug for the connection
2. Connect it with the jack white (L) and red (R) properly



Specifications

- **Max. Power handling:** 100W
- **Signal to noise ratio:** ≥ 80 dB(A)
- **Distortion:** $\leq 0.5\%$
- **Frequency response:** 40-20KHz
- **Treble Unit:** ϕ inch silk dome tweeter
- **Bass unit:** 5 inch(127mm)
- **Dimension:** 250mm(W) $\times$ 180mm(D) $\times$ 300mm (H)
- **Weight (net/gross):** 7.5/8.6KG

Documents / Resources

	AUDIBAX Signature S1E Bookshelf HiFi Speakers [pdf] User Manual Signature S1E Bookshelf HiFi Speakers, Signature S1E, Bookshelf HiFi Speakers, HiFi Speakers
---	---