H3080

Wireless Foldable Headset
Quick Start Guide (A.1)
无线折叠麦克风耳机
快速开始指南
無線折疊麥克風耳機
快速開始指南
무선 접이식 헤드셋
사용자 설명서

The ultimate wireless













Index

Language	Page
English	1
简体中文	2
繁體中文	3
한국어	4

Installation

A. Headset
B. Transmitter
C. 3.5mm AUX
D. USB cable
E. 3.5mm to USB audio cable

Wireless mode
-Connect the transmitter to an audio device with USB port.
-Turn on the headset.
-The green LED will blink and then stay on when the headset is connected.

- Before using the headset needs to be fully charged.
- Connect the USB charging cable to the headset and a computer to charge it.
- The red LED will be on when charging.
- The red LED will go off when the headset is fully charged.

Wired mode
-Connect the headset to an audio device with a 3.5mm audio cable.
-Note:It is recommended to turn off the headset under wired mode.

Configuration

Windows 7/ Vista

- Click "Play device".
- Set the 'Rapoo Wireless Audio' as your default device.
- Select the "Recording" tab.
- Set the "Rapoo Wireless Audio" as your default device.
- Double click on the "Microphone".
- Set the level to 100%.

Windows XP

- Click "Adjust audio properties".
- Go to the "Voice" tab.
- Set the 'Rapoo Wireless Audio' as your default device.
- Click on the "Volume" of the Voice recording.
- Set the level to 100%.

Trouble Shooting

Problem	Solution
No sound at all	-Make sure you have charged the headset. -Make the headset as your default audio device. Refer to step 5 , 6 and 9 . -Restart the media player. -Connect the transmitter to another USB port.
My friend on msn/skype does not hear what I'm saying	-Check if wireless headset is set as default device. Refer to step 5 , 6 and 9 . -Check if wireless headset is set as default device on msn/skype software. -Check if wireless headset is set as default device on msn/skype software.
Bad sound quality	-Maximum wireless range is 10 m, but walls or big objects may reduce the range. -Move other working wireless devices away from the transmitter and headset.
Volume control under wired mode	-Under wired mode, the volume control on the headset can not work, You can use the volume control of your PC or media playing software.

■ If your problem is not solved, please contact the helpdesk at www.rapoo.com.

安装步骤

A. 耳麦
B. 发射器
C. 音频线
D. USB传输线
E. 3.5mm转USB音频线

无线模式
-将发射器连接到带USB接口的音频设备。
-打开耳麦电源开关。
-连接耳机时，绿灯闪烁后常亮。

- 使用前耳麦需充满电。
- 将USB充电线连接耳麦和电脑连接即可充电。
- 充电时红灯常亮。
- 红灯灭表示充电完成。
- 红灯闪烁表示电池电量不足。

有线模式
-使用3.5mm音频线将耳麦和音频设备连接。
注：建议在有线模式下关闭耳麦。

配置

Windows 7/ Vista

- 点击“播放设备”。
- 将“Rapoo Wireless Audio”设为默认设备。
- 选择“录制”选项。
- 将“Rapoo Wireless Audio”设为默认设备。
- 双击“麦克风”。
- 将音量设为100%。

Windows XP

- 点击“调整音频属性”。
- 转到“语音”选项。
- 将“Rapoo Wireless Audio”设为默认设备。
- 点击“音量”。
- 将录音音量设为100%。

故障分析

问题	解决办法
没有声音	-确保耳麦已充电。 -将耳麦设为默认音频设备。请参考第5，6 和 9步。 -重新开启音频播放器。 -将发射器连接到其他的USB接口。
朋友在msn/skype上听不到我的声音	-请检查耳麦是否是默认设备。请参考第5，6 和 9 步。 -请检查耳麦是否是msn/skype的默认设备。 -请检查耳麦是否是msn/skype的默认设备。
音质不好	-耳麦的最大有效距离是10 m，但墙壁或大的物体可能会减小传输距离。 -将其他正在工作的无线设备远离发射器和耳麦。
有线模式的音量调节	-有线模式下，耳麦的音量调节不能使用。您可以使用电脑或多媒体播放软件调节音量。

■ 如您的问题还没解决，请登录www.rapoo.com。

安装步骤

A. 耳麦
B. 發射器
C. 音源線
D. USB充電線
E. 3.5mm轉USB音頻線

無線模式
-將發射器連接到帶USB接口的音頻設備。
-打開耳麥電源開關。
-連接後它綠燈，綠燈閃爍後常亮。

- 使用前耳麥需要先充電。
- 將USB充電線與耳麥和電腦連接即可充電。
- 充電時紅燈常亮。
- 紅燈熄滅表示電池充滿。
- 紅燈閃爍表示電池電量不足。

有線模式
-使用3.5mm音頻線將耳麥和音頻設備連接。
注：建議在有線模式下關閉耳麥。

配置

Windows 7/ Vista

- 點擊“播放設備”。
- 將“Rapoo Wireless Audio”設為默認設備。
- 選擇“錄制”選項。
- 將“Rapoo Wireless Audio”設為默認設備。
- 雙擊“麥克風”。
- 將音量設為100%。

Windows XP

- 點擊“調整音頻屬性”。
- 轉到“語音”選項。
- 將“Rapoo Wireless Audio”設為默認設備。
- 點擊“音量”。
- 將錄音音量設為100%。

故障分析

問題	解決辦法
沒有聲音	-確保耳麥已充電。 -將耳麥設為默認音頻設備。請參考第5，6 和 9步。 -重新開啟音頻播放器。 -將發射器連接到其他的USB接口。
朋友在msn/skype上聽不到我的聲音	-請檢查耳麥是否是默認設備。請參考第5，6 和 9 步。 -請檢查耳麥是否是msn/skype的默認設備。 -請檢查耳麥是否是msn/skype的默認設備。
音質不好	-耳麥的最大有效距離是10 m，但牆壁或大的物體可能會減小傳輸距離。 -將其他正在工作的無線設備遠離發射器和耳麥。
有線模式的音量調節	-有線模式下，耳麥的音量調節不能使用。您可以使用電腦或多媒體播放軟體調節音量。

■ 如您的問題還沒解決，請登錄www.rapoo.com。

설치

A. 헤드셋
B. 송신기
C. 3.5mm AUX
D. USB 충전 케이블
E. 3.5mm-USB 오디오 케이블

무선 모드
- 송신기를 USB 포트가 있는 오디오 장치에 연결하십시오.
- 헤드셋을 켜십시오.
- 헤드셋이 연결되면 녹색 LED가 깜박이다가 켜진 상태로 유지됩니다.

- 헤드셋을 완전히 충전하여 사용하십시오.
- USB 충전 케이블을 헤드셋과 컴퓨터에 연결하여 충전하십시오.
- 충전 중에는 빨간색 LED가 켜집니다.
- 헤드셋이 완전히 충전되면 빨간 색 LED가 꺼집니다.

유선 모드
- 3.5mm 오디오 케이블을 사용하여 헤드셋을 오디오 장치에 연결하십시오.
- 참고: 유선 모드에서는 헤드셋을 끄는 것이 좋습니다.

구성

Windows 7/ Vista

- "Play device" 를 선택합니다.
- "Rapoo Wireless Audio"(Rapoo 무선 오디오)를 기본 장치로 설정하십시오.
- "Recording"(녹음) 탭을 선택하십시오.
- "Rapoo Wireless Audio"(Rapoo 무선 오디오)를 기본 장치로 설정하십시오.
- "Microphone"(마이크)을 더블 클릭하십시오.
- 볼륨을 100%로 설정하십시오.

Windows XP

- "Adjust audio properties" 를 선택합니다.
- "Voice"(음성) 탭으로 이동하십시오.
- "Rapoo Wireless Audio"(Rapoo 무선 오디오)를 기본 장치로 설정하십시오.
- 음성녹음의 "Volume"을 선택하십시오.
- 볼륨을 100%로 설정하십시오.

문제 해결

문제	해결책
소리가 나지 않음	-헤드셋을 충전했는지 확인하십시오. -헤드셋을 기본 오디오 장치로 설정하십시오. 단계 5,6 및 9를 참조하십시오. -미디어 플레이어를 다시 시작하십시오. -송신기를 다른 USB 포트에 연결하십시오.
MSN/SKYPE 에 있는 친구가 내 말을 들을 수 없음	-헤드셋이 기본 장치로 설정되어 있는지 확인하십시오. 단계 5,6 및 9를 참조하십시오. -MSN/SKYPE 에서 헤드셋이 기본 장치로 설정되어 있는지 확인하십시오. -MSN/SKYPE 에서 헤드셋이 기본 장치로 설정되어 있는지 확인하십시오.
음질 나쁨	-최대 무선 범위 10 미터(33 피트)이지만 벽 또는 커다란 물체 등은 범위 감소 장치 가능성이 있습니다. 장치 간 간섭을 방지하십시오. -작동하는 다른 무선 장치를 트랜스미터와 헤드셋에서 멀리 이동하십시오.
유선 모드의 볼륨 조정	-유선 모드에서 헤드셋의 볼륨 조절 버튼은 작동할 수 없습니다. PC 또는 미디어 재생 소프트웨어의 볼륨 조절 기능을 이용할 수 있습니다.

■ 문제가 해결되지 않을 경우 www.rapoo.com 에서 헬프데스크에 문의하십시오.

产品中有害有害物质或元素的名称及含量
根据中国《电子信息产品污染控制管理办法》

部件名称	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
PCB板	○	○	○	○	○	○
电路连接线Wire	○	○	○	○	○	○
塑料件Plastic parts	○	○	○	○	○	○
金属结构件Metal parts	○	○	○	○	○	○
其他Other parts	○	○	○	○	○	○

○ 表示该有害物质在该部件所有均质材料中的含量均在SJ/T 11363-2006标准规定的限量要求以下。
×: 表示该有害物质至少在该部件的某一均质材料中的含量超出SJ/T 11363-2006标准规定的限量要求。

Agent Information

Country or area	Information	Description
Hongkong	Company name Tel#	RAPOO (HONG KONG) LIMITED (852) 2950 6628
Malaysia	Company name Tel#	RAPOO(M) (AM 004 BHD) NO.204,JALAN SG.3/KAWASAN PERINDUSTRIAN SUNGAI BESI,57100 KUALA LUMPUR MALAYSIA (0060)379536511
Viet Nam	Tel only in Ho Chi Minh Mob Phone	(CNG) 71-73 PHAN VĂN TRỊ (CNG) NGHĨ TAM THÀNH TỔ 7, KP. HÒA BÌNH TRUNG TÂY, thành Thủy Hòa, tỉnh Bình Dương, Việt Nam (844) 6276 0420 (844) 6276 0421
代理公司	名称/电话 地址	北京瑞柏科技有限公司 电话：010-64363388 北京市海淀区中关村南大街甲59号文华苑B座16层

保修期限	三 包 期	维 修 地 点
南京三维		
南京南点		
产品售所在		
其他城市		

Note:
Model No.:
RAPOO Mfg.:
RAPOO Mfg. Address:
Made in China

Note:
Model No.:
RAPOO Mfg.:
RAPOO Mfg. Address:
Made in China

FCC
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC
This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

CE
RAPOO declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. For more information, please visit www.rapoo.com

Warranty
The device is provided with one-year limited hardware warranty from the purchase day. Please see www.rapoo.com for more information.

保修期限
自购买日起，享有壹年硬件保修。详情请参阅www.rapoo.com

保修期限
自購買日起，享有壹年硬件保修。詳情請參閱www.rapoo.com

보증
이 장치는 구입일로부터 1 년간 제한된 하드웨어 보증이 제공됩니다. 자세한 내용은 www.rapoo.com 을 참조하십시오.

Warranty
The device is provided with one-year limited hardware warranty from the purchase day. Please see www.rapoo.com for more information.

保修期限
自购买日起，享有壹年硬件保修。详情请参阅www.rapoo.com

保修期限
自購買日起，享有壹年硬件保修。詳情請參閱www.rapoo.com

보증
이 장치는 구입일로부터 1 년간 제한된 하드웨어 보증이 제공됩니다. 자세한 내용은 www.rapoo.com 을 참조하십시오.

The ultimate wireless

www.rapoo.com

It is forbidden to reproduce any part of this quick start guide without the permission of Rapoo Technology Co., Ltd.

5935-01701-222

125*125（mm） 12p骑马钉 70g书纸 单黑双面印刷