



盾山之书  
GANKER EX



# GANKER EX盾山机器人



“修……修……”

盾山靠着强大的精神力量支撑着它沉重、庞大的身躯，迷迷糊糊发出属于它声线，脑海中还浮现着那场硝烟，它受到了前所未有的重创，几乎告别于世，然而正值它命悬一线之时，眼前的这些小兵像蚂蚁一样包围着它，把它带到这个未知的领域，一个仿如隔世的空间，没有温度，只有冰冷冷的墙，一架架从未见过的仪器，它不知道这些小兵们在计划着什么，迷糊中依稀听到“把它改装成机器人吧，盾山机器人…”，什么？机器人？什么东西....它想问个究竟，但是微弱的气息让的意识又渐渐.昏了过去.....

其实它不知道，眼前的世界已被无数个日月洗礼，眼前的它还保持着盾山的心神，可是，一切都变了。过去的它已成为历史，现在和未来，神明再度赋予它新的使命：为格斗而生——盾山机器人。







经过数日的努力，小兵们终于把这位长城守卫军打造成历史与未来的结合体——盾山机器人！它还是它，但它又不是它，昔日的容貌尚存，但是从内到外的机械感赋予了它新生命，现在，万事俱备，就等那一声召唤！





拼装外壳前请务必先阅读本说明

Read the assembly instructions carefully before beginning the assembly procedure









01 02




\*ONLY FIRST TIME  
\*仅第一次






拼装外壳前请务必先阅读本说明


Read the assembly instructions carefully before beginning the assembly procedure




A1



A2




C




D




B1




B2



E



F



G



H

部件清单  
Part List

A1 × 1	C × 1	F × 1
A2 × 1	D × 1	G × 1
B1 × 1	E × 2	H × 1
B2 × 1		

⚠ 注意：

- 此外壳需要组装，开始组装前请仔细阅读说明图。
- 警告：此产品可能包含可能有危险的锋利边缘，请谨慎处理本产品。
- 我们建议使用水口钳从板件框中剪出部件，水口钳与模型刀 8 岁以上儿童使用时必须由成人协助下完成
- 警告：本产品内含小零件，请勿吞食以免发生窒息危险，不适合 3 岁以下儿童使用。

⚠ WARNING!



- This armor needs to be assembled. Read the assembly instructions carefully before beginning the assembly procedure.
- Warning: This product may contain sharp edges that could be dangerous. Caution should be used when handling the product. Keep out of the reach of small children.
- We suggest using sprue cutters to remove parts from the parts tree and finish off any remaining plastic with a hobby knife or file. The use of sprue cutters or hobby knives by children under 8 years of age is not recommended unless supervised by a parent or guardian.
- Warning: This product does contain small parts that could be swallowed and must be kept out of the reach of children under the age of 3 years old.





了解更多功能，请扫码下载《GANKER EX 使用说明书》。

For more information, please scan the QR code to download 《GANKER EX User Manual》.



### 注意事项

- 充电器由成人或在成人监护下使用；
- 电池的安装：本产品机器人主体使用 1 个 7.4V 锂电池，需由成人组装，遥控器使用 1 个 3.7V 不可拆卸可充电电池；
- 定期检查充电器的电线、插头、外壳和其它部件是否损坏，发现损坏时应停止使用，直至修复完好；
- 充电器不是玩具，玩具只能使用推荐的充电器（5V，2A）；
- 本产品只能用干布擦拭，玩具清洁前应与充电器断开；
- 充电电池只能在成人的监护下充电；
- 充电电池在充电前应从玩具中取出；
- 电池应以正确的极性放入；
- 用尽的电池应从玩具中取出；
- 电源端子不得短路。


### ⚠ WARNING!

- The charger is used by an adult or under the supervision of an adult;
- Battery installation: This product uses a 7.4V lithium battery. Need to be assembled by an adult. The joystick controller uses a 3.7V built-in battery;
- Regularly check the charger's wires, plugs, casing and other parts for damage and stop using them until they are repaired;
- The charger is not a toy, the toy can only use the recommended charger (5V, 2A);
- This product can only be wiped with a dry cloth. The toy should be disconnected from the charger before cleaning. The rechargeable battery can only be charged under the supervision of an adult;
- The rechargeable battery should be taken out of the toy before charging;
- The battery should be placed in the correct polarity;
- The used battery should be taken out of the toy;
- The power terminals must not be short-circuited;
- Only use the battery specified by the manufacturer.


快速指南内含重要信息,请保留备用。

The Quick Guide contains important information, please reserve it for future use.


# FRONT



1




2




# BACK



3




4







5




A2-1



6




7





G4

B2-3




A2-3


8





9






10






# 11





# 12




# 13





# 14




# 15




# 16







17



18







# 长城守卫军背景



王者大陆的中部，富饶平原蔓延，诞生了最为强盛和繁华的国家“大唐”。它的边境，矗立着许久之之前遗留下来的，绵延不绝的长城——传说那是为了抵御来自遥远彼方的威胁而建造。总之，千百年来，它就那样静静的矗立着：一边是广阔无垠的灼热大漠，一边是肥沃的绿地以及日渐繁荣的国土。曾经，长城的门户也对外开放过。大漠中存在水源，水源滋养了绿洲。商人们穿过长城互相通商往来，甚至吸引了远至西方的旅客。关市举行的日子里，往往如节日般盛大，游历至此的伶人们还会献上独特的戏法和歌舞。人们庆祝着丝绸、茶叶和瓷器的交易，赞美精致的工艺品，并将它们带往大陆各地。然而谁也不曾料到，大漠

下沉睡着秘密。其中一些绿洲的统治者经不起魔道秘密的诱惑，开始滥用这些力量。强大的魔种被制造了出来，野心也随之被撩拨。这为大漠的人们带来毁灭。最终，不幸的日子到来。王庭沦陷了，都护府沦陷了。唐国的军队也不得不暂时退却，长城的关隘从此紧闭。这些事件改变了许许多多人的命运，也包括长城守卫军的其中一只小队。因为帝国的包容，长城守卫军吸纳了有才华人们的参与，无论他们是魔种混血、异乡人、屯田军人的后裔，亦或是女性。

无尽之盾

盾山



辅助  
SUPPORT

生存能力

攻击伤害

技能效果

上手难度



那位少有的英姿飒爽的女性，奉命驻守长城一角。她对眼前混乱的局势产生了怀疑：真的只是魔种在兴风作浪吗？那潜入长城的敌对者——高长恭，他暗示着什么样的秘密？她想要清楚所有的真相。

# 长城守卫军背景

她不是孤身一人。她的如今和未来的队员们：失去记忆却拥有强大魔铠之力的异乡人，或许是悲剧最核心的目睹者。那个总是超越命令的范畴行动，却做得一手好菜的神射手，对搜寻大漠表现出了强烈的兴趣。伤痕累累的中年人，拥有超越身份的见识与谋略，也隐藏了真正的来历。还有，还有在大漠深处等待的神秘敌人，以及被他收养的弟子——他们会一道揭开秘密，去找出操纵所有悲剧的无形之手。



全部的原因，在于他们想要守住长城：千百年来带给所有人安全、富饶、贸易和交流的长城，他们想要守住故乡：无论在长城的这一边，还是那一边。长城之畔，是故乡。





# GANKER EX 盾山机器人 售后保修卡

## GANKER EX DUNSHAN ROBOT Warranty Card

尊敬的用户，感谢您购买了工匠社的产品，为了使您更好地使用我们的产品，更好地享受我们的服务，请仔细阅读以下内容并妥善保管本保修卡。

### 一、注意事项

- 1.参与售后保修服务时，需同时提供本保修卡；
- 2.必须如实填写本保修卡，否则无效；
- 3.本产品非整机质保，具体的《GANKER EX盾山机器人产品保修期列表》详见官网信息；

### 二、产品属于下述所列情况的不在保修范围

- 1.非工匠社正规官方合作渠道购买的产品的；
- 2.无法提供购买凭证，产品保修卡或者发票的（能证明在保修期内的除外）；
- 3.购买凭证或产品保修卡上的产品信息内容与产品实物信息不符的；
- 4.非指定机构或维修点进行的违规拆解、维修造成的损坏；
- 5.私自或未经授权的拆卸，维修，改装产品元器件造成损坏的；
- 6.浸液，受潮和发霉的；
- 7.有明显人为损坏痕迹导致产品出现性能故障的；
- 8.因不可抗力造成损坏的；
- 9.使用非工匠社提供产品配件造成的损坏；

### 三、保修期结束后，工匠社仍提供维修服务，但需用户支付相应费用。

\*更多有关本产品的维保政策内容请在工匠社官方网址查询

Dear users, thank you for purchasing our product. In order to enjoy our product and service better, please read following contents carefully and keep this Warranty Card safely.

### I . Attentions

- 1.This Warranty Card must be provided when you apply for the warranty service.
- 2.Must fill in the Warranty Card truthfully, or the warranty service will be invalid.
- 3.Not all the parts of this product enjoy the warranty service. Please check the detailed information in GJS official website.

### II . The situation is not covered under the warranty conditions listed below

- 1.The product purchased from unauthorized channel.
- 2.Can't provide the Warranty Card or purchase certificate.
- 3.The information of the Warranty Card or purchase certificate doesn't match with the product.
- 4.The damage caused by the disassembly and repair of unauthorized organization.
- 5.The damage caused by the personal or unauthorized disassembly and repair.
- 6.Liquid, damped or moldy product.
- 7.The damage caused by human damage.
- 8.Damaged due to force majeure.
- 9.The damage caused by using the spare parts which were not provided by GJS.

### III . After the warranty period, GJS still provides the service, but the user is required to pay the corresponding fee.

\*For more detailed Warranty Policy of this product, please browse GJS official website to check.



姓名* Name*		电话* Tel*		
地址* Address*			购买日期* Purchasing Date*	
产品型号* Product Model*		产品编号* Product SN*		
送修日期* Ship-out Date*	故障描述* Malfunction Description*	处理方法 Repair Method	返机日期 Ship-back Date	用户签名* Signature*

\*表中 “\*” 项为用户必填项  
The items with “\*” must be filled in by users.  
\*为了提高服务效率与准确率，请仔细填写维修卡所需内容  
\*In order to improve service efficiency and accuracy, please fill in the required contents of Warranty Card carefully

获取更多支持，请联系：  
For more support, please contact with GJS by:  
热线/Tel: 400-1002-624  
邮箱/Mail: gjs-cs@gjs.so









长城在 故乡就在

**GJS ROBOT**

深圳市工匠社科技有限公司  
Shenzhen GJS Technology Co., LTD.

[WWW.GJSROBOT.COM](http://WWW.GJSROBOT.COM)