

PYLE®



High-Fidelity Noise Canceling Headphones

PHPNC85

User Manual

www.PyleAudio.com

PHPNC85 - High-Fidelity Active Noise Canceling Headphones


Thank you for purchasing the Pyle High-Fidelity Active Noise Canceling Headphones. These headphones combine the comfort of traditional high performance headphones with active noise control, reducing the effects of unwanted ambient sounds for the increased audio and listener experience. Enjoy the headphones when you work, fly or when you just want to relax.

Once the headphones are on, locate the power switch on the right ear-cup and press forward to the 'ON' position. The Blue battery light indicator will illuminate and the noise canceling function is activated. Adjust the levels of noise cancelation using the HI/LO slider switch found at the base of the right ear-cup.

When the power switch is set to OFF, the noise cancelling function ceases and the unit can be used as a traditional set of premium headphones.

NOTE: Batteries are required in order for the noise cancellation function to work.

Connecting the Headphones



Open the protective rubber housing situated on the lower side of the right ear-cup. Gently push the 3.5mm headphone plug all the way into the connector opening and then connect the headphone cord into the port of your chosen audio sound system. If the plug on the audio cable does not fit use the adaptor for 6.3mm ports.

To connect to in-flight entertainment systems equipped with dual output connectors, use the flight plug adaptor provided.

NOTE: Do not use with airline onboard sound systems under the following conditions:

- Whenever the cabin crew announces that electronic devices are prohibited
- When the use of privately owned headphones is prohibited inside the plane

Storing the Headphones

To store the headphones, rotate the ear-cups inward, and then place the headphones in the carry case.

CAUTION: Incorrectly rotating the ear-cups can damage the headphones

Headphones Come with:

- Headphones
- Carrying Case
- Audio cable- 3.5mm
- Audio System adaptor- 3.5mm to 6.3mm
- Airline adaptor

Confirm the presence of all parts and components before use.

Before You Put On Your Headphones

- Remove the headphones from the carry case
- Locate the battery compartment situated in the front shell of the left ear-cup
- Unclip the latch and insert two AAA batteries.
- Close the compartment

NOTE: Batteries are not included.

Press down on headband
towards left ear-cup


Gently, pry open



Opening Battery Compartment

Fitting

Confirm the left/right orientation by the L/R marks on the inside of the ear-cups/ headband. Then rotate the ear-cups (they swivel 90 degrees). Place the headphones on your head and adjust the length of the headband for the most comfortable fit. Length of headband is adjustable to accommodate various head sizes.



Inserting Batteries

PHPNC85 - High-Fidelity Active Noise Canceling Headphones

Specifications:

- Reduces Ambient Noise By 97%
- Ergonomically Designed For Maximum Comfortable Listening Experience
- Up To 20dB of Noise Cancellation; Effectively Reduces Aircraft or Subway Engine Noise
- Convenient Foldable Swivel Design
- Larger 40mm Driver with Clear Sound And Well Defined Bass
- Headphone Driver Unit: Open Air
- Frequency Response: 30 - 20000 Hz
- Speaker Type: 40mm Mylar
- Cone Impedance: 32ohm
- Noise Reduced Over Frequencies 70 - 1200 Hz
- 2 X AAA Batteries Required
- Cable Length: Detachable 1.0m
- 1/8" Stereo Mini Plug Compatibility
- Connects With 3.5mm Stereo Jack
- Sensitivity: (db): 102/mw
- 30mm Dynamic Closed Type
- 30HZ-20,000HZ
- 33 Ohms @ 1K

Included Accessories:

Detachable Audio Cable, 1/4-Inch Stereo-Plug Adapter, Dual-Plug Adapter (For Airplane), Hard Carry Case

