

Smart TV BOX




QUICK START GUIDE


All the I/O



About Android TV box




Connect the power and start up the box



1. Turn on the TV or monitor and change the video output to be HDMI.
2. Connect the Android box to the HDMI connector of the TV or monitor with a HDMI cable.
3. Connect the power adapter into the wall socket, and the other end into the DC port on the box.
4. Then the device starts and LED light on the box is on.
5. When it finishes to start, the TV or monitor screen will show the Home interface, see Page 4.

Introduction of Remote



Note: When some interface can't operate by remote-controller, please use the mouse or keyboard.

Operate the device


1. Use the infrared remote control to operate the box.
2. Or use a wired or wireless mouse/keyboard to operate the box.

Connect to the network


There are two ways to connect to network, one is by Ethernet, another is by Wi-Fi. When first time use Wi-Fi you need to set up the Wi-Fi.

1. Click 'Settings'.
2. Turn on Wi-Fi, choose the Wi-Fi router.
3. Input the password (if has), click 'Connect' and when connected, the upper right corner of the screen will display the Wi-Fi icon.


Home screen UI




Home screen UI2




WIFI Setting




Display Setting



4K x 2K video playback in FileManager




'Music' app for music playback



'Gallery' app for picture playback



'Browser' app for Internet browsing



Share fun with the family

With this app, we can mirror the whole screen of iPhone/iPad to TV, or stream multimedia contents from Android phone/tablet to TV wirelessly

is an AirPlay/DLNA app



An Android 4.2.2 phone screen shown on TV, supports rotation


with Miracast, we can push screen of an Android 4.2 phone/tablet to TV wirelessly



is a Miracast app,

Google Play Store

The first time use the 'Play Store', you need to input your Google mail account and password following the tips as your Play Store account.




Frequently Asked Questions:

1. If you do not see the LED lights, check the power if connected well.
2. If the LED light is bright and the TV is turned on but TV screen doesn't show TV box interface, please check whether the HDMI is connected well, or check whether the TV video output has been switched to HDMI output.
3. If you can not see mouse icon on TV screen, please check whether the mouse is connected well, if you use 2.4G wireless mouse, please make sure it has battery inside. (Some of the mice do not match the TV box due to non-standard, please consult the mouse suppliers)
4. If you have set up the Wi-Fi network, but still no Internet access, please approach the router or access point to verify wireless connection.
5. Some applications are designed for mobile phones and may not be full screen displayed.
6. If some applications can not be used, these applications may not be optimized for the Android operation system.



安 卓 电 视 盒
快速开始指南





设备操作

1.使用红外线遥控器操作盒子；
2.或者使用有线或者无线鼠标/键盘操作盒子。

连接网络

有两种方式可连接网络，一是通过以太网连接，另外一种是通过WIFI连接。
第一次使用WIFI时，需要设置。

1.点击“设置”；
2.打开WIFI,选择WIFI路由器；
3.输入密码（如有），点击“连接”。连接之后，屏幕右上角会显示WIFI图标。



常见问题：

1.如果LED灯不亮，请检查电源是否接好。

2.如果LED灯亮，并且电视机处于打开状态，但是电视屏幕上不显示电视盒子界面，请检查HDMI是否连接正常，或者检查电视的视频输出是否已切换成HDMI输出。

3.如果电视屏幕上没有鼠标光标，请检查鼠标是否连接正常，如果你使用的是2.4 G无线鼠标，请确保里面装有电池。（由于一些鼠标不标准，不能匹配电视盒子，请咨询鼠标供应商。）

4.如果已设置好WIFI网络，但是仍然无法连接网络，请设置路由器或者接入点验证无线连接。

5.一些应用仅适用于手机，或许不能全屏播放。

6.如果无法使用某些应用，这些应用或许尚不能用于安卓操作系统。