Guide to MB512

LEFT HAND PANEL



Projector On	Turns On the projector
Projector Off	Turns Off the projector
Main PC	Selects the Teaching PC as a source
Visualiser	Selects the Visualiser as a source
Laptop	Selects the Laptop input as a source
Video	Selects the Video input as a source
Volume Up	Turns Up the source volume
Volume Down	Turns Down the source volume

RIGHT HAND PANEL



Pod Screen On	Turns On all the side screens
Pod Screen Off	Turns Off all the side screens
Pods Local	Displays the PC mounted behind the 10 side screens
Pods Global	Displays the source selected at the teaching position
Mute Audio	Mutes the audio
Picture Blank	Blanks the picture
Rep Screen On	Turns On the big screens suspended from the ceiling
Rep Screen Off	Turns Off the big screens suspended from the ceiling

To turn on the Student PCs look behind the side screens to find them. The keyboards/mice are wireless and kept in a cupboard next to the entry door.

The microphone needs to be turned on to use it but putting it back in the charger will turn it off.

The Visualiser (Wolfvision) turns on and off as it is raised and lowered.