Klipsch

# AUTHENTIC AMERICAN AUDIO



SINCE 1946

## Flexus CORE 200

Sound Bar | Barre de son | Barra de sonido | Barra sonora | 条形音箱 | サウンドバー

# KLIPSCH CONNECT APP

**APPLICATION KLIPSCH CONNECT • APLICACIÓN KLIPSCH CONNECT • KLIPSCH CONNECT APP • APP KLIPSCH CONNECT • APLICATIVO KLIPSCH CONNECT**
**KLIPSCH CONNECT**応用 • KLIPSCH CONNECTアプリ

1. **Download the Klipsch Connect app**
2. **Follow the instructions**

# ADD TO YOUR SYSTEM

Flexus Sound System is built to grow with you. Add up to two wireless subwoofers and wireless surround speakers to create a home theater.

For more information, please visit: <link to Flexus landing page>

# IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions
2. Keep these instructions
3. Heed all warnings
4. Follow all instructions
5. Do not use this apparatus near water
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacture's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



13. Unplug the apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

## FCC AND CANADA EMC COMPLIANCE INFORMATION

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Any Changes or modifi cations not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit diff erent from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement
1. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.
2. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter.
3. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

CE RF Radiation Exposure Statement

This device can be operated in at least one Member State without infringing applicable requirements on the use of radio spectrum.

This equipment complies with EU radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to

the following two conditions:
(1) This device may not cause interference; and
(2) This device must accept any interference, including interference that may cause undesired operation of the device
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."
Radio Frequency (RF) Exposure Information
The radiated output power of the Wireless Device is below the Industry Canada (IC) radio frequency exposure limits. The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.
This device has also been evaluated and shown compliant with the IC RF Exposure limits under mobile exposure conditions. (antennas are greater than 20cm from a person's body).

for each off mode, standby mode (or another condition which does not exceed the applicable power consumption requirements for off mode or standby mode) and networked standby into which the equipment is switched by the power management function or similar function:
— the power consumption expressed in watts rounded to the first decimal place;
— the period after which the equipment reaches automatically standby mode, off mode or networked standby in minutes and rounded to the nearest minute;

DC OUT 1 ---------USB Type-C(5V/2.0A)
DC OUT 2----------USB Type-A(connect with Flexus Transport 100) ,data transmission

# INSIDE

CONTENU • CONTENIDO • INHALT • CONTENUTO • CONTEÚDO • 内 • 内部



Sound Bar




Wall-Mount Template




Remote




Wall Mount Brackets (2)



Wall Mount Screws (2)



Power Cord



HDMI Cable


| Sound Bar | Wall-Mount Template | Remote |
|---|---|---|
| Barre de son | Gabarit de montage mural | Télécommande |
| Barra de sonido | Plantilla de montaje en la pared | Control remoto |
| Sound Bar | Wandbefestigungsschablone | Fernbedienung |
| Sound Bar | Dima per il fissaggio a parete | Telecomando |
| Barra sonora | Modelo para instalação na parede | Controle remoto |
| 条形音箱 | 挂壁模板 | 遥控器 |
| サウンドバー | 壁取付け用テンプレート | リモート |

| Wall Mount Brackets | Wall Mount Screws | Power Cord | HDMI Cable |
|---|---|---|---|
| Supports pour montage mural | vis pour montage mural | Cordon d'alimentation | Câble HDMI |
| Soportes de montaje en la pared | Tornillos de 1/4 plg. | Cordón de alimentación | Cable de HDMI |
| Wandhalterungen | 1/4" Schrauben | Gleichstromkabel | HDMI-Kabel |
| Staffe per montaggio a parete | Viti per montaggio a parete | Cavo di alimentazione | Cavo HDMI |
| Suportes para montagem em parede | Parafusos 1/4" | Cabo de alimentação | Cabo HDMI |
| 壁挂式支架 | 1/4" 螺钉 | 直流电源线 | HDMI 电缆 |
| 壁取付け用ブラケット | 壁取付け用ねじ | 電源コード | HDMIケーブル |

# SOUND BAR CONTROLS


BARRE DE SON • BARRA DE SONIDO • SOUND BAR • SOUND BAR • BARRA SONORA • 条形音箱 • サウンドバーコントロール

| | |
|---|---|
| **On / Off**<br>Sous tensio / Hors tension<br>Encendido / Apagado<br>Ein / Aus<br>Acceso / Spento<br>Ligar / Desligar<br>开/关<br>オン／オフ | **Source Select (Toggle)**<br>Sélection de la source (commutation)<br>Selección de fuente (cíclica)<br>Quellenwahl (Umschalten)<br>Selezione segnale (in sequenza ciclica)<br>Seleção da fonte (Alternar)<br>电源选择（切换）<br>ソース選択(トグル) |
| **Volume Down**<br>Volume bas<br>Bajada de volumen<br>Leiser<br>Riduzione volume<br>Diminuir o volume<br>音量减小<br>音量ダウン | **Volume Up**<br>Volume haut<br>Subida de volumen<br>Lauter<br>Aumento volume<br>Aumentar o volume<br>音量增大<br>音量アップ |




# DIRECT WALL MOUNTING

MONTAGE MURAL DIRECT • MONTAJE DIRECTO EN LA PARED • DIREKTE WANDBEFESTIGUNG • MONTAGGIO DIRETTO A PARETE • MONTAGEM DIRETA NA PAREDE
直接墙上安装 • 壁への直接取付け




# CONNECTING TO POWER

PUISSANCE DE CONNEXION • CONEXIÓN PODER • VERBINDUNGSSTROM • COLLEGAMENTO ALLA PRESA DI CORRENTE • PODER DE CONEXÃO • 连接电源
電源に接続する




# CONNECTING WIRED SUBWOOFER

**CONNEXION CÂBLÉE DU CAISSON DE GRAVES • CONEXIÓN DE SUBWOOFER DE CABLE • KABELANSCHLUSS EINES SUBWOOFERS • COLLEGAMENTO A UN SUBWOOFER CABLATO • CONEXÃO DO SUBWOOFER COM FIO •** 连接有线低音炮 **•** 有線サブウーファーの接続



# LED ON/OFF


**DEL MARCHE/ARRÊT • ENCENDIDO/APAGADO DE INDICADORES LED • LED AN/AUS • LED ACCESO/SPENTO • LED LIGA/DESLIGA • LED** 灯开/关
LEDオン／オフ




| Press x1 | BRIGHT | DIM | OFF AFTER INACTIVITY |
|---|---|---|---|
| Appuyer 1 fois | Lumineux | Sombre | Arrêt après inactivité |
| Oprima 1 vez | Brillante | Oscuro | Apagado después de inactividad |
| 1x drücken | Hell | Dunkel | Nach Inaktivität aus |
| Premere 1 volta | Luminoso | Attenuato | Spento dopo un certo periodo di inattività |
| Pressionar uma vez | Brilhante | Esmaecido | Apagado depois de inatividade |
| 按 1 次 | 明亮 | 昏暗 | 无操作后关闭 |
| X1を押します | 明るい | 暗い | 非アクティブ後にオフ |

# REMOTE

TÉLÉCOMMANDE • CONTROL REMOTO • FERNBEDIENUNG • TELECOMANDO • CONTROLE REMOTO • 遥控器




**On/Off**

**LEDs High/Low**

**Source Select**
Selects HDMI eARC Input


**Play/Pause**

**Source Select**
Selects Optical Input

***Bluetooth*® Source Select**
Long press to enter Bluetooth pairing mode

**Surround Level**
Adjusts channel levels.
FH - Front Height
If surrounds present:
SL - Side Left Surround
SR - Side Right Surround


**Bass Level**
Adjusts Bass equalizer value.
Use [Vol +] and [Vol -] to adjust.



**Increase Volume**

**Mute**

**Decrease Volume**




**1 Sound Mode**
Cycles through available Sound Modes. Movie (default) is highly

**2 Dialog Boost**
Toggles through Off, Low, Medium, High

**3 Night Mode**
Enables/disables Night Mode.

## Advanced Functionality

**(Long Press):**
Displays decoding mode.


**(Long Press):**
Sets Dialog Boost to OFF.

**(Long Press):**
Exits Surround adjust mode.

**(Long Press):**
Enters remote pairing mode.

# CONNECTIONS - HDMI eARC


CONNEXIONS - HDMI-ARC • CONEXIONES - HDMI-ARC • ANSCHLÜSSE – HDMI-ARC • CONNESSIONI - HDMI-ARC • CONEXÕES - HDMI-ARC • 连接-HDMI-ARC 接続 – HDMI-ARC



# CONNECTIONS - DIGITAL OPTICAL


**CONEXÕES - ÓTICA DIGITAL (SE A TV NÃO TIVER SAÍDA ÓTICA, CONSULTE A PRÓXIMA PÁGINA) • CONEXIONES - DIGITAL ÓPTICA (SI EL TELEVISOR NO TIENE SALIDA ÓPTICA, VEA LA PÁGINA SIGUIENTE.) • ANSCHLÜSSE – DIGITAL-OPTISCH (WENN TV KEINEN OPTISCHEN AUSGANG HAT, SIEHE NÄCHSTE SEITE) CONNESSIONI – OTTICA DIGITALE (SE IL TELEVISORE NON HA UN'USCITA OTTICA, VEDERE ALLA PAGINA SUCCESSIVA) • CONEXÕES - ÓTICA DIGITAL (SE A TV NÃO TIVER SAÍDA ÓTICA, CONSULTE A PRÓXIMA PÁGINA) • 连接 – 数字光学（如果电视没有光学输出，请参见下一页）**

接続 - 光デジタル出力（TV側に光出力端子がない場合は、次のページを参照）



# CONNECTIONS - EXTERNAL HDMI SOURCE THROUGH TV

**CONNEXIONS - SOURCE HDMI EXTERNE PAR LA TÉLÉVISION • CONEXIONES - FUENTE EXTERNA DE HDMI A TRAVÉS DE TV • ANSCHLÜSSE – EXTERNE HDMI-QUELLE VIA FERNSEHER • CONNESSIONI - SORGENTE AUDIO HDMI ESTERNA ATTRAVERSO UN TELEVISORE • CONEXÕES - FONTE HDMI EXTERNA ATRAVÉS DA TV • 连接-通过电视的外部HDMI信号源 • 接続 - TVから外部HDMIソース**





Use this connection method when using external HDMI sources (Streaming boxes, Blu-Ray Players, gaming consoles, etc) to play audio/video content, and want to use TV as the source switch.

Note: This connection method will only support Dolby Atmos playback if your TV supports HDMI eARC. Check your TV owner's manual for compatibility. Dolby Atmos playback also requires Dolby Atmos content and Dolby Atmos compatible playback hardware.

# CONNECTIONS - EXTERNAL AUDIO VIA DIGITAL OPTICAL

**CONNEXIONS - AUDIO EXTERNE VIA OPTIQUE NUMÉRIQUE • CONEXIONES - AUDIO EXTERNO POR VÍA DIGITAL ÓPTICA • ANSCHLÜSSE – EXTERNES AUDIO VIA DIGITAL-OPTISCH • CONNESSIONI - AUDIO ESTERNO ATTRAVERSO INGRESSO OTTICO DIGITALE • CONEXÕES - ÁUDIO EXTERNO VIA LIGAÇÃO ÓPTICA DIGITAL • 连接-通过数字光纤的外部音频 • 接続 – 光デジタルケーブルから外部オーディオ**




Use this connection method when connecting audio sources with a digital optical output, such as CD Players, PC audio servers, or streaming audio players.

**Note: Digital connection only supports Dolby Audio-Dolby Digtial Decoding, not Dolby Atmos.**

# TURN OFF TV SPEAKERS

**MISE HORS TENSION DES HAUT-PARLEURS DU TÉLÉVISEUR • APAGADO DE LOS ALTAVOCES DEL TELEVISOR • TV-LAUTSPRECHER DEAKTIVIEREN • SPEGNIMENTO DEGLI ALTOPARLANTI DEL TELEVISORE • DESLIGUE OS ALTO-FALANTES DA TV** • 关闭电视机扬声器 • TVスピーカー電源オフ





**(Recommended)**

**OR**





**OR**




**OU RÉGLER SUR AUTO SUR ARC**
**O BIEN FIJAR EN "AUTO ON ARC"**
**ODER BEI ARC AUF AUTOMATISCH EINSTELLEN**
**OPPURE IMPOSTARE SU AUTO ON ARC**
**OU CONFIGURE PARA "AUTO ON ARC"**
**或设置为 "AUTO ON ARC"**
または「AUTO FOR ARC」に設定する


# ADJUSTING BASS LEVEL

**AJUSTEMENT DU NIVEAU DU CAISSON DE GRAVES • AJUSTE DEL VOLUMEN DEL SUBWOOFER • SUBWOOFER-LAUTSTÄRKE EINSTELLEN • REGOLAZIONE DEL LIVELLO DEL SUBWOOFER • AJUSTE DO NÍVEL DO SUBWOOFER •** 调整低音炮水平 • サブウーファーレベルの調整




# SURROUND LEVEL ADJUSTMENT


**NIVEAU DU SURROUND - AJUSTEMENT RAPIDE • VOLUMEN DE SURROUND - AJUSTE RÁPIDO • SURROUND-LAUTSTÄRKE - SCHNELLEINSTELLUNG • REGOLAZIONE RAPIDA DEL LIVELLO DEL SUBWOOFER • NÍVEL SURROUND - AJUSTE RÁPIDO •** 环绕声水平-快速调整 • サラウンドレベル - クイック調整




# NIGHT MODE

MODE NUIT • MODALIDAD NOCTURNA • NACHTMODUS • MODALITÀ ORE NOTTURNE • MODO NOTURNO • 夜间模式 • ナイトモード





**NIGHT DISABLED**
Full dynamic range with full bass





**NIGHT ENABLED**
Reduced dynamic range with compressed bass for low volume listening

# DIALOGUE MODE


**MODE DIALOGUE • MODALIDAD DE DIÁLOGO • DIALOGMODUS • MODALITÀ DIALOGO • MODO DIÁLOGO • 対話模式 • ダイアログモード**



# FACTORY RESET

**RÉINITIALISATION • RESTABLECIMIENTO DE FÁBRICA • RÜCKSETZUNG AUF WERKSEINSTELLUNG • RIPRISTINO IMPOSTAZIONI DI FABBRICA RESTABELECIMENTO DAS CONFIGURAÇÕES DE FÁBRICA • 恢复出厂设置**




**Hold 10 Seconds**
Appuyer pendant 10 secondes
Mantenga oprimido durante 10 segundos
10 Sekunden gedrückt halten
Tenere premuto per 10 secondi
Manter pressionado por 10 segundos
保持 10 秒

## Clears *Bluetooth*® pairing history and user programmed IR commands

Efface l'historique d'appariement *Bluetooth*® et les commandes IR programmées par l'utilisateur
Borra el historial de sincronización de *Bluetooth*® y los comandos programados por el usuario
Löscht Bluetooth®-Kupplungsdaten und benutzerprogrammierte IR-Befehle
Vengono cancellati la cronologia delle associazioni *Bluetooth*® e i comandi programmati dall'utente sul telecomando a infrarossi
Limpa o histórico de pareamento *Bluetooth*® e os comandos de IR programados pelo usuário
清除蓝牙® 配对历史记录及用户编程的 IR 指令。

# DECODING AND PLAYBACK MODES

| INCOMING DIGITAL AUDIO SIGNALS THE FLEXUS CORE 200 WILL DECODE | PCM |
|---|---|
| | LPCM Up to 8 Channels |
| | Dolby Audio-Dolby Digital (2.0, 5.1, Etc.) |
| | Dolby Audio-Dolby Digital Plus (2.0, 5.1, 7.1, Etc.) |
| | Dolby TrueHD |
| | Dolby Atmos |

Flexus Core 200 comes equipped with several user selectable playback modes. Depending on which playback mode the user has selected, the system will decode the surround sound signal. The following chart shows which playback modes will result in which type of surround sound from the system, along with the recommended uses for each mode.

| USER SELECTED INPUT MODE | OUTPUT FORMAT | RECOMMENDED FOR: |
|---|---|---|
| MOVIE (DEFAULT) | Dolby Atmos mixed to 5.1.4 | The most immersive and complete system tuning for everyday use. Perfect for shows and movies, Movie mode upmixes all signals into all available channels and virtualizes a wide soundstage. Movie mode boosts surround effects and increases dialog clarity. |
| MUSIC | Dolby Atmos mixed to 5.1.4 | Optimized to keep music sounding like the artist intended, Music mode disables virtualization, dialog enhancement, and boosted surround experience while maintaining upmixing stereo sources to all available channels. |

# LED DISPLAY

| | DISPLAY | BAR STATUS |
|---|---|---|
| INPUTS | BT | Bluetooth Input Selected |
| | DIGITAL | Digital (Optical) input Selected |
| | TV | HDMI-eARC input Selected |
| | USB | USB Thumb Drive Input |
| SOUND MODES | MOVIE (Default) | Movie Mode ON |
| | MUSIC | Music Mode ON |
| DIALOG MODE | DLG OFF | Dialog Boost Off |
| | DLG LOW | Dialog Boost Low |
| | DLG MED | Dialog Boost Medium |
| | DLG HIGH | Dialog Boost High |
| NIGHT MODE | NGT OFF | Night Mode OFF |
| | NGT ON | Night Mode ON |

| | DISPLAY | BAR STATUS |
|---|---|---|
| LEVEL ADJUST | [SOURCE] XX | System Volume Setting [0] – [50] |
| | MUTE | System Muted / Volume Set To Minimum |
| | [SOURCE] MAX | System Volume Set To Max |
| | BASS [XX] | Bass equalizer volume [-6] - [+6] |
| CEC TOGGLE | CEC [XXX] | CEC Protocol Turned [On] or [Off] |
| DECODING | DOLBY SURROUND | Dolby Audio (supporting Dolby Digital, Dolby Digital Plus, Dolby TrueHD) |
| | DOLBY ATMOS | Dolby Atmos Input |
| | PCM | PCM or LPCM Input |
| OTHER | BT PAIRING | Pairing Bluetooth |
| | BT PAIRED | Bluetooth Paired |
| | LED HI | LED high brightness |
| | LED LOW | LED low brightness |

Klipsch®

KEEPERS OF THE SOUND®

**3502 WOODVIEW TRACE, INDIANAPOLIS, IN, USA**

**KLIPSCH.COM**

©2023, Klipsch Group, Inc. Klipsch Group, Inc. is a wholly-owned subsidiary of Voxx International Corporation. Klipsch and Keepers of the Sound are trademarks of Klipsch Group, Inc., registered in the United States and other countries. The *Bluetooth*® word mark is a registered trademark owned by Bluetooth SIG, Inc. and any use of such mark by Klipsch Group, Inc. is under license.

V00 - 231110