
Dresser (8755) - Assembly and Operation Manual

Congratulations on purchasing a MDB Family product. This product will provide many years of service if you adhere to the following guidelines for assembly, maintenance, and operation. This product is for residential use only. Any institutional use is strictly prohibited.


Please be sure to follow the instructions for proper assembly. Use a Phillips head screwdriver for assembling the product in addition to the Allen wrench included in the hardware box. Do not use power screwdrivers. All of our products are made from natural woods. Please understand that natural woods have color variations which are the result of nature and not defects in workmanship.


DO NOT SUBSTITUTE PARTS. ALL MODELS HAVE THE SAME QUANTITY OF PARTS AND HARDWARE. YOUR MODEL MAY LOOK DIFFERENT FROM THE ONE ILLUSTRATED DUE TO STYLISTIC VARIATIONS.




PARTS


A. Dresser Top



B. Left Panel



C. Right Panel



D. Center Support



E. Dresser Back



F-1. Top Front Cross Bar



F-2. Bottom Front Cross Bar


F-3. Bottom Back Cross Bar



F-4. Top Back Cross Bar


G. Dresser Back Panel


H. Door



J. Drawer Bottom (3)


K. Drawer Right Panel (3)



L. Drawer Left Panel (3)


M. Drawer Back (3)



N. Drawer Front (3)



P. Shelf (2)


HARDWARE



H1. 1-1/4” Wood Screws (24)



H2. 1/2” Screws (36)



H3. 1/2” Screws (14)


H4. 1 1/4” Bolts (7)



H5. 2-1/4” Bolt



H6. 1-1/8” Bolts For Knobs (7)



H7. 5/8” Bolts (24)



H8. Brackets (8)



H9. Knobs (7)


H10. Right Panel Glides (3)



H12. Right Drawer Glides (3)


H11. Left Panel Glides (3)


H13. Left Drawer Glides (3)



H14. Hinges (2)


H15. 5/8” Screws (12)


H16. 1” Metal Pegs (4)


STEP 1.

Install brackets onto cross bars.




STEP 2.


Attach panel glides and hinges.



B. Left Panel




D. Center Support




C. Right Panel

2a.)





2b.)




STEP 3.

Attach cross bars to the center support.







Make sure that the cross bars with countersunk holes are facing the correct direction.



STEP 4.


Attach panels and cross bars.






STEP 5.

Attach dresser top.




STEP 6.

Attach back panel.




STEP 7.

Attach door.




7a.)




H. Door

7b.)




H. Door




STEP 8. **Assemble drawers-** Both small and large drawers are assembled in the same way.


8a.)




8b.)




8c.)



8d.)




8e.)



STEP 9.

Insert drawers and shelves.



READ ALL INSTRUCTIONS BEFORE USING THE PRODUCT.
KEEP THE INSTRUCTIONS FOR FUTURE USE.

⚠ WARNING:

Young children can be seriously injured when furniture tips over. Before using this product, anchor and secure it to the wall with the enclosed anti-tip to prevent any injuries or damage from product. Follow the installation instructions included with the anti-tip.

Care and cleaning:

Do not scratch or chip the finish. Do not use abrasive chemicals for cleaning. Clean with mild soap on a soft rag. Rinse and dry thoroughly. If you ever refinish this furniture, be sure to use only a non-toxic finish specified for children's products.


Storage:

Pine woods exchange moisture with the air adjusting to major changes in room temperature and humidity. Therefore it is best to place your furniture away from heating or air-conditioning vents. Sunlight is not friendly to solid wood furniture and prolonged direct exposure to harsh sunlight can discolor the finish. Be careful not to place your furniture in direct sunlight for extended periods of time. As with all your fine furniture, blot up spills immediately.

Furniture Anti-tip kit Installation instructions

Young children may be injured from furniture tipover and the use of tipover restraint is highly recommended. This hardware, when properly installed, could provide protection against unexpected tipover of furniture due to improper use.

!! WARNING!!: THE INSTALLATION OF THE ANTI-TIP KIT IS NOT A SUBSTITUTE FOR PROPER ADULT SUPERVISION.



1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the shorter screws.

2. Determine where furniture is to be placed and mark location on the wall for the mounting bracket screw hole to be approximately 2” below the bracket mounted to the back edge of the furniture.

3. Drill a 3/16” hole in the wall. Press the plastic anchor into the hole and gently tap until the flange on the anchor is against the wall surface.

4. Position the bracket over the anchor and use the longer screw to securely attach the bracket to the wall.

5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.

6. Lace an end of the nylon restraint strap down through each bracket. Bring both ends together and slide the beaded end of the strap through the keyhole shaped slot in the other end until snug. Pull down on the beaded end until it snap-locks into the keyhole slot.

7. To double lock, return the beaded end back through the keyhole as illustrated above.

8. Check to make sure the strap is securely laced and locked to the bracket.